



Instruction Manual

Model 8500 300W DC Electronic Load

Warranty Information

Certification

We certify that this product met its published specifications at time of shipment from the factory.

Safety Summary

The following general safety precautions must be observed during all phases of operation of this instrument. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the instrument .We assumes no liability for the customer's failure to comply with these requirements.

Environmental Conditions

This instrument is intended for indoor use. Pollution degree 2 environments . It is designed to operate at a maximum relative humidity of 95% and at altitudes of up to 2000 meters. Refer to the specifications tables for the ac mains voltage requirements and ambient operating temperature range.

Before Applying Power

Verify that all safety precautions are taken. Note the instrument's external markings described under "Safety Symbols".

Ground The Instrument

This product is a Safety Class 1 instrument (provided with a protective earth terminal). To minimize shock hazard, the instrument chassis and cover must be connected to an electrical ground. The instrument must be connected to the ac power mains through a grounded power cable, with the ground wire firmly connected to an electrical ground (safety ground) at the power outlet. Note: Any interruption of the protective (grounding) conductor or disconnection of the protective earth terminal will cause a potential shock hazard that could result in personal injury.

DO NOT OPERATE IN AN EXPLOSIVE ATMOSPHERE

Do not operate the instrument in the presence of fumes or flammable gases.

KEEP AWAY FROM LIVE CIRCUITS

Operating personnel must not remove instrument covers except as instructed in this Guide for installing or removing electronic load modules. Component replacement and internal adjustments must be made only by qualified service personnel. Do not replace components with power cable connected. Under certain conditions dangerous voltages may exist even with the power cable removed. To avoid injuries always disconnect power, discharge circuits, and remove external voltage sources before touching components.

DO NOT SERVICE OR ADJUST ALONE

Do not try to do some internal service or adjustment unless another person capable of rendering first aid resuscitation is present.

Safety Symbols



Direct current



Alternating current



Both direct and alternating current



Protective earth (ground) terminal



Caution (refer to accompanying documents)

WARNING


The WARNING sign denotes a hazard. It calls attention to a procedure, practice, or the like, which, if not correctly performed or adhered to, could result in personal injury. Do not proceed beyond a WARNING sign until the indicated conditions are fully understood and met.

CAUTION

The CAUTION sign denotes a hazard. It calls attention to an operating procedure, or the like, which, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the product. Do not proceed beyond a CAUTION sign until the indicated conditions are fully understood and met.

Quick Reference

The Front Panel



1 16-character display shows voltage and current measurements.

2 Rotary knob

3 Keypad:

Enable/disable input.

Setup the current, resistance and voltage modes.

Set and reset protection functions.

Scroll through front panel.

4 Entry keys:(numeric keys)

Enter values.


Increasing or decreasing the setup values.

Menu commands.

5 Power switch ON/OFF

6 Input terminals.

The Rear Panel




1 4 Pin Trigger and Remote sensing connectors.

2 9-Pin COM port interface connector.

3 Power switch (110V / 220V)


4 3 Pin IEC320 ac input connector. (Power code requires ground conductor).

Front Panel Annunciators




| | | | |
|--------------|---|----------------|--|
| OFF | power off | Trigger | Indicates that the electronic load is waiting an initiate and trigger to occur. |
| CC | Constant current (CC) mode. | Sense | Indicates that the electronic load is in Remote sensing state |
| CV | Constant voltage (CV) mode. | Error | A errors have occurred |
| CW | Constant power (CW) mode. | Link | In the communication state |
| CR | Resistance (CR) mode. | Rmt | Indicates that the electronic load is in remote state (RS-232). In the remote state, only the active key is the Local key. |
| Tran | The input channel is enabled for transient operation. | Shift | Indicates that the shift key has been pressed. |
| List | List mode is initiated or running. | Lock | keyboard is locked by password |
| Unreg | The input is unregulated. | | |

Immediate Action Keys

| | |
|---|--|
| V-set | Choosing CV mode and setting the input of regulation voltage mode |
| I-set | Choosing CI mode and setting the input of regulation current mode |
| P-set | Choosing CP mode and setting the input of regulation power mode |
| R-set | Choosing CR mode and setting the input of regulation resistor mode |
| Shift +  | Switch to A setting value |

| | |
|---------------------------------------|---|
| <div>Shift +</div> <div>B</div> | Switch to B setting value |
| <div>Shift +</div> <div>store</div> | Press to store an existing electronic load state in non-volatile Memory. |
| <div>Shift +</div> <div>Recall</div> | Press to recall an existing electronic load state in non-volatile Memory. |
| <div>Shift +</div> <div>Menu</div> | Enter operation Menu. |
| <div>Shift +</div> <div>Short</div> | Turn on or turn off short circuit Test. |
| <div>Shift +</div> <div>Tran</div> | Start /Stop transition operation |
| <div>Shift +</div> <div>Trigger</div> | Causes a trigger to occur. Change the trigger source is IMMEDIATE |
| <div>Shift +</div> <div>Battery</div> | Battery discharge electronic operation |
| <div>Shift +</div> <div>S-Tran</div> | Set the transition operation parameter |
| <div>Input on/off</div> | Enable or disable load input. |

Front Panel Menus



Key Pad

| | |
|--------------|---|
| 0 ~ 9 | 0 through 9 are used for entering numeric values. |
| • | Decimal point. |
| ESC | The escape key. It may used to exit any working state. |
| I-set | Choosing CC mode and setup the input current of regulation current mode. |
| V-set | Choosing CV mode and setup the input voltage of regulation voltage mode. |
| P-set | Choosing CW mode and setup the input watt of regulation power mode. |
| R-set | Choosing CR mode and setup the input resistor of regulation resistance mode. |
| Shift | Shift keys. |
| Input on/off | Power ON/OFF |
| ? | Scrolling keys let you move through the commands in the presently Selected function menu. Bring up the next command in the list. Function menus are circular; you can return to the starting position by continuous pressing the key. |
| ? | Go back to the previous command in the list .Function menus Are circular; you can return to the starting position by continuous pressing the key. |
| ENTER | Confirmation key. |

Menu Operation

Press Menu to indicate operation mode .View the menu in VFD and using ? and ? to scroll through the completely menu list as following .IF press **ENTER** key, you could get the selected menu function. Press **ESC** back to the previous menu selection page.

| MENU | | |
|---------------|-----------------------------|---|
| CONFIG | | |
| | INITIAL CONFIG | Return to the factory default setup value. |
| | POWER-ON RECALL | Setting Power-on state of Load. |
| | ON | When users turn on the electronic load; the electronic load setup value will keep the state of last time when users turn off the electronic load. |
| | OFF<DEFAULT> | Disable this function. |
| | INPUT RECALL | Setup of the electronic load input state in Power on. |
| | ON | When users turn on the electronic load; the electronic load input will keep the state of last time when users turn off the electronic load. |
| | OFF<DEFAULT> | When users turn on the electronic load, the electronic load input will keep the state off. |
| | KEY SOUND SET | Keypad sound setting. |
| | ON<DEFAULT> | Enable key sound. |
| | OFF | Disable key sound. |
| | KNOB LOCK SET | Setup Rotary knob lock state. |
| | ON | Lock Rotary knob. |
| | OFF<DEFAULT> | Unlock Rotary knob. |
| | REMOTE SENSE | Setup voltage measurement Mode. |
| | ON | The electronic load will measure input voltage from the remote sense connector. |
| | OFF<DEFAULT> | The electronic load will measure input voltage from the front panel connector. |
| | TRIGGER SOURCE | Choosing the trigger signals source. |
| | IMMEDIATE<DEF> | Trigger signals from Shift + Trigger key |
| | EXTERNAL | Trigger signals from the TRIG connector in the rear panel. |
| | BUS | Communication command trigger mode. |
| | BAUDRATE SET | Setting baud rate. |
| | 9600<DEFAULT> | |

| | | |
|----------------------|----------------------------|---|
| | 9600 | |
| | 19200 | |
| | 38400 | |
| | COMM. PARITY SET | Command parity setting. |
| | NONE<DEFAULT> | |
| | EVEN | |
| | ODD | |
| | ADDRESS SET | Setting communication Flow mode |
| | KEY LOCK SET | Setting keypad password. Press ENTER directly to disable the key lock function. |
| | EXIT | |
| SYSTEM SET | | |
| | MAX CURRENT SET | Setup the Maximum current. |
| | MAX POWER SET | Setup the Maximum Power. |
| | MAX VOLTAGE SET | Setup the Maximum Voltage. |
| | EXIT | |
| LIST SET | | |
| | MODE SET | Setting operation mode. |
| | FIXED MODE | Fixed mode. |
| | LIST MODE | Choosing List mode. |
| | CALL LIST FILE | Recall list operation file. |
| | EDIT LIST FILE | Edit list operation file. |
| | LIST STORE MODE | Users can choose 4 kind of memory space to save the list file. |
| | 8 X 120 STEPS | Total 8 files and each file have 120 list steps. |
| | 4 X 250 STEPS | Total 4 files and each file have 250 list steps. |
| | 2 X 500 STEPS | Total 2 files and each file have 500 list steps. |
| | 1 X 1000 STEPS | Total 1 file and each file have 1000 list steps. |
| | EXIT | |
| LOAD ON TIMER | | |
| | TIMER STATE | Setting LOAD ON timer state |
| | ON | When users choose the timer state ON, and then turn on the electronic load input, the LOAD ON TIMER will start working, and when the LOAD ON TIMER is reach the setup time, the electronic load input will turn off automatically,. |
| | OFF<DEFAULT> | |
| | TIMER SET | Setting time of LOAD ON timer, |
| | EXIT | |
| EXIT | | |

General Information

Document Orientation

This manual describes the operation of the Model 8500 DC Electronic Loads. Unless otherwise noted, all units will be referred to by the description "electronic load" throughout this User's manual. The following documents and software are shipped with your electronic load.

This User's Guide (this document), contains installation, checkout, front panel information and detailed programming information.

The Getting Started Map will help you find the information you need to complete the specific task that you want to accomplish. Refer to the table of contents or index of each guide for a complete list of the information contained within.

Getting Started Map

| Task | Where to find information |
|---|---------------------------|
| Checking out the unit Verifying proper operation Using the front panel Calibrating the unit | User's Guide |
| Using the front panel Front panel keys Front panel examples | User's Guide |
| Using the programming interface RS-232 interface | User's Guide |
| Remote operation mode Protocol information | User's Guide |
| Controller Program and Software driver: Power View PV8500 software Calibration PC8500 software Active driver PD-8500 OCX software | CD-ROM |

Options and Accessories

Options

IT-E151 Rack mounts kit: for install one or two 8500 series load on the 19 inch rack.

ITE-131 isolated communication cable: This cable converts the Electronic Load's serial port (TTL 5V level) to PC RS232 interface.

Accessories

Power cord
User's manual
Software CD-Rom

Description

The 8500 serial Electronic Load is used for design, manufacturing, and evaluation of DC power supplies, batteries, and power components and so on. The Electronic load contains a processor, serial port connector, front-panel keypad and VFD, and other circuits common to the other entire load module.

8500 serial Electronic Load could work in constant current (CC) mode, constant voltage (CV) mode, or constant resistance (CR) mode and constant power (CW) Mode.

Features And Capabilities

- High accuracy and high resolution
- Capable to work with constant current (CC), constant voltage (CV), constant resistance (CR) mode and constant power (CW) operation.
- Serial port interface-DB9-RS232 port.
- Triggered input and measurement functions.
- Within the controlled keypad in the front panel
- Built-in pulse generator for continuous, pulsed, and toggled transient mode operation.
- Over voltage, over current, overpower, and over temperature protection.
- Electronic load calibrate by Software.
- Fan speed control by temperature.
- VFD display
- Short circuit test
- Battery testing function.

Front Panel Controls

The front panel has keyboard controls for setting the input voltage, current and resistance. The panel display provides digital readouts of a number of functions including the inputs. Annunciators display the operating status of the electronic load.

Remote Programming

The electronic load may be remotely programmed from the computer via the **IT-E131** isolated communication cable.


Operating Modes

The four modes of operation are:

- 1: Constant current (CC).
- 2: Constant voltage (CV).
- 3: Constant resistance (CR).
- 4: Constant power (CW)


Constant Current(CC) Mode

In this mode, the electronic load will sink a current in accordance with the programmed value regardless of the input voltage. CC mode can be set with front panel keys. The CC mode parameters are discussed in the following paragraphs.




Constant Resistance (CR) Mode

In this mode, the module will sink a current linearly proportional to the input voltage in accordance with the programmed resistance. The CR mode can be set at the front panel. The CR mode parameters are described in the following paragraph




Constant Voltage (CV) Mode

In this mode, the electronic load will attempt to sink enough current to control the source voltage to the programmed value. The module acts as a shunt voltage regulator when operating in the CV mode. The CV mode can be set at the front panel. The CV mode parameters are described in the following paragraphs.



Constant Power (CW) Mode

In this mode, the electronic loads will consumption power accordance with the programmed value regardless of the input voltage. The CW mode can be set with front panel keys. The CW mode parameters are discussed in the following paragraphs.




Transient Operation

Transient operation enables the electronic load to periodically switch between two load levels, as might be required for testing power supplies. A power supply's regulation and transient characteristics can be evaluated by monitoring the supply's output voltage under varying combinations of load levels, frequency, and duty cycle. Transient operation can be turned on and off at the front panel or PC via the IT-E131 isolated communication cable. Before you turn on transient operation, you should set the desired mode of operation as well as all of the parameters associated with transient operation. Transient operation may be used in the CC, CR, or CV or CW modes and can be setup in continuous, pulsed, or toggled operation mode.


Continuous

Generates a repetitive pulse stream that toggles between two load levels and changes the state between value A and value B.




Pulse

Switch to value B as receiving one trigger signal , taking the pulse time(**TWD**) of value B , Load will return to Value A .



Trigger Mode

Switching the state between value A and value B once receiving a triggering signal




List Operation

List mode lets you generate complex sequences of input changes with rapid, precise timing, which may be synchronized with internal or external signals. List operation can be changed by edit every step value and time in list operation. The parameter of list operation include the group file name, input step setting (the max steps is 1000 steps), time of one step(1mS~1h) and setting value of one step. In CC mode, dwell time range is 1mS to 6S, which also have an associated value. Note that lists data can only be saved in total 1000 steps memory of 4 situations.

| | |
|--------------|---------------------------|
| GROUP | Total = 1000 steps |
|--------------|---------------------------|

| | | | | | | | | |
|---|------------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|
| 1 | 1000 steps | | | | | | | |
| 2 | 500 steps | | | | 500 steps | | | |
| 4 | 250 steps | | 250 steps | | 250 steps | | 250 steps | |
| 8 | 120 steps | 120 steps | 120 steps | 120 steps | 120 steps | 120 steps | 120 steps | 120 steps |

When receiving one trigger signal, it will start the list operation until receiving another trigger signal or finish the List operation.



Triggered Operation

The electronic load has various triggering modes to allow synchronization with other test equipment or events. Such as:

Keypad triggering mode: Press **Shift** + **Trigger** to trigger the electronic load.

TTL triggering mode: Send a high pulse with a constant time more than 5m Sec to the trigger terminals in rear panel to trigger the electronic load.

Command triggering mode: Send triggering command to the electronic load via the serial port.

Input Control

Short On/Off

Load can simulate a short circuit at its input by turning the load on with full-scale current. The short circuit can be toggled on/off at the front panel using the



.Short operation is not influence the operation setting current value , When short operation is on OFF state , Load back to the original setting state. The actual value of the electronic short is dependent on the mode and current range that are active when the short is turned on.

In CC, CW and CR mode, the max short-circuit current value is 1.2 times of the current range. In CV mode, short-circuit operation is same as the operation of setting CV to 0V.

NOTE

Turning the **Short Test** on in CV mode may cause the load to draw so much current that the software current limit operates, which may turn the input off. Turning the short circuit on does not affect the programmed settings, and the load input will return to the previously programmed values when the short is turned off.

Input On/Off


Electronic load's input can be toggled on/off at the front panel. Turning the input off (zero current) does not affect the programmed settings. The input will return to the previously programmed values when the input is turned on again.

NOTE


The **Input On/Off** command supersedes the mode commands and **Short Test On/Off** command.

Operation Range

Work in the range of Rated Current, Rated voltage and Rated Power, The figure is as following:



Operation mode change state



Protection Features

Electronic load includes the following protection features:

Over Voltage

If input voltage exceeds the voltage limit, Load will turn OFF the input, Buzzer is mooring. VFD display as following:

OVER VOLTAGE

Over Current

When work in the CR or CC and CP mode, input current is ascending continuously, the load current will be limited by a current limit circuit, Load will work in the over current protection state , VFD display the information as CC.

When work in CV mode and transition mode and List mode, Input current exceeds the current limit, Buzzer is mooing, VFD display the flashing current value.

Over Power

If the input power exceeds the power limit in the normal operation mode, Load will work in the over power protection state. VFD displays the information as CW.

When work in transition mode and list mode, If the input power exceeds the power limit. Buzzer is mooing, VFD display the flashing current value and voltage value.

Reverse Voltage

This feature protects the load module in case the input DC voltage lines are connected with wrong polarity, if a reverse voltage condition is detected, Buzzer is mooing. VFD display as following:

REVERSE VOLTAGE

Over Temperature

If internal power components 's temperature exceeds safe limits (80?), Over temperature protection is on work . Load will turn off the input and Buzzer is mooing, VFD display as following:

OVER HEAT

Remote Sense Function

When work in CV, CR and CP mode, if load consumes biggish current, it will cause one depressed voltage in the connection line between tested machine and terminals of Load. In order to assure testing precision, Load provides one remote testing terminals in the rear panel, Users could test the output terminals voltage of tested machine through it. Users should set the Load in REMOTE mode before using the function.

Saving And Recalling Settings

The electronic load has internal registers in which settings (mode, current, voltage, resistance, transient level, etc.).Users could use **Shift** + **Store** and

Shift + **Recall** to save and recall the relative data as following:

CC value /CW value /CR value /CV value

Transition current A value /Transition current B value /Transition voltage A value

/Transition voltage B value / Transition power A value /Transition power B value

/Transition Resistance A value /Transition Resistance B value

Current A pulse width time/ Current B pulse width time/Voltage A pulse width time/

Voltage B pulse width time /Power A pulse width time/Power B pulse width time


/Resistance A pulse width time /Resistance B width time

Transition current testing mode/Transition voltage testing mode/Transition power testing mode /Transition resistance testing mode

Max current value / Max voltage value / Max power value

Battery Testing

Load provides the function of discharging electronic of testing battery. Setting discharging current by press **I-set**, then press **Shift** + **Battery** to set the mix voltage, Battery testing operation is run. When Battery Voltage setting value is lower than the limited voltage; Load will turn off the input. VFD will display the capacity of testing battery, Press **Shift** + **Battery** and return the normal mode.



External Control Signals

Electronic Load has a 4-pin connector mounted on its rear panel. These signals are described in the following paragraphs.

Remote Sensing: **SENSE (+)** and **SENSE (-)** are the remote sensing inputs. By eliminating the effect of the inevitable voltage drop in the load leads, remote sensing provides greater accuracy by allowing the load to regulate directly at the source's output terminals.

TRIG: A TTL-compatible input that responds to external edge trigger signal. A trigger applied to this input can be used to change settings (voltage, current, resistance, etc.), toggle between settings in transient-toggle mode, or generate a pulse in transient-pulse mode.

Installation

Inspection

Damage

When you receive your electronic load, inspect it for any obvious damage that may have occurred during shipment. If there is damage, notify the shipping carrier and nearest Agent office and Support Office immediately.

Items Supplied

The following user replaceable items are included with your electronic load.

| Item | Description |
|--------------------|--|
| Power Cord | Users will get one of the power cord. |
| User's Guide | Contains installation, checkout, and front panel information and |
| Software CD-Rom | Programming information |
| Calibration Report | The Instrument calibration report. |

Cleaning

Use a dry cloth or one slightly dampened with water to clean the external case parts. Do not attempt to clean internally.

WARNING


To prevent electric shock, unplug unit before cleaning.

Location

The outline diagram in following figure gives the dimensions of your electronic load. The electronic load must be installed in a location that allows sufficient space at the sides and back of the unit for adequate air circulation.


Installation

Dimension :101mmW x 215mm H x 366mm D
Terminal length: 29.4mm Feet height:17.5mm



Outline Diagram Unit (mm)

Carrying Handle



Bench Operation

A fan cools the electronic load by drawing air through the bottom and sides and exhausting it out the back.

Minimum clearances for bench operation are 25 mm along the sides.


CAUTION

Do not block the fan exhaust at the rear of the Load.


Rack Mounting

The 8500 serial electronic load can be mounted in a standard 19-inch rack. Rack mount kits are available as Option IT-E151. The electronic load can be mounted in a standard 19-inch rack panel or enclosures using an Option IT-E151 rack mount kit. A rack mount kit for joining two half-rack units is also available by using Option IT-E151.


Rack Installation



Elevation for Installation one electronic load in a standard 19-inch rack



Side elevation for Installation one electronic load in a standard 19-inch rack



Elevation for Installation two electronic loads in a standard 19-inch rack

NOTE

Remove the carrying handle and the two plastic ears before rack-mounting the instrument. To remove the handle, grasp the handle by sides and pull outwards and rotate it to a special position to let the arrow on the handle oppose the another arrow on the plastic ears, then pull the handle outward. After removing the handle, you can use a screwdriver to remove the two plastic ears.

Trigger And Remote Sensing Connections

A 4-pin connector and a quick-disconnect mating plug are provided on rear panel for accessing input signals and remote sensing, all leads connected to the connector should be twisted and shielded to maintain the instrument's specified performance.

Remote Sensing: sense (+) and sense (-) Used to connect the remote sensing leads to the power source.

TRIG IN: TRIG (IN) A TTL-compatible input that responds to external edge trigger signal. A trigger applied to this input can be used to change settings (voltage, current, resistance, etc.), toggle between settings in transient-toggle mode, or generate a pulse in transient-pulse mode.


TRIG GND: TRIG ($\overline{\text{GND}}$) Provides the common connection for the trigger signals.

Computer Connections

The electronic load can be controlled through a PC serial port.

RS-232 Interface

The electronic loads have an serial port programming interface; all applicable commands are available through serial port programming. It available to connect the electronic load to any computer or terminal with the IT-E131 isolated communication cable.



CAUTION

Users must use IT-E131 to realize the remote operation between PC and 8500 series electronic load.


Turn-On Checkout


Introduction

Successful tests in this chapter provide a high degree of confidence that the electronic load is operating properly.

Checkout Procedure

The test in this section checks for proper operation of the electronic load. If you have not already done so, connect the power cord to the unit and plug it in.

| Procedure | Display | Explanation |
|--|--|---|
| 1. Turn the unit on. The electronic Load undergoes a self-test when you First turn it on. |  | During self test, all segments are briefly lit |
| 2. Wait for 1s after turn on electronic load. | EPROM ERROR | EEPROM damage or Lost data of last power off Run well if no such display, system will go to the step 3 directly. |
| 3. Wait for another 2S. | ERROR CAL.DATA | EEPROM Lost calibration data Run well if no such display, system will go to the step 4 directly. |

| | | |
|---|---|---|
| 4. Press Shift button and ? ? keys . | LOAD MODEL:IT85XX SN: XXX-XXX-XXX VER x.xx | Display the information of the product Type, series number version of software. |
| 5. Press  button | 0.000V 0.000A | Display the actual input voltage and current value. |
| 6. Press ? ? | 0.000W I: 0.000A | Display the actual power value and setting value. |

In Case Of Trouble

Electronic load failure to run during power-on operation. The test of following in this section help you to solve the possible problem When you turn on the power of electronic load .


1) Make sure if you have connected the power cord to the unit and plug it in.
Power switch have been pressed.

2) Check the power voltage setting.
Work voltage of load have two type 110V or 220V , Please make sure it is right voltage accordance to the voltage in your area. You could change the voltage setting through dial the switch in the rear panel.

3) Check the fuse of load.
If fuse is blowout, please change it as following specification.

| Model | Fuse specification (110VAC) | Fuse specification (220VAC) |
|-------|--------------------------------|--------------------------------|
| 8500 | T0.5A 250V | T0.3A 250V |
| | | |

4) Location of Fuse




Front Panel Operation

Introduction:

Here is what you will find in this chapter:

A complete description of the front panel controls

Front panel programming examples.



Display

16-character fluorescent display for showing measurements and programmed values.

Annunciators

Annunciators light to indicate operating modes and status conditions:

| | | | |
|-------------|--|----------------|--|
| OFF | power off | Trigger | Indicates that the electronic load is waiting an initiate and trigger to occur. |
| CC | The selected input channel is in the constant current (CC) mode. | Sense | Indicates that the electronic load is in sense state |
| CV | The selected input channel is in the constant voltage (CV) mode. | Error | A errors have occurred |
| CW | The selected input channel is in the constant power (CW) mode. | Link | In the communication state |
| CR | The selected input channel is in the resistance (CR) mode. | Rmt | Indicates that the electronic load is in remote state (RS-232). In the remote state, only the active key is the Local key. |
| Tran | The selected input channel is enabled for transient operation. | Shift | Indicates that the shift key has been pressed. |
| List | A list is initiated or running. | Lock | keyboard is the mode for password |

Function keys

Main Function:

Set up a constant current output.

Set up a constant power output.

Set up a constant resistance output

Select CC, CR and CV and CW modes.

Select Current, Resistance and Voltage levels.

Set Trigger and Transient levels.

Set up front panel measurements.

Recall the stored data

Battery testing

Short-circuit testing

Entry Keys

Entry keys let you:

Enter programming values.

Increasing or decreasing setup values.

Press **?** or **?** select the front panel menu parameters.

Power

The Power switch turns the electronic load power on or off.

Example

I-set (set up a constant current from 0 to Max current)

Set up a constant DC current input is the first main function of programmable DC electronic load,

8500 serial electronic load provides two methods to set up the constant DC current output by using the number keyboard and the rotary button. Please see the following operation procedure.

| Procedure | Operation details | VFD display |
|-----------|--|---------------------------|
| STEP 1 | Press I-set | CURRENT=0.000A |
| STEP 2 | Enter the password or jump the step 4 if your password for reentering | PASSWORD: |
| STEP 3 | Enter the original value which displayed in the LCD or enter a new value by using number keys or Rotary knob to adjust the voltage value | CURRENT=*.***A |
| STEP 4 | Press ENTER to confirm | 0.000V *.***A |

Setup the output current at 4.33A.

Method 1: To set up by using number keyboard

Step1. Press **I-set** button.

Step2. Press numeric button to enter the current value 4.33.

Step3. Press **ENTER** button to confirm the current value.

Method 2: To set up **I-set** by using Rotary SW

(1) If the key board is unlocked by password, directly adjust the Rotary SW button, and voltage will be continually changed from the previews value according the rotation. At the beginning, the cursor will be shown on the last number of the value which is indicated on the VFD, you can move the cursor to the first number, second number etc by using number buttons, and then adjust the Rotary SW to change each number, and let it stay at *.* A. Please see the following description. Then press I-set to confirm the value.

0.00A 0.00V

0.0W 4.33A

Procedure:

Step1. Press **I-set** button,

Step2. Adjust the Rotary knob to change the value, the operation is as the same as item (1)

Step5. Press **ENTER** button to confirm the current value.

P-set (set up a constant power from 0 to Max power)

8500 series electronic load can be set up for a constant power.

Constant power setup procedure is as following:

| Procedure | Operation details | VFD display |
|-----------|--|----------------------|
| Step 1 | Press P-set | POWER =0.000W |
| Step 2 | Enter a new value by using numeric keys or Rotary knob to adjust the voltage value | POWER=*.***W |

| | | |
|--------|--------------------------------|------------------------|
| Step 3 | Press ENTER to confirm. | 0.000W P:*.000W |
|--------|--------------------------------|------------------------|

R-set (set up a constant resistance from 0.1 Ω to 4000 Ω)

8500 series electronic load can be setup for a constant resistance.

Constant resistance setup procedure is as following:

| Procedure | Operation details | VFD display |
|-----------|---|--------------------------|
| Step 1 | Press R-set | RESISTANCE =0000R |
| Step 2 | enter a new value by using numeric keys or Rotary knob to adjust the resistance value | RESISTANCE=*****R |
| Step 3 | Press ENTER to confirm. | 0.000W R:0000R |




V-set (set up a constant voltage from 1.5V to Max voltage)

8500 electronic load can be setup for a constant voltage.




Constant voltage setup procedure is as following:

| Procedure | Operation details | VFD display |
|-----------|---|------------------------|
| Step 1 | Press V-set | VOLTAGE=1.500V |
| Step 2 | enter a new value by using numeric keys or Rotary knob to adjust the resistance value | VOLTAGE=*.***V |
| Step 3 | Press ENTER to confirm. | 0.000W V:3.000V |



Shift + Store

| Procedure | Operation details | VFD display |
|-----------|---|-------------------------|
| Step 1 | Press  and  | STORE 1 |
| Step 2 | Press  to confirm. | Store the relative data |



Shift + Recall

| Procedure | Operation details | VFD display |
|-----------|---|------------------------|
| Step 1 | Press  and  | RECALL 1 |
| Step 2 | Press  to confirm | Recall the saving data |

Out On/Off input setting

Use  to change the state of electronic load. Switch on to off state by press .

Menu description

| procedure | The operation methods | VFD display |
|---|--|-----------------|
| Step 1 | Press  +  button | |
| Step 2 The VFD display the menu functions one by one, user can use | ? | CONFIG |
| | Enter | INITIAL CONFIG |
| | ? | POWER-ON LOAD |
| | ? | POWER-ON RECALL |
| | ? | KEY SOUND SET |
| | ? | KNOB LOCK SET |
| | ? | REMOTE SENCE |

| | | |
|---|--------------|----------------------|
| the ? and ? button to change the selecting function, press ENTER button to execute the selection function or step into the next sub-menu | ? | TRIGGER SOURUSE |
| | ? | BAUDRATE SET |
| | ? | COMM.PARITY SET |
| | ? | ADDRESS SET |
| | ? | KEY LOCK SET |
| | ? | EXIT |
| | ? | SYSTEM SET |
| | ENTER | MAX CURRENT SET |
| | ? | MAX POWER SET |
| | ? | MAX VOLTAGE SET |
| | ? | EXIT |
| | ? | LIST SET |
| | Enter | MODE SET |
| | ? | CALL LIST FILE |
| | ? | EDIT LIST FILE |
| | ? | LIST STORE MODE |
| | ? | EXIT |
| | ? | LOAD ON TIMER |
| | Enter | TIMER STATE |
| | ? | TIMER SET |
| | ? | EXIT |
| | ? | EXIT |

Transition Testing Operation

Users could switch between the two different current and voltage in the transition mode; it could test the transition specialty of power supply. Users could use front panel or communication interface (TRAN ON AND TRAN OFF) to make it work or not, Please setting parameters before transition operation. Include Transition setting value, Constant pulse width setting and Transition Pulse width setting and Transition testing mode. The mix pulse width is 500uS. The Max pulse width is 6S. Transition Operation only could work in CC and CV mode.

Users can choose one of the three operation modes: Continuous, Pulse and Toggling mode.

Transition Parameter Setting

Users could press **Shift** + **S-Tran** to set the transition parameter.

| | | |
|------------------------------|------------------------|---------------|
| Shift + S-Tran | LEVEL A = ***** | Setup value A |
|------------------------------|------------------------|---------------|

| | | |
|-------|--------------------------------|--|
| ENTER | WIDTH A = ***** | Setup time width of value A |
| ENTER | LEVEL B=***** | Setup value B |
| ENTER | WIDTH B= ***** | Setup time width of value B |
| ENTER | CONTINUOUS PULSE TOGGLED | Choose one of the three transition modes |
| ENTER | | Finish transition setting |


Continuous Transient Operation

In this mode, electronic load will generates a repetitive pulse stream that toggles between two load levels. ; Load could switch the state between two setting value (value A and value B).

In this following example, assume that the CC mode is active; the applicable transient operation parameters have been set as follows.

For example:

Continuous mode, current level A =5A, width = 2mS. Current level B =10A, width = 3ms. Testing machine output voltage is 12V.




Action

1. On the Function keypad, press **Input on/off** button to turn off the load input.
2. Press **Shift** and **S-Tran**, setting LEVEL A=5A, WIDTH A=3mS, LEVER B=10A, WIDTH B=2mS, transition mode is **CONTINUOUS**.
3. Press **Shift** and **Tran** to activate the transient mode.
4. Press **Shift** and **Tran** again to stop the transient operation.

Pulse Transient Operation

In this mode, generates a transient pulse of programmable width when pulsed transient operation is in effect.

For example: When load receiving one trigger signal, it will switch to 10A current value, and taking 10mS to return the current value of 5A.



Action


1. On the Function keypad, press **Input on/off** button to turn off the load input.
2. Press **Shift** and **S-Tran**, set LEVER A=5A, LEVER B=10A, WIDTH B=10mS, Transition mode is **PULSE**.
3. Press **Shift** and **Tran** to activate the transient mode.
4. Press **Shift** and **Trigger** to start another pulse. Press **Shift** and **Trigger**, get more pulse.
5. Press **Shift** and **Tran** again to stop the transient operation.

Toggled Transient Operation

In this mode, after transition operation start, Load could change the input between the main level and the transient level when toggled transient operation is in effect.

For example:

When Load receives one trigger signal, Load current will switch between 5A and 10A.




Action

1. Press **Shift** and **S-Tran** , Setting LEVER A=5A, LEVER B=10A, Transition mode is PULSE .
2. Press **Shift** and **Tran** to activate the transient mode.
3. Press **Shift** and **Trigger** switch to the current value of 10A.
4. Press **Shift** and **Trigger** , switch between 5A and 10A.
5. Press **Shift** and **Tran** again to stop the transient operation.

List Operation

Users can use the front panel keypad or Power View 8500(PV-8500) software to programming the list sequence. Please refer to the software user's guide.

The following example will help you how to do the list operation in front panel.



Action

- 1) Press the button of **Input on/off** , execute the input of Load I in **OFF** state.

- 2) Press **Shift** and **Menu**, move cursor to the option of menu of **CONFIG**,
Press **ENTER** into the next step menu ,move cursor to **TRIGGER**
SOURCE . Press **ENTER** and move cursor to **IMMEDIATE <DEF>**, setting
trigger source mode is panel **IMMEDIATE** mode.
- 3) Press **ENTER** to confirm.
- 4) Press **ESC** to the previous menu , move cursor to **LIST SET** .
- 5) Press **ENTER** into the next step menu .move cursor to **EDIT LIST FILE**.
- 6) Press **ENTER** into the next step menu, move cursor to **CURRENT LIST**,
select **CURRENT MODE**.
- 7) Press **ENTER**, move cursor to **REPEAT** . Setup LIST is in cycle mode.
- 8) Press **ENTER** to confirm, setup the list steps = 5.
- 9) Press **ENTER** to confirm, setup step 1 current =3A.
- 10) Press **ENTER** to confirm, setup step 1 width=6mS.
- 11) Repeat 7) and 8) operation , set current and width of one step 0A, 5mS;2A,
4mS;6A,2mS;0A,5mS.
- 12) Press **ENTER** to confirm, Menu **STORE LIST FILE 1**. save file in group1.
- 13) Move cursor to **Mode Set** , press **ENTER** to enter into the next step menu to
set mode is **<LIST MODE >**
- 14) Press **ENTER** to confirm
- 15) Press **ESC** , Press **Input on/off**, Make Load in ON state.
- 16) Press **Shift** and **Trigger**, make list operation run or stop.
- 17) Stop the list operation mode. Move cursor to **LIST SET** , Press **ENTER**,
move cursor to **Mode Set** in option menu, press **ENTER**, Enter into next
step menu . Select mode is **<FIXED MODE>** ?
- 18) Press **ENTER** to confirm.

Specifications

| Parameter | | 8500 | |
|------------------------------|--|---------------------------|------------|
| Input rating (0 ~ 40 ?) | Voltage | 0 to 120V | |
| | Current | 1mA to 30A | |
| | Power | 300 W | |
| Load Regulation | Range | Accuracy | Resolution |
| | 0-18V | $\pm(0.05\%+0.02\%FS)$ | 1mV |
| | 0-120V / 500V | $\pm(0.05\%+0.025\%FS)$ | 10mV |
| | 0-3A | $\pm(0.1\%+0.1\%FS)$ | 0.1mA |
| | 0-30A / 15A | $\pm(0.2\%+0.15\%FS)$ | 1mA |
| CV Mode | 1.5-18V | $\pm(0.05\%+0.02\%FS)$ | 1mV |
| Regulation | 1.5-120V/500V | $\pm(0.05\%+0.025\%FS)$ | 10mV |
| CC Mode | 0-3A | $\pm(0.1\%+0.1\%FS)$ | 0.1mA |
| Regulation | 0-30A /15A | $\pm(0.2\%+0.15\%FS)$ | 1mA |
| CR Mode | 0.1-100 | $\pm(1\%+0.3\%FS)$ | 0.0010 |
| Regulation | 10-990 | $\pm(1\%+0.3\%FS)$ | 0.010 |
| Input current FS | 100-9990 | $\pm(1\%+0.3\%FS)$ | 0. 10 |
| 10% | 100-9990 | $\pm(1\%+0.3\%FS)$ | 0. 10 |
| Input VoltageFS | 1K-4K0 | $\pm(1\%+0.8\%FS)$ | 10 |
| 10% | 1K-4K0 | $\pm(1\%+0.8\%FS)$ | 10 |
| CW Mode | 0-100W | $\pm(1\%+0.1\%FS)$ | 1mW |
| Regulation | 0-100W | $\pm(1\%+0.1\%FS)$ | 1mW |
| Input current FS | 0-100W | $\pm(1\%+0.1\%FS)$ | 1mW |
| 10% | 100-300W | $\pm(1\%+0.1\%FS)$ | 10mW |
| Input VoltageFS | 100-300W | $\pm(1\%+0.1\%FS)$ | 10mW |
| 10% | 100-300W | $\pm(1\%+0.1\%FS)$ | 10mW |
| Current | 0-3A | $\pm(0.1\% + 0.1\%FS)$ | 0.1mA |
| Measurement | 0-30A /15A | $\pm(0.2\%+0.15\%FS)$ | 1mA |
| Voltage | 1.5-18V | $\pm(0.02\% + 0.02\%FS)$ | 1mV |
| Measurement | 1.5-120V/500V | $\pm(0.02\% + 0.025\%FS)$ | 10mV |
| Power | 0-100W | $\pm(1\%+0.1\%FS)$ | 1mW |
| Measurement | 0-100W | $\pm(1\%+0.1\%FS)$ | 1mW |
| Input currentFS | 100-300W | $\pm(1\%+0.1\%FS)$ | 10mW |
| 10% | 100-300W | $\pm(1\%+0.1\%FS)$ | 10mW |
| Input VoltageFS | 100-300W | $\pm(1\%+0.1\%FS)$ | 10mW |
| 10% | 100-300W | $\pm(1\%+0.1\%FS)$ | 10mW |
| Battery testing function | Input=0.8-120V / 500V Max measurement capacity= 999A/H Resolution =10mA Timer range=1~60000sec | | |
| Transition Mode | Frequency 0.1Hz-1kHz Frequency error rate< 0.5% | | |
| Weight | 11.6lb. (5.25 kg) | | |

Remote Operation Mode

DB9 in the rear panel of electronic load could connect with RS-232 through on TTL connector. The following information may help you to know how to control the output of Electronic load through PC.

1. Communication Setting


Ensure setting the same baud rate in the communication address of Electronic load and computer software .otherwise, the communication will fail. You can adjust the baud rate and communication address in Menu button in front panel of machine. Address of the Electronic load. (0 ~ 0XFE, default value is 0)

1. Baud rate : (4800,9600,19200,38400, default value is 9600)
2. Data bit : 8
3. Stop bit : 1
4. sum: (NONE,ODD,EVEN,INITIAL SETTING is NONE)

| | | | |
|---------------|-----------|-------------|----------|
| PARITY = NONE | Start Bit | 8 Data Bits | Stop Bit |
|---------------|-----------|-------------|----------|

2. DB9 Interface Details

DB9 in the rear panel of electronic load is TTL (5V) level signal .it can be connecting with standard PC interface through the IT-E131 isolated communication cable.



CAUTION

Forbidden to connect DB9 connector in Electronic load directly with PC or other RS232 port.

3. Frame Format

Frame length is 26 bytes. Details as following:

| AAH | Address | Command | 4—25bytes are information content | Parity code |
|-----|---------|---------|-----------------------------------|-------------|
|-----|---------|---------|-----------------------------------|-------------|

Description :

1. Start bit is AAH, occupies one byte.
2. Address range from 0 to FE, occupies one byte.
3. Each command occupies one byte. Following is the command details.

| | |
|-----|--|
| 20H | Selecting the Remote control mode |
| 21H | Selecting the input on/off state |
| 22H | Setting the max input voltage |
| 23H | Reading the max setup input voltage. |
| 24H | Setting max input current |
| 25H | Reading the max setup input current. |
| 26H | Setting max input power. |
| 27H | Reading the max setup input power. |
| 28H | Selecting CC/CV/CW/CR operation mode of Electronic load. |

| | |
|-----|--|
| 29H | Reading the operation mode. |
| 2AH | Setting CC mode current value |
| 2BH | Reading CC mode current value |
| 2CH | Setting CV mode voltage value |
| 2DH | Reading CV mode voltage value |
| 2EH | Setting CW mode watt value |
| 2FH | Reading CW mode watt value |
| 30H | Setting CR mode resistance value |
| 31H | Reading CR mode resistance value |
| 32H | Setting CC mode transient current and timer parameter. |
| 33H | Reading CC mode transient parameter |
| 34H | Setting CV mode transient voltage and timer parameter. |
| 35H | Reading CV mode transient parameter |
| 36H | Setting CW mode transient watt and timer parameter |
| 37H | Reading CW mode transient parameter |
| 38H | Setting CR mode transient resistance and timer parameter |
| 39H | Reading CR mode transient parameter |
| 3AH | Selecting the list operation mode (CC/CV/CW/CR) |
| 3BH | Reading the list operation mode. |
| 3CH | Setting the list repeat mode (ONCE / REPEAT) |
| 3DH | Reading the list repeat mode. |
| 3EH | Setting the number of list steps. |
| 3FH | Reading the number of list steps |
| 40H | Setting one of the step's current and time values. |
| 41H | Reading one of the step's current and time values. |
| 42H | Setting one of the step's voltage and time values. |
| 43H | Reading one of the step's voltage and time values |
| 44H | Setting one of the step's power and time values |
| 45H | Setting one of the step's power and time values. |
| 46H | Setting one of the step's resistance and time values |
| 47H | Reading one of the step's resistance and time values |
| 48H | Setting list file name. |
| 49H | Reading list file name. |
| 4AH | Selection the memory space mode for storing list steps. |
| 4BH | Reading the memory space mode for storing list steps. |
| 4CH | Save list file in appointed area. |
| 4DH | Get the list file from the appointed area. |
| 4EH | Setting min voltage value in battery testing mode. |
| 4FH | Reading min voltage value in battery testing mode |
| 50H | Setting timer value of FOR LOAD ON |
| 51H | Reading timer value of FOR LOAD ON |
| 52H | Disable/Enable timer of FOR LOAD ON |

| | |
|-----|--|
| 53H | Reading timer state of FOR LOAD ON |
| 54H | Setting communication address |
| 55H | Enable/Disable LOCAL control mode. |
| 56H | Enable/Disable remote sense mode. |
| 57H | Reading the state of remote sense mode. |
| 58H | Selecting trigger source. |
| 59H | Reading trigger source. |
| 5AH | Sending a trigger signal to triggering the electronic load. |
| 5BH | Saving user's setting value in appointed memory area for recall. |
| 5CH | Recall user's setting value in appointed memory area. |
| 5DH | Selecting FIXED/SHORT/TRAN/LIST/BATTERY function mode. |
| 5EH | Getting function mode state. |
| 5FH | Reading input voltage, current, power and relative state |
| 60H | Enter the calibration mode |
| 61H | Getting the calibration mode state. |
| 62H | Calibrate voltage value. |
| 63H | Sending the actual input voltage to calibration program. |
| 64H | Calibrate current value. |
| 65H | Sending the actual input current to calibration program. |
| 66H | Store the calibration data to EEPROM. |
| 67H | Setting calibration information. |
| 68H | Reading calibration information. |
| 69H | Restore the factory default calibration data. |
| 6AH | Reading product's model, series number and version information. |
| 6BH | Reading the information of bar code. |
| 6CH | Setting information of bar code |
| 12H | The return information of command operation in electronic load. |

NOTE

If control output of electronic through PC, please setting Electronic load is on PC control state. Command is 20H. Make a calibration on input of electronic Load, Ensure the calibration protection mode is OFF state when setting calibration information.

If electronic load in calibration mode, user's can't change the input and operation mode of electronic load

4. From 4th byte to 25th byte are information contents.
5. 26th is sum code, is the sum of the former 25 bytes.

4. Communication Protocol

1. Selecting the Remote control mode(20H)

| | |
|---|--|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(20H) |
| 4 th byte | Operation mode(0 is front panel operation mode , 1 is remote operation mode) |
| From 5 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

NOTE

Front panel operation state is not in effect if electronic load is in calibration mode.

2. Selecting the input on/off state (21H)

| | |
|---|---------------------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address(0—0XFE) |
| 3 rd byte | Command(21H) |
| 4 th byte | Input state(0 is OFF, 1 is ON) |
| From 5 th to 25 th byte | System reserve |
| From 26 th byte | Sum code |

3. Setting / Reading max input voltage(22H/23H)

| | |
|---|--|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(22H/23H) |
| 4 th byte | The Lowest byte of max voltage value |
| 5 th byte | The lower byte of max voltage value. |
| 6 th byte | The higher byte of max voltage value. |
| 7 th byte | The highest byte of max voltage value. |
| From 8 th to 25 th byte | System reserve. |
| 26 th byte | Sum code. |

NOTE

Represent a voltage upper limit value by 4 bytes of Hex. Lower bytes are in the front location, higher bytes are in the later location. 1 represent 1mV. For Example : The voltage upper limit is 16.000V, the hex code is 0X00003EB0, then the 4th byte is 0XB0, 5th byte is 0X3E, 6th byte is 0X00, 7th byte is 0X00?

4. Setting / Reading the max input current .

(24H/25H)

| | |
|---|---------------------------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address(0—0XFE) |
| 3 rd byte | Command(24H/25H) |
| 4 th byte | The Lowest byte of max current value |
| 5 th byte | The Lowest byte of max current value |
| 6 th byte | The higher byte of max current value |
| 7 th byte | The highest byte of max current value |
| From 8 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

NOTE

Represent an current value by 4 bytes of Hex .Lower bytes are in the front location, higher bytes are in the later location. 1 represent 0.1mA, If setting upper limit is **3.0000A**, the hex code is **0X00007530**, then the 4th byte is **0X30**, 5th is **0X75**, 6th is 0X00, 7th is **0X00**?

5. Setting / Reading max input power(26H/27H)

| | |
|----------------------|--------------------------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(26H/27H) |
| 4 th byte | The lowest byte of max power value. |
| 5 th byte | The lower byte of max power value |
| 6 th byte | The higher byte of max power value. |
| 7 th byte | The highest byte of max power value. |

| | |
|---|----------------|
| From 8 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

NOTE

Represent power value by 4 bytes of Hex. Lower bytes are in the Front location, higher bytes are in the later location. 1 represents 1mW. If setting upper value is **200.000W**, the hex code is **0X00030d40**, then the 4th byte is **0X40**, 5th is **0X0d**, 6th is 0X03, 7th is **0X00**.

6. Selecting / Reading CC/CV/CW/CR operation

mode of Electronic load.(28H/29H)

| | |
|--|--|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(28H/29H) |
| 4 th byte | Mode(0 is CC mode, 1 is CV mode , 2 is CW mode , 3 is CR mode) |
| From 5 th To 25 th byte | System reserve |
| 26 th byte | Sum code |

7. Setting / Reading CC mode current value

(2AH/2BH)

| | |
|--|------------------------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command (2AH/2BH) |
| 4 th byte | The lowest byte of current value |
| 5 th byte | The lower byte of current value. |
| 6 th byte | The higher byte of current value. |
| 7 th byte | The highest byte of current value. |
| From 8 th To 25 th byte | System reserve |

| | |
|-----------------------|----------|
| 27 th byte | Sum code |
|-----------------------|----------|

NOTE

Represent current by 4 bytes of Hex. Lower bytes are in the front location, higher bytes are in the later location. For example: current is **3.0000A**, Hex code is **0X00007530**, NO. 4 byte is **0X30**, NO. 5 byte is **0X75**, NO. 6 byte is **0X00**, NO. 7 byte is **0X00**?

8. Setting / Reading CV mode voltage value.

(2CH/2DH)

| | |
|---|------------------------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(2CH/2DH) |
| 4 th byte | The lowest byte of voltage value. |
| 5 th byte | The lower byte of voltage value. |
| 6 th byte | The higher byte of voltage value. |
| 7 th byte | The highest byte of voltage value. |
| From 8 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

NOTE

Represent voltage by 4 bytes of Hex. Lower bytes are in the front location, higher bytes are in the later location. For example :voltage is **16.000V**, Hex code is **0X00003EB0**, 4th byte **0XB0**, 5TH byte is **0X3E**, 6th byte is **0X00**, 7th byte is **0X00**?

9. Setting / Reading CW mode watt value

(2EH/2FH)

| | |
|----------------------|-------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |

| | |
|--|-------------------------------------|
| 3 rd byte | Command(2EH/2FH) |
| 4 th byte | The lowest byte of max power value |
| 5 th byte | The lower byte of max power value |
| 6 th byte | The higher byte of max power value |
| 7 th byte | The highest byte of max power value |
| 8 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

NOTE

Represent power by 4 bytes of Hex. Lower bytes are in the front location, higher bytes are in the later location. For example :power is **200.000W**, Hex is **0X00030d40**, 4th byte is **0X40**, 5th byte is **0X0d**, 6th byte is 0X03, 7th byte is **0X00**?

10. Setting / Reading CR mode resistance value

(30H/31H)

| | |
|--|---------------------------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(30H/31H) |
| 4 th byte | The lowest byte of resistance value. |
| 5 th byte | The lower byte of resistance value. |
| 6 th byte | The higher byte of resistance value. |
| 7 th byte | The highest byte of resistance value. |
| 8 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

NOTE

Represent resistance value by 4 bytes of Hex. Lower bytes are in the front location, higher bytes are in the later location. If resistance value is **200.000R**, Hex code is **0X00030d40**, 4TH byte is **0X40**, 5TH byte is **0X0d**, 6th byte is 0X03, 7th byte is **0X00**?

11. Setting /Reading CC mode transient current and timer parameter. (32H/33H)

| | |
|--|---|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(32H/33H) |
| From 4 th byte to 7 th byte | Setting value of current A (Lower bytes are in the front location, higher bytes are in the later location.) |
| From 8 th byte to 9 th byte. | Time value of timer A ((Lower bytes are in the front location, higher bytes are in the later location) (1 represent 0.1mS) |
| From 10 th to 13 th byte | Setting value of current B (Lower bytes are in the front location, higher bytes are in the later location) |
| From 14 th to 15 th byte | Time value of timer B (Lower bytes are in the front location, higher bytes are in the later location) (1 represent 0.1mS) |
| 16 th byte | Transition operation mode (0 is CONTINUES, 1 is PULSE, 2 is TOGGLED) |
| From 17 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

12. Setting /Reading CV mode transient voltage and timer parameter.(34H/35H)

| | |
|--|---|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(34H/35H) |
| From 4 th to 7 th byte. | Setting value of voltage A (Lower bytes are in the front location, higher bytes are in the later location) |
| From 8 th to 9th byte. | Time value of timer A (Lower bytes are in the front location, higher bytes are in the later location) (1represent 0.1mS) |
| From 10 th to 13 th byte | Setting value of voltage B(Lower bytes are in the front location, higher bytes are in the later location) |
| From 14 th to 15 th byte | Time value of timer B (Lower bytes are in the front location, higher bytes are in the later location) (1represent 0.1mS) |

| | |
|--|---|
| 16 th byte | Transient operation mode (0 is CONTINUES,1 is PULSE,2 is TOGGLED) |
| From 17 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

13. Setting /Reading CW mode transient watt and timer parameter(36H/37H)

| | |
|--|--|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(36H/37H) |
| From 4 th to 7 th byte | Setting value of power A (Lower bytes are in the front location, higher bytes are in the later location) |
| From 8 th to 9 th byte | Time value of timer A (Lower bytes are in the front location, higher bytes are in the later location) (1 represent 0.1mS) |
| From 10 th to 13 th byte | Setting value of power B(Lower bytes are in the front location, higher bytes are in the later location) |
| From 14 th to 15 th byte | Time value of timer B (Lower bytes are in the front location, higher bytes are in the later location) (1 represent 0.1mS) |
| 16 th byte | Transition operation mode (0 is CONTINUES,1is PULSE,2 is TOGGLED) |
| From 17 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

14. Setting /Reading CR mode transient resistance and timer parameter(38H/39H)

| | |
|---|---|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(38H/39H) |
| From 4 th byte to 7 th byte | Setting value of resistance A (Lower bytes are in the front location, higher bytes are in the later location) |

| | |
|---|--|
| From 8 th byte to 9 th byte. | Time value of timer A (Lower bytes are in the front location, higher bytes are in the later location) (1 represent 0.1mS) |
| From 10 th byte to 13 th byte | Setting value of resistance B (Lower bytes are in the front location, higher bytes are in the later location) |
| From 14 th byte to 15 th byte | Time value of timer B (Lower bytes are in the front location, higher bytes are in the later location) (1 represent 0.1mS) |
| 16 th byte | Transition operation mode (0 is CONTINUES,1 is PULSE,2 is TOGGLED) |
| 17 th byte to 25 th byte | System reserve |
| 26 th byte | Sum code |

15. Selecting /Reading the list operation mode

(CC/CV/CW/CR)(3AH/3BH)

| | |
|---------------------------------|--|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(3AH/3BH) |
| 4 th byte | LIST operation mode(0is CC mode, 1 is CV mode ,2 is CW mode,3 is CR mode) |
| From 5 th to 25 byte | System reserve |
| 26 th byte | Sum code |

16. Setting /Reading the list repeat mode.

(3CH/3DH)

| | |
|---|--|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(3CH/3DH) |
| 4 th byte | LIST repeat operation mode(0 is ONCE, 1 is REPEAT) |
| From 5 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

17. Setting / Reading the number of list steps.

(3EH/3FH)

| | |
|---|-------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(3EH/3FH) |
| From 4 th to 5 th byte | LIST steps |
| From 6 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

18. Setting / Reading one of the step's current

and time values. (40H/41H)

| | |
|---|---|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(40H/41H) |
| From 4 th byte to 5 th byte | Appointed one step |
| From 6 th to 9 th byte | Current value of current step (Lower bytes are in the front location, higher bytes are in the later location) |
| From 10 th to 11 th byte | Time value of current step (Lower bytes are in the front location, higher bytes are in the later location) (1 represent 0.1MS) |
| From 12 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

19. Setting / Reading one of the step's voltage

and time values. (42H/43H)

| | |
|--|--------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(42H/43H) |
| From 4 th to 5 th byte | Appointed one step |

| | |
|---|---|
| From 6 th byte to 9 th byte | Voltage value of current step (Lower bytes are in the front location, higher bytes are in the later location) |
| From 10 th to 11 th byte | Time value of current step (Lower bytes are in the front location, higher bytes are in the later location) (1 represent 0.1MS) |
| From 12 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

20. Setting / Reading one of the step's power and time values. (44H/45H)

| | |
|--|--|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(44H/45H) |
| 4 th byte | Appointed one step |
| From 5 th to 8 th byte | Power value of current step (Lower bytes are in the front location, higher bytes are in the later location) |
| From 9 th to 10 th byte | Time value of current step (Lower bytes are in the front location, higher bytes are in the later location) (1 represent 0.1MS) |
| From 11 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

21. Setting / Reading one of the step's power and time values. (46H/47H)

| | |
|--|---|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command (46H/47H) |
| From 4 th to 5 th byte | Appointed one step |
| From 6 th to 9 th byte | Resistance value of current step (Lower bytes are in the front location, higher bytes are in the later location) |
| From 10 th to 11 th byte | Time value of current step (Lower bytes are in the front location, higher bytes are in the later location) (1 represent 0.1MS) |
| From 12 th to 25 th byte | System reserve |

| | |
|-----------------------|----------|
| 26 th byte | Sum code |
|-----------------------|----------|

22. Setting / Reading List file name (48H/49H)

| | |
|--|------------------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command (48H/49H) |
| From 4 th to 13 th byte | LIST file name (ASSIC code) |
| From 14 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

23. Selection / Reading the memory space mode for storing list steps. (4AH/4BH)

| | |
|---|--------------------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(4AH/4BH) |
| 4 th byte | partition mode (1 2 4 8) |
| From 5 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

24. Save / Get list file in appointed area..

(4CH/4DH)

| | |
|---|---------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(4CH/4DH) |
| 4 th byte | Storing area 1 ~ 8) |
| From 5 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

25. Setting / Reading min voltage value in battery testing mode.(4EH/4FH)

| | |
|---|------------------------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(4EH/4FH) |
| 4 th byte | The lowest byte of voltage value. |
| 5 th byte | The lower byte of voltage value. |
| 6 th byte | The higher byte of voltage value. |
| 7 th byte | The highest byte of voltage value. |
| From 8 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

26. Setting / Reading timer value of FOR LOAD ON (50H/51H)

| | |
|---|--|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(50H/51H) |
| 4 th byte | The lowest byte of time value in timer. (1 represent 1S) |
| 5 th byte | The highest byte of time value in timer. |
| From 8 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

Time unit in Timer is S, 1S is represented by 1.

27. Disable / Enable timer of FOR LOAD ON (52H);

Reading timer state of FOR LOAD ON(53H)

| | |
|----------------------|-------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(52H/53H) |

| | |
|---|--|
| 4 th byte | Timer state (0 is disable ,1 is enable) |
| From 5 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

28. Setting communication address (54H)

| | |
|---|------------------------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command (54H) |
| 4 th byte | New communication address (0~0XFE) |
| From 5 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

29. Enable/Disable LOCAL control mode. (55H)

| | |
|---|---|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command (55H) |
| 4 th byte | State of LOCAL button(0:disable,1:enable “) |
| From 5 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

30.Enable / Disable remote sense mode.(56H)

Reading the state of remote sense mode.(57H)

| | |
|--|--|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(56H/57H) |
| 4 th byte | Remote mode state (0:disable,1:enable) |
| 5 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

31. Selecting / Reading trigger source. (58H/59H)

| | |
|----------------------|--------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command (58H/59H) |

| | |
|---|---|
| 4 th byte | Trigger mode (0:Keypad,1 External,2.command) |
| From 5 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

32. Sending a trigger signal to triggering the electronic load. (5AH)

| | |
|---|-------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(5AH) |
| From 4 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

33. Saving / Recall user's setting value in appointed memory area for recall. (5BH/5CH)

| | |
|---|-------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(5BH/5CH) |
| 4 th byte | Storing area () |
| From 5 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

34. Selecting / Getting FIXED/SHORT/TRAN/LIST/BATTERY function mode. (5DH/5EH)

| | |
|---|---|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(5DH/5EH) |
| 4 th byte | Work mode (0:FIXED,1:SHORT, 2:TRANSITION,3:LIST,4: BATTERY) |
| From 5 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

35. Reading input voltage, current, power and relative state. (5FH)

| | |
|--|--|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command (5FH) |
| From 4 th to 7 th byte | Actual input voltage value (Lower bytes are in the front location, higher bytes are in the later location) |
| From 8 th to 11 th byte | Actual input current value (Lower bytes are in the front location, higher bytes are in the later location) |
| From 12 th to 15 th byte | Actual input power value (Lower bytes are in the front location, higher bytes are in the later location) |
| 16 th byte | Operation state register |
| From 17 th to 18 th byte | Demand state register |
| From 19 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

| BIT | Signal | Meaning |
|-----|--------|--|
| 0 | CAL | Operation state register Calculate the new demarcate coefficient |
| 1 | WTG | Wait for trigger signal |
| 2 | REM | Remote control mode |
| 3 | OUT | Output state |
| 4 | LOCAL | LOCAL button state (0 is represent “not in effect “,1 is represent ‘in effect “) |
| 5 | SENSE | Remote testing mode |
| 6 | LOT | FOR LOAD ON timer state |
| 0 | RV | Demand state register Input reverse voltage |
| 1 | OV | Over voltage |
| 2 | OC | Over current |
| 3 | OP | Over power |
| 4 | OT | Over temperature |
| 5 | SV | Not connect remote terminal |
| 6 | CC | Constant current |
| 7 | CV | Constant voltage |
| 8 | CP | Constant power |
| 9 | CR | Constant resistance |

36. Enter the calibration mode(60H)

| | |
|---|---|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(60H) |
| 4 th byte | Calibration mode select(0:disable;1:enable) |
| 5 th byte | Calibration password(0X85H) |
| 6 th byte | Calibration password(0X11H or 0X12H) |
| From 7 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

| |
|-------------|
| NOTE |
|-------------|

If Load is not in protection state, users could do the calibration operation.

37. Getting the calibration mode state(61H)

| | |
|---|------------------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(61H) |
| 4 th byte | Calibration protection state |
| From 5 th to 25 th byte | System |
| 26 th byte | Sum code |

| |
|-------------|
| NOTE |
|-------------|

Represent calibration protection state by one byte. Each byte is defined as:

From high to low

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|---|---|---|---|---|---|---|---|

0 byte: protection state, 0 represent not in the protection state , 1 represent in protection state.

38. Calibrate voltage value(62H)

| | |
|---|---------------------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(62H) |
| 4 th byte | Voltage calibration point(1~4) |
| From 5 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

| |
|-------------|
| NOTE |
|-------------|

Current calibration standard points have four: 1, 2, 3, 4.

39. Sending the actual input voltage to calibration program(63H)

| | |
|---|-------------------------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(63H) |
| 4 th byte | The lowest byte of actual voltage |
| 5 th byte | The lower byte of actual voltage |
| 6 th byte | The higher byte of actual voltage. |
| 7 th byte | The highest byte of actual voltage. |
| From 8 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

40. Calibrate current value(64H)

| | |
|---|----------------------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(64H) |
| 4 th byte | Current calibration point (1~4) |
| From 5 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

NOTE

Current calibration standard points have four: 1,2,3,4

41. Sending the actual input current to calibration program (65H)

| | |
|---|------------------------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(65H) |
| 4 th byte | The lowest byte of actual current |
| 5 th byte | The lower byte of actual current |
| 6 th byte | The higher byte of actual current |
| 7 th byte | The highest byte of actual current |
| From 8 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

42. Store the calibration data to EEPROM(66H)

| | |
|---|-------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command (66H) |
| From 4 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

NOTE

Finish the calibration operation, users should save the calibration parameter in EEPROM with this command; users could use these data in next power on.

43. Setting / Reading calibration information (67H/68H)

| | |
|----------------------|-------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |

| | |
|---|-----------------------------------|
| 3 rd byte | Command(67H/68H) |
| From 4 th to 23 rd byte | Demarcate information(ASIC code) |
| 24 th byte | System reserve |
| 25 th byte | System reserve |
| 26 th byte | Sum code |

44. Restore the factory default calibration data

(69H)

| | |
|---|-------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(69H) |
| From 4 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

NOTE

User could use the initial calibration data of factory with this command.

45. Reading product's model, series number and version information(6AH)

| | |
|--|---|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(6AH) |
| From 4 th to 8 th byte | Mode information (ASIC code) |
| 9 th byte | The lowest byte of software version number(BCD code) |
| 10 th byte | The highest byte of software version number(BCD code) |
| From 11 th to 20 th byte | Product series number (ASIC code) |
| From 21 st to 25 th byte | System reserve |
| 26 th byte | Sum code |

For example:


Product's series number is 000045, product mode is 8511, software version number is V2.03, data as following

| | | | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| AA | 00 | 31 | 38 | 35 | 31 | 31 | 00 | 03 | 02 | ZZ | ZZ | ZZ | ZZ | ZZ | ZZ | ZZ | ZZ | ZZ | ZZ | XX | XX | XX | XX | XX | 57 |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|

46. Reading information in bar code (6BH)

| | |
|--|-----------------------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command (6BH) |
| From 4 th to 22 nd byte | Information in bar code(ASIC ?) |
| From 23 rd to 25 th byte | System reserve |
| 26 th byte | Sum code |

Bar code rule : All of bar cod of our products is distinguished by the former three characters.



47. Setting information of bar code(6CH)

| | |
|--|-----------------------------------|
| 1 st byte | Start bit (AAH) |
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(6CH) |
| 4 th to 22 nd byte | Product series number(ASIC code) |
| 24 th byte | System reserve |
| 25 th byte | System reserve |
| 26 th byte | Sum code |

48. The return information of command

operation in electronic load(12H)

| | |
|----------------------|-------------------|
| 1 st byte | Start bit (AAH) |
|----------------------|-------------------|

| | |
|---|----------------------------|
| 2 nd byte | Address (0—0XFE) |
| 3 rd byte | Command(12H) |
| 4 th byte | Command calibration result |
| From 5 th to 25 th byte | System reserve |
| 26 th byte | Sum code |

NOTE

Receiving one frame command and verify them
 If verify sum is wrong, return the parameter 90H
 If setting parameter is wrong or over brim, return parameter A0H.
 If command is not enforce, return to parameter B0H
 If command is invalid, return to parameter C0H
 Otherwise, return to parameter 80H

NOTE

Receiving one frame command and verify them
 If verify sum is correct, return the relative reading data.
 If verify sum is wrong , return the verify command(90H) ?



Limited One-Year Warranty

B&K Precision Corp. warrants to the original purchaser that its product and the component parts thereof, will be free from defects in workmanship and materials for a period of one year from the date of purchase.

B&K Precision Corp. will, without charge, repair or replace, at its' option, defective product or component parts. Returned product must be accompanied by proof of the purchase date in the form a sales receipt.

To obtain warranty coverage in the U.S.A., this product must be registered by completing and mailing the enclosed warranty card to B&K Precision Corp., 22820 Savi Ranch Parkway, Yorba Linda, CA 92887 within fifteen (15) days from proof of purchase.

Exclusions: This warranty does not apply in the event of misuse or abuse of the product or as a result of unauthorized alterations or repairs. It is void if the serial number is altered, defaced or removed.

B&K Precision Corp. shall not be liable for any consequential damages, including without limitation damages resulting from loss of use. Some states do not allow limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific rights and you may have other rights, which vary from state-to-state.

Model Number: _____

Date Purchased: _____

22820 Savi Ranch Parkway
Yorba Linda, CA 92887
714.921.9095
714.921.6422 Facsimile



Service Information

Warranty Service: Please return the product in the original packaging with proof of purchase to the below address. Clearly state in writing the performance problem and return any leads, connectors and accessories that you are using with the device.

Non-Warranty Service: Return the product in the original packaging to the below address. Clearly state in writing the performance problem and return any leads, connectors and accessories that you are using with the device. Customers not on open account must include payment in the form of a money order or credit card. For the most current repair charges contact the factory before shipping the product.

Return all merchandise to B&K Precision Corp. with pre-paid shipping. The flat-rate repair charge includes return shipping to locations in North America. For overnight shipments and non-North America shipping fees contact B&K Precision Corp..

B&K Precision Corp.
22820 Savi Ranch Parkway
Yorba Linda, CA 92887
Phone: 714- 921-9095
Facsimile: 714-921-6422
Email: service@bkprecision.com

Include with the instrument your complete return shipping address, contact name, phone number and description of problem.

PN: 481-535-9-001
Printed in China
©2005 B&K Precision Corp.

22820 Savi Ranch Parkway
Yorba Linda, CA 92887
USA
TEL: 714-921-9095
FAX: 714-921-6422
www.bkprecision.com