

Serial Wiring 5 Port Solenoid Valve for EX510 Series *VQ1000/2000*




Manifold Variations

Series VQ

Series		A, B port size								
		Piping with one-touch fitting								Port piping
		ø3.2	ø4	ø6	ø8	ø1/8"	ø5/32"	ø1/4"	ø5/16"	
VQ1000		●	●	●		●	●	●		●
VQ2000			●	●	●		●	●	●	



Refer to SMC's "Best Pneumatics" catalogue for detailed specifications and precautions.



EX510 Serial Wiring Series VQ1000/2000 Base Mounted Plug-in Manifold

How to Order Manifold

VV5Q 1 1-SB 08 D Q

Manifold series

1	VQ1000
2	VQ2000

SI unit COM.

-	+COM.
N	-COM.

Stations

Symbol	No. of stations
01	1 station
⋮	⋮
08	8 stations

Note) Maximum 16 stations (for special wiring specifications)

Option

-	None
B	With back pressure check valve ^{Note 2)}
G1	1 set of regulator unit ^{Note 3) Note 7)}
G2	2 sets of regulator unit ^{Note 3) Note 7)}
G3	3 sets of regulator unit ^{Note 3) Note 7)}
J□	With vacuum ejector unit ^{Note 4) Note 7)}
K	Special wiring specifications (Except double wiring) ^{Note 5)}
N	With name plate
R	External pilot ^{Note 6)}
S	Built-in silencer, direct exhaust



Note 1) When two or more symbols are specified, indicate them alphabetically. Example: "-BRS"



Note 2) Models with a suffix "-B" have check valves for prevention of back pressure at all manifold stations. If not all stations need this check valve, specify the stations where check valves are installed by using a manifold specification sheet.

Note 3) Specify the mounting position on a manifold specification sheet.

Note 4) For details, refer to SMC's "Best Pneumatics" catalogue. A combination of "J" and "N" is unavailable.

Note 5) Specify the wiring by using a manifold specification sheet.

Note 6) Indicate "R" for the valve with external pilot.

Note 7) Applicable to the VQ1000 only.

Cylinder port


	Symbol	Port size	VQ1000	VQ2000
Metric size	C3	With one-touch fitting for ø3.2	○	
	C4	With one-touch fitting for ø4	○	○
	C6	With one-touch fitting for ø6	○	○
	C8	With one-touch fitting for ø8		○
	M5	M5 thread	○	
	CM	Mixed size/with port plug ^{Note)}	○	○
	L3	With elbow one-touch fitting ø3.2 for top piping	○	
	L4	With elbow one-touch fitting ø4 for top piping	○	○
	L6	With elbow one-touch fitting ø6 for top piping	○	○
	L8	With elbow one-touch fitting ø8 for top piping		○
	L5	Elbow M5 thread for top piping	○	
	B3	With elbow one-touch fitting ø3.2 for bottom piping	○	
	B4	With elbow one-touch fitting ø4 for bottom piping	○	○
	B6	With elbow one-touch fitting ø6 for bottom piping	○	○
Inch size	B8	With elbow one-touch fitting ø8 for bottom piping		○
	B5	Elbow M5 thread for bottom piping	○	
	LM	Mixed size for elbow piping	○	○
	N1	With one-touch fitting for ø1/8"	○	
	N3	With one-touch fitting for ø5/32"	○	○
	N7	With one-touch fitting for ø1/4"	○	○
	N9	With one-touch fitting for ø5/16"		○
	M5T	UNF10-32 thread	○	
	NM	Mixed size/with port plug ^{Note)}	○	○
	LN1	With elbow one-touch fitting ø1/8" for top piping	○	
	LN3	With elbow one-touch fitting ø5/32" for top piping	○	○
	LN7	With elbow one-touch fitting ø1/4" for top piping	○	○
	LN9	With elbow one-touch fitting ø5/16" for top piping		○
	L5T	Elbow UNF10-32 thread for top piping	○	
	BN1	With elbow one-touch fitting ø1/8" for bottom piping	○	
	BN3	With elbow one-touch fitting ø5/32" for bottom piping	○	○
	BN7	With elbow one-touch fitting ø1/4" for bottom piping	○	○
	BN9	With elbow one-touch fitting ø5/16" for bottom piping		○
	B5T	Elbow UNF10-32 thread for bottom piping	○	
	LNM	Mixed size for elbow piping	○	○

Note) Specify "Mixed size/with port plug" on a manifold specification sheet.

DIN rail mounting

How to Order Valve Manifold Assembly (Example)

Example



VV5Q11-SB08C6-D ... 1 set (SB kit, 8 station manifold base part no.)

* VQ1100-5-Q 4 sets (Single solenoid part no.)

* VQ1200-5-Q 3 sets (Double solenoid part no.)

* VQ1300-5-Q 1 set (3 position type part no.)

→ The asterisk denotes the symbol for assembly. Prefix it to the part nos. of the solenoid valve, etc.

→ Enter in order starting from the first station on the D side.

Add the valve and option part number under the manifold base part number. In the case of a complex arrangement, specify them on a manifold specification sheet.

How to Order Valves

VQ **1** **1** **0** **0** **Y** **5** **—** **Q**

Series

1	VQ1000
2	VQ2000

Type of actuation

1	2 position single	
2	Metal 2 position double	
	Rubber 2 position double	
3	3 position closed centre	
4	3 position exhaust centre	
5	3 position pressure centre	
Note) A	4 position dual 3 port valve (A)	
Note) B	4 position dual 3 port valve (B)	
Note) C	4 position dual 3 port valve (C)	




Note) Rubber seal type only.

Manual override


--: Non-locking push type (Tool required)



B: Locking type (Tool required)



C: Locking type (Manual)



Rated voltage

5	24 VDC
---	--------

Function

Symbol	Specifications
-	Standard
H	High pressure type (0.8 MPa)
Y	Low wattage type (0.5 W)
K	High pressure type (1 MPa) ^{Note 1)}
N	Negative COM
R	External pilot ^{Note 2)}

Note 1) Metal seal type only.


Note 2) Not applicable to dual 3 port.

Seal

0	Metal seal
1	Rubber seal

Series VQ1000/2000

Dimensions: VQ1000




















Dimensions

Formula L1 = 10.5n + 44.5, L2 = 10.5n + 91 n: Station (Maximum 16 stations)















L \ n	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	55	65.5	76	86.5	97	107.5	118	128.5	139	149.5	160	170.5	181	191.5	202	212.5
L2	101.5	112	122.5	133	143.5	154	164.5	175	185.5	196	206.5	217	227.5	238	248.5	259
L3	125	137.5	150	162.5	175	175	187.5	200	212.5	225	237.5	237.5	250	262.5	275	287.5
L4	135.5	148	160.5	173	185.5	185.5	198	210.5	223	235.5	248	248	260.5	273	285.5	298

Series VQ1000/2000

Manifold Options: VQ1000

Blanking plate assembly VVQ1000-10A-1 	SUP block plate VVQ1000-16A 	Double check block VQ1000-FPG-□□ 	Dual flow fitting assembly VVQ1000-52A-C8 
Blanking plug KQ2P- 23 04 06 08 	Individual SUP spacer VVQ1000-P-1-C6 	EXH block base assembly VVQ1000-19A- F□ C3 P□ C4 L□ C6 M5 	Elbow fitting assembly VVQ1000-F-L C3 C4 C6 M5 
Silencer (For EXH port) AN200-KM8/AN203-KM8 	Blanking plate with connector VVQ1000-1C□-□ 	Individual EXH spacer VVQ1000-R-1-C6 	Back pressure check valve assembly [-B] VVQ1000-18A 
Regulator unit VVQ1000-AR-1 	With vacuum ejector unit [-J□] 	Name plate [-N] VVQ1000-^N_{NC}-Station (1 to max. stations) 	Built-in silencer, direct exhaust [-S] 
Port plug VVQ0000-58A 	 • For cylinder port fittings part no., refer to SMC's "Best Pneumatics" catalogue. • For replacement parts, refer to SMC's "Best Pneumatics" catalogue.		

Manifold Options: VQ2000

Blanking plate assembly VVQ2000-10A-1 	SUP block plate VVQ2000-16A 	Port plug VVQ1000-58A 	Individual SUP spacer VVQ2000-P-1-C8  C8 (SUP port) One-touch fitting for ø8
EXH block plate VVQ2000-19A 	Built-in silencer, direct exhaust [-S]  Exhaust port	Blanking plug KQ2P- 04 06 08 10 	Individual EXH spacer VVQ2000-R-1-C8  C8 (EXH port) One-touch fitting for ø8
Name plate [-N] VVQ2000-N-Station (1 to max. stations) 	Silencer (For EXH port) AN200-KM10 	Back pressure check valve assembly [-B] VVQ2000-18A 	Elbow fitting assembly VVQ2000-F-L (C4, C6, C8) 
Dual flow fitting assembly VVQ2000-52A-C10 	Double check block VQ2000-FPG-□□  To CYL port	 • For cylinder port fittings part no., refer to SMC's "Best Pneumatics" catalogue. • For replacement parts, refer to SMC's "Best Pneumatics" catalogue.	



EUROPEAN SUBSIDIARIES:



Austria

SMC Pneumatik GmbH (Austria).
Girakstrasse 8, A-2100 Korneuburg
Phone: +43 2262-62280, Fax: +43 2262-62285
E-mail: office@smc.at
http://www.smc.at



France

SMC Pneumatique, S.A.
1, Boulevard de Strasbourg, Parc Gustave Eiffel
Bussy Saint Georges F-77607 Marne La Vallée Cedex 3
Phone: +33 (0)1-6476 1000, Fax: +33 (0)1-6476 1010
E-mail: contact@smc-france.fr
http://www.smc-france.fr



Netherlands

SMC Pneumatics BV
De Ruyterkade 120, NL-1011 AB Amsterdam
Phone: +31 (0)20-5318888, Fax: +31 (0)20-5318880
E-mail: info@smcpneumatics.nl
http://www.smcpneumatics.nl



Spain

SMC España, S.A.
Zuazobidea 14, 01015 Vitoria
Phone: +34 945-184 100, Fax: +34 945-184 124
E-mail: post@smc.smces.es
http://www.smces.es



Belgium

SMC Pneumatics N.V./S.A.
Nijverheidsstraat 20, B-2160 Wommelgem
Phone: +32 (0)3-355-1464, Fax: +32 (0)3-355-1466
E-mail: post@smcpneumatics.be
http://www.smcpneumatics.be



Germany

SMC Pneumatik GmbH
Boschring 13-15, D-63329 Egelsbach
Phone: +49 (0)6103-4020, Fax: +49 (0)6103-402139
E-mail: info@smc-pneumatik.de
http://www.smc-pneumatik.de



Norway

SMC Pneumatics Norway A/S
Vollsveien 13 C, Granfos Næringspark N-1366 Lysaker
Tel: +47 67 12 90 20, Fax: +47 67 12 90 21
E-mail: post@smc-norge.no
http://www.smc-norge.no



Sweden

SMC Pneumatics Sweden AB
Ekhagsvägen 29-31, S-141 71 Huddinge
Phone: +46 (0)8-603 12 00, Fax: +46 (0)8-603 12 90
E-mail: post@smcpneumatics.se
http://www.smc.nu



Bulgaria

SMC Industrial Automation Bulgaria EOOD
16 kliment Ohridski Blvd., fl.13 BG-1756 Sofia
Phone: +359 2 9744492, Fax: +359 2 9744519
E-mail: office@smc.bg
http://www.smc.bg



Greece

SMC Hellas EPE
Anagenniseos 7-9 - P.C. 14342. N. Philadelphia, Athens
Phone: +30-210-2717265, Fax: +30-210-2717766
E-mail: sales@smchellas.gr
http://www.smchellas.gr



Poland

SMC Industrial Automation Polska Sp.z.o.o.
ul. Konstruktorska 11A, PL-02-673 Warszawa,
Phone: +48 22 548 5085, Fax: +48 22 548 5087
E-mail: office@smc.pl
http://www.smc.pl



Switzerland

SMC Pneumatik AG
Dorfstrasse 7, CH-8484 Weisslingen
Phone: +41 (0)52-396-3131, Fax: +41 (0)52-396-3191
E-mail: info@smc.ch
http://www.smc.ch



Croatia

SMC Industrijska automatika d.o.o.
Cromerec 12, 10000 ZAGREB
Phone: +385 1 377 66 74, Fax: +385 1 377 66 74
E-mail: office@smc.hr
http://www.smc.hr



Hungary

SMC Hungary Ipari Automatizálási Kft.
Budafoki út 107-113, H-1117 Budapest
Phone: +36 1 371 1343, Fax: +36 1 371 1344
E-mail: office@smc.hu
http://www.smc.hu



Portugal

SMC Sucursal Portugal, S.A.
Rua de Engº Ferreira Dias 452, 4100-246 Porto
Phone: +351 22-610-89-22, Fax: +351 22-610-89-36
E-mail: postpt@smc.smces.es
http://www.smces.es



Turkey

Entek Pnömatik San. ve Tic.Ltd. Sti.
Perpa Tic. Merkezi Kat: 11 No: 1625, TR-80270 Okmeydanı Istanbul
Phone: +90 (0)212-221-1512, Fax: +90 (0)212-221-1519
E-mail: smc-entek@entek.com.tr
http://www.entek.com.tr



Czech Republic

SMC Industrial Automation CZ s.r.o.
Hudcova 78a, CZ-61200 Brno
Phone: +420 5 414 24611, Fax: +420 5 412 18034
E-mail: office@smc.cz
http://www.smc.cz



Ireland

SMC Pneumatics (Ireland) Ltd.
2002 Citywest Business Campus, Naas Road, Saggart, Co. Dublin
Phone: +353 (0)1-403 9000, Fax: +353 (0)1-464-0500
E-mail: sales@smcpneumatics.ie
http://www.smcpneumatics.ie



Romania

SMC Romania srl
Str Frunzei 29, Sector 2, Bucharest
Phone: +40 213205111, Fax: +40 213261489
E-mail: smcromania@smcromania.ro
http://www.smcromania.ro



UK

SMC Pneumatics (UK) Ltd
Vincent Avenue, Crownhill, Milton Keynes, MK8 0AN
Phone: +44 (0)800 1382930 Fax: +44 (0)1908-555064
E-mail: sales@smcpneumatics.co.uk
http://www.smcpneumatics.co.uk



Denmark

SMC Pneumatik A/S
Knudsmide 4B, DK-8300 Odder
Phone: +45 70252900, Fax: +45 70252901
E-mail: smc@smc-pneumatik.dk
http://www.smc.dk.com



Italy

SMC Italia S.p.A
Via Garibaldi 62, I-20061 Carugate, (Milano)
Phone: +39 (0)2-92711, Fax: +39 (0)2-9271365
E-mail: mailbox@smcitalia.it
http://www.smcitalia.it



Russia

SMC Pneumatik LLC.
4B Sverdlovskaja nab, St. Petersburg 195009
Phone: +812 718 5445, Fax: +812 718 5449
E-mail: info@smc-pneumatik.ru
http://www.smc-pneumatik.ru



Estonia

SMC Pneumatics Estonia OÜ
Laki 12-101, 106 21 Tallinn
Phone: +372 (0)6 593540, Fax: +372 (0)6 593541
E-mail: smc@smcpneumatics.ee
http://www.smcpneumatics.ee



Latvia

SMC Pneumatics Latvia SIA
Smerla 1-705, Riga LV-1006, Latvia
Phone: +371 781-77-00, Fax: +371 781-77-01
E-mail: info@smclv.lv
http://www.smclv.lv



Slovakia

SMC Priemyselná Automatizácia, s.r.o.
Námestie Martina Benku 10, SK-81107 Bratislava
Phone: +421 2 444 56725, Fax: +421 2 444 56028
E-mail: office@smc.sk
http://www.smc.sk



Finland

SMC Pneumatics Finland Oy
PL72, Tiistiniittyntie 4, SF-02031 ESPOO
Phone: +358 207 513513, Fax: +358 207 513595
E-mail: smcfin@smc.fi
http://www.smc.fi



Lithuania

SMC Pneumatics Lietuva, UAB
Savanoriu pr. 180, LT-01354 Vilnius, Lithuania
Phone: +370 5 264 81 26, Fax: +370 5 264 81 26



Slovenia

SMC industrijska Avtomatika d.o.o.
Grajski trg 15, SLO-8360 Zuzemberk
Phone: +386 738 85240 Fax: +386 738 85249
E-mail: office@smc.si
http://www.smc.si



OTHER SUBSIDIARIES WORLDWIDE:

ARGENTINA, AUSTRALIA, BOLIVIA, BRASIL, CANADA, CHILE,
CHINA, HONG KONG, INDIA, INDONESIA, MALAYSIA, MEXICO,
NEW ZEALAND, PHILIPPINES, SINGAPORE, SOUTH KOREA,
TAIWAN, THAILAND, USA, VENEZUELA

<http://www.smceu.com>
<http://www.smcworld.com>