




TWR-K40D100M Quick Start Guide

Low-Power MCU with USB
and Segment LCD

Tower System
Development Board
Platform



Get to Know the TWR-K40D100M Board






Figure 2: Front side of TWR-K40D100M board with TWRPI-SLCD attached




Figure 3: Back side of TWR-K40D100M board

TWR-K40D100M Features

- MK40DX256VMD10 MCU (100 MHz ARM® Cortex®-M4 core, 512 KB flash, SLCD, USB FS OTG, 144 MAPBGA)
- Integrated open source JTAG (OSJTAG) circuit
- MMA8451Q 3-axis accelerometer
- Four user-controlled status LEDs
- Four capacitive touchpads and two mechanical pushbuttons
- General-purpose TWRPI socket (Tower plug-in module)
- Potentiometer, SD card socket and coin-cell battery holder

Step-by-Step Installation Instructions

In this Quick Start Guide, you will learn how to set up the TWR-K40D100M module and run the default demonstration.

1

Install the Software and Tools

Install the P&E Micro Kinetis Tower toolkit. The toolkit includes the OSJTAG and USB-to-serial drivers. These can be found online at **freescale.com/TWR-K40D100M**.

**2**

Configure the Hardware

Install the included battery into the VBAT (RTC) battery holder. Then, plug the included segment LDC TWRPI-SLCD into the TWRPI socket. Finally, connect one end of the USB cable to the PC and the other end to the power/OSJTAG

mini-B connector on the TWR-K40D100M module. Allow the PC to automatically configure the USB drivers if needed.

3 Tilt the Board

Tilt the board side to side to see the LEDs on D8, D9, D10 and D11 light up as it is tilted.

4 Navigate the Segment LDC

The segment LDC will display the seconds elapsed since boot-up. Press **SW2** to toggle between viewing the seconds, hours and minutes, potentiometer and temperature.

5 Explore Further

Explore all of the features and capabilities of the preprogrammed demo by reviewing the lab document located at **freescale.com/TWR-K40D100M**.

6 Learn More About Kinetis K40 MCUs

Find more MQX™ RTOS and bare-metal labs and software for the Kinetis 40 MCUs at **freescale.com/TWR-K40D100M**.

TWR-K40D100M Jumper Options

The following is a list of all jumper options. The default installed jumper settings are shown in shaded boxes.

Jumper	Option	Setting	Description
J10	V_BRD Voltage Selection	1-2	Onboard power supply set to 3.3 V
		2-3	Onboard power supply set to 1.8 V (Some onboard peripherals may not operate)
J13	MCU Power Connection	ON	Connect MCU to onboard power supply (V_BRD)
		OFF	Isolate MCU from power (Connect to ammeter to measure current)
J9	VBAT Power Selection	1-2	Connect VBAT to onboard power supply
		2-3	Connect VBAT to the higher voltage between onboard power supply or coin-cell supply

Jumper	Option	Setting	Description
J14	OSJTAG Bootloader Selection	ON	OSJTAG bootloader mode (OSJTAG firmware reprogramming)
		OFF	Debugger mode
J15	JTAG Board Power Connection	ON	Connect onboard 5 V supply to JTAG port (supports powering board from JTAG pod supporting 5 V supply output)
		OFF	Disconnect onboard 5 V supply from JTAG port
J12	IR Transmitter Connection	ON	Connect PTD7/CMT_IR0 to IR transmitter (D5)
		OFF	Disconnect PTD7/CMT_IR0 from IR transmitter (D5)
J11	IR Receiver Connection	ON	Connect PTC6/CMP0_IN0 to IR receiver (Q2)
		OFF	Disconnect PTC6/CMP0_IN0 from IR receiver (Q2)
J2	VREGIN Power Connection	ON	Connect USB0_VBUS from elevator to VREGIN
		OFF	Disconnect USB0_VBUS from elevator to VREGIN
J3	GPIO to Drive RSTOUT	1-2	PTE27 to drive RSTOUT
		2-3	PTB9 to drive RSTOUT
J1	FlexBus Address Latch Selection	1-2	FlexBus address latch disabled
		2-3	FlexBus address latch enabled

Visit **freescale.com/TWR-K40D100M**, **freescale.com/K40** or **freescale.com/Kinetis** for information on the TWR-K40D100M module, including:

- TWR-K40D100M user manual
- TWR-K40D100M schematics
- Tower System fact sheet

Support

Visit **freescale.com/support** for a list of phone numbers within your region.

Warranty

Visit **freescale.com/warranty** for complete warranty information.

For more information, visit **freescale.com/Tower**

Join the online Tower community at **towergeeks.org**

Freescale, the Freescale logo, the Energy Efficient Solutions logo and Kinetis are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. Tower is a trademark of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners. ARM and Cortex are registered trademarks of ARM Limited (or its subsidiaries) in the EU and/or elsewhere. All rights reserved. © 2013, 2014 Freescale Semiconductor, Inc.

