

ET-7000/PET-7000 AIO series

User Manual

Service and usage information for



ET-7005/PET-7005

ET-7015/PET-7015

ET-7017/PET-7017

ET-7017-10/PET-7017-10

ET-7018Z/PET-7018Z

ET-7019/PET-7019

Warranty

All products manufactured by ICP DAS are under warranty regarding defective materials for a period of one year, beginning from the date of delivery to the original purchaser.

Warning

ICP DAS assumes no liability for any damage resulting from the use of this product. ICP DAS reserves the right to change this manual at any time without notice. The information furnished by ICP DAS is believed to be accurate and reliable. However, no responsibility is assumed by ICP DAS for its use, not for any infringements of patents or other rights of third parties resulting from its use.

Copyright

Copyright © 2009 by ICP DAS Co., Ltd. All rights are reserved.

Trademark

The names used for identification only may be registered trademarks of their respective companies.

Contact US

If you have any problem, please feel free to contact us.
You can count on us for quick response.

Email: service@icpdas.com

Table of Contents


Chapter 1. Introduction.....	7
1.1. ET-7000/PET-7000 Family.....	8
1.1.1. PET-7000/ET-7000 Module Naming Convention	9
1.1.2. PET-7000/ET-7000 Comparison.....	10
1.2. Features.....	12
1.3. Specification.....	15
1.3.1. System Specification	15
1.3.2. I/O Specification.....	17
1.3.2.1. PET-7005/ET-7005	17
1.3.2.2. PET-7015/ET-7015	19
1.3.2.3. PET-7017/ET-7017	21
1.3.2.4. PET-7017-10/ET-7017-10	23
1.3.2.5. PET-7018Z/ET-7018Z	25
1.3.2.6. PET-7019/ET-7019	27
1.4. Overview.....	29
1.4.1. Front Panel	29
1.4.2. Back Panel	32
1.5. Dimensions	34
1.6. Companion CD.....	35
 Chapter 2. Getting Started	 36
2.1. Mounting the Hardware.....	36
2.2. Configuring the Boot Mode.....	38

2.3. Connecting to Network, PC and Power	39
2.4. Installing the MiniOS7 Utility	40
2.5. Using MiniOS7 Utility to Assign a New IP.....	41
2.6. Enabling Adobe Flash Player in Browser	45
 Chapter 3. Web Applications.....	 47
3.1. Overview.....	50
3.2. Configuration	52
3.2.1. Network Settings	53
3.2.1.1. Configure the Network Settings	54
3.2.1.2. Check the software information.....	56
3.2.2. Basic Settings.....	57
3.2.2.1. Configure the Module Information.....	58
3.2.2.2. Configure the Web site Information.....	59
3.2.2.3. Reset All Settings to Default.....	61
3.2.2.3.1. Factory Default Settings for Configuration Menu Service	62
3.2.2.3.2. Factory Default Settings for Authentication Menu Service	68
3.2.2.3.3. Factory Default Settings for Web HMI Menu Service	68
3.2.2.3.4. Factory Default Settings for Pair Connection Menu Service.....	68
3.2.3. Module I/O Settings	69
3.3. Authentication.....	70
3.3.1. Account Management.....	71
3.3.1.1. Configure the user accounts	72
3.3.1.2. Load the factory default user accounts	73
3.3.2. Accessible IP Settings	74
3.3.2.1. Configuring IP filter.....	75
3.4. Web HMI.....	77

3.4.1. Web HMI.....	78
3.4.2. Web Edit.....	79
3.5. Pair Connection	87
3.6. More Information	88
Chapter 4. Modbus Applications	89
4.1. What is Modbus TCP/IP?.....	90
4.2. Modbus Message Structure	90
4.2.1. Address	91
4.2.2. Function Codes	92
4.2.3. Data Field	92
4.2.4. Error Check	92
4.3. Modbus Register Map.....	93
4.3.1. Common Function	93
4.3.2. Particular Function.....	95
4.3.2.1. PET-7005/ET-7005 I/O Address Mapping	96
4.3.2.2. PET-7015/ET-7015 I/O Address Mapping	104
4.3.2.3. PET-7017/ET-7017 I/O Address Mapping	107
4.3.2.4. ET-7017-10 I/O Address Mapping.....	112
4.3.2.5. PET-7018Z/ET-7018Z I/O Address Mapping.....	116
4.3.2.6. ET-7019 I/O Address Mapping	123
Chapter 5. MiniOS7 Utility Tool	129
5.1. Establishing a Connection.....	129
5.2. Exchanging the Protocol (TCP/IP to UDP).....	132
5.3. Updating the ET-7000/PET-7000 OS	134

5.4. Uploading the ET-7000/PET-7000 Firmware	139
Chapter 6. External Tools and Tasks	144
6.1. LabVIEW	144
6.2. OPC Server	145
6.3. SCADA	146
6.3.1. InduSoft	147
6.3.2. Citect	148
6.3.3. iFix	149
Appendix A. Node Information Area	150
Appendix B. Modbus Application Notes	151
B.1. Dual Watchdog	151
B.2. Power ON Value	152
B.3. Safe Value	153
B.4. AI High/Low Alarm	154
B.5. AI High/Low Latch	159
Appendix C. Troubleshooting	163

Chapter 1. Introduction



The PET-7000/ET-7000, a web-based Ethernet I/O module, features a built-in web server, which allows configuration, I/O monitoring and I/O control by simply using a regular web browser. Besides, with the web HMI function, no more programming or HTML skills are needed; creating dynamic and attractive web pages for I/O monitoring and I/O control would be fun to engineers ever after. The PET-7000/ET-7000 offers easily and safely access for users from anytime and anywhere! In addition, PET-7000/ET-7000 also supports Modbus/TCP protocol that makes perfect integration to SCADA software.


1.1. ET-7000/PET-7000 Family

Either ET-7000 or PET-7000 has released three different types of analog series modules, which provides a variety of analog module choice, listed in the following table.

Type	Model	Description
Thermistor	PET-7005/ ET-7005	8-channel Thermistor inputs and 4-channel digital outputs
RTD	PET-7015/ ET-7015	7-channel RTD Inputs with 3-wire RTD lead resistance elimination
Voltage and Current	PET-7017/ ET-7017	8-channel differential analog inputs and 4-channel digital outputs
	ET-7017-10/ PET-7017-1 0	10-channel differential or 20-channel single-ended analog inputs
Thermocouple	PET-7018Z/ ET-7018Z	10-channel Thermocouple inputs and 6-channel isolated digital outputs
	ET-7019/PE T-7019	8-channel differential analog inputs and 4-channel digital outputs

1.1.1. PET-7000/ET-7000 Module Naming Convention

As you examine this manual, you'll notice there are many different products available. Sometimes it is difficult to remember the specifications for any given product. The figure below shows how the module naming conventions work for each PET-7000/ET-7000 product, you can take a few minutes to understand the module naming conventions, and it may save you sometime and confusion.



X	Y	Z
Number of variance	1. AI module	4. Transmitter 5. RTD 6. Strain Gauge 7. Analog Input 8. Thermocouple
	2. AO module	1. Voltage output 2. Current output
	3. Reserved	
	4. DIO module	Number of variance
	5. DIO module	Number of variance
	6. DIO module with relay	Number of variance
	7. Multi-function	1. General purpose
	8. Counter/Frequency	Number of variance
	9. Motion	N: Number of axes

1.1.2. PET-7000/ET-7000 Comparison

The features of the PET-7000 differ from the ET-7000

Power over Ethernet + ET-7000 = PET-7000

PET-7000 features “PoE” and many other advantages in ET-7000. Now, not only data but power is carried through an Ethernet cable. This feature makes installation of PET-7000 a piece of cake. Imagine that no more unnecessary wires, only an Ethernet cable takes care of everything in the field.

PET-7000 also features a built-in web server and the web HMI function. A built-in web server allows basic setting configuration, I/O monitoring and I/O control by simply using a regular web browser. Remote control is as easy as you surf the internet.

As to the web HMI function, no programming or HTML skills are required; creating dynamic and attractive web pages for I/O monitoring and I/O control would be fun for engineers ever after.

PET-7000 also supports Modbus/TCP protocol that makes perfect integration for PET-7000 to SCADA software.

Industrial PoE Solution

When using PoE devices like PET-7000, you can choose ICP DAS “PoE” switch — “NS-205PSE” as the power source, NS-205PSE automatically detects the connected devices whether they are PoE devices or not. This mechanism ensures NS-205PSE to work with both PoE and non-PoE devices coordinately at the same time.

Being as a power source for PoE devices, NS-205PSE requires its power input ranging from +46 ~ +55VDC.


More information about PET-7000

There are two ways for PET-7000 getting the power. One is through Ethernet by a PoE switch; the other is as usual through wiring by an external power. External power should range from +12 ~ 48 VDC. The reason we keep the second way is because it might be useful if someday or somehow you have different applications.

1.2. Features


► Built in Web Server

Each PET-7000/ET-7000 module has a built-in web server that allows users to easily configure, monitor and control the module from a remote location using a regular web browser.



► Web HMI

The Web HMI function allows the users to create dynamic and attractive web pages to monitor and control the I/O points. Users can upload specific I/O layout pictures (bmp, jpg, gif format) and define a description for each I/O point. No HTML or Java skills are needed to create the web pages.



➤ Communication Security

Account and password are required when logging into the PET-7000/ET-7000 web server. An IP address filter is also included, which can be used to allow or deny connections with specific IP addresses.

➤ Modbus Protocol

The Modbus/TCP slave function on the Ethernet port can be used to provide data to remote SCADA software.

➤ Built-in Multi-function I/O

All Digital Output modules provide:

Power on value (On boot up, the DO status is set to the Power-on value)

Safe value (If Modbus/TCP communication is lost for a certain period, the DO status will be set to the user defined safe value)

All Digital Input modules provide:

High/Low latched status

DI channels can also be used as DI status and 32-bit low speed (100Hz) counters.

➤ All-in-one Module

Various I/O components are mixed with multiple channels in a single module, which provides the most cost effective I/O usage and enhances performance of the I/O operations.

➤ Automatic MDI / MDI-X Crossover for Plug-and-play

RJ-45 port supports automatic MDI/MDI-x that can automatically detect the type of connection to the Ethernet device without requiring special straight or crossover cables.

► Built-in Dual Watchdog

The Dual Watchdog consists of a Module Watchdog and a Host Watchdog.

Module Watchdog is a built-in hardware circuit that can be used to monitor the operation of the module and will reset the CPU module if a failure occurs in the hardware or the software.

Power on value (On boot up, the DO status is set to the Power-on value)

Host Watchdog is a software function that can be used to monitor the operating status of the host, and is used to prevent network communication problems or host failures.

Safe value (If Modbus/TCP communication is lost for a certain period, the DO status will be set to the user defined safe value)


► Ventilated Housing Designed to Operate Between -25 °C to +75 °C

PET-7000/ET-7000 is housed in a plastic-based shell/case with a column-like ventilator that helps to cool the working environment inside the shell/case and allows PET-7000/ET-7000 to operate at temperatures ranging from -25 °C to +75 °C.

► I/O Pair Connection

This function is used to create a DI to DO pair through the Ethernet. Once the configuration is completed,

PET-7000/ET-7000 module can continuously poll the status of remote DI device using the Modbus/TCP protocol and then write to local DO channels in the background.



1.3. Specification

1.3.1. System Specification

System	
CPU	80186 CPU (80 MHz)
SRAM	512 KB
Flash Memory	512 KB
EEPROM	16 KB
Dual Watchdog	Yes

Communication	
Ethernet Port	10/100 Base-TX (With Link, Activity LED Indicator) Automatic MDI/MDI-X

Isolation	
Ethernet	-
I/O	2500 V _{DC}

LED Display	
PoE	PoE On (for PET-7000 series only)
L1	Run indicator
L2	Link/Act indicator
L3	10/100M indicator

Mechanical	
Dimensions (W x H x D)	123 mm x 72 mm x 35 mm
Installation	DIN Rail or Wall mounting


Environment	
Operating Temperature	-25 °C ~ +75 °C
Storage Temperature	-30 °C ~ +80 °C
Humidity	5 ~ 90 % RH, non-condensing

Power Requirements (for ET-7000 series only)	
Protection	Power reverse polarity protection
Required Supply Voltage	+10 V _{DC} ~ +30 V _{DC} (non-regulated)
Power Consumption	0.10 A @ 24 V _{DC} Max.

Power Requirements (for PET-7000 series only)	
IEEE 802.3af	Class 1
Required Supply Voltage	Powered by Power-Over-Ethernet (PoE) or external +12~ 48 V _{DC} (non-regulated)
LED Indicator	Yes
Power consumption	0.08 A @ 24 V _{DC} Max


1.3.2. I/O Specification

1.3.2.1. PET-7005/ET-7005




Analog Input	
Input Channels	8 (Differential)
Input Type	Precon ST-A3, Fenwell U, YSI L100, YSI L300, YSI L1000, YSI B2252, YSI B3000, YSI B5000, YSI B6000, YSI B10000, YSI H10000, YSI H30000, User-defined
Resolution	16-bit
Sampling Rate	8 Samples/second (Total)
Accuracy	+/- 0.01 % or better
Zero drift	+/- 10 μ V/°C
Span drift	+/- 25 ppm/°C
Overvoltage Protection	110 V _{DC} /V _{AC}
Common Mode Rejection	86 dB
Normal Mode Rejection	100 dB
Open Wire Detection	Yes
3-wire RTD lead resistance elimination	Yes
ESD Protection	4 kV Contact for each terminal, and 8 kV Air for random point
EFT Protection	4 kV for Power

1.3.2.2. PET-7015/ET-7015



Analog Input	
Input Channels	7 (Differential)
Input Type	RTD
Wire Connection	2/3 wire
RTD Type	Pt100, Pt1000, Ni120, Cu100, Cu1000
Resolution	16-bit
Sampling Rate	12 Samples/second (Total)
Accuracy	+/- 0.05 %
-3dB Bandwidth	15.7 Hz
Zero drift	+/- 0.5 μ V/°C
Span drift	+/- 20 μ V/°C
Voltage Input Impedance	> 1 M Ohm
Common Mode Rejection	150 dB
Normal Mode Rejection	100 dB
Open Wire Detection	Yes
Individual Channel Configurable	Yes
3-wire RTD lead resistance elimination	Yes
ESD Protection	4 kV Contact for each terminal, and 8 kV Air for random point
EFT Protection	4 kV for Power


1.3.2.3. PET-7017/ET-7017



Analog Input	
Input Channels	8 (Differential)
Input Type	+/- 150 mV, +/- 500 mV, +/- 1 V, +/- 5V, +/- 10 V, +/- 20 mA, 0 ~ 20 mA, 4 ~ 20 mA (jumper selectable)
Resolution	16-bit (Normal Mode) /12-bit (Fast Mode)
Sampling Rate	10 Samples/second (Normal Mode) / 60 Samples/ second (Fast Mode) total
Accuracy	+/- 0.1 % (Normal Mode)/ +/- 0.5 % (Fast Mode) or better
Bandwidth	15.7 Hz (Normal Mode) /78.7 Hz (Fast Mode)
Zero drift	+/- 10 μ V/ $^{\circ}$ C
Span drift	+/- 25 μ V/ $^{\circ}$ C
Input Impedance	Voltage: 2 M Ohm Current: 125 Ohm
Common Mode Rejection	86 dB min
Normal Mode Rejection	100 dB
Individual Channel Configuration	Yes
Over Voltage Protection	240 Vrms
ESD Protection	4 kV Contact for each terminal, and 8 kV Air for random point
EFT Protection	4 kV for Power

Digital Output	
Output Channels	4 (Sink)
Output Type	Isolated Open Collector
Max Load Current	700 mA/channel
Load Voltage	5 ~ 50 V _{DC}


1.3.2.4. PET-7017-10/ET-7017-10



Analog Input	
Input Channels	10 differential or 20 single-ended (Note 1), software selectable
Input Type	+/- 150 mV, +/- 500 mV, +/- 1 V, +/- 5 V, +/- 10 V, +/- 20 mA, 0 ~ 20 mA, 4 ~ 20 mA (jumper selectable)
Resolution	16-bit (Normal Mode) /12-bit (Fast Mode)
Sampling Rate	10 Samples/second (Normal Mode) / 60 Samples/ second (Fast Mode) total
Accuracy	+/- 0.1 % (Normal Mode)/ +/- 0.5 % (Fast Mode) or better
Bandwidth	15.7 Hz (Normal Mode) /78.7 Hz (Fast Mode)
Zero drift	+/- 20 μ V/ $^{\circ}$ C
Span drift	+/- 25 μ V/ $^{\circ}$ C
Input Impedance	Voltage: 2 M Ohm (Differential), 1 M Ohm (Single-ended) Current: 125 Ohm
Common Mode Rejection	86 dB min.
Normal Mode Rejection	100 dB
Individual Channel Configuration	Yes
Over Voltage Protection	Differential: 240 Vrms, Single-ended: 150 Vrms
ESD Protection	4 kV Contact for each terminal, and 8 kV Air for random point
EFT Protection	4 kV for Power

Note 1: Differential mode can be used for voltage input and current input. Single-Ended mode can be used for voltage input only.

1.3.2.5. PET-7018Z/ET-7018Z




Analog Input	
Input Channels	10 (Differential)
Input Type	+/- 15 mV, +/- 50 mV, +/- 100 mV, +/- 500 mV, +/- 1 V, +/- 2.5 V, +/- 20 mA, 0 ~ 20 mA, 4 ~ 20 mA (Requires Optional External 125 Ohm Resistor) Thermocouple (J, K, T, E, R, S, B, N, C, L, M, LDIN43710)
Resolution	16-bit
Sampling Rate	10 Samples/second total
Accuracy	+/- 0.1 % or better
-3dB Bandwidth	15.7 Hz
Zero drift	+/- 0.5 μ V/°C
Span drift	+/- 25 ppm/°C
Input Impedance	> 300 K Ohm
Common Mode Rejection	150 dB min
Normal Mode Rejection	100 dB
Open Wire Detection	Yes
Individual Channel Configurable	Yes
Over Voltage Protection	240 Vrms
ESD Protection	4 kV Contact for each terminal, and 8 kV Air for random point
EFT Protection	4 kV for Power

Digital Output	
Output Channels	6 (Sink)
Output Type	Isolated Open Collector
Max Load Current	700 mA/channel
Load Voltage	5 ~ 50 V _{DC}

DB-1820	
Wire Strip Length	4 ~ 5 mm
Wire Range	16 ~ 24 AWG

1.3.2.6. PET-7019/ET-7019



Analog Input	
Input Channels	8 (Differential)
Input Type	+/- 15 mV, +/- 50 mV, +/- 100 mV, +/- 500 mV, +/- 1 V, +/- 5 V, +/- 10V, +/- 20 mA, 0 ~ 20 mA, 4 ~ 20 mA (Jumper selectable) Thermocouple (J, K, T, E, R, S, B, N, C, L, M, LDIN43710)
Resolution	16-bit
Sampling Rate	10 Samples/second total
Accuracy	+/- 0.1 % or better
-3dB Bandwidth	15.7 Hz
Zero drift	+/- 10 μ V/°C
Span drift	+/- 25 ppm/°C
Input Impedance	Voltage: > 1 M Ohm, Current: 125 Ohm
Common Mode Rejection	86 dB min
Normal Mode Rejection	100 dB
Open Wire Detection	Yes
Individual Channel Configurable	Yes
Over Voltage Protection	240 Vrms
ESD Protection	4 kV Contact for each terminal, and 8 kV Air for random point
EFT Protection	4 kV for Power


Digital Output	
Output Channels	4 (Sink)
Output Type	Isolated Open Collector
Max Load Current	700 mA/channel
Load Voltage	5 ~ 50 V _{DC}

1.4. Overview

Here is a brief overview of the components and its descriptions for module status.

1.4.1. Front Panel

The PET-7000/ET-7000 front panel contains the Ethernet port, connectors and LEDs.



➤ J1 Connector

Depending on the types of the PET-7000/ET-7000 modules.

For more detailed information regarding the pin assignments of the J1 Connector, please refer to “1.3.2. I/O Specification”

➤ J2 Connector


Depending on the types of the PET-7000/ET-7000 modules.

For more detailed information regarding the pin assignments of the J2 Connector, please refer to “1.3.2. I/O Specification”

Tips & Warnings



The definition of pin 8 and pin 9 applies to all types of the PET-7000/ET-7000 modules. The definition of the other pins is dependent on the particular PET-7000/ET-7000 modules.



Pin number	Name	Function
8	+VS	10 ~ 30 VDC power input
9	GND	Ground connection

➤ LED Indicators

Name	LED Action	Function
Run	Flashing	Firmware is running
Link/ACT	ON	Ethernet link detected
	OFF	No Ethernet link detected
	Flashing Green	Ethernet packet received
10/100M	OFF	Speed 10 Mbps
	Orange	Speed 100 Mbps

Tips & Warnings



If the Run LED does not display the information as above, the following steps should be taken:

Step 1: Switch the power off

Step 2: Check that the Init/Normal switch is in the Normal position
(Refer to “1.4.2. Back Panel”)

Step 3: Switch the power on and double-check the LED indicators

➤ Poe LED Indicator


When unit power is supplied via PoE (Power-over-Ethernet), the PoE indicator will be on.

➤ Ethernet Port

An Ethernet port is an opening on PET-7000/ET-7000 network equipment that Ethernet cables plug into. Ethernet ports accept cables with RJ-45 connectors.

1.4.2. Back Panel

The PET-7000/ET-7000 back panel contains the frame ground and operating mode selector switch.



➤ Operating Mode Selector Switch

Init mode: MiniOS7 configuration mode

Normal mode: Firmware running mode

In the PET-7000/ET-7000 series, the Switch is always in the Normal position. Only when updating the PET-7000/ET-7000 firmware or OS, the switch can be moved from the Normal position to the Init position.

Move the Switch to the Normal position after the update is complete.


➤ Frame Ground

Electronic circuits are constantly vulnerable to Electro-Static Discharge (ESD), which become worse in a continental climate area. PET-7000/ET-7000 series modules feature a new design for the frame ground, which provides a path for bypassing ESD, allowing enhanced static protection (ESD) capability and ensures that the module is more reliable.

The following options will provide a better protection for the module:


The PET-7000/ET-7000 controller has a metallic board attached to the back of the plastic basket as shown in the figure below, point 1.

When mounted to the DIN rail, connect the DIN rail to the earth ground because the DIN rail is in contact with the upper frame ground as shown in the figure below, point 2.




1.5. Dimensions

All dimensions are in millimeters.



1.6. Companion CD

This package comes with a CD that provides drivers, software utility, all of the required documentations..., etc. All of them are listed below.



Chapter 2. Getting Started



If you are a new user, begin with this chapter, it includes a guided tour that provides a basic overview of installing, configuring and using the ET-7000/PET-7000.

2.1. Mounting the Hardware

The ET-7000/PET-7000 can be mounted with the bottom of the chassis on the DIN rail, the wall or piggyback.


► DIN Rail mounting

The ET-7000/PET-7000 has simple rail clips for mounting reliably on a standard 35 mm DIN rail.



Din Rail Mountable Model


Three Din rail mountable models are available to mount a variety of ICP DAS devices. Each is made of stainless steel and has a ground wire at the end.



Part number	Maximum number of modules	Dimensions
DRS-125	2	125 mm x 35 mm
DRS-240	3	240 mm x 35 mm
DRS-360	5	360 mm x 35 mm

► Piggyback Mounting

The ET-7000/PET-7000 has two holes on both sides for piggyback mounting




2.2. Configuring the Boot Mode

The ET-7000/PET-7000 has two operating modes that can be determined by the switch mechanism on the chassis.


► Init Mode

Init mode is a way to use MiniOS7 configuration mode.



► Normal Mode


Normal mode is the default mode of operation and the one you will use most of the time. Use this mode for more tasks and configurations. Programs also are executed in this mode.



Init mode is a method to use MiniOS7 configuration mode and update the program. After the update is completed, move the switch to the Normal position.

2.3. Connecting to Network, PC and Power


The ET-7000/PET-7000 is equipped with an RJ-45 Ethernet port for connection to an Ethernet hub/switch and PC



2.4. Installing the MiniOS7 Utility

The MiniOS7 Utility is a useful tool that provides a quick and easy way to update OS image or firmware, configure Ethernet settings, and download files to ET-7000/PET-7000 from PC.


Step 1: Get the MiniOS7 Utility tool



The MiniOS7 Utility can be obtained from companion CD or our FTP site:
CD:\Napdos\minios7\utility\minios7_utility\
ftp://ftp.icpdas.com/pub/cd/8000cd/napdos/minios7/utility/minios7_utility/

Step 2: Follow the prompts to complete the installation

After the installation has been completed, there will be a new short-cut for MiniOS7 Utility on the desktop.



2.5. Using MiniOS7 Utility to Assign a New IP

The ET-7000/PET-7000 are web-based devices, which comes with a default IP address, therefore, you must first assign a new IP address to the ET-7000/PET-7000.


The factory default IP settings are as follows:

Item	Default
IP Address	192.168.255.1
Subnet Mask	255.255.0.0
Gateway	192.168.0.1

Step 1: Run the MiniOS7 Utility




Double-click the MiniOS7 Utility shortcut on your desktop.




Step 2: Press “F12” or choose “Search” from the “Connection” menu

After pressing F12 or choosing Search from Connection menu, that will search all of the MiniOS7 modules on your network.



Step 3: Choose the field “192.168.255.1” and then choose “IP setting” from the toolbar

Choose default value “192.168.255.1” for fields in the list, and then choose IP setting from the toolbar.




Step 4: Assign a new IP address and then choose “Set” button



You can manually assign an IP address or use DHCP to dynamically assign IP addresses


Step 5: Choose “Yes” button

After completing the settings, the Confirm dialog box will appear, and then choose the Yes button to exit the procedure.



Step 6: Reboot the module and then press “F12” or choose “Search” from the “Connection” menu to check the IP setting

After completing the settings, you can reboot the module and then using MiniOS7 to search module again for making sure that your IP settings are correct.



2.6. Enabling Adobe Flash Player in Browser

Your browser must support the Adobe Flash Player in order to view the ET-7000/PET-7000 web site.

If you do not have it installed, please follow the instructions below.

Step 1: Go to the Adobe Flash Player Download Center




The Adobe Flash Player Download Center:

<http://get.adobe.com/flashplayer/>

Step 2: Follow the prompts to download the installation file


Click the Agree and install now button and follow the instructions to download the installation file

A screenshot of the Adobe Flash Player download page. The page features the Adobe Flash logo on the left. The main content area is titled 'Install Adobe Flash Player' and lists the version as 10.0.32.18, compatible with Windows and Internet Explorer. It shows a download size of 1.87 MB. Below this, there are links for 'Learn more', 'System requirements', 'Distribute Flash Player', and 'Installation instructions'. A section titled 'Also install:' shows a checkbox for 'Free Google Toolbar (optional)' with a download size of 1.8 MB. Below this is a screenshot of the Google Toolbar. At the bottom, there is a yellow button with a downward arrow and the text 'Agree and install now', which is circled in green. To the right of the button, the total download size is listed as 3.67 MB. At the very bottom, there is a disclaimer about the Software License Agreement and the Google Toolbar Terms of Service.

Step 3: Verify that the Adobe Flash Player has been installed

You can verify that it has been installed correctly by clicking the link below.

<http://get.adobe.com/flashplayer/completion/dlm/>



Chapter 3. Web Applications

The ET-7000/PET-7000 contains an advanced web configuration system that provides users with access ET-7000/PET-7000 applications through a standard web browser.

Logging in to the ET-7000/PET-7000 Web site

You can log in to the ET-7000/PET-7000 web site from any computer that has Internet access.

Step 1: Open a browser

In several browsers, Mozilla Firefox and Internet Explorer are both reliable and popular internet browsers.

Step 2: Type the URL address of the ET-7000/PET-7000


If you haven't changed the default IP address of the ET-7000/PET-7000, please refer section "2.5. Using MiniOS7 Utility to Assign a New IP" to configure it.

Step 3: Fill out the User name and Password

After entering the IP address, the login dialog box will appear and prompt you to enter your username and password.


The factory default user name and password are as follows:

Item	Default
User name	Admin
Password	Admin



Step 4: Welcome to ET-7000/PET-7000 web site

After logging into the ET-7000/PET-7000 web site, the welcome page will appear.




This site serves several functions. You can easily access these functions through the menu on the left side.

The Overview of the Main menu provides a brief introduction and explanation of this site.

3.1. Overview

The Overview links to the welcome page that determines two message body parts.



The first part of this page provides basic information about the ET-7000/PET-7000 hardware and software.

Welcome to the ET7000 Web configuration page	
Model Name	ET-7067
MAC Address	0:d:e0:64:0:65
Module Information	Anna
Firmware Version	V110 (Jul 31 2008)
OS Version	V229 (May 12 2009)
DI channels	0
DO channels	8
AI channels	0
AO channels	0

The second part of this page provides a brief introduction of this web site.

General Description

The ET-7000 series is a selection of cost effective, high performance 10/100 Mbps I/O modules designed for remote data collection and remote Ethernet application control. Each ET-7000 module includes its own internal Ethernet configuration, Modbus TCP/IP port and web port, with a built-in simple HMI that makes configuration and access easy, together with an I/O LED display to indicate the current transmission status.

The ET-7000 supports Modbus/TCP without the need for any extra programming. It can be easily connected to most SCADA software such as Indusoft, iFix and Labview. The ET-7000 also supports Web server access allowing the user to monitor and access the remote I/O from a Web browser. Users can also download their own custom defined pages into the ET-7000 via our Windows Utility. ICP DAS also provides a Java script page for the ET-7000 as a reference allowing design their own Web interface.

Configuration

1. [Network Settings](#)

IP address, Net mask, default gateway, DHCP, Static or Dynamic IP, Firmware and OS version information...

1. [Basic Settings](#)


Module name, Module information, Real Time Clock, Time Server IP address, Web HMI and Telnet console Enable, Disable functions. Load the factory default settings

1. [Module I/O Settings](#)

DI channels, DO channels, AI channels, AO channels, Analog input range, Analog output range, Analog input resolution, Analog output resolution, Analog input filter, Analog output filter, Analog input impedance, Analog output impedance, Analog input voltage, Analog output voltage, Analog input current, Analog output current, Analog input accuracy, Analog output accuracy, Analog input range, Analog output range, Analog input resolution, Analog output resolution, Analog input filter, Analog output filter, Analog input impedance, Analog output impedance, Analog input voltage, Analog output voltage, Analog input current, Analog output current, Analog input accuracy, Analog output accuracy

3.2. Configuration

All items below are located under the **Configuration** menu:



Network Settings: Links to the Ethernet Settings page that allows you to access the IP settings and check the software version.

Basic Settings: Links to the Basic Settings page that allows you to configure the basic information of this site.

Module I/O Settings: Links to the Common Functions page that allows you to configure the settings of the Modbus

3.2.1. Network Settings

The Ethernet Settings page provides the following functions:

Items	Current Value	New Value
IP	10.1.0.67	10.1.0.67
Gateway	10.1.0.254	10.1.0.254
Mask	255.255.0.0	255.255.0.0
DHCP	☐ Enable ☒ Disable	
Web Server Lib Ver.	Version 112 (Jun 03 2008)	
MiniOS7 Ver.	Version 2.02.9	
MODIFY_SETTING		

Please access the new IP Address after modifying the configuration

- Configure the network settings
- Check the software information

3.2.1.1. Configure the Network Settings

A generally network setting includes the following parameters:

- **IP address**: Each device including PET-7000/ET-7000 on the network must have a unique IP address. It is used to assign the unique IP address.
- **Gateway address**: The address of the gateway server on the network.
- **Subnet mask**: The subnet mask of the LAN that the PET-7000/ET-7000 connects to.

There are two ways to configure the network settings:

- **Dynamic configuration**: Dynamic Host Configuration Protocol (DHCP) is a network application protocol that automatically assigns IP address to devices.
- **Manually configuration**: If you don't have a DHCP server in your network, you can configure network settings manually.

Dynamic Configuration

Items	Current Value	New Value
IP	10.1.0.67	10.1.0.67
Gateway	10.1.0.254	10.1.0.254
Mask	255.0.0.0	255.255.0.0
DHCP	☒ Enable ☐ Disable	
Web Server Lib Ver.	Version 1.12 (Jun 03 2008)	
MiniOS7 Ver.	Version 2.02.9	
MODIFY_SETTING		

Dynamic configuration is very easy to configure. If you have a DHCP server, network address can be configured dynamically by following steps:

Step 1: Enable the **DHCP**

Step 2: Click **MODIFY_SETTING** to save the network settings

Manually Configuration

In manual configuration, you have to assign all the network settings manually. To configure network settings manually, follow the following steps:

Ethernet Settings

Items	Current Value	New Value
IP	10.1.0.46	10.1.0.46
Gateway	10.1.0.254	10.1.0.254
Mask	255.255.0.0	255.255.0.0
DHCP	☐ Enable ☒ Disable	
Web Server Lib Ver.	Version 113 (Mar 26 2009)	
MiniOS7 Ver.	Version 2.02.9	
MODIFY_SETTING		

Step 1: Disable the **DHCP**

Step 2: Enter the **network settings**

Step 3: Click **MODIFY_SETTING** to save the network settings

3.2.1.2. Check the software information

The software information includes the following data items:

- **Web Server Lib Ver.**: The version of the web server library. The web server library is a collection of web development solutions.
- **MiniOS7 Ver.**: The version of the MiniOS7 OS image. The MiniOS7 is an embedded OS designed for ICP DAS controller.

After updating the PET-7000/ET-7000 firmware, you can check the version of the PET-7000/ET-7000 software information.

Items	Current Value	New Value
IP	10.1.0.46	10.1.0.46
Gateway	10.1.0.254	10.1.0.254
Mask	255.255.0.0	255.255.0.0
DHCP	☐ Enable ☒ Disable	
Web Server Lib Ver.	Version 113 (Mar 26 2009)	
MiniOS7 Ver.	Version 2.02.9	

MODIFY_SETTING

3.2.2. Basic Settings

The Basic Settings page provides the following functions:

Basic Settings

Module Name	ET-7026
Module Information	(Maximum 16 characters) (The content cannot include "/" or "*" character)
Top page Information (First line)	ICP DAS (Maximum 20 characters) Color: Red Font: 0
Top page Information (Second line)	http://www.icpdas.com (Maximum 50 characters) Color: Red Font: 0
More Information URL	http://www.icpdas.com/products/Remote_IO/et-7000/et (Maximum 100 characters)
Web Server TCP Port	80

Submit

Load All Setup Defaults

- ☐ Configuration
- ☐ Authentication
- ☐ Web HMI
- ☐ Pair Connection
- ☐ All

Submit

- Configure the module information
- Configure the web site information
- Reset all settings to default

3.2.2.1. Configure the Module Information

The module information includes the following data items:

- **Module Name**: The name of the module that can be modified. It has an initial value depending on the name of the module.
- **Module Information**: The module information indicates the name of the alias that is used to identify the module.

To configure the module information, follow the following steps:

Basic Settings	
Module Name	ET-7026
Module Information	(Maximum 16 characters) (The content cannot include ' or " character)
Top page Information (First line)	ICP DAS (Maximum 20 characters) Color: Red Font: 0
Top page Information (Second line)	http://www.icpdas.com (Maximum 50 characters) Color: Red Font: 0
More Information URL	http://www.yahoo.com.tw (Maximum 100 characters)
Web Server TCP Port	80
2 Submit	


Step 1: Enter the **module information**

Step 2: Click **Submit** to save the module information


3.2.2.2. Configure the Web site Information

The module information includes the following data items:

- 
Top page Information (First line) and **Top page Information (Second line)**: The title of the website that can be modified, you can view the title information in the top-left corner. The title information can be determined as follows:



- **More Information URL**: The URL that the more information item in left menu links can be modified by inputting the URL in the textbox to More Information URL on Basic Settings page, you can specify the PET-7000/ET-7000 URL for getting additional PET-7000/ET-7000 supports.



- **Web Server TCP Port:** A port number of the TCP/IP port. A port number is a 16-bit unsigned integer. By default, TCP/IP uses port 80.

To configure the web site information, follow the following steps:

Basic Settings


Module Name	ET-7026
Module Information	(Maximum 16 characters) (The content must include "ICP DAS")
Top page Information (First line)	ICP DAS (Maximum 20 characters) Color: Red v Font: 0
Top page Information (Second line)	http://www.icpdas.com (Maximum 50 characters) Color: Red v Font: 0
More Information URL	http://www.yahoo.com.tw (Maximum 100 characters)
Web Server TCP Port	80
Submit	

Step 1: Enter the **web site information**

Step 2: Click **Submit** to save the module information

3.2.2.3. Reset All Settings to Default


According to the menu selection of this web, the reset function can be divided into the following categories. You can use this function to reset the settings to their factory default.



The screenshot shows a web form titled "Load All Setup Defaults". It contains five rows, each with a checkbox and a label: "Configuration", "Authentication", "Web HMI", "Pair Connection", and "All". Below these rows is a "Submit" button.

- Configuration
- Authentication
- Web HMI
- Pair Connection
- All

To reset the settings to their factory default, follow the following steps:



The screenshot shows the same web form as before, but with two green circles and numbers indicating steps. Circle 1 is around the checkboxes, and circle 2 is around the "Submit" button.

Step 1: Enable the **reset selection**

Step 2: Click **Submit** to reset the settings to their factory default

3.2.2.3.1. Factory Default Settings for Configuration Menu Service

The table below lists the factory default settings of the configuration menu.

Network Settings

Data Item	Factory Default Settings
IP	192.168.255.1
Gateway	192.168.0.1
Mask	255.255.0.0
DHCP	Disable

Basic Settings

Data Item	Factory Default Settings
Module Name	Depending on the module name
Module Information	Empty
Top page Information (First line)	Empty
Top page Information (Second line)	Empty
More Information URL	Empty
Web Server TCP Port	80
Configuration	Disable
Authentication	Disable
Web HMI	Disable
Pair	Disable
All	Disable

Module I/O Settings

- **PET-7017/ET-7017 and the ET-7017-10**

Modbus Settings (Common Functions)	
CPU reset events	0
Set Host Watchdog Timer	0
CPU reset status	2
CPU reset events	1
Set Host Watchdog Timer	0
Host WDT events	0
Modbus Address	
Modbus NetID	1
Digital Output	
Power Value	OFF
Safe Value	OFF
Modbus Settings (AI Basic Setting)	
Analog Input Range	Type 60, PreCon Type III, -30°F to 240 °F
Enable	ON
AI Data Format	Hex unit format
Temperature Scale	Celsius
Modbus Settings (AI High/Low Alarm Setting)	
AI High Alarm Value	240 °F (-34.444 °C)
AI High Alarm Enable	OFF
AI High Alarm Mode	0 – Moment
AI Low Alarm Value	- 30 °F (115.555 °C)
AI Low Alarm Enable	OFF
AI Low Alarm Mode	0 – Moment
Modbus Settings Average Value of Analog Inputs	
Enable/Disable the Average value of the previous AI Channel of the one Channel	OFF
Enable/Disable the Average Value of All Enabled AI Channels	OFF
Average Times for Each Channel	10
High Alarm Value for Average	0

Value of All AI Channels	
Low Alarm Value for Average Value of All AI Channels	0

- **PET-7015/ET-7015**

Modbus Address	
Modbus NetID	1
Modbus Settings (AI Basic Setting)	
Analog Input Range	20, +/- 100 °C, Pt 100, $\alpha=0.00385$
Enable	ON
50/60 Hz rejection for AI	OFF (60 Hz rejection)
AI Data Format	OFF (Hex)
AI temperature offset	0
AI resistance offset	0

- **PET-7017/ET-7017 and the ET-7017-10**

Modbus Address	
Modbus NetID	1
Digital Output	
Power Value	OFF
Safe Value	OFF
Modbus Settings (AI Basic Setting)	
Analog Input Range	08 (+/- 10 V)
Enable	ON
50/60 Hz rejection for AI	OFF (60 Hz rejection)
AI Data Format	OFF (Hex)
Input Mode	Normal
Modbus Settings (AI High/Low Alarm Setting)	
AI High Alarm Value	+ 10 V
AI High Alarm Enable	OFF
AI High Alarm Mode	0 – Moment
AI Low Alarm Value	- 10 V
AI Low Alarm Enable	OFF
AI Low Alarm Mode	0 – Moment
Modbus Settings Average Value of Analog Inputs	
Enable/Disable the Average value of the previous AI Channel of the one Channel	OFF
Enable/Disable the Average Value of All Enabled AI Channels	OFF
Average Times for Each Channel	10
High Alarm Value for Average Value of All AI Channels	0
Low Alarm Value for Average Value of All AI Channels	0

• PET-7018Z/ET-7018Z

Modbus Address	
Modbus NetID	1
Digital Output	
Power Value	OFF
Safe Value	OFF
Modbus Settings (AI Basic Setting)	
Analog Input Range	05 (+/- 2.5 V)
Enable	ON
50/60 Hz rejection for AI	OFF (60 Hz rejection)
AI Data Format	OFF (Hex)
CJC	
CJC	ON
CJC Total Offset	0
CJC Update Setting	Start
CJC Offset	0
Modbus Settings (AI High/Low Alarm Setting)	
AI High Alarm Value	+ 2.5 V
AI High Alarm Enable	OFF
AI High Alarm Mode	0 – Moment
AI Low Alarm Value	- 2.5 V
AI Low Alarm Enable	OFF
AI Low Alarm Mode	0 – Moment
Modbus Settings Average Value of Analog Inputs	
Enable/Disable the Average value of the previous AI Channel of the one Channel	OFF
Enable/Disable the Average Value of All Enabled AI Channels	OFF
Average Times for Each Channel	10
High Alarm Value for Average Value of All AI Channels	0
Low Alarm Value for Average Value of All AI Channels	0

- ET-7019/PET-7019

Modbus Address	
Modbus NetID	1
Digital Output	
Power Value	OFF
Safe Value	OFF
Modbus Settings (AI Basic Setting)	
Analog Input Range	05 (+/- 2.5 V)
Enable	ON
50/60 Hz rejection for AI	OFF (60 Hz rejection)
AI Data Format	OFF (Hex)
CJC	
CJC	ON
CJC Total Offset	0
CJC Update Setting	Start
CJC Offset	0
Modbus Settings (AI High/Low Alarm Setting)	
AI High Alarm Value	+ 2.5 V
AI High Alarm Enable	OFF
AI High Alarm Mode	0 – Moment
AI Low Alarm Value	- 2.5 V
AI Low Alarm Enable	OFF
AI Low Alarm Mode	0 – Moment
Modbus Settings Average Value of Analog Inputs	
Enable/Disable the Average value of the previous AI Channel of the one Channel	OFF
Enable/Disable the Average Value of All Enabled AI Channels	OFF
Average Times for Each Channel	10
High Alarm Value for Average Value of All AI Channels	0
Low Alarm Value for Average Value of All AI Channels	0

3.2.2.3.2. Factory Default Settings for Authentication Menu Service

Account Management

Factory Default Setting
A default user account consists of a account name “Admin” and a password “Admin”.

Accessible IP Settings

Factory Default Setting
Empty, there is no IP limit on incoming terminals.

3.2.2.3.3. Factory Default Settings for Web HMI Menu Service

Web HMI

Factory Default Setting
Depending on the Modbus setting function of the PET-7000/ET-7000.

Web Editing

Factory Default Setting
0 Page

3.2.2.3.4. Factory Default Settings for Pair Connection Menu Service

Pair Connection

Factory Default Setting
Empty

3.2.3. Module I/O Settings

Module I/O settings page includes Common Functions settings and particular I/O settings such as Power-on, safe value, enable/disable I/O channels. On the page the Modbus address mapping of each function is also listed for easy checking and using.

The illustration below shows the Modbus settings for the ET-7019 module

Common Functions

Common Functions

Modbus Address	Function	Action
00226	Recover all I/O default settings	☐ 1=Clear
00233	Reboot ET-7000	☐ 1=Reboot
40555	CPU reset status	3 1= power on/2= 0.8 second WDT/3= Reset command
40556	CPU reset events	18 reset count
40557	Set Host Watchdog Timer	0 5:Disable 5~65535:Enable (unit:second) (default=0)
40558	Host WDT events	0 WDT count

Modbus Definition


Modbus Address	Function	Action
40271	Modbus NetID	1 1 ~ 255 (default=1)

This page display different contents depending on the Modbus function of the ET-7000/PET-7000 module.

For a more detailed description of these Modbus function, please refer to section “4.3. Modbus Register Map”.

3.3. Authentication

All items below are located under the **Authentication** menu:



Account Management: Links to the Privilege management page that allows you to manage the user accounts and their privileges.

Accessible IP Settings: Links to the IP filter Settings page that allow you to control access privileges by filtering IP address.

3.3.1. Account Management

The Basic Settings page provides the following functions:

The screenshot displays the 'Privilege management' interface. It features a table with columns for 'No.', 'Account', 'Password', 'Verify', 'Authority', and 'Enable'. The first row shows an 'Admin' account with passwords masked by dots and an 'On' status. Rows 2 through 5 are empty for new account creation, each with a default 'Admin' authority and an 'Off' status. Below the table is a 'Submit' button. At the bottom, there are labels for 'Account' and 'Password' (both with an 8-character limit), a checkbox for 'Load Setup Default', and another 'Submit' button.

No.	Account	Password	Verify	Authority	Enable
1	Admin			Admin	On
2				Admin ▼	☐
3				Admin ▼	☐
4				Admin ▼	☐
5				Admin ▼	☐

Account: (Maximum 8 characters)
Password: (Maximum 8 characters)

☐ Load Setup Default

- Configure the user accounts
- Load the factory default user account

3.3.1.1. Configure the user accounts

The PET-7000/ET-7000 web site supports up to 5 user accounts.

- A built-in administrator account

The built-in Administrator is basically a setup and disaster recovery account that can be deleted. You can change the administrator account's password.

- Four user-defined account

Each user account consists of

- An **account** name: Specifies the name of This can be your name or another alias
- A **password**: The system will ask you to type this in twice to ensure it is correct.
- The **authority**: that determines what operations the user is allowed to perform.

The authority has the following roles to determine what operations the user is allowed to perform.

- **Admin**: Enables access to all PET-7000/ET-7000 website features, functions, and commands.
- **User**: Enables limited access to PET-7000/ET-7000 website features, functions, and commands. In general, operators cannot change configuration settings.

When you create user accounts, you can **Enable** or **Disable** user accounts.

No.	Account	Password	Verify	Authority	Enable
1	Admin	****	****	Admin	On
2	ET7000	****	****	User	☒
3	ICPDAS	***	***	Admin	☒
4				Admin	☐
5				Admin	☐

Submit

Account: (Maximum 8 characters)
Password: (Maximum 8 characters)

Step 1: Enter the **user account information**, and then select the **enable** checkbox

Step 2: Click **Submit** to finished configuring the user accounts

3.3.1.2. Load the factory default user accounts

The PET-7000/ET-7000 has a built-in administrator account named **Admin** which is created when it is installed by default. The default account cannot be deleted.

The screenshot shows a web interface titled "Privilege management". It contains a table with the following columns: No., Account, Password, Verify, Authority, and Enable. The first row shows the "Admin" account with a password of four asterisks, verified with four asterisks, authority of "Admin", and is enabled. Below the table is a "Submit" button. At the bottom, there are two input fields labeled "Account:" and "Password:" with a note "(maximum 8 characters)". Below these fields is a checkbox labeled "Load Setup Default" and a "Submit" button. A green circle with the number "1" highlights the "Load Setup Default" checkbox, and another green circle with the number "2" highlights the "Submit" button at the bottom.

No.	Account	Password	Verify	Authority	Enable
1	Admin	****	****	Admin	On
2				Admin	☐
3				Admin	☐
4				Admin	☐
5				Admin	☐

Submit

Account: (maximum 8 characters)
Password: (maximum 8 characters)

☐ Load Setup Default


Submit

Step 1: Select the **Load Setup Default** checkbox

Step 2: Click **Submit** to finished configuring the user accounts

3.3.2. Accessible IP Settings

The IP filter Settings page provides the following functions:



IP filter Settings

☐ Enable the IP filter table. ("Disable" will allow connection requests from all IPs.)

IP address at the browser PC: 10.1.0.37

No.	Active the rule	From (IP Address)	To (IP Address)
1	☐		
2	☐		
3	☐		
4	☐		
5	☐		
6	☐		

Submit

- Configure connection filtering

3.3.2.1. Configuring IP filter

The PET-7000/ET-7000 with an IP filter that enables you to restrict or grant user access based on an IP filter list you create.

The filter can be enabled or disabled by selecting the **Enable the IP filter table** checkbox

☐ Enable the IP filter table. ("Disable" will allow connection requests from all IPs.)

Tips & Warnings



By default, there is no limit to allow any outgoing access.

Each list entry can be active or inactive by clicking its Active the rule

No.	Active the rule	From (IP Address)	To (IP Address)
1	☒	10.1.0.1	10.1.8.9

Here we provide two basic methods for configuring the IP filter.

Method 1: Allows access from a single IP address

IP filter settings

☒ Enable the IP filter table. ("Disable" button)

IP address at the browser PC: 10.1.0.37

No.	Active the rule	From (IP Address)	To (IP Address)
1	☒	10.1.0.1	10.1.0.1
2	☐		
3	☐		
4	☐		
5	☐		
6	☐		

Submit

Step 1: Select the Enable the IP filter table checkbox

Step 2: Enter the same IP address in the From (IP Address) and To (IP Address)

Step 3: Select the Active the rule checkbox

Step 4: Click Submit to finished configuring the IP filter list

Method 2: Allow access from a group of IP addresses

IP filter settings

☒ Enable the IP filter table. ("Disable" button)

IP address at the browser PC: 10.1.0.37

No.	Active the rule	From (IP Address)	To (IP Address)
1	☒	10.1.0.1	10.1.8.9
2	☐		
3	☐		
4	☐		
5	☐		
6	☐		

Submit

Step 1: Select the Enable the IP filter table checkbox


Step 2: Enter a range of IP addresses in the From (IP Address) and To (IP Address)

Step 3: Select the Active the rule checkbox

Step 4: Click Submit to finished configuring the IP filter list

3.4. Web HMI

All items below are located under the **Web HMI** menu:




Web HMI: Links to the I/O monitor page that allows you to monitor the

Web Edit: Links to the Web Page Configuration page that allows you to

3.4.1. Web HMI


By default, this page displays summary information about I/O channels which are classified according to the module type.

Here you can add more tabs and set the starting tab by editing the web edit page, for more details, please refer to 3.4.2. Web Edit.



3.4.2. Web Edit

The Web Editing page provides functions to create the user-defined web pages which are displayed on the Web HMI page.



By default, there are no pages to be listed in the Web Page Configuration form.

The screenshot shows the 'Web Page Configuration' window. At the top, there is a dropdown menu set to 'MainPage' and a 'Go' button. Below this is a table with three columns: 'No', 'Page Description', and 'Function'. The table contains one entry with 'No' as an asterisk (*), 'Page Description' as 'Main Page', and the 'Function' column is empty. At the bottom of the window, there is a status bar that says '*: Start Page' and an 'Add new Page' button.

No	Page Description	Function
*	Main Page	

*: Start Page

Add new Page

The ET-7000/PET-7000 supports up to 10 user-defined web pages

The screenshot shows the 'Web Page Configuration' window with a table containing 10 user-defined pages. A green arrow points from the number '10' in the 'No' column to a green callout box. The table has columns for 'No', 'Page Description', and 'Function'. The 'Function' column is split into 'Edit' and 'Delete' links. The status bar at the bottom says '*: Start Page' and there is an 'Add new Page' button.

No	Page Description	Function	
*	Main Page		
1	floor 1	Edit	Delete
2	floor 2	Edit	Delete
3	floor 3	Edit	Delete
4	floor 4	Edit	Delete
5	floor 5	Edit	Delete
6	floor 6	Edit	Delete
7	floor 7	Edit	Delete
8	floor 8	Edit	Delete
9	floor 9	Edit	Delete
10	floor 10	Edit	Delete

*: Start Page


Add new Page

A maximum of 10 pages can be created.

Below is an example of how to create your own page.


Example:

Create a Web page to monitor the I/O of the conveyor system shown below. The I/O system contains a sensor that are used to detect the products, and a switch that are used to turn the conveyor motor on and off.




Step 1: Add a new page

Click **Add new Page**



Step 2: Upload a diagram

Click **Browse...** to select an image, and then click **Upload** to upload images to the ET-7000/PET-7000 module.




Tips & Warnings



The file type of images can be either of .jpg, .gif, or .bmp. The recommended resolution for the image to be displayed on the editing Web page is 340 * 250 pixels.

After the upload is completed, the image information will be displayed and the image will be added in the Image list box as below shown.



Step 3: Set the page name and select the diagram

Type the page name in the Page Name field and then select the diagram from the Image list box. (After selecting the diagram, the diagram will be shown in the Preview window)

Step 4: Add the register item for reading selected sensor input

Click Edit in the first row of the Group table and then the Edit Group Register window will be displayed.

Web Page Configuration

Picture: Browse... Upload Del All

Free space=51221 bytes

Page Name: Picture: Save ☐ Start page

Register	Alias	Scaling	Type	Data type	Edit	Clear
1					Edit	Clear
2					Edit	Clear
3					Edit	Clear
4					Edit	Clear
5					Edit	Clear
6					Edit	Clear
7					Edit	Clear
8					Edit	Clear
9					Edit	Clear
10					Edit	Clear

Edit Group Register

Modbus Register:

Alias:


Scaling: 0

Register Type: Read

Data type:

Save

Step 5: Add a DI for reading PHS1 input
Set PHS1 to be an input, you can using the **Modbus Register 1**, then select **Discrete Input** as the **Register Type** and type **PHS** as the **Alias**.



Step 6: Save selected sensor settings
Click **Save** button to complete set up

MainPage Go

Edit Group Register			
Modbus Register	1		
Alias	PHS1		
Scaling	Disabled	0	
Register Type	Discrete Input	Read	
Data type	Signed 16		
Save			

Step 7: Add the register item for writing selected motor output to turn/
After save the register settings, the new register item will be displayed in the Group table.
Click Edit in the second row of the Group table and then the Edit Group Register window will be displayed.


Group					
Register	Alias	Scaling	Type	Data type	
1	PHS1	0	Discrete Input	Boolean	Edit Clear
2					Edit Clear
3					Edit Clear
4					Edit Clear
5					Edit Clear
6					Edit Clear
7					Edit Clear
8					Edit Clear
9					Edit Clear
10					Edit Clear

MainPage Go

Edit Group Register			
Modbus Register	1		
Alias	Voltage1		
Scaling	Disabled	0	
Register Type	Discrete Input	Read	
Data type	Signed 16		
Save			

Click Edit to edit the register item

Step 8: Add a DO for writing Motor1 output to turn the conveyer motor on and off
Set Motor to be an output, you can using the **Modbus Register 1**, then select **Coil** as the **Register Type** and type **Motor** as the **Alias**.



Step 9: Save selected sensor settings
Click **Save** button to complete set up

MainPage Go

Edit Group Register

Modbus Register: 1

Alias: Motor1

Scaling: Disabled 0

Register Type: Coil Write


Data type: Signed 16

Save

Step 10: Save the editing page.
Click **Save** button to complete set up

MainPage Go

Web Page Configuration

Picture:  Browse... Upload Del All

The total spaces for saving picture only is 64KB, the picture must be less than 64k

ET6K.jpg : 04/06/2006 15:40:29, size=17427

conveyer.gif : 08/14/2126 17:46:32, size=14251

Free space=51221 bytes


Page Name: Conveyer Picture: conveyer.gif Save ☐ Set as Start Page

Group


Register	Alias	Scaling	Type	Data type	Edit	Clear
1	PHS1	0	Discrete Input	Boolean	Edit	Clear
2	PHS2	0	Discrete Input	Boolean	Edit	Clear
3					Edit	Clear
4					Edit	Clear
5					Edit	Clear
6					Edit	Clear
7					Edit	Clear
8					Edit	Clear
9					Edit	Clear
10					Edit	Clear

Step 11: Browse the Conveyor web page.

After saving the editing page, the editing page named as **Conveyer** has been added to the list box on the top-left hand side of the **Web Page Configuration** window. Then select the **Conveyer** item and click **Go** to browse to the **Conveyer** web page.




The conveyor image file and all register items will be displayed on the **Conveyer** web page.



3.5. Pair Connection

The Pair Connection links to the configuration page of the pair connection function.



This pair connection function is a particular feature of ET-7000/PET-7000 that can enable a pair of DI-to-DO via Modbus/TCP (Ethernet).

Modbus Settings

Modbus port	502		
☐ I/O Pair connection			
Remote IP Address		Remote TCP Port	0
Connection Timeout	0 ms	Reconnect Interval	0 ms
Remote Net ID	0	Scan Time	0 ms
Access Type	DO ☐		
Local DO Base Address	0	Remote DI Base Address	0
I/O Count	0	Communication Timeout	0 ms
Submit			

3.6. More Information


The More Information links to the ET-7000/PET-7000 web site that provides more detailed information related to ET-7000/PET-7000 series products.



You can change the URL of this link by simply editing the URL, for more details, please refer to section “3.2.2.2. Configure the Web site Information”


The default URL of the More Information item is:

http://www.icpdas.com/products/Remote_IO/et-7000/et-7000_introduction.htm



Chapter 4. Modbus Applications

The ET-7000/PET-7000 is a Modbus device that allows you to access terminals data via Ethernet and communicates using a master-slave technique in which only one device (the master) can initiate transactions (called queries). The other devices (slaves) respond by supplying the requested data to the master, or by taking the action requested in the query.



Most SCADA Supervisor Control And Data Acquisition and HMI software can easily integrate serial devices via the Modbus protocol, such as Citect, ICONICS, iFIX, InduSoft, Intouch, Entivity Studio, Entivity Live, Entivity VLC, Trace Mode, Wizcon, Wonderware, etc.

4.1. What is Modbus TCP/IP?

Modbus is a communication protocol developed by Modicon in 1979.

Different versions of Modbus used today include Modbus RTU (based on serial communication like RS485 and RS232), Modbus ASCII and Modbus TCP, which is the Modbus RTU protocol embedded into TCP packets.

Modbus TCP is an internet protocol. The protocol embeds a Modbus frame into a TCP frame so that a connection oriented approach is obtained thereby making it reliable. The master queries the slave and the slave responds with the reply. The protocol is open and hence highly scalable.

4.2. Modbus Message Structure

Modbus devices communicate using a master-slave (client-server) technique in which only one device (the master/client) can initiate transactions (called queries). The other devices (slaves/servers) respond by supplying the requested data to the master, or by taking the action requested in the query.

A master's query will consist of a slave address (or broadcast address), a function code defining the requested action, any required data, and an error checking field. A slave's response consists of fields confirming the action taken, any data to be returned, and an error checking field.

Address (1 byte)	Function Code (1 byte)	Data (0 to 252 bytes)	Checksum (2 bytes)
---------------------	---------------------------	--------------------------	-----------------------

Address specifies the address of the receiver.

Function Code specifies the message type.

Data is the data block.

Checksum specifies the numerical check value for testing the validity of the protocol.

4.2.1. Address

The first byte of information in the message structure of Modbus is the receiver's address. The valid addresses are in the range of 0 to 247. Addresses from 1 to 247 are given to individual Modbus devices and 0 is used for broadcast.

Reference	Description
0xxxx	<u>Read/Write Discrete Outputs or Coils.</u> A 0x reference address is used to device output data to a digital output channel.
1xxxx	<u>Read Discrete Inputs.</u> The ON/OFF status of a 1x reference address is controlled by the corresponding digital input channel.
3xxxx	<u>Read Input Registers.</u> A reference register contains a 16-bit number received from an external source --- e.g. an analog signal.
4xxxx	<u>Read/Write Output or Holding Registers.</u> A 4x register is used to store 16-bits of numerical data (binary or decimal), or to send the data from the CPU to an output channel.

4.2.2. Function Codes

The second byte in the frame structure is the function code. The function code describes what the slave is required to do. Valid function codes are between 1 and 255. The slave uses the same function code as the request to answer it. Only when error occurs in the system, the highest bit of the function code will be made '1'. Hence the master will know if the message has been transmitted correctly or not.

Code	Function	Reference
01 (01H)	Read Coils (Output) Status	0xxxx
02 (02H)	Read Input Status	1xxxx
03 (03H)	Read Holding Registers	4xxxx
04 (04H)	Read Input Registers	3xxxx
05 (05H)	Force Single Coil (Output)	0xxxx
06 (06H)	Preset Single Register	4xxxx
15 (0FH)	Force Multiple Coils (Outputs)	0xxxx
16 (10H)	Preset multiple Registers	4xxxx

4.2.3. Data Field

The data field consists of messages sent between master and slave. The messages contain additional information about the action to be taken by the slave or any information requested by the slave. When the slave does not require this information the data field can be nonexistent.

4.2.4. Error Check

The error check performed in Modbus/RTU is Cyclic Redundancy Check (CRC). Both the transmitting device and the receiver compute CRC. Two bytes are used for this purpose and generally one bit errors are detected by this method.

4.3. Modbus Register Map

4.3.1. Common Function

- (0xxxx) DO address

Begin address	Points	Description	Registers per Point	Range	Access Type
226	1	Recover all I/O default settings	1	1=recover	W (Pulse)
233	1	Reboot ET-7000/PET-7000	1	1=reboot	W (Pulse)

- (3xxxx) AI address


Begin address	Points	Description	Registers per Point	Range	Access Type
350	1	OS image version	1	123 (hex) means version=1.2.3	R
351	1	Total Firmware version	1	123 (hex) means version=1.2.3	R
358	1	Modbus communication status	1	0= No Error -1= CRC error -2= Timeout	R
360	1	Pair Connection	1	0=Normal 1=Timeout 2=Disconnected	R

• (4xxxx) AO address

Begin address	Points	Description	Registers per Point	Range	Access Type
555	1	CPU reset status	1	1= by power on 2= by 0.8 second WDT 3= by Reset command	R/W
556	1	CPU reset events	1	How many CPU reset events has happened? When CPU is reset by one of the situations described in register 555, the event increases one count.	R/W/E
557	1	Set host watch dog timer	1	<5: Disabled 5~65535: Enabled (unit: second) (default=0) When ET-7000/PET-7000 loses communication with PC more than the WDT setting, DO and AO go to their safe values and host WDT events plus 1 count.	R/W/E
558	1	Host WDT events	1	How many host WDT events have happened after CPU reset?	R/W
559	1	Module name	4	16 ASCII characters	R
563	1	Module nick name	8	16 ASCII characters	R/W/E

4.3.2. Particular Function

4.3.2.1. PET-7005/ET-7005 I/O Address Mapping



Detailed Modbus Address Table for ET-7005/PET-7005 (D)

• (0xxxx) DO address

Begin address	Points	Description	Registers per Point	Range	Access Type
0	0~31 (32)	Digital Out	1	0=off 1=on	R/W
32~161		Reserved			
162	0~31 (32)	Clear AI Latch High (single)	1	1=clear	W (Pulse)
194	0~31 (32)	Clear AI Latch Low (single)	1	1=clear	W (Pulse)
226	1	Recover all I/O default settings	1	1=clear	W (Pulse)
233	1	Reboot ET-7000	1	1=reboot	W (Pulse)
250	0~89 (90)	DO mapping address for external Modbus devices.	1	0=off 1=on	R/W
340~346	7	Reserved			
347	1	Enable the average value of the previous AI values of one channel for all AI	1	0=disable 1=enable (Default=0)	R/W/E
348	1	Enable Average of all enabled channel, High/Low Alarm value of all AI average value and Average latched values for all AI channels.	1	0=disable 1=enable (Default=0)	R/W/E
349	1	Save Module Nick Name to EEPROM	1	1=write	W/E (Pulse)
350~430		Reserved			
431	1	Write DO Power on value to EEPROM	1	1=write	W (Pulse)
432	1	Write DO Safe value to EEPROM	1	1=write	W (Pulse)
435	0~79 (80)	Power on value for DO	1	0=disable 1=enable (Default=0)	R/W/E
515	0~79	Safe value for DO	1	0=off	R/W/E

	(80)			1=on (Default=0)	
595	0~31 (32)	Enable/Disable AI channel	1	0=disable 1=enable (Default=1)	R/W/E
627	1	Temperature Scale	1	0: F 1: C (Default=0)	R/W/E
628	1	Reserved			
629	1	50/60Hz rejection for AI	1	1=50Hz 0=60Hz (Default=0)	R/W/E
630	1	Reserved			
631	1	AI data format	1	0=hex 1=engineering (Default=0)	R/W/E
632	1	Return the factory calibration (All)	1	1=clear	R/W (Pulse)
633		Reserved			
634	1	Clear AI Latch High (All)	1	1=clear	W (Pulse)
635	1	Clear AI Latch Low (All)	1	1=clear	W (Pulse)
636	0~31 (32)	AI Alarm High switch	1	0=disabled 1=enabled	R/W/E
668	0~31 (32)	AI Alarm Low switch	1	0=disabled 1=enabled	R/W/E
700	0~31 (32)	AI Alarm High mode	1	0=Moment 1=Latched	R/W/E
732	0~31 (32)	AI Alarm Low mode	1	0=Moment 1=Latched	R/W/E
764	0~31 (32)	AI High Alarm	1	0=OK 1=alarm (Clear)	R/W (Pulse)
796	0~31 (32)	AI Low Alarm	1	0=OK 1=alarm (Clear)	R/W (Pulse)

828	1	High Alarm of Average value of all AI channel	1	0=OK 1=alarm (Clear)	R/W (Pulse)
829	1	Low Alarm of Average value of all AI channel	1	0=OK 1=alarm (Clear)	R/W (Pulse)
830	1	Enable/Disable Calibration	1	0=disabled 1=enabled	R/W
831	1	Zero calibration channel 0	1	1=write	W (Pulse)
832	1	Span calibration channel 0	1	1=write	W (Pulse)

• (1xxxx) DI Address

Begin address	Points	Description	Registers per Point	Range	Access Type
0~303		Reserved			
224	0~31 (32)	AI High Alarm	1	0=normal 1=alarm	R
256	0~31 (32)	AI Low Alarm	1	0=normal 1=alarm	R
304	0~31 (32)	Break line status of AI registers	1	0=ok 1=break	R
336	1	High alarm for the average value of all AI registers	1	0=ok 1=alarm	R
337	1	Low alarm for the average value of all AI registers	1	0=ok 1=alarm	R
338	0~11	Reserved			
350	0~89 (90)	DI mapping address for external Modbus devices	1	0=normal 1=alarm	R
440	0~n	Reserved			

• (3xxxx) AI address

Begin address	Points	Description	Registers per Point	Range	Access Type
0	0~31 (32)	Analog Input	word	-32768 ~ +32767	R
32~143		Reserved			
144	0~31 (32)	Average value of one channel	word	0~65535 or -32768 ~ +32767	R
176	1	Average value of all enabled AI channel	word	0~65535 or -32768 ~ +32767	R
177	1	Average value of all maximum latched AI value	word	0~65535 or -32768 ~ +32767	R
178	1	Average value of all minimum latched AI value	word	0~65535 or -32768 ~ +32767	R
180	0~49 (50)	AI mapping address for external Modbus devices	word	0~65535 or -32768 ~ +32767	R
230~235		Reserved			
Analog Latched Value					
236	0~31 (32)	Analog Latched value (High)	word	0~65535 or -32768 ~ +32767	R
268	0~31 (32)	Analog Latched value (Low)	word	0~65535 or -32768 ~ +32767	R
300~309		Reserved			
Channel number for DO registers					
310	1	DO (channel number)	word	0 ~ 79	R
311	1	Power on value for DO (channel number)	word	0 ~ 79	R
312	1	Safe value for DO (channel number)	word	0 ~ 79	R


313~319		Reserved			
320	1	AI (channel number)	word	0 ~ 16	R
321~349		Reserved			
350	1	OS image version	word	123 (hex) means version=1.2.3	R
351	1	Total firmware version	word	123 (hex) means version=1.2.3	R
352	1	CPU lib version	word	123 (hex) means version=1.2.3	R
353	1	I/O firmware version	word	123 (hex) means version=1.2.3	R
354	1	MFW lib version	word	123 (hex) means version=1.2.3	R
355	1	TCP/IP lib version	word	123 (hex) means version=1.2.3	R
356	1	Modbus lib version	word	123 (hex) means version=1.2.3	R
357	1	Web lib version	word	123 (hex) means version=1.2.3	R
358	1	Modbus communication status	word	0= no error -1=CRC error -2=timeout	R
359		Reserved			
360	1	Pair Connection	word	0=normal 1=timeout 2=disconnected	R
371	1	Software protection CRC 16	word		R
373~n	0~n	Reserved			

• (4xxxx) AO address

Begin address	Points	Description	Registers per Point	Range	Access Type
0~58		Reserved			
59	1	Average times for every channel	word	0 ~ 40	R/W/E
60	0~49 (50)	AO mapping address for external Modbus devices	word	0x0000 ~ 0xffff	R/W/E
110~141	0~31 (32)	Temperature offset of channel	word		R/W/E
142~173	0~31 (32)	Resistance offset of channel	word		R/W/E
174	1	Enable/Disable AI channel	word	0 ~ 65535	R/W
175~197		Reserved			
198	1	High alarm value for average value of all AI channel	word	0 ~ 65535 or -32768 ~ +32767	R/W/E
199	1	Low alarm value for average value of all AI channel	word	0 ~ 65535 or -32768 ~ +32767	R/W/E
200~270		Reserved			
271	1	Modbus address (Net ID)	word	1 ~ 255	R/W/E
272~295		Reserved			
296	0~31 (32)	High alarm value for AI	word	-32768 ~ +32767 (Default=32767)	R/W/E
328	0~31 (32)	Low alarm value for AI	word	-32768 ~ +32767 (Default=-32768)	R/W/E
360~426		Reserved			
427	1	Type code for AI	word	Refer to type code table	R/W/E
428~554		Reserved			
555	1	CPU reset status	word	1=by power on 2=by 0.8 second WDT 3=by Reset command	R/W
556	1	CPU reset events	word	When CPU is reset by one of	R/W/E

				the situations described in register 555, the event increases one count	
557	1	Set host watch dog timer	word	<5: Disable 5 ~ 65535: Enable (Unit: second)	R/W/E
558	1	Host watch dog events	word	0 ~ 32767	R/W
559	1	Module name	4 word	16 ASCII characters	R
563	1	Module nick name	8 word	16 ASCII characters	R/W
572	1	Station per COM port	word	1~255	R/W/E
573	0~7 (8)	COM port enable mode	word	0~5	R/W
581	0~7 (8)	COM port Communication Timeout	word	10~65535 (ms)	R/W/E
589		Reserved			
590~621	0~31 (32)	Stein-hart Coefficient A	word		R/W/E
622~653	0~31 (32)	Stein-hart Coefficient B	word		R/W/E
654~685	0~31 (32)	Stein-hart Coefficient C	word		R/W/E

4.3.2.2. PET-7015/ET-7015 I/O Address Mapping



Detailed Modbus Address Table for ET-7015/PET-7015 (D)

• (0xxxx) DO address

Begin address	Points	Description	Registers per Point	Range	Access Type
595	7	Enable/Disable AI channel	1	0=disable 1=enable (Default=1)	R/W/E
629	1	50/60Hz rejection for AI	1	0=50Hz 1=60Hz (Default=1)	R/W/E
631	1	AI data format	1	1=engineering 0=hex (Default=0)	R/W/E
632	1	Return the factory calibration (All)	1	1=clear	R/W/E
830	1	Enable/ Disable calibration(All)	1	0=disable 1=enable	R/W
831	1	Zero calibration command of ch0	1	1=run (Pulse)	R/W
832	1	Span calibration command of ch0	1	1=run (Pulse)	R/W
833	1	Zero calibration command of ch1	1	1=run (Pulse)	R/W
834	1	Span calibration command of ch1	1	1=run (Pulse)	R/W
835	1	Zero calibration command of ch2	1	1=run (Pulse)	R/W
836	1	Span calibration command of ch2	1	1=run (Pulse)	R/W
837	1	Zero calibration command of ch3	1	1=run (Pulse)	R/W
838	1	Span calibration command of ch3	1	1=run (Pulse)	R/W
839	1	Zero calibration command of ch4	1	1=run (Pulse)	R/W
840	1	Span calibration command of ch4	1	1=run (Pulse)	R/W
841	1	Zero calibration command of ch5	1	1=run (Pulse)	R/W
842	1	Span calibration command of ch5	1	1=run (Pulse)	R/W
843	1	Zero calibration command of ch6	1	1=run (Pulse)	R/W
844	1	Span calibration command of ch6	1	1=run (Pulse)	R/W

- **(3xxxx) AI address**

Begin address	Points	Description	Registers per Point	Range	Access Type
0	7	Analog Input	word	-32768 ~ +32767	R

- **(4xxxx) AO address**


Begin address	Points	Description	Registers per Point	Range	Access Type
110	7	Temperature offset	word	-128 ~ 127	R/W/E
271	1	Modbus NetID	word	1 ~ 255	R/W
142	7	Resistance offset	word	0 ~ 255	R/W/E
427	7	Type code for AI	word	20 ~ 83 (hex)	R/W/E

- **Note:**

Unit of temperature offset is 0.1 °C, valid range: -128 ~ 127

Unit of resistance offset is 0.1 ohm, valid range: 0 ~ 255

4.3.2.3. PET-7017/ET-7017 I/O Address Mapping



Detailed Modbus Address Table for ET-7017/PET-7017 (D)

• (0xxxx) DO address

Begin address	Points	Description	Registers per Point	Range	Access Type
0	4	Digital Out	1	0=off 1=on	R/W
162	32	Clear AI Latch High	1	1=clear	W (Pulse)
194	32	Clear AI Latch Low	1	1=clear	W (Pulse)
347	1	Enable the average value of the previous AI values of one channel for all AI	1	0=disable 1=enable (Default=0)	R/W/E
348	1	Enable average of all enable channel, High/Low Alarm value of all AI average value and Average latched values for all AI channels	1	0=disable 1=enable (Default=0)	R/W/E
431	1	Write DO Power on value to EEPROM	1	1=write	W (Pulse)
432	1	Write DO Safe value to EEPROM	1	1=write	W (Pulse)
435	4	Power on value for DO	1	0=off 1=on (Default=0)	R/W/E
515	4	Safe value for DO	1	0=off 1=on (Default=0)	R/W/E
595	8	Enable/Disable AI channel	1	0=disable 1=enable (Default=1)	R/W/E
628	1	Normal/Fast mode for AI	1	0=normal (16 bit) 1=fast (12 bit) (Default=0)	R/W/E
629	1	50/60Hz rejection for AI	1	1=50Hz 0=60Hz	R/W/E

				(Default=0)	
631	1	AI data format	1	1=engineering 0=hex (Default=0)	R/W/E
632	1	Return the factory calibration (All)	1	1=clear	R/W/E
634	1	Clear AI Latch High (All)	1	1=clear	W (Pulse)
635	1	Clear AI Latch Low (All)	1	1=clear	W (Pulse)
636	8	AI Alarm High switch	1	0=disabled 1=enabled	R/W/E
668	8	AI Alarm Low switch	1	0=disabled 1=enabled	R/W/E
700	8	AI Alarm High mode	1	0=Moment 1=Latched	R/W/E
732	8	AI Alarm Low mode	1	0=Moment 1=Latched	R/W/E
764	8	AI High Alarm	1	0=OK 1=alarm (Clear)	R/W (Pulse)
796	8	AI Low Alarm	1	0=OK 1=alarm (Clear)	R/W (Pulse)
828	1	High Alarm of Average value of all AI channel	1	0=OK 1=alarm (Clear)	R/W (Pulse)
829	1	Low Alarm of Average value of all AI channel	1	0=OK 1=alarm (Clear)	R/W (Pulse)


• (3xxxx) AI address

Begin address	Points	Description	Registers per Point	Range	Access Type
0	8	Analog Input	word	-32768 ~ +32767	R
144	8	Average value of one channel	word	-32768 ~ +32767	R
176	1	Average value of all enabled AI channel	word	-32768 ~ +32767	R
177	1	Average value of all maximum latched AI value	word	-32768 ~ +32767	R
178	1	Average value of all minimum latched AI value	word	-32768 ~ +32767	R
236	8	Analog Latched value (High)	word	-32768 ~ +32767	R
268	8	Analog Latched value (Low)	word	-32768 ~ +32767	R
310	1	DO (channel number)	word	0 ~ 79	R
311	1	Power on value for DO (channel number)	word	0 ~ 79	R
312	1	Safe value for DO (channel number)	word	0 ~ 79	R
320	1	AI (channel number)	word	0 ~ 16	R

• (4xxxx) AO address

Begin address	Points	Description	Registers per Point	Range	Access Type
59	1	Average times for every channel	word	0 ~ 40	R/W/E
174	1	Enable/Disable AI channel	word	0 ~ 65535	R/W
198	1	High alarm value for average value of all AI channel	word	0 ~ 65535 or -32768 ~ +32767	R/W/E
199	1	Low alarm value for average value of all AI channel	word	0 ~ 65535 or -32768 ~ +32767	R/W/E
296	8	High alarm value for AI	word	-32768 ~ +32767 (Default=32767)	R/W/E
328	8	Low alarm value for AI	word	-32768 ~ +32767 (Default=-32768)	R/W/E
427	1	Type code for AI	word	Refer to type code table	R/W/E

4.3.2.4. ET-7017-10 I/O Address Mapping



Detailed Modbus Address Table for ET-7017/PET-7017 (D)

• (0xxxx) DO address

Begin address	Points	Description	Registers per Point	Range	Access Type
162	32	Clear AI Latch High	1	1=clear	W (Pulse)
194	32	Clear AI Latch Low	1	1=clear	W (Pulse)
347	1	Enable the average value of the previous AI values of one channel for all AI	1	0=disable 1=enable (Default=0)	R/W/E
348	1	Enable average of all enable channel, High/Low Alarm value of all AI average value and Average latched values for all AI channels	1	0=disable 1=enable (Default=0)	R/W/E
595	8	Enable/Disable AI channel	1	0=disable 1=enable (Default=1)	R/W/E
628	1	Normal/Fast mode for AI	1	0=normal (16 bit) 1=fast (12 bit) (Default=0)	R/W/E
629	1	50/60Hz rejection for AI	1	1=50Hz 0=60Hz (Default=0)	R/W/E
631	1	AI data format	1	1=engineering 0=hex (Default=0)	R/W/E
632	1	Return the factory calibration (All)	1	1=clear	R/W/E
634	1	Clear AI Latch High (All)	1	1=clear	W (Pulse)
635	1	Clear AI Latch Low (All)	1	1=clear	W (Pulse)
636	8	AI Alarm High switch	1	0=disabled 1=enabled	R/W/E
668	8	AI Alarm Low switch	1	0=disabled 1=enabled	R/W/E

700	8	AI Alarm High mode	1	0=Moment 1=Latched	R/W/E
732	8	AI Alarm Low mode	1	0=Moment 1=Latched	R/W/E
764	8	AI High Alarm	1	0=OK 1=alarm (Clear)	R/W (Pulse)
796	8	AI Low Alarm	1	0=OK 1=alarm (Clear)	R/W (Pulse)
828	1	High Alarm of Average value of all AI channel	1	0=OK 1=alarm (Clear)	R/W (Pulse)
829	1	Low Alarm of Average value of all AI channel	1	0=OK 1=alarm (Clear)	R/W (Pulse)


• **(3xxxx) AI address**

Begin address	Points	Description	Registers per Point	Range	Access Type
0	8	Analog Input	word	-32768 ~ +32767	R
144	8	Average value of one channel	word	-32768 ~ +32767	R
176	1	Average value of all enabled AI channel	word	-32768 ~ +32767	R
177	1	Average value of all maximum latched AI value	word	-32768 ~ +32767	R
178	1	Average value of all minimum latched AI value	word	-32768 ~ +32767	R
236	8	Analog Latched value (High)	word	-32768 ~ +32767	R
268	8	Analog Latched value (Low)	word	-32768 ~ +32767	R
320	1	AI (channel number)	word	0 ~ 16	R

• (4xxxx) AO address

Begin address	Points	Description	Registers per Point	Range	Access Type
59	1	Average times for every channel	word	0 ~ 40	R/W/E
174	1	Enable/Disable AI channel	word	0 ~ 65535	R/W
198	1	High alarm value for average value of all AI channel	word	0 ~ 65535 or -32768 ~ +32767	R/W/E
199	1	Low alarm value for average value of all AI channel	word	0 ~ 65535 or -32768 ~ +32767	R/W/E
296	8	High alarm value for AI	word	-32768 ~ +32767 (Default=32767)	R/W/E
296	8	Low alarm value for AI	word	-32768 ~ +32767 (Default=-32768)	R/W/E
427	1	Type code for AI	word	Refer to type code table	R/W/E

4.3.2.5. PET-7018Z/ET-7018Z I/O Address Mapping



Detailed Modbus Address Table for ET-7018Z/PET-7018Z

• (0xxxx) DO address

Begin address	Points	Description	Registers per Point	Range	Access Type
0	6	Digital Out	1	0=off 1=on	R/W
162	10	Clear AI Latch High	1	1=clear	W (Pulse)
194	10	Clear AI Latch Low	1	1=clear	W (Pulse)
347	1	Enable the average value of the previous AI values of one channel for all AI	1	0=disable 1=enable (default=0)	R/W/E
348	1	Enable average of all enable channel, High/Low Alarm value of all AI average value and Average latched values for all AI channels	1	0=disable 1=enable (default=0)	R/W/E
349	1	Save module nick name to EEPROM	1	1=write	W (Pulse)
431	1	Write DO Power On value to EEPROM	1	1=write	W (Pulse)
432	1	Write DO Safe value to EEPROM	1	1=write	W (Pulse)
435	6	Power On value for DO	1	0=off 1=on (default=0)	R/W/E
515	6	Safe value for DO	1	0=off 1=on (default=0)	R/W/E
595	10	Enable/Disable AI channel	1	0=disable 1=enable (default=1)	R/W/E
627	1	Enable/Disable CJC	1	0=Disable 1=Enable (default=1)	R/W/E
629	1	50/60Hz rejection for AI	1	0=50Hz	R/W/E

				1=60Hz (default=1)	
631	1	AI data format	1	1=engineering 0=hex (default=0)	R/W/E
632	1	Return the factory calibration (all)	1	1=clear	R/W (Pulse)
634	1	Clear AI Latch High (all)	1	1=clear	W (Pulse)
635	1	Clear AI Latch Low (all)	1	1=clear	W (Pulse)
636	10	AI Alarm High switch	1	0=disabled high alarm 1=enabled high alarm	R/W/E
668	10	AI Alarm Low switch	1	0=disabled low alarm 1=enabled low alarm	R/W/E
700	10	AI Alarm High mode	1	0=Moment 1=Latched	R/W/E
732	10	AI Alarm Low mode	1	0=Moment 1=Latched	R/W/E
764	10	AI High Alarm	1	0=OK 1=alarm (clear)	R/W (Pulse)
796	10	AI Low Alarm	1	0=OK 1=alarm (clear)	R/W (Pulse)
828	1	High Alarm of Average value of all AI channel	1	0=OK 1=alarm (clear)	R/W (Pulse)
829	1	Low Alarm of Average value of all AI channel	1	0=OK 1=alarm (clear)	R/W (Pulse)
830	1	Enable/Disable calibration	1	0=disabled 1=enabled	R/W

831	1	Zero calibration channel 0	1	1 = write	W (Pulse)
832	1	Span calibration channel 0	1	1=write	W (Pulse)

• **(1xxxx) DI Address**

Begin address	Points	Description	Registers per Point	Range	Access Type
336	1	High alarm for the average value of all AI registers	1	0=ok 1=alarm	R
337	1	Low alarm for the average value of all AI registers	1	0=ok 1=alarm	R

• (3xxxx) AI address


Begin address	Points	Description	Registers per Point	Range	Access Type
0	10	Analog Input	word	-32768 ~ +32767	R
143	1	CJC temperature	word	-32768 ~ +32767	R
144	10	Average value of one channel	word	0 ~ 65535 or -32768 ~ +32767	R
176	1	Average value of all enabled AI channel	word	0 ~ 65535 or -32768 ~ +32767	R
177	1	Average value of all maximum latched AI value	word	0 ~ 65535 or -32768 ~ +32767	R
178	1	Average value of all minimum latched AI value	word	0 ~ 65535 or -32768 ~ +32767	R
236	10	Analog Latched value (High)	word	0 ~ 65535 or -32768 ~ +32767	R
268	10	Analog Latched value (Low)	word	0 ~ 65535 or -32768 ~ +32767	R
310	1	DO (channel number)	word	0 ~ 79	R
311	1	Power on value for DO (channel number)	word	0 ~ 79	R
312	1	Safe value for DO (channel number)	word	0 ~ 79	R
320	1	AI (channel number)	word	0 ~ 16	R
350	1	OS image version	word	123 (hex) means version=1.2.3	R
351	1	Total firmware version	word	123 (hex) means version=1.2.3	R
352	1	CPU lib version	word	123 (hex)	R

				means version=1.2.3	
353	1	I/O firmware version	word	123 (hex) means version=1.2.3	R
354	1	Xserver lib version	word	123 (hex) means version=1.2.3	R
355	1	TCP/IP lib version	word	123 (hex) means version=1.2.3	R
356	1	Modbus lib version	word	123 (hex) means version=1.2.3	R
357	1	Web lib version	word	123 (hex) means version=1.2.3	R
358	1	Modbus communication status	word	0= no error -1=CRC error -2=timeout	R
360	1	Pair connection	word	0=normal 1=timeout 2=disconnected	R

• (4xxxx) AO address

Begin address	Points	Description	Registers per Point	Range	Access Type
59	1	Average times for every channel	word	0 ~ 40	R/W/E
174	1	Enable/Disable AI channel	word	0 ~ 65535	R/W
198	1	High alarm value for average value of all AI channel	word	0 ~ 65535 or -32768 ~ +32767	R/W/E
199	1	Low alarm value for average value of all AI channel	word	0 ~ 65535 or -32768 ~ +32767	R/W/E
271	1	Modbus address (Net ID)	word	1 ~ 255	R/W/E
296	10	High alarm value for AI	word	-32768 ~ +32767 (Default=32767)	R/W/E
328	10	Low alarm value for AI	word	-32768 ~ +32767 (Default=-32767)	R/W/E
427	10	Type code for AI	word	Refer to type code table	R/W/E
491	10	CJC offset of channel	word	-4096 ~ 4096 (unit = 0.01 °C)	R/W/E
589		CJC update setting	word	0=stop CJC update 1=start CJC update 2=update CJC once only after this command is received	R/W/E

4.3.2.6. ET-7019 I/O Address Mapping



Detailed Modbus Address Table for ET-7019

• (0xxxx) DO address

Begin address	Points	Description	Registers per Point	Range	Access Type
0	4	Digital Out	1	0=off 1=on	R/W
162	8	Clear AI Latch High	1	1=clear	W (Pulse)
194	8	Clear AI Latch Low	1	1=clear	W (Pulse)
226	1	Recover all I/O default settings	1	1=clear	W (Pulse)
233	1	Reboot ET-7000	1	1=clear	W (Pulse)
347	1	Enable the average value of the previous AI values of one channel for all AI	1	0=disable 1=enable (Default=0)	R/W/E
348	1	Enable average of all enable channel, High/Low Alarm value of all AI average value and Average latched values for all AI channels	1	0=disable 1=enable (Default=0)	R/W/E
431	1	Write DO Power on value to EEPROM	1	1=write	W (Pulse)
432	1	Write DO Safe value to EEPROM	1	1=write	W (Pulse)
435	4	Power on value for DO	1	0=off 1=on (Default=0)	R/W/E
515	4	Safe value for DO	1	0=off 1=on (Default=0)	R/W/E
595	8	Enable/Disable AI channel	1	0=disable 1=enable (Default=1)	R/W/E
627	1	Enable/Disable CJC	1	0=normal (16 bit)	R/W/E

				1=fast (12 bit) (Default=0)	
629	1	50/60Hz rejection for AI	1	1=50Hz 0=60Hz (Default=0)	R/W/E
631	1	AI data format	1	1=engineering 0=hex (Default=0)	R/W/E
632	1	Return the factory calibration (All)	1	1=clear	R/W/E
634	1	Clear AI Latch High (All)	1	1=clear	W (Pulse)
635	1	Clear AI Latch Low (All)	1	1=clear	W (Pulse)
636	8	AI Alarm High switch	1	0=disabled 1=enabled	R/W/E
668	8	AI Alarm Low switch	1	0=disabled 1=enabled	R/W/E
700	8	AI Alarm High mode	1	0=Moment 1=Latched	R/W/E
732	8	AI Alarm Low mode	1	0=Moment 1=Latched	R/W/E
764	8	AI High Alarm	1	0=OK 1=alarm (Clear)	R/W (Pulse)
796	8	AI Low Alarm	1	0=OK 1=alarm (Clear)	R/W (Pulse)
828	1	High Alarm of Average value of all AI channel	1	0=OK 1=alarm (Clear)	R/W (Pulse)
829	1	Low Alarm of Average value of all AI channel	1	0=OK 1=alarm (Clear)	R/W (Pulse)
830	1	Enable/Disable Calibration	1	0=Disable 1=Enable	R/W
831	1	Zero calibration channel 0	1	1=Write	W

					(Pulse)
832	1	Span calibration channel 0	1	1=Write	W (Pulse)

• **(1xxxx) DI Address**

Begin address	Points	Description	Registers per Point	Range	Access Type
244	8	AI alarm high	1	0=Normal 1=Alarm	R
256	8	AI alarm low	1	0=Normal 1=Alarm	R
336	1	High alarm for the average value of all AI registers	1	0=Normal 1=Alarm	R
337	1	Low alarm for the average value of all AI registers	1	0=Normal 1=Alarm	R

• (3xxxx) AI address


Begin address	Points	Description	Registers per Point	Range	Access Type
0	8	Analog Input	word	-32768 ~ +32767	R
143	1	CJC data	word	-32768 ~ +32767	R
144	8	Average value of one channel	word	0 ~ 65535 or -32768 ~ +32767	R
176	1	Average value of all enabled AI channel	word	0 ~ 65535 or -32768 ~ +32767	R
177	1	Average value of all maximum latched AI value	word	0 ~ 65535 or -32768 ~ +32767	R
178	1	Average value of all minimum latched AI value	word	0 ~ 65535 or -32768 ~ +32767	R
236	8	Analog Latched value (High)	word	0 ~ 65535 or -32768 ~ +32767	R
268	8	Analog Latched value (Low)	word	0 ~ 65535 or -32768 ~ +32767	R
310	1	DO (channel number)	word	4	R
320	1	AI (channel number)	word	8	R
350	1	OS image version	word	123 means version = 1.2.3	R
351	1	Total firmware version	word		R
352	1	CPU lib version	word	123 means version = 1.2.3	R
353	1	I/O firmware version	word	123 means version = 1.2.3	R
354	1	MFW lib version	word	123 means version = 1.2.3	R
355	1	TCP/IP lib version	word	123 means version = 1.2.3	R
356	1	Modbus lib version	word	123 means version = 1.2.3	R
357	1	Web lib version	word	123 means version = 1.2.3	R
360	1	Pair connection	word	0=Normal 1=Timeout 2=Disconnected	R

• (4xxxx) AO address

Begin address	Points	Description	Registers per Point	Range	Access Type
59	1	Average times for every channel	word	0 ~ 40	R/W/E
174	1	Enable/Disable AI channel	word	0 ~ 65535	R/W
198	1	High alarm value for average value of all AI channel	word	0 ~ 65535 or -32768 ~ +32767	R/W/E
199	1	Low alarm value for average value of all AI channel	word	0 ~ 65535 or -32768 ~ +32767	R/W/E
271	1	Modbus address (Net ID)	word	1 ~ 255	R/W/E
296	8	High alarm value for AI	word	-32768 ~ +32767	R/W/E
328	8	Low alarm value for AI	word	-32768 ~ +32767	R/W/E
427	1	Type code for AI	word	Refer to type code table	R/W/E
491	1	CJC offset of channel	word	-9999.0 ~ +9999.0	R/W/E
523	1	CJC Offset (for all channel)	word	-9999.0 ~ +9999.0	R/W/E
555	1	CPU reset status	word	1=by power on 2=by 0.8 second WDT 3=by Reset command	R/W
556	1	CPU reset events	word	When CPU is reset by one of the situations described in register 555, the event increases one count	R/W/E
557	1	Set host watch dog timer	word	<5: Disable 5 ~ 65535: Enable (Unit: second)	R/W/E
558	1	Host watch dog events	word	0 ~ 32767	R/W
559	1	Module name	word	16 ASCII characters	R
563	1	Module nick name	4 word	16 ASCII characters	R/W
589	1	CJC update settings	8 word	0: Stop 1: Start 2: Read once	R/W/E


Step 2: Press “F12” or choose “Search” from the “Connection” menu

After pressing **F12** or choosing **Search** from **Connection** menu, that will search all of the MiniOS7 modules on your network.




Step 3: Double-Click the field of your ET-7000/PET-7000 module

Double-Click the field of your ET-7000/PET-7000 module in the list to connect to your ET-7000/PET-7000.



Step 4: The connection has ready been established

Check the connection status in the top right side to make sure the connection has been established



5.2. Exchanging the Protocol (TCP/IP to UDP)

MiniOS7 Utility supports both UDP and TCP protocols.


For MiniOS7 Utility, the TCP/IP is the default protocol for communicating with ET-7000/PET-7000, and the UDP is used to update the OS. Therefore, if you want to update the OS, you might need to change protocols to support them.

Step 1: Establish a connection to ET-7000/PET-7000

For more detailed about this process, please refer to section “5.1. Establishing a Connection” to establish a connection.


Step 2: Right Click the file list of the right side window, and then choose “Quit Firmware” to stop the firmware running

Right click the file list of the right side windows, and then choose **Quit Firmware** to stop the firmware running and exchange TCP/IP protocol to UDP protocol.




Step 3: Click “Yes” to continue

After executing the **Quick Firmware** command, the Confirm dialog will appear, and then click **Yes** button to continue and stop the firmware running.



Step 4: Click “Yes” to continue

After confirming the command, the Confirm dialog will appear, and then click **Yes** button to exchange UDP protocol for TCP protocol.




Step 5: The changes have been affected

5.3. Updating the ET-7000/PET-7000 OS

ICP DAS will continue to add additional features to ET-7000/PET-7000 OS in the future, so we advise you to periodically check the ICP DAS web site for the latest updates.


Step 1: Get the latest version of the MiniOS7 OS image



The latest version of the MiniOS7 OS image can be obtained from:
CD:\NAPDOS\ET7000\OS_image\
http://ftp.icpdas.com/pub/cd/6000cd/napdos/et7000/os_image/

Step 2: Turn the switch to “Init” position

Turn the Init/Normal switch to **Init** position.



Step 3: Establish a connection to ET-7000/PET-7000


For more detailed about this process, please refer to section “5.1. Establishing a Connection” to establish a connection.

Step 4: Exchange the protocol

For more detailed about this process, please refer to section “5.2. Exchanging the Protocol (TCP/IP to UDP)” to exchange the protocol.

Step 5: Choose “Update MiniOS7 Image” from the “File” menu

After exchanging the protocol, then choose **Update MiniOS7 Image** from **File** menu to start the update procedure.



Step 6: Select the latest version of the MiniOS7 OS image

After choosing the **update MiniOS7 Image** command, the Select MiniOS7 Image file will appear, and then select the latest version of the MiniOS7 OS image.



Step 7: Click “OK” to finish the procedure

After confirming the command, you just need to wait awhile until the following dialog appear, and then click **OK** button to finish the procedure.




Step 8: Restart the MiniOS7 Utility, and then exchange the protocol to UDP

You may need to restart the MiniOS7 Utility for refreshing the settings, and then exchanging the protocol to UDP

For more detailed about this process, please refer to section “5.2. Exchanging the Protocol (TCP/IP to UDP)” to exchange the protocol.

Step 9: Press “F7” or choose “Info” from the “Command” menu to check the OS version


After pressing F7 or choosing **info** from **Command** menu to check the OS version.



5.4. Uploading the ET-7000/PET-7000 Firmware

The firmware is stored in flash memory and can be updated to fix functionality issues or add additional features, so we advise you to periodically check the ICP DAS web site for the latest updates.

Step 1: Get the latest version of the MiniOS7 firmware and the autoexec.bat file




The latest version of the MiniOS7 firmware and autoexec.bat file can be obtained from:

CD:\NAPDOS\ET7000\Firmware\

<http://ftp.icpdas.com/pub/cd/6000cd/napdos/et7000/Firmware/>

Step 2: Turn the switch to “Init” position

Turn the Init/Normal switch to **Init** position.




Step 3: Establish a connection to ET-7000/PET-7000

For more detailed about this process, please refer to section “5.1. Establishing a Connection” to establish a connection.

Step 4: Choose “Erase Disk” from the “Command” menu

After establishing a connection, then choose **Erase Disk** from **Command** menu to erase the contents of the flash memory.




Tips & Warnings



You have to delete all files existed on the ET-7000/PET-7000 before uploading the firmware.


Step 5: Click “Yes” to continue

After executing the **Erase Disk** command, the Confirm dialog will appear, and then click Yes button to continue erasing the memory contents.




Step 6: Select the latest version of the MiniOS7 firmware and autoexec.bat file

After confirming the command, all files of the ET-7000/PET-7000 will be deleted. Select MiniOS7 Image file will appear, and then select the latest version of the MiniOS7 OS image.




Step 7: Click OK to finish and restart the MiniOS7 Utility

After confirming the command, you just need to wait awhile until the following dialog appear, and then click OK button to finish the procedure.



Chapter 6. External Tools and Tasks

6.1. LabVIEW



LabVIEW is the best way to acquire, analyze, and present data. LabVIEW delivers a graphical development environment that can be used to quickly build data acquisition quickly, instrumentation and control systems, boosting productivity and saving development time. With LabVIEW, it is possible to quickly create user interfaces that enable interactive control of software systems. To specify your system functionality, simply assemble block diagram – a natural design notation for scientists and engineers.

The document containing the detailed instructions for linking to the ET-7000/PET-7000 using the Modbus protocol is located on the shipped

CD:\NAPDOS\PET7000_ET7000\Document\Application\LabVIEW\ or

ftp://ftp.icpdas.com/pub/cd/6000cd/napdos/pet7000_et7000/document/application/labview/

6.2. OPC Server

OPC (OLE for Process Control) is the first standard resulting from the collaboration of a number of leading worldwide automation suppliers working in cooperation with Microsoft. Originally based on Microsoft's OLE COM (Component Object Model) and DCOM (Distributed Component Object Model) technologies, the specification defines a standard set of objects, interfaces and methods for use in process control and manufacturing automation applications to facilitate interoperability.

There are many different mechanisms provided by various vendors that allow access to a variety of devices via specific applications. However, if an OPC server is provided for the device, other applications will be able to access the OPC Server via the OPC interface.

6.3. SCADA

SCADA stands for Supervisor Control and Data Acquisition. It is a production automation and control system based on PCs

SCADA is widely used in many fields e.g. power generation, water systems, the oil industry, chemistry, the automobile industry. Different fields require different functions, but they all have the common features:

- Graphic interface
- Process mimicking
- Real time and historic trend data
- Alarm system
- Data acquisition and recording
- Data analysis
- Report generator

► Accessing ET-7000/PET-7000 module


SCADA software is able to access ET-7000/PET-7000 devices using Modbus communication protocols, and can communicate without the need for other software drivers.

► Famous SCADA software

Citect, ICONICS, iFIX, InduSoft, Intouch, Entivity Studio, Entivity Live, Entivity VLC, Trace Mode, Wizcon, Wonderware ... etc

In the following sections 3 popular brands of SCADA software are introduced together with the detailed instructions in how use them to communicate with ET-7000/PET-7000 series module using the Modbus/TCP protocol.

6.3.1. InduSoft



InduSoft Web Studio is a powerful, integrated collection of automation tools that includes all the building blocks needed to develop modern Human Machine Interfaces (HMI), Supervisory Control and Data Acquisition (SCADA) systems, and embedded instrumentation and control applications. InduSoft Web Studio's application runs in native Windows NT, 2000, XP, CE and CE .NET environments and conforms to industry standards such as Microsoft .NET, OPC, DDE, ODBC, XML, and ActiveX.

The document containing detailed instructions for linking to the ET-7000/PET-7000 module using the Modbus protocol is located on the shipped

CD:\NAPDOS\PET7000_ET7000\Document\Application\InduSoft\

ftp://ftp.icpdas.com/pub/cd/6000cd/napdos/pet7000_et7000/document/application/indusoft/

6.3.2. Citect



CitectSCADA is a fully integrated Human Machine Interface (HMI) / SCADA solution that enables users to increase return on assets by delivering a highly scalable, reliable control and monitoring system. Easy-to-use configuration tools and powerful features enable rapid development and deployment of solutions for any size application.

The document containing detailed instructions for linking to the ET-7000/PET-7000 module using the Modbus protocol is located on the shipped

CD:\NAPDOS\PET7000_ET7000\Document\Application\Citect\

ftp://ftp.icpdas.com/pub/cd/6000cd/napdos/pet-7000_et7000/document/application/citect/


6.3.3. iFix



The document containing detailed instructions for linking to the ET-7000/PET-7000 module using the Modbus protocol is located on the shipped CD:\NAPDOS\PET7000_ET7000\Document\Application\iFix\
ftp://ftp.icpdas.com/pub/cd/6000cd/napdos/pet7000_et7000/document/application/ifix/

Appendix A. Node Information Area

Each ET-7000/PET-7000 module has a built-in EEPROM to store configuration information such as IP address, type code, etc. One minor drawback is that there are no visual indications of the configuration of the module. New ET-7000/PET-7000 modules include node information areas that are protected by a cover, as shown below, and can be used to make a written record of the node information, such as IP address, etc. To access the node information areas, first slide the covers outward, as shown in the figure below.




Appendix B. Modbus Application Notes

B.1. Dual Watchdog

Dual Watchdog consists of Module Watchdog and Host Watchdog.

1. The Module Watchdog is a built-in hardware circuit that will reset the CPU module if a failure occurs in either the hardware or the software. If the application does not refresh the watchdog timer within 0.8 seconds, the watchdog circuit will initiate a reset of the CPU.
2. The Host Watchdog is a software function that can be used to monitor the operating status of the host. Its purpose is to prevent network communication problems or a host failure. If the Watchdog timeout interval expires, the module will return all outputs to a predefined Safe value (Refer to the Safe Value application note), which can prevent the controlled target from unexpected situation.

AO address 40557 of the ET-7000/PET-7000 series Modbus register is the address of the Host Watchdog timer, and will be stored into EEPROM. The WDT function will be disabled if the value is set to less than 5 seconds.



B.2. Power ON Value

If the ET-7000/PET-7000 series module is reset, the output of the module is set to the predefined Power ON Value for the DO and AO channels. DO address 00435 of the ET-7000/PET-7000 series Modbus register is the first address of the Power ON value, and the total number of channels depend on the type of module.

For example:

Addresses 00435 to 00438 records the Power ON value for the 4-Channel ET-7017/PET-7017.

Be careful to set the ON value to DO address 00431 to write the DO Power ON value to the EEPROM of the ET-7000/PET-7000 DO module after using Modbus commands (05 or 15) to change the Power ON value.

Configuration via Web page

Browse to the homepage of the ET-7000/PET-7000, and click the “Modbus I/O Settings” link in the Configuration Section of the Main Menu tree.

Modbus Address	Function	Action
435	Power-on value for DO	0 OFF ☐ ON ☐
		1 OFF ☐ ON ☐
		2 OFF ☐ ON ☐
		3 OFF ☐ ON ☐
		4 OFF ☐ ON ☐
		5 OFF ☐ ON ☐
		6 OFF ☐ ON ☐
		7 OFF ☐ ON ☐

0=OFF 1=ON (default=0)

Click the ON/OFF radio box to set the power ON/OFF value and then click the button to enable the settings to take effect.

B.3. Safe Value

If the time of the Host PC losing Modbus/TCP communication with the module is greater than the host WatchDog timer setting (called WDT timeout), the output of the Digital and Analog channels is set to the Safe Value, and the count of the host WDT events is increased by one.

AO address 40558 is the address of the Host WDT events. The value of the WDT events will be not stored into EEPROM, and will return to 0 after the module is rebooted. DO address 00515 is the first address of the Safe value and the total number of channels depends on the type of module.

For example:

Address 00515 to 00518 records the Safe value for the 4-Channel ET-7017/PET-7017.

Be careful to set the ON value to DO address 00432 to write the DO Safe value to the EEPROM of the ET-7000/PET-7000 DO module after using Modbus commands (05 or 15) to change the Power ON value.

While the WDT timeout is set, the module can also receive the Modbus/TCP commands (05, 06, 15 and 16) to change the DO or AO value without needing to clear the host watchdog timeout value.

Configuration via Web page

Browse to the homepage of the ET-7000/PET-7000, and click the “Modbus I/O Settings” link in the Configuration Section of the Main Menu tree.

The screenshot shows a web interface for configuring DO Safe values. On the left, there is a label '515' and a text input field containing 'Safe value for DO'. On the right, there is a vertical list of eight radio button controls, numbered 0 through 7. Each control has 'OFF' and 'ON' options. The 'ON' option for control 0 is selected. Below the list, there is a note: '0=off/1=on (default=0)'. At the bottom center, there is a 'Submit' button.

Click the ON/OFF radio box to set the Safe value and then click the  button to enable the settings to take effect.

B.4. AI High/Low Alarm

ET-7017/PET-7017 and ET-7017-10 module equip with the High/Low Alarm function. When the alarm function is enabled, the specified registers are the alarm indicator. The alarm function is to compare the analog input value with given high alarm value and low alarm value.

Address 00636 to 00667 can be used to enable/disable the AI High Alarm function.

Address 00668 to 00699 can be used enable/disable the AI Low Alarm function.

• ET-7017/PET-7017 AI High/Low Alarm Switch Table

Channel Number	AI High Alarm		AI Low Alarm	
	Register	Description	Register	Description
AI0	00636	0: Disable/1: Enable	00668	0: Disable/1: Enable
AI1	00637	0: Disable/1: Enable	00669	0: Disable/1: Enable
AI2	00638	0: Disable/1: Enable	00670	0: Disable/1: Enable
AI3	00639	0: Disable/1: Enable	00671	0: Disable/1: Enable
AI4	00640	0: Disable/1: Enable	00672	0: Disable/1: Enable
AI5	00641	0: Disable/1: Enable	00673	0: Disable/1: Enable
AI6	00642	0: Disable/1: Enable	00674	0: Disable/1: Enable
AI7	00643	0: Disable/1: Enable	00675	0: Disable/1: Enable
AI8	00644	0: Disable/1: Enable	00676	0: Disable/1: Enable
AI9	00645	0: Disable/1: Enable	00677	0: Disable/1: Enable

Address 40296 to 40327 records the High Alarm value. Address 40328 to 40359 records the Low Alarm value. By the default, the High Alarm value is 32767 and the Low Alarm value is -32768.

• **ET-7017/PET-7017 AI High/Low Alarm Value Table**

Channel Number	High Alarm Value of AI		Low Alarm Value of AI	
	Register	Description	Register	Description
AI0	40296	-32768 ~ 32767	40328	-32768 ~ 32767
AI1	40297	-32768 ~ 32767	40329	-32768 ~ 32767
AI2	40298	-32768 ~ 32767	40330	-32768 ~ 32767
AI3	40299	-32768 ~ 32767	40331	-32768 ~ 32767
AI4	40270	-32768 ~ 32767	40332	-32768 ~ 32767
AI5	40271	-32768 ~ 32767	40333	-32768 ~ 32767
AI6	40272	-32768 ~ 32767	40334	-32768 ~ 32767
AI7	40273	-32768 ~ 32767	40335	-32768 ~ 32767
AI8	40274	-32768 ~ 32767	40336	-32768 ~ 32767
AI9	40275	-32768 ~ 32767	40337	-32768 ~ 32767

The analog input High/Low Alarm contains two alarm types, Momentary Alarm and Latch Alarm. Address 00700 of Modbus register can be used to set the High Alarm type of channel 0 and the total number of channels depends on the type of module. Address 00732 of Modbus register can be used to set the Low Alarm type of channel 0.

• **ET-7017/PET-7017 AI High/Low Type Value Table**

Channel Number	AI High Alarm Type		AI Low Alarm Type	
	Register	Description	Register	Description
AI0	00700	0: Momentary Alarm 1: Latch Alarm	00732	0: Momentary Alarm 1: Latch Alarm
AI1	00701	0: Momentary Alarm 1: Latch Alarm	00733	0: Momentary Alarm 1: Latch Alarm
AI2	00702	0: Momentary Alarm 1: Latch Alarm	00734	0: Momentary Alarm 1: Latch Alarm
AI3	00703	0: Momentary Alarm 1: Latch Alarm	00735	0: Momentary Alarm 1: Latch Alarm
AI4	00704	0: Momentary Alarm 1: Latch Alarm	00736	0: Momentary Alarm 1: Latch Alarm
AI5	00705	0: Momentary Alarm 1: Latch Alarm	00737	0: Momentary Alarm 1: Latch Alarm
AI6	00706	0: Momentary Alarm 1: Latch Alarm	00738	0: Momentary Alarm 1: Latch Alarm
AI7	00707	0: Momentary Alarm 1: Latch Alarm	00739	0: Momentary Alarm 1: Latch Alarm
AI8	00708	0: Momentary Alarm 1: Latch Alarm	00740	0: Momentary Alarm 1: Latch Alarm
AI9	00709	0: Momentary Alarm 1: Latch Alarm	00741	0: Momentary Alarm 1: Latch Alarm

The following are the descriptions for two alarm types.

- **Momentary Alarm**

The alarm status is cleared while the analog input is not exceeding the alarm value.

For example:

If analog input value of channel 0 (30001) > High Alarm value (40296), the address 00764 is 1, else it is 0.

If analog input Value of channel 0 (30001) < Low Alarm value (40328), the address 00796 is 1, else it is 0.

The address 00764 to 00795 is the High alarm indicator. If a High alarm occurred, the value of register is 1. In normal condition, it will be 0. The address 00796 to 00827 is the Low alarm indicator. If a Low alarm occurred, the value of register is 1. In normal condition, it will be 0.

- **Latch Alarm**

When the Latch Alarm mode is enabled, the register stays latched until the specified registers are cleared.

For example:

If analog input value of channel 0 (30001) > High Alarm value (40296), the address 00764 is 1, else if analog input value of channel 0 (30001) < Low Alarm value (40328), the address 00796 is 1.

The address 00764 to 00795 is the High alarm indicator. In normal condition, the value of register is 0. If a High alarm occurred, the value of register stays 1 until the address 00764 to 00795 is cleared. The address 00796 to 00827 is the Low alarm indicator. In normal condition, the value of register is 0. If a Low alarm occurred, the value of register stays 1 until the address 00796 to 00827 is cleared.

The address 00764 to 00795 can be used to clear the High Latch Alarm. The address 00796 to 00827 can be used to clear the Low Latch Alarm.

Configuration via Web page

Browse to the homepage of the ET-7000/PET-7000, and click the “Modbus I/O Settings” link in the Configuration Section of the Main Menu tree.

Modbus Settings (AI High/Low Alarm)

Modbus Address	Function	Action
636	AI Alarm High Switch	0 OFF ☐ ON ☒
		1 OFF ☐ ON ☒
		2 OFF ☐ ON ☒
		3 OFF ☐ ON ☒
		4 OFF ☐ ON ☒
		5 OFF ☐ ON ☒
		6 OFF ☐ ON ☒
		7 OFF ☐ ON ☒

View the Power ON/Safe Value via Web page

Click the “Web HMI” link in the Web HMI Section of the Main Menu tree.

Analog Alarm High/Low Value				
No	High Alarm		Low Alarm	
	Register	Value	Register	Value
AI0	30764	0000	30796	0000
AI1	30765	0000	30797	0000
AI2	30766	0000	30798	0000
AI3	30767	0000	30799	0000
AI4	30768	0000	30800	0000
AI5	30769	0100	30801	0000
AI6	30770	0101	30802	0000
AI7	30771	0001	30803	0000

B.5. AI High/Low Latch


The address 30236 to 30267 records the maximum value of analog inputs and stays the value until another maximum input enters. The address 30268 to 30299 records the minimum value of analog inputs and stays the value until another minimum input enters.

View the Power ON/Safe Value via Web page

Click the “Web HMI” link in the Web HMI Section of the Main Menu tree.

Analog Latched High/Low Value				
No	Latched High		Latched Low	
	Register	Value	Register	Value
AI0	30236	0019	30268	FFD2
AI1	30237	0018	30269	FFED
AI2	30238	0021	30270	FFE5
AI3	30239	0016	30271	FFEC
AI4	30240	002A	30272	FFEC
AI5	30241	0018	30273	FFE0
AI6	30242	0018	30274	FFE9
AI7	30243	0013	30275	FFE9

Moving average value of one AI channel



$$V_{Ave_n} = (V_n + V_{n-1} + V_{n-1} + V_{n-3} + \dots + V_{n-6}) / 7 \quad (7: 7 \text{ records})$$

The average value of each AI can be reached on a regular interval when the moving average function is enabled.

For example, a five-item simple moving average would be the sum of the reading value of the five most recent reading value, divided by five; a 20-item moving average would be the sum of the 20 most recent reading value divided by 20, and so on. Each item the most recent reading value is added to the equation and the most distant item is dropped off.

Register	Description
00347	Enable the moving value of the AI channels 0=Disabled 1=Enabled (Default=0)
40059	Average times for each AI channel 0 ~ 40

Address 30144 to 30153 recodes the average value of each AI channel.


• **ET-7017/PET-7017 Average value of one channel Table**

Channel Number	Register	Description
AI0	30144	0 ~65535 or -32768 ~ +32767
AI1	30145	0 ~65535 or -32768 ~ +32767
AI2	30146	0 ~65535 or -32768 ~ +32767
AI3	30147	0 ~65535 or -32768 ~ +32767
AI4	30148	0 ~65535 or -32768 ~ +32767
AI5	30149	0 ~65535 or -32768 ~ +32767
AI6	30150	0 ~65535 or -32768 ~ +32767
AI7	30151	0 ~65535 or -32768 ~ +32767
AI8	30152	0 ~65535 or -32768 ~ +32767
AI9	30153	0 ~65535 or -32768 ~ +32767

Average value of all AI channel

The value of all AI channel is obtained on a regular interval. The average of AI channels can be reached and then stored in the specified registers.

Register	Description
00348	Enable the average value of all enabled channels, High/Low Alarm value of all AI average value and Average Latched values. 0=Disabled 1=Enabled (Default=0)
30176	Average value of all enabled AI channel. Address 00595~00626 is used to enable/disable the AI channel. 0 ~ 65535 or -32768 ~ +32767



$$V_{Ave_all} = (V_0 + V_1 + V_2 + V_3 + \dots + V_n) / n \quad (n: n \text{ records})$$

High/Low Alarm of the average value of all AI channels

The average value of all AI channels also can equip with the alarm function like the AI High/Low Alarm. For the detailed description, please refer the AI High/Low Alarm.

Register	Description
10336	High alarm for the average value of all AI registers 0=normal 1=alarm
10337	Low alarm for the average value of all AI registers 0=normal 1=alarm
40198	High alarm value for Average value of all AI channels 0 ~ 65535 or -32768 ~ +32767
40199	Low alarm value for Average value of all AI channels 0 ~ 65535 or -32768 ~ +32767

Appendix C. Troubleshooting

A number of common problems are easy to diagnose and fix if you know the cause.

Symptom/Problem	Possible cause	Solution
The Run LED doesn't light	Internal power has failed	Return the module for repair.
The Run LED indicator is ON (light), but not flashing.	The module has possibly crashed.	Reboot the module
Cannot communicate via the Ethernet port, but the ET-7000/PET-7000 is still operating.	The IP/Mask/Gateway address isn't within the IP address range of the LAN.	Change the IP/Mask/Gateway address to match the LAN, or ask the MIS administrator for assistance.
	The IP address has restricted by the IP filter settings	Check the IP filter setting using the Web configuration.
	There are more than 30 TCP/IP connections.	Reboot the module.
Able to explore the web page through port 80 using a web browser, but the Web HMI and Modbus/TCP program cannot access the module through port 502.	Port 502 has been restricted by the firewall.	Consult your MIS administrator for assistance.
The Web HMI and Modbus/TCP program can access the module through port 502, but Web browser cannot explore the web page through port 80 using a web browser.	The Port 502 has restricted by the firewall.	Consult your MIS administrator for assistance.
	The Web Configuration function has been disabled. (Shown on the Basic Settings page)	Enable the Web Configuration function using either the SMMI or the console.
	The Web server TCP port has been changed from port 80 (Shown on the Basic Settings page)	Change the TCP port to 80 or reconnect the ET-7000/PET-7000 using the specific TCP port.