




Arduino Mini



Overview

The Arduino Mini is a small microcontroller board based on the ATmega168 ([datasheet](#)), intended for use on breadboards and when space is at a premium. It has 14 digital input/output pins (of which 6 can be used as PWM outputs), 8 analog inputs, and a 16 MHz crystal oscillator. It can be programmed with the [Mini USB adapter](#) or other USB or RS232 to TTL serial adapter.

Warning: Don't power the Arduino mini with more than 9 volts, or plug the power in backwards: you'll probably kill it.

Summary

Microcontroller	ATmega168
Operating Voltage	5V Input Voltage 7-9 V
Digital I/O Pins	14 (of which 6 provide PWM output)
Analog Input Pins	8 (of which 4 are broken out onto pins) DC Current per I/O Pin 40 mA
Flash Memory	16 KB (of which 2 KB used by
bootloader) SRAM	1 KB
EEPROM	512 bytes
Clock Speed	16 MHz

Programming

The Arduino Mini can be programmed with the Arduino software ([download](#)). For details, see the [reference](#) and [tutorials](#).

To program the Arduino Mini, you will need a [Mini USB adapter](#) or other USB or RS232 to TTL serial adapter. See the page on [getting started with the Arduino Mini](#) for instructions.

The ATmega168 on the Arduino Mini comes preburned with a [bootloader](#) that allows you to upload new code to it without the use of an in-system-programmer. The bootloader communicates using the original STK500 protocol ([reference](#), [C header files](#)).

You can also bypass the bootloader and program the ATmega168 with ICSP (In-Circuit Serial Programming); see the page on [bootloading the Mini](#) for information on wiring up an ICSP header to the Mini and the [programmer](#) for instructions on using a programmer to upload a sketch.

Input and Output

Each of the 14 digital pins on the Mini can be used as an input or output. They operate at 5 volts. Each pin can provide or receive a maximum of 40 mA and has an internal pull-up resistor (disconnected by default) of 20-50 kOhms. Pins 3, 5, 6,


9, 10, and 11 can provide PWM output; for details see the [analogWrite\(\)](#) function. If anything besides the Mini USB (or other) adapter is connected to pins 0 and 1, it will interfere with the USB communication, preventing new code from being uploaded or other communication with the computer.

The Mini has 8 analog inputs, each of which provide 10 bits of resolution (i.e. 1024 different values). Inputs 0 to 3 are broken out onto pins; input 4 to 7 require soldering into the provided holes. By default the analog inputs measure from ground to 5 volts, though it is possible to change the upper end of their range using the AREF pin and some low-level code.


See also the [mapping between Arduino pins and ATmega168 ports](#).

Pinout

Note: the pinout changed from version 03 to version 04 of the Mini, please be sure you use the right diagram.



Pin out of the Arduino Mini 03. (older versions are compatible, but missing the IO7 header at the top)



Pin out of the Arduino Mini 04. (Note that the ground pin on the left has moved down one pin.)

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[Arduino:](#)

[A000004-ML](#)