

Advanced 1/16 DIN Preset Counter with Enhanced Features

- Configure as a 1-stage or 2-stage, total, batch, or dual counter; or use as a tachometer (configurability depends on model)
- High-speed response of up to 5 kHz and can be scaled to 10 kHz
- Programmable display color to alert any output status change
- All parameters can be set via front membrane keys or DIP switches
- PNP/NPN selectable input
- Key protection function
- NEMA4/IP66 front



Ordering Information

■ Standard Counters (1 Stage)

Six-digit type

Item		Part number	
12 VDC	Output type	11-pin socket	Screw terminal
	Contact output	H7CX-A11 AC100-240	H7CX-A AC100-240
		H7CX-A11D1 DC12-24/AC24	---
	Transistor output	H7CX-A11S AC100-240	H7CX-AS AC100-240
		H7CX-A11SD1 DC12-24/AC24	---
None	Contact output	---	H7CX-AD DC12-24
	Transistor output	---	H7CX-ASD DC12-24

Four-digit type

Item		Part number	
12 VDC	Output type	11-pin socket	Screw terminal
	Contact output	H7CX-A114 AC100-240	H7CX-A4 AC100-240
		H7CX-A114D1 DC12-24/AC24	---
	Transistor output	H7CX-A114S AC100-240	H7CX-A4S AC100-240
None	Contact output	---	H7CX-A4D DC12-24
	Transistor output	---	H7CX-A4SD DC12-24

■ Advanced Counters (2 Stage)

Six-digit type

Item		Part number	
12 VDC	Output type	Screw terminal – non-configurable output	Screw terminal – configurable output
	Contact output	H7CX-AW AC100-240	---
		H7CX-AWD1 DC12-24/AC24	---
	Transistor output	H7CX-AWS AC100-240	---
		H7CX-AWSD1 DC12-24/AC24	H7CX-AUSD1 DC12-24/AC24
	Contact and Transistor output	---	H7CX-AU AC100-240
		---	H7CX-AUD1 DC12-24/AC24
None	Transistor output	H7CX-AWSD DC12-24	---
		H7CX-A4WSD DC12-24	---

Four-digit type

Item	Part number	
Sensor power supply	Output type	Screw terminal
12 VDC	Contact output	H7CX-A4W AC100-240

■ Model Number Legend:

H7CX-A□□□□□□

1 2 3 4 5 6

1. External connection

None: Screw terminals
11: 11-pin socket

2. No. of digits

None: 6 digits
4: 4 digits

3. Stage setting

None: 1-stage setting
U: Factory-set to 1-stage setting
W: Factory-set to 2-stage setting

4. Output type

None: Contact output or contact and transistor in combination
S: Transistor output

5. Supply voltage/external power supply

None: 100 to 240 VAC at 50/60 Hz with 12 VDC power supply
D: 12 to 24 VDC without external power supply
D1: 12 to 24 VDC or 24 VAC at 50/60 Hz with 12 VDC power supply

6. Case color

None: Black
G: Light gray (Munsell 5Y7/1): Produced upon request.

■ Accessories (Order Separately)

Name	Part number	
Flush mounting adapter (See note 1.)	Y92F-30	
Waterproof packing (See note 1.)	Y92S-29	
Track mounting/front connecting socket	11-pin	P2CF-11
	11-pin, finger-safe type	P2CF-11-E
Back connecting socket	11-pin	P3GA-11
	11-pin, finger-safe type	P3GA-11 with Y92A-48G (See note 2.)
Hard cover	Y92A-48	
Soft cover	Y92A-48F1	
Mounting track	50 cm (l) × 7.3 mm (t)	PFP-50N
	1 m (l) × 7.3 mm (t)	PFP-100N
	1 m (l) × 16 mm (t)	PFP-100N2
End plate	PFP-M	
Spacer	PFP-S	

Note: 1. Supplied with screw-terminal models (i.e., excluding H7CX-A11□/-A114□ models).

2. Y92A-48G is a finger-safe terminal cover attached to the P3GA-11 Socket.

Specifications

■ Standard Counter Ratings

Item	H7CX-A4□	H7CX-A□	H7CX-A114□	H7CX-A11□
Classification	Preset counter			
Supported configurations (selectable)	1-stage counter, 1-stage counter with total counter			
Rated supply voltage (See note 1.)	100 to 240 VAC (50/60 Hz), 12 to 24 VDC	100 to 240 VAC (50/60 Hz) 24 VAC (50/60 Hz)/12 to 24 VDC		
Operating voltage range	85% to 110% of rated supply voltage (90% to 110% at 12 VDC)			
Power consumption	Approx. 9.2 VA at 264 VAC Approx. 7.2 VA at 26.4 VAC Approx. 3.7 W at 12 VDC			
Mounting method	Flush mounting	Flush mounting, surface mounting, or DIN track mounting		
External connections	Screw terminals	11-pin socket		
Terminal screw tightening torque	0.5 N·m max.	---		
Display	7-segment, negative transmissive LCD;			
PV	11.5 mm-high characters, red or green (programmable)	9 mm-high characters, red or green (programmable)	11.5-mm high characters, red	9 mm-high characters, red
	SV	6 mm-high characters, green		
Digits	4 digits (-999 to 9,999) SV range: 0 to 9,999	6 digits (-99,999 to 999,999) SV range: -99,999 to 999,999 (See note 2.) or 0 to 999,999	4 digits (-999 to 9,999) SV range: 0 to 9,999	6 digits (-99,999 to 999,999) SV range: -99,999 to 999,999 (See note 2.) or 0 to 999,999
Max. counting speed	30 Hz or 5 kHz (selectable, ON/OFF ratio 1:1), common setting for CP1 and CP2			
Input modes	Increment, decrement, command, individual, and quadrature			
Input signals	CP1, CP2, reset, and total reset			
Input method	No-voltage input/voltage input (switchable) No-voltage input ON impedance: 1 kΩ max. (Leakage current: 5 to 20 mA at 0 Ω) ON residual voltage: 3 V max. OFF impedance: 100 kΩ min. Voltage input High (logic) level: 4.5 to 30 VDC Low (logic) level: 0 to 2 VDC (Input resistance: approx. 4.7 kΩ)			
Reset input	Minimum reset input signal width: 1 or 20 ms (selectable), common setting for all inputs			
Reset system	External, manual, and automatic reset (internal according to C, R, P, and Q mode operation)			
Output modes	N, F, C, R, K-1, P, Q, A (8)	N, F, C, R, K-1, P, Q, A, K-2, D, L (11)	N, F, C, R, K-1, P, Q, A (8)	N, F, C, R, K-1, P, Q, A, K-2, D, L (11)
One-shot output time	0.01 to 99.99 s			
Output type	Contact type: SPDT Transistor type: 1 transistor			
Control output	Contact output: 3 A at 250 VAC/30 VDC, resistive load ($\cos\phi=1$) Minimum applied load: 10 mA at 5 VDC (failure level: P, reference value) Transistor output: NPN open collector, 100 mA at 30 VDC Residual voltage: 1.5 VDC max. (approx. 1 V) Leakage current: 0.1 mA max. NEMA B300 Pilot Duty, 1/4 HP 5-A resistive load at 120 VAC, 1/3 HP 5-A resistive load at 240 VAC			
External power supply	12 VDC ($\pm 10\%$), 100 mA (except for H7CX-A□D models) Refer to <i>Precautions</i> for details.			
Key protection	Yes			
Prescaling function	Yes (0.001 to 9.999)	Yes (0.001 to 99.999)	Yes (0.001 to 9.999)	Yes (0.001 to 99.999)
Decimal point adjustment	Yes (rightmost 3 digits)			
Sensor waiting time	250 ms max. (Control output is turned OFF and no input is accepted during sensor waiting time.)			
Memory backup	EEPROM (overwrites: 100,000 times min.) that can store data for 10 years min.			
Ambient temperature	Operating: -10 to 55°C (14 to 131°F), -10 to 50°C (14 to 122°F) if counters are mounted side by side, with no icing or condensation Storage: -25 to 65°C (-13 to 149°F) with no icing or condensation			
Ambient humidity	25% to 85%			
Case color	Black (N1.5)			
Attachments	Waterproof gasket, panel-mounting adapter	None		

Note: 1. Permissible ripple: 20% (p-p) max.

2. Only when the following modes are selected.

Input mode: command, individual, or quadrature; output mode: K-2, D, or L

■ Multifunction Counter Ratings

Item	H7CX-A4W□	H7CX-AW□	H7CX-AU□
Classification	Preset counter	Preset counter/tachometer	
Supported configurations (selectable)	1-stage counter, 2-stage counter, 1-stage counter with total counter, 1-stage counter with batch counter, dual counter		
Rated supply voltage (See note 1.)	100 to 240 VAC (50/60 Hz), 12 to 24 VDC	100 to 240 VAC (50/60 Hz), 24 VAC (50/60 Hz)/12 to 24 VDC, 12 to 24 VDC	100 to 240 VAC (50/60 Hz), 24 VAC (50/60 Hz)/12 to 24 VDC
Operating voltage range	85% to 110% of rated supply voltage (90% to 110% at 12 VDC)		
Power consumption	Approx. 9.2 VA at 264 VAC, Approx. 7.2 VA at 26.4 VAC, Approx. 3.7 W at 12 VDC		
Mounting method	Flush mounting		
External connections	Screw terminals		
Terminal screw tightening torque	0.5 N·m max.		
Display	7-segment, negative transmissive LCD		
	PV	11.5 mm-high characters, red or green (programmable)	9 mm-high characters, red or green (programmable)
	SV	6 mm-high characters, green	
Digits	4 digits (-999 to 9,999) SV range: 0 to 9,999	6 digits (-99,999 to 999,999 or 0 to 999,999 when using as Tachometer) SV range: -99,999 to 999,999 (See note 2.) or 0 to 999,999	
Input signals	CP1, CP2, reset 1, and reset 2		
Input method	No-voltage input/voltage input (switchable) No-voltage input ON impedance: 1 kΩ max. (Leakage current: 5 to 20 mA at 0 Ω) ON residual voltage: 3 V max. OFF impedance: 100 kΩ min. Voltage input High (logic) level: 4.5 to 30 VDC Low (logic) level: 0 to 2 VDC (Input resistance: approx. 4.7 kΩ)		
Counter	Max. counting speed	30 Hz or 5 kHz (selectable, ON/OFF ratio 1:1), common setting for CP1 and CP2	
	Input mode	Increment, decrement, command, individual, and quadrature	
	Reset input	Minimum reset input signal width: 1 or 20 ms (selectable), common setting for all inputs	
	Reset system	External, manual, and automatic reset (internal according to C, R, P, and Q mode operation)	
	Output modes	N, F, C, R, K-1, P, Q, A (8)	N, F, C, R, K-1, P, Q, A, K-2, D, L, H (12)
	One-shot output time	0.01 to 99.99 s	
Tachometer	Pulse measurement method	---	Periodic measurement (Sampling period: 200 ms)
	Max. counting speed	---	30 Hz or 10 kHz (selectable)
	Measuring ranges	---	30 Hz: 0.01 to 30.00 Hz 10 kHz: 0.01 Hz to 10 kHz
	Measuring accuracy	---	±0.1% FS ±1 digit max. (at 23 ±5°C)
	Output modes	---	HI-LO, AREA, HI-HI, LO-LO
	Auto-zero time	---	0.1 to 99.9 s
	Startup time	---	0.0 to 99.9 s
	Average processing	---	OFF/2/4/8 times
Output type	H7CX-A4W/-AW/-AWD1: SPDT (OUT2) and SPST-NO (OUT1) H7CX-A4WSD/-AWS/-AWSD/-AWS1: 2 transistors		H7CX-AU/-AUD1: SPDT and 1 transistor H7CX-AUSD1: 2 transistors (Output allocation possible)
Control output	Contact output: 3 A at 250 VAC/30 VDC, resistive load ($\cos\phi=1$) Minimum applied load: 10 mA at 5 VDC (failure level: P, reference value) Transistor output: NPN open collector, 100 mA at 30 VDC Residual voltage: 1.5 VDC max. (approx. 1 V) Leakage current: 0.1 mA max. NEMA B300 Pilot Duty, 1/4 HP 5-A resistive load at 120 VAC, 1/3 HP 5-A resistive load at 240 VAC		
External power supply	12 VDC (±10%) 100 mA (except for H7CX-A□D models) Refer to <i>Precautions</i> for details.		
Key protection	Yes		
Prescaling function	Yes (0.001 to 9,999)	Yes (0.001 to 99,999)	
Decimal point adjustment	Yes (rightmost 3 digits)		
Sensor waiting time	250 ms max. (Control output is turned OFF and no input is accepted during sensor waiting time.)		
Memory backup	EEPROM (overwrites: 100,000 times min.) that can store data for 10 years min.		
Ambient temperature	Operating: -10 to 55°C (14 to 131°F), -10 to 50°C (14 to 122°F) if counters are mounted side by side, with no icing or condensation Storage: -25 to 65°C (-13 to 149°F) with no icing or condensation		
Ambient humidity	25% to 85%		
Case color	Black (N1.5)		
Attachments	Waterproof gasket, panel-mounting adapter		

Note: 1. Permissible ripple: 20% (p-p) max.

2. Only when the following modes are selected.

- Input mode: command, individual, or quadrature; output mode: K-2, D, L, or H
- Dual count calculating mode: SUB; output mode: K-2, D, L, or H in dual counter operation

■ Characteristics


Item	H7CX
Insulation resistance	100 MΩ min. (at 500 VDC) between current-carrying terminal and exposed non-current-carrying metal parts, and between non-continuous contacts
Dielectric strength	2,000 VAC, 50/60 Hz for 1 min between current-carrying metal parts and non-current-carrying metal parts 2,000 VAC (for 100 to 240 VAC), 50/60 Hz for 1 min between power supply and input circuit (1,000 VAC for 24 VAC/12 to 24 VDC) 1,000 VAC (for H7CX-□SD/-□SD1), 50/60 Hz for 1 min between control output, power supply, and input circuit (2,000 VAC for models other than H7CX-□SD/-□SD1) 1,000 VAC, 50/60 Hz for 1 min between non-continuous contacts
Impulse withstand voltage	3 kV (between power terminals) for 100 to 240 VAC, 1 kV for 24 VAC/12 to 24 VDC and 12 to 24 VDC 4.5 kV (between current-carrying terminal and exposed non-current-carrying metal parts) for 100 to 240 VAC, 1.5 kV for 24 VAC/12 to 24 VDC and 12 to 24 VDC
Noise immunity	±1.5 kV (between power terminals) for 100 to 240 VAC and 24 VAC/12 to 24 VDC, ±480 V for 12 to 24 VDC ±600 V (between input terminals) Square-wave noise by noise simulator (pulse width: 100 ns/1 μs, 1-ns rise)
Static immunity	Destruction: 15 kV Malfunction: 8 kV
Vibration resistance	Destruction: 10 to 55 Hz with 0.75-mm single amplitude each in three directions Malfunction: 10 to 55 Hz with 0.35-mm single amplitude each in three directions
Shock resistance	Destruction: 294 m/s ² each in three directions Malfunction: 98 m/s ² each in three directions
Life expectancy	Mechanical: 10,000,000 operations min. Electrical: 100,000 operations min. (3 A at 250 VAC, resistive load)
Approved safety standards (See note 1.)	UL508/Listing, CSA C22.2 No. 14, conforms to EN61010-1 (Pollution degree 2/overvoltage category II) Conforms to VDE0106/P100 (finger protection).
EMC	(EMI) Emission Enclosure: EN61326 Emission AC mains: EN55011 Group 1 class A (EMS) Immunity ESD: EN61326 EN61000-4-2: 4 kV contact discharge (level 2) 8 kV air discharge (level 3) Immunity RF-interference: EN61000-4-3: 10 V/m (Amplitude-modulated, 80 MHz to 1 GHz) (level 3); 10 V/m (Pulse-modulated, 900 MHz ±5 MHz) (level 3) Immunity Conducted Disturbance: EN61000-4-6: 10 V (0.15 to 80 MHz) (according to EN61000-6-2) Immunity Burst: EN61000-4-4: 2 kV power-line (level 3); 1 kV I/O signal-line (level 4) Immunity Surge: EN61000-4-5: 1 kV line to lines (power and output lines) (level 2); 2 kV line to ground (power and output lines) (level 3) Immunity Voltage Dip/Interruption EN61000-4-11: 0.5 cycle, 100% (rated voltage)
Degree of protection	Panel surface: IP66 and NEMA Type 4 (indoors) (See note 2.)
Weight	Approx. 140 g

Note: 1. To meet UL listing requirements with the H7CX-A11□ models, an OMRON P2CF-11-□ or P3GA-11 Socket must be mounted on the H7CX. If any other manufacturers sockets are used, H7CX-A11□ models will only meet UL508 recognition requirements.


2. A waterproof packing is necessary to ensure IP66 waterproofing between the H7CX and installation panel.

■ Engineering Data (Reference Values)

Electrical Life Expectancy (Resistive Load)



Electrical Life Expectancy (Inductive Load)



Reference: A current of 0.15 A max. can be switched at 125 VDC (cosφ=1) and current of 0.1 A max. can be switched if L/R=7 ms. In both cases, a life of 100,000 operations can be expected. The minimum applicable load is 10 mA at 5 VDC (failure level: P).

Nomenclature

Indicators

① Reset Indicator (Orange)
Lit when the reset input (1) or reset key is ON.

② Key Protection Indicator (Orange)

③ Control Output Indicator (Orange)
OUT: One stage
OUT1, OUT2: Two stages


④ Total Count Indicator
Lit when the total count value is displayed.

⑤ Batch Indicator
Lit when the batch count value is displayed.


⑥ Set Value 1, 2 Stage Indicator

⑦ Present Value (Main Display)
Character height: 11.5 mm (6-digit: 9 mm)


⑧ Set Value (Sub-display)
Character height: 6 mm



Front view of 4-digit model



Front view of 6-digit model



Operation Keys

⑨ Mode Key
Used to switch mode and setting items.

⑩ Reset Key
The operation of the reset function depends on the configuration selected as shown in the table below.

⑪ Up Keys: 1 to 4
(6-digit models: 1 to 6)

⑫ Down Keys: 1 to 4

Switches

⑬ Key Protect Switch
(Factory setting) OFF ON




⑭ DIP Switch

Reset Operation by Reset Key

Configuration	Reset operation
1-stage/2-stage counter	Resets the present value and outputs.
Total and preset counter	<ul style="list-style-type: none"> Resets the present value and outputs. When the total count value is displayed, resets the present value, the total count value, and outputs.
Batch counter	<ul style="list-style-type: none"> Resets the present value and OUT2. When the batch count value is displayed, resets the present value, the batch count value, and outputs.
Dual counter	Resets the CP1 present value, CP2 present value, dual count value, and outputs.
Tachometer	Maintains the measured value and outputs (hold function).

Operation

■ Block Diagram



Note: All models except for H7CX-□D (models with 12 to 24-VDC power supplies) have basic insulation.

■ I/O Functions

Using as a Counter

Inputs	CP1, CP2	<ul style="list-style-type: none"> In general (except for dual counter mode) Reads counting signals Increment, decrement, command, individual, and quadrature inputs accepted. When used as a dual counter Reads CP1 count signals with CP1 input and CP2 count signals with CP2 input. Increment signals can be input.
	Reset or Reset 1	<ul style="list-style-type: none"> In general (except for dual counter mode) Resets present value and outputs (OUT2 when using the batch counter). (See note.) Counting cannot be performed during reset/reset 1 input. The reset indicator is lit during reset input. When used as a dual counter Resets the CP1 present value (to 0). Counting for CP1 input cannot be performed during reset 1 input. The reset indicator is lit during reset 1 input.
	Total Reset or Reset 2	<ul style="list-style-type: none"> When used as a 1-stage/2-stage counter Does not operate (Not used). When used as a total and preset counter Resets the total count value. Hold the total count value at 0 during total reset input. When used as a batch counter Rest the batch count value and batch output (OUT1). Holds the batch count value at 0 during reset 2 input. When used as a dual counter Resets the CP2 present value. Counting for CP2 input cannot be performed during reset 2 input.
Outputs	OUT1, OUT2	Outputs take place according to designated output mode when corresponding preset is reached.

Note: In increment mode or increment/decrement mode, the present value returns to 0; in decrement mode, the present value returns to the set value with 1-stage models, and returns to set value 2 with 2-stage models.

Using as a Tachometer

Inputs	CP1, CP2	Reads counting signals. (CP2 input is not used.)
	Reset 1, Reset 2	Holds the measurement value and outputs. (Reset 2 input is not used.) The reset indicator is lit during hold.
Outputs	OUT1, OUT2	Outputs signals according to the specified output mode when a set value is reached.

Setting Procedure Guide

■ Setting for Counter Operation

(1-stage/2-stage Counter, Total and Preset Counter, Batch Counter, Dual Counter)

When Using Basic Settings Only

- Basic Settings
 - Counting speed (30 Hz, 5 kHz)
 - Input mode (UP, DOWN)
 - Output mode (N, F, C, K-1)
 - One-shot output time (0.5 s, 0.05 s) (See note 2.)
 - Reset input signal width (20 ms, 1 ms)
 - NPN/PNP input mode (NPN, PNP)

The settings can be performed easily with the DIP switch.
→For detailed setting methods, refer to *Quick Setup - Basic Counter Operation*



When Using Settings Other than the Above

All the functions can be set with the operation keys.
→For detailed setting methods, refer to *Quick Setup - Advanced Counter Operation*

- Other Settings
 - Input mode (UP/DOWN A, UP/DOWN B, UP/DOWN C)
 - Output mode (R, P, Q, A, K-2, D, L, H)
 - One-shot output time (except for 0.5 s and 0.05 s) (See note 2.)

When Using Advanced Functions

Settings for advanced functions other than the basic settings above can be performed with the operation keys.
→For detailed setting methods, refer to *Quick Setup - Advanced Counter Operation*

- Advanced Functions
 - Dual count calculating mode
 - Output 1 time (for 2-stage counter)
 - Decimal point position
 - Prescale value
 - Display color
 - Output allocation
 - Key protect level


Note: 1. At the time of delivery, the H7CX is set to the 1-stage counter (2-stage counter for H7CX-AW□/-A4W□ models) configuration.
2. Set to output 2 time when using as a 2-stage counter or batch counter.

■ Setting for Tachometer Operation

When Using Basic Settings Only

- Basic Settings
 - Counting speed (30 Hz, 5 kHz)
 - Output mode (HI-LO, AREA, HI-HI, LO-LO)
 - Average processing (OFF, 2, 4, 8 times)
 - NPN/PNP input mode (NPN, PNP)

The settings can be performed easily with the DIP switch.
→For detailed setting methods, refer to *Quick setup - Basic Tachometer Operation*.



When Using Advanced Functions

Settings for advanced functions other than the basic settings above can be performed with the operation keys.
→For detailed methods, refer to *Quick setup - Advanced Tachometer Operation*.


- Advanced Functions
 - Decimal point position
 - Prescale value
 - Auto-zero time
 - Startup time
 - Display color
 - Output allocation
 - Key protect level

Note: At the time of delivery, the H7CX is set to the 2-stage counter (1-stage counter for H7CX-AU□ models) configuration.

Operation — Counter Function

■ Quick Setup — Basic Counter Operation

Settings for basic functions can be performed with just the DIP switch.



	Item	OFF	ON
1	DIP switch settings enable/disable	Disabled	Enabled
2	Counting speed	30 Hz	5 kHz
3	Input mode	UP (increment)	DOWN (decrement)
4	Output mode	Refer to the table on the right.	
5			
6	One-shot output time (See note.)	0.5 s	0.05 s
7	Reset input signal width	20 ms	1 ms
8	NPN/PNP input mode	NPN	PNP

Note: Set to one-shot output 2 time when using as a 2-stage counter or batch counter.

Easy Confirmation of Switch Settings Using Indicators

The ON/OFF status of the DIP switch pins can be confirmed using the front display. For details, refer to *Operation in Configuration Selection Mode*.

Pin 4	Pin 5	Output mode
OFF	OFF	N
ON	OFF	F
OFF	ON	C
ON	ON	K-1

Note:

1. Be sure to set pin 1 of the DIP switch to ON. If it is set to OFF, the DIP switch settings will not be enabled.
2. Changes to DIP switch settings are enabled when the power is turned ON.
3. When setting input modes, output modes, or output times that cannot be set with the DIP switch, all of the settings have to be made using the operation keys. For detailed setting methods, refer to *Quick Setup - Advanced Counter Operation*. When making settings using the operation keys, be sure to set pin 1 of the DIP switch to OFF.



Switching to Total and Preset Counter, Batch Counter, and Dual Counter Operation (See note.)

The H7CX is factory-set to the 1-stage counter (2-stage counter for H7CX-AW□/-A4W□ models) configuration. To change to a different configuration, use the procedure shown on the right.

Note: This includes changing to the 2-stage counter (or 1-stage counter) configuration.

Power ON

Configuration selection mode

Funct

Hold down for 1 s min. (See note.)

Run mode

0

Note: **T**_{MODE} key must be pressed before the **SET** key.

Select the configuration using the **▲** and **▼** keys (**▲** key with 6-digit models).

→ 1st nk ← → 2st nk ← → t nk ← → b nk ← → d nk ← → t RL nk ← →

(1-stage counter) (2-stage counter) (Total and preset counter) (Batch counter) (Dual counter) (Tachometer)

Note: The configurations that can be selected vary with the model.




Advanced-Function Settings

After making DIP switch settings for basic operation, advanced functions (see note) can be added using the operation keys. For details, refer to *Quick Setup - Advanced Counter Operation*

Note: Advanced functions consist of the dual count calculating mode, output 1 time (for 2-stage counter), decimal point position, prescale value, display color, output allocation, and key protect level.

■ Quick Setup — Advanced Counter Functions

Note: At the time of delivery, the H7CX is set to the 1-stage counter (2-stage counter for H7CX-AW□/-A4W□ models) configuration. When using as a 2-stage (or 1-stage) counter, total and preset counter, batch counter, or dual counter, switch to the configuration using the procedure given in the *Operation in Configuration Selection Mode* section.



■ Explanation of Counter Functions

Input Mode (入力モード) (Setting possible using DIP switch.)

Set increment mode (UP), decrement mode (DOWN), or one of the increment/decrement modes (UP/DOWN A, UP/DOWN B, or UP/DOWN C) as the input mode. Input modes other than UP or DOWN modes cannot be set using the DIP switch and so use the operation keys if other modes are required. (For details on the operation of the input modes, refer to "Input Modes and Present Value".)

Dual Count Calculating Mode (二重カウント計算モード) (Setting possible using DIP switch.)

When using as a dual counter, select either ADD (addition) or SUB (subtraction) as the calculation method for the dual count value.

ADD: Dual count value = CP1 PV + CP2 PV

SUB: Dual count value = CP1 PV - CP2 PV

Output Mode (出力モード) (Setting possible using DIP switch.)

Set the way that control output for the present value is output. The possible settings are N, F, C, R, K-1, P, Q, A, K-2, D, L, and H. Output modes other than N, F, C, or K-1 cannot be set using the DIP switch and so use the operation keys if other modes are required. The output modes that can be set vary with the model. (For details on the operation of the output modes, refer to "Input/Output Mode Settings".)

One-shot Output Time (一時出力時間) (Setting possible using DIP switch.)

Set the one-shot output time (0.01 to 99.99 s) for control output. One-shot output can be used only when C, R, K-1, P, Q, A, or K-2 is selected as the output mode. Output times other than 0.5 s or 0.05 s cannot be set with the DIP switch and so use the operation keys if other settings are required.

One-shot Output 2 Time (一時出力2時間) (Setting possible using DIP switch.)

When using as a 2-stage counter or batch counter, set the one-shot output time (0.01 to 99.99 s) for control output (OUT2). One-shot output can be used only when C, R, K-1, P, Q, A, or K-2 is selected as the output mode. Output times other than 0.5 s or 0.05 s cannot be set with the DIP switch and so use the operation keys if other settings are required.

One-shot Output 1 Time (一時出力1時間) (Setting possible using DIP switch.)

When using as a 2-stage counter, set the one-shot output time (0.01 to 99.99 s) for control output (OUT1). One-shot output can be used only when D, L, or H is selected as the output mode. If the output time is set to 0.00, *HOLD* is displayed, and outputs are held. HOLD cannot be set when the output mode is K-2.

Counting Speed (カウント速度) (Setting possible using DIP switch.)

Set the maximum counting speed (30 Hz/5 kHz) for CP1 and CP2 inputs together. If contacts are used for input signals, set the counting speed to 30 Hz. Processing to eliminate chattering is performed for this setting.

Reset Input Signal Width (リセット入力信号幅) (Setting possible using DIP switch.)

Set the reset input signal width (20 ms/1 ms) for reset/reset 1 and total reset/reset 2 inputs together. If contacts are used for input signals, set the counting speed to 20 ms. Processing to eliminate chattering is performed for this setting.

Decimal Point Position (小数点位置) (Setting possible using DIP switch.)


Decide the decimal point position for the present value, CP1/CP2 present values, set value (SV1, SV2), total count value, and dual count set value.

Prescale Value (プレスケール) (Setting possible using DIP switch.)

Pulses input to the counter are converted according to the specified prescale value. (Setting range: 0.001 to 99.999 for 6-digit models and 0.001 to 9.999 for 4-digit models.)

Example: To display the feed distance for systems that output 25 pulses for a feed length of 0.5 m in the form □□.□□ m:

1. Set the decimal point position to 2 decimal places.
2. Set the prescale value to 0.02 (0.5÷25).



NPN/PNP Input Mode (入力モード) (Setting possible using DIP switch.)

Select either NPN input (no-voltage input) or PNP input (voltage input) as the input format. The same setting is used for all external inputs. For details on input connections, refer to *Input Connection*.

Display Color (ディスプレイ色) (Setting possible using DIP switch.)

Set the color used for the present value.

	Output OFF (See note.)	Output ON (See note.)
<i>rEd</i>	Red (fixed)	
<i>Grn</i>	Green (fixed)	
<i>r-<i>U</i></i>	Red	Green
<i>U-r</i>	Green	Red

Note: When using as a 2-stage counter, this is the status of output 2.

Output Allocation (出力割り当て) (Setting possible using DIP switch.)

When using H7CX-AU□ models as a 2-stage counter, the output can be flexibly allocated to either stage 1 or 2.

Transistor output can be allocated to SV1 and contact output for SV2 or vice versa, as in the following table.

H7CX-AU1-AUD1

	OUT1	OUT2
<i>OFF</i>	Transistor (12-13)	Contact (3, 4, 5)
<i>on</i>	Contact (3, 4, 5)	Transistor (12-13)


H7CX-AUSD1

	OUT1	OUT2
<i>OFF</i>	Transistor (12-13)	Transistor with diode (3, 4, 5)
<i>on</i>	Transistor with diode (3, 4, 5)	Transistor (12-13)

Key Protect Level (KP₁ to KP₅)

Set the key protect level.

When the key-protect switch is set to ON, it is possible to prevent setting errors by prohibiting the use of certain operation keys by specifying the key protect level (KP-1 to KP-5). The key protect indicator is lit while the key-protect switch is set to ON. Confirm the ON/OFF status of the key-protect switch after the H7CX is mounted to the panel.




Level	Meaning	Details			
		Changing mode (See note.)	Switching display during operation	Reset key	Up/down key (Up key for 6-digit models)
KP-1 (default setting)		No	Yes	Yes	Yes
KP-2		No	Yes	No	Yes
KP-3		No	Yes	Yes	No
KP-4		No	Yes	No	No
KP-5		No	No	No	No

Note: Changing mode to configuration selection mode (MODE + 1 s min.) or function setting mode (MODE 3 s min.).

■ Operation in Counter Run Mode

Set values for each digit as required using the  and  keys   key only for 6-digit



1-stage Counter




Present Value

Shows the present count value.


Set Value (Set Value 1, Set Value 2)

Set the set value. When the present value reaches the set value, signals are output according to the specified output mode.

2-stage Counter



Total and Preset Counter




Present Value/Set Value

Same as 1-stage counter.

Total Count Value

Shows the present total count value.

Batch Counter



Present Value/Set Value

Same as 1-stage counter.


Batch Count Value

Shows the number of times the count has been completed for the present value.

Batch Count Set Value

Set the batch count set value. When the batch count value reaches the batch count set value, batch output (OUT1) turns ON.

Dual Counter



Dual Count Value

Shows the sum of the CP1 present value and CP2 present value when the dual count calculating mode is ADD and shows the value obtained by subtracting the CP2 present value from the CP1 present value when the dual count calculating mode is SUB.

Dual Count Set Value





Set the dual count set value. When the dual count value reaches the dual count set value, signals are output according to the specified output mode.




CP1/CP2 Present Value

Show the present count values for CP1 and CP2 present values respectively.

Note: ★ indicates the displays at power-ON for the respective configurations.

■ Input Modes and Present Value

<p>UP (Increment) Mode</p> <p>CP1: Count input; CP2: Prohibit (gate) input</p>  <p>Present value</p> <p>Note: Input CP2 while CP1 is "L." Ⓐ must be greater than the minimum signal width. (See note 2.)</p>	<p>DOWN (Decrement) Mode</p> <p>CP1: Count input; CP2: Prohibit (gate) input</p>  <p>Present value</p> <p>Note: Input CP2 while CP1 is "L." Ⓐ must be greater than the minimum signal width. (See note 2.)</p>
<p>CP1: Prohibit (gate) input; CP2: Count input</p>  <p>Present value</p> <p>Note: Input CP1 while CP2 is "H." Ⓐ must be greater than the minimum signal width. (See note 2.)</p>	<p>CP1: Prohibit (gate) input; CP2: Present value</p>  <p>Present value</p> <p>Note: Input CP1 while CP2 is "H." Ⓐ must be greater than the minimum signal width. (See note 2.)</p>

<p>UP/DOWN A Command Input Mode</p>  <p>Present value</p> <p>Ⓐ must be greater than the minimum signal width. (See note 2.)</p>
<p>UP/DOWN B Individual Input Mode</p>  <p>Present value</p>
<p>UP/DOWN C Quadrature Input Mode</p>  <p>Present value</p> <p>Ⓑ must be at least 1/2 the minimum signal width. (See note 2.)</p>

Note: 1. If the configuration selection is set to dual counter, regardless of the input mode setting, CP1 and CP2 input will operate in the same way as the count input (CP1) of UP (increment) mode.

2. Ⓐ must be greater than the minimum signal width and Ⓑ must be at least 1/2 the minimum signal width. If they are less, a count error of ± 1 may occur.

Minimum signal width: 16.7 ms (when maximum counting speed = 30 Hz)
100 μ s (when maximum counting speed = 5 kHz)


3. The meaning of the H and L symbols in the tables is explained below.

Input method Symbol	No-voltage input (NPN input)	Voltage input (PNP input)
H	Short-circuit	4.5 to 30 VDC
L	Open	0 to 2 VDC

■ Input/Output Mode Settings

Operation for 1-stage models is the same as that for OUT2.

When using a 2-stage model as a 1-stage counter, total and preset counter, or dual counter, OUT1 and OUT2 turn ON and OFF simultaneously.



Input mode		Operation after count completion			
		UP	DOWN	UP/DOWN A, B, C	
Output mode setting	N	<p>Reset/reset 1</p> <p>999999</p> <p>Set value 2</p> <p>Set value 1</p> <p>0</p> <p>OUT1</p> <p>OUT2</p>	<p>Reset/reset 1</p> <p>999999</p> <p>Set value 2</p> <p>Set value 1</p> <p>0</p> <p>OUT1</p> <p>OUT2</p>	<p>Reset/reset 1</p> <p>999999</p> <p>Set value 2</p> <p>Set value 1</p> <p>0</p> <p>OUT1</p> <p>OUT2</p>	The outputs and present value display are held until reset/reset 1 is input.
	F	<p>Reset/reset 1</p> <p>999999</p> <p>Set value 2</p> <p>Set value 1</p> <p>0</p> <p>OUT1</p> <p>OUT2</p>	<p>Reset/reset 1</p> <p>999999</p> <p>Set value 2</p> <p>Set value 1</p> <p>0</p> <p>OUT1</p> <p>OUT2</p>	<p>Reset/reset 1</p> <p>999999</p> <p>Set value 2</p> <p>Set value 1</p> <p>0</p> <p>OUT1</p> <p>OUT2</p>	The present value display continues to increase/decrease. The outputs are held until reset/reset 1 is input.
	C	<p>Reset/reset 1</p> <p>999999</p> <p>Set value 2</p> <p>Set value 1</p> <p>0</p> <p>OUT1</p> <p>OUT2</p>	<p>Reset/reset 1</p> <p>999999</p> <p>Set value 2</p> <p>Set value 1</p> <p>0</p> <p>OUT1</p> <p>OUT2</p>	<p>Reset/reset 1</p> <p>999999</p> <p>Set value 2</p> <p>Set value 1</p> <p>0</p> <p>OUT1</p> <p>OUT2</p>	As soon as the count reaches SV, the present value display returns to the reset start status. The present value display does not show the present value upon count-up. The outputs repeat one-shot operation. OUT1 self-holding output turns OFF after the OUT2 one-shot output time. The OUT1 one-shot output time is independent of OUT2.
	R	<p>Reset/reset 1</p> <p>999999</p> <p>Set value 2</p> <p>Set value 1</p> <p>0</p> <p>OUT1</p> <p>OUT2</p>	<p>Reset/reset 1</p> <p>999999</p> <p>Set value 2</p> <p>Set value 1</p> <p>0</p> <p>OUT1</p> <p>OUT2</p>	<p>Reset/reset 1</p> <p>999999</p> <p>Set value 2</p> <p>Set value 1</p> <p>0</p> <p>OUT1</p> <p>OUT2</p>	The present value display returns to the reset start status after the one-shot output time. The outputs repeat one-shot operation. OUT1 self-holding output turns OFF after the OUT2 one-shot output time. The OUT1 one-shot output time is independent of OUT2.


Note: 1. The full scale (FS) for H7CX 4-digit models is 9999.

2. When the present value reaches 999999, it returns to 0.

		Input mode			Operation after count completion
		UP	DOWN	UP/DOWN A, B, C	
Output mode setting	K-1	Reset/ reset 1			The present value display continues to increase/decrease. OUT1 self-holding output turns OFF after the OUT2 one-shot output time. The OUT1 one-shot output time is independent of OUT2.
		999999			
		Set value 2			
		Set value 1			
	P	0			The present value display does not change during the one-shot output time period, but the actual count returns to the reset start status. The outputs return to the one-shot start state and repeat one-shot operation. OUT1 self-holding output turns OFF after the OUT2 one-shot output time. The OUT1 one-shot output time is independent of OUT2.
		OUT1			
		OUT2			
	Q	Reset/ reset 1			The present value continues to increase/decrease for the one-shot output time, but returns to the reset start status after the one-shot output time has elapsed. The outputs repeat one-shot operation. OUT1 self-holding output turns OFF after the OUT2 one-shot output time. The OUT1 one-shot output time is independent of OUT2.
		999999			
		Set value 2			
		Set value 1			
	A	0			The present value display and OUT1 self-holding output is held until reset/reset 1 is input. OUT1 and OUT2 are independent.
		OUT1			
		OUT2			

Note:

1. The full scale (FS) for H7CX 4-digit models is 9999.
2. When the present value reaches 999999, it returns to 0.




Input mode		Operation after count completion
UP/DOWN A, B, C		
Output mode setting	K-2	<p>Reset/ reset 1</p> <p>999999 Set value 2 Set value 1 0 -99999</p> <p>OUT1</p> <p>OUT2</p> <p>The display continues to increase/decrease until the overflow or underflow value is reached. One-shot output only.</p>
	D	<p>Reset/ reset 1</p> <p>999999 Set value 2 Set value 1 0 -99999</p> <p>OUT1</p> <p>OUT2</p> <p>The display continues to increase/decrease until the overflow or underflow value is reached. The outputs are ON while the count is equal.</p>
	L	<p>Reset/ reset 1</p> <p>999999 Set value 2 Set value 1 0 -99999</p> <p>OUT1</p> <p>OUT2</p> <p>The display continues to increase/decrease until the overflow or underflow value is reached. OUT1 is held while the present value is less than or equal to set value 1. OUT2 is held while the present value is greater than or equal to set value 2.</p>
	H	<p>Reset/ reset 1</p> <p>999999 Set value 2 Set value 1 0 -99999</p> <p>OUT1</p> <p>OUT2</p> <p>The display continues to increase/decrease until the overflow or underflow value is reached. OUT1 is held while the present value is greater than or equal to set value 1. OUT2 is held while the present value is greater than or equal to set value 2.</p> <p>Note: H mode is available for 2-stage models only.</p>

Note:

1. Counting cannot be performed during reset/reset 1 input.
2. If reset/reset 1 is input while one-shot output is ON, one-shot output turns OFF.
3. If the count is reached while one-shot output is ON, the one-shot output is newly generated.


Total and Preset Counter Operation

The H7CX has a total counter, separate from the 1-stage preset counter, for counting the total accumulated value.



Batch Counter Operation

The H7CX has a batch counter, separate from the 1-stage preset counter, for counting the number of times the count has been completed.




Note:

1. The batch count value is held at 0 during batch counter reset input.
2. If the batch count set value is 0, batch count will be performed but there will be no batch output.
3. The batch count value returns to 0 when it reaches 999,999 (9,999 for 4-digit models).
4. Once batch input has been turned ON, it will return to the ON state after power interruptions.
5. If the batch count set value is changed from a value that is greater than the batch count value to one that is less, batch output will turn ON.
6. After batch output turns ON, the ON state will be held even if the batch count set value is changed to a value greater than the batch count value.

Dual Counter Operation

Using the dual counter allows the count from 2 inputs to be added or subtracted and the result displayed. It is possible to specify a set value for which output turns ON when the set value matches the added or subtracted result. OUT1 and OUT2 turn ON and OFF simultaneously.



Note:

1. Counting is not possible for CP1 during reset 1 input. CP2 will not be affected. The dual count value will be calculated based on a CP1 present value of 0.
2. Counting is not possible for CP2 during reset 2 input. CP1 will not be affected. The dual count value will be calculated based on a CP2 present value of 0.
3. The counting range for the dual count value is -99,999 to 999,999 (-999 to 9,999 for 4-digit models). The counting ranges for the CP1 present value and CP2 present value are 0 to 999,999 (0 to 9,999 for 4-digit models). If a present value exceeds 999,999 (9,999 for 4-digit models), FFFFFFF (FFFF for 4-digit models) will be displayed to indicate an overflow, and all counting will stop.


■ Reset Function List

Function	1-stage/2-stage counter	Total and preset counter		Batch counter		Dual counter	
Screen displayed in run mode	Present value/ set value (1, 2)	Present value/ set value	Total count value	Present value/ set value	Batch count value/batch count set value	Dual count value/dual count set value	CP1 present value/CP2 present value
Reset/reset 1	Present value and output reset.	Present value and output reset.		Present value and output reset.		Only the CP1 present value is reset.	
Total reset/ reset 2	No effect.	Only the total count value is reset.		Batch count value and batch output reset.		Only the CP2 present value is reset.	
Reset key	Present value and output reset.	Present value and output reset.	Present value, total count value, and output reset.	Present value and output reset.	Present value, batch count value, output and batch output reset.	CP1 present value, CP2 present value, dual count value, and output reset.	

Operation — Tachometer Function

■ Switching from Counter to Tachometer


The H7CX is factory-set to the 2-stage counter (1-stage counter for H7CX-AU□ models) configuration. To switch to the tachometer configuration, use the procedure shown on the right. For details, refer to *Operation in Configuration Selection Mode*.



Note: The **MODE** key must be pressed before the **▲1** key.

■ Quick Setup — Basic Tachometer Operation

Settings for basic functions can be performed with just the DIP switch.



	Item	OFF	ON
1	DIP switch settings enable/disable	Disabled	Enabled
2	Counting speed	30 Hz	10 kHz
3	Tachometer output mode	Refer to the table on the right.	
4			
5	Average processing	Refer to the table on the right.	
6			
7	---	---	---
8	NPN/PNP input mode	NPN	PNP

Pin 3	Pin 4	Tachometer output mode
OFF	OFF	Upper and lower limit
ON	OFF	Area
OFF	ON	Upper limit
ON	ON	Lower limit


Pin 5	Pin 6	Average processing
OFF	OFF	OFF (no average processing)
ON	OFF	2 times
OFF	ON	4 times
ON	ON	8 times

Easy Confirmation of Switch Settings Using Indicators

The ON/OFF status of the DIP switch pins can be confirmed using the front display. For details, refer to *Operation in Configuration Selection Mode*.

Note:


1. Be sure to set pin 1 of the DIP switch to ON. If it is set to OFF, the DIP switch settings will not be enabled.
2. Changes to DIP switch settings are enabled when the power is turned ON.



■ Quick Setup — Advanced Functions

Note: When using as a tachometer, switch to tachometer configuration using the procedure in *Operation in Configuration Selection Mode*.

Settings that cannot be performed with the DIP switch are performed with the operation



■ Explanation of Tachometer Function

Tachometer Output Mode (タコメータ出力モード) (Setting possible using DIP switch.)

Set the output method for control output based on the OUT1/OUT2 set value. Upper and lower limit (HI-LO), area (AREA), upper limit (HI-HI), and lower limit (LO-LO) can be set. (For details on the operation of the output modes, refer to "Output Mode Settings" in the Installation section)

Counting Speed (カウント速度) (Setting possible using DIP switch.)

Set the maximum counting speed (30 Hz/10 kHz) for CP1 input. If contacts are used for input signals, set the counting speed to 30 Hz. Processing to eliminate chattering is performed for this setting.

Decimal Point Position (小数点位置)

Decide the decimal point position for the measurement value, OUT1 set value, and OUT2 set value.

Prescale Value (プレスケール値)

It is possible to display the rate of rotation or the speed of a device or machine to which the H7CX is mounted by converting input pulses to a desired unit. If this prescaling function is not used, the input frequency (Hz) will be displayed.

The relationship between display and input is determined by the following equation. Set the prescale value according to the unit to 0VxK-.KB)d)HTK:)is)dHBK:)pl)dHBK:)ayH0S:KB)d)HTVV).HOHS:-:•cO20SKUTU-2}%cOSUOWS2)cKU)iHTOKpU)iHHVKT)B0V-KU)iHHV:)a:0VWK:)eHTOK

Output Allocation (Output)

When using H7CX-AU□ models as 2-stage counter, each output can be flexibly allocated to either stage 1 or 2. Transistor output placed for SV1 and contact output for SV2 or vice versa, as in the following table.

H7CX-AU/-AUD1

	OUT1	OUT2
\bar{FF}	Transistor (12-13)	Contact (3, 4, 5)
\bar{on}	Contact (3, 4, 5)	Transistor (12-13)


H7CX-AUSD1

	OUT1	OUT2
<i>off</i>	Transistor (12-13)	Transistor with diode (3, 4, 5)
<i>on</i>	Transistor with diode (3, 4, 5)	Transistor (12-13)

Key Protect Level (ΚΥΡΤ)




Set the key protect level.

When the key-protect switch is set to ON, it is possible to prevent setting errors by prohibiting the use of certain operation keys by specifying the key protect level (KP-1 to KP-5). The key protect indicator is lit while the key-protect switch is set to ON. Confirm the ON/OFF status of the key-protect switch after the H7CX is mounted to the panel.



Note: Factory-set to OFF


Key protect indicator

Level	Meaning	Details			
		Changing mode (See note.)	Switching display during operation	Reset key	Up/down key (Up key for 6-digit models)
KP-1 (default setting)		No	Yes	Yes	Yes
KP-2		No	Yes	No	Yes
KP-3		No	Yes	Yes	No
KP-4		No	Yes	No	No
KP-5		No	No	No	No

Note: Changing mode to configuration selection mode (**MODE** + **↑↓** 1 s min.) or function setting mode (**MODE** 3 s min.).

■ Operation in Tachometer Run Mode

Set values for each digit as required using the  key.







Measurement Value

Displays the currently measured value.

OUT1/OUT2 Set Value


Set OUT1 set value and OUT2 set value. The measurement value is compared to OUT1 set value and OUT2 set value and output is made according to the selected output mode.

■ Output Mode Settings

Output mode setting	Upper and lower limit (HI-LO)	 <p>(Upper-limit) OUT2 set value Measurement value (Lower-limit) OUT1 set value OUT1 OUT2</p> <p>ON condition for OUT1: measurement value \leq OUT1 set value ON condition for OUT2: measurement value \geq OUT2 set value</p>								
	Area (AREA)	 <p>OUT2 set value Measurement value OUT1 set value OUT1 OUT2</p> <table border="1" data-bbox="388 861 1465 1024"> <thead> <tr> <th>Condition</th> <th>OUT1 set value \leq OUT2 set value</th> <th>OUT1 set value $>$ OUT2 set value</th> </tr> </thead> <tbody> <tr> <td>ON condition for OUT1</td> <td>OUT1 set value \leq measurement value \leq OUT2 set value</td> <td>OUT2 set value \leq measurement value \leq OUT1 set value</td> </tr> <tr> <td>ON condition for OUT2</td> <td>measurement value $<$ OUT1 set value or measurement value $>$ OUT2 set value</td> <td>measurement value $<$ OUT2 set value or measurement value $>$ OUT1 set value</td> </tr> </tbody> </table>	Condition	OUT1 set value \leq OUT2 set value	OUT1 set value $>$ OUT2 set value	ON condition for OUT1	OUT1 set value \leq measurement value \leq OUT2 set value	OUT2 set value \leq measurement value \leq OUT1 set value	ON condition for OUT2	measurement value $<$ OUT1 set value or measurement value $>$ OUT2 set value
Condition	OUT1 set value \leq OUT2 set value	OUT1 set value $>$ OUT2 set value								
ON condition for OUT1	OUT1 set value \leq measurement value \leq OUT2 set value	OUT2 set value \leq measurement value \leq OUT1 set value								
ON condition for OUT2	measurement value $<$ OUT1 set value or measurement value $>$ OUT2 set value	measurement value $<$ OUT2 set value or measurement value $>$ OUT1 set value								
Upper limit (HI-HI)		 <p>(Upper-limit) OUT2 set value Measurement value (Upper-limit) OUT1 set value OUT1 OUT2</p> <p>ON condition for OUT1: Measurement value \geq OUT1 set value ON condition for OUT2: Measurement value \geq OUT2 set value</p>								
Lower limit (LO-LO)		 <p>(Lower-limit) OUT2 set value Measurement value (Lower-limit) OUT1 set value OUT1 OUT2</p> <p>ON condition for OUT1: Measurement value \leq OUT1 set value ON condition for OUT2: Measurement value \leq OUT2 set value</p>								

Operation in Configuration Selection Mode

Select which H7CX configuration is used (i.e., 1-stage counter, 2-stage counter, total and preset counter, batch counter, dual counter, or tachometer) in configuration selection mode. The H7CX is also equipped with a DIP switch monitor function, a convenient function that enables the settings of the DIP switch pins to be confirmed using the front display.



• H7CX-AU

Y92F-30 (provided)
Panel-Mounting Adapter

Terminal Models with External Power Supplies (with Adapter and Waterproof Gasket)

• H7CX-AW


(provided)
of Packing

Y92S-29 (provided)
Waterproof Packing

Panel

Y92F-30 (provided)
Panel-Mounting Adapter

Panel cutouts are
as shown below.
(according to DIN43700).



Note 1. The mounting panel thickness
should be 1 to 5 mm.

Terminal Models without External Power Supplies (with Adapter and Waterproof Gasket)

• H7CX-AWSD

• H7CX-ASD

• H7CX-A4WSD

• H7CX-A4D
• H7CX-A4P
• H7CX-ASD
• H7CX-A11S
• H7CX-A11D1
• H7CX-A11SD1

• H7CX-A114
• H7CX-A114S
• H7CX-A114D1

Panel

Y92F-30 (order separately)
Panel-Mounting Adapter

3. It is possible to mount counters
side by side, but only in the
direction without the hooks.
If they are mounted side-by-side,
water-resistant specifications
cannot be ensured.


- 2.5)

Panel Cutouts

A = (48n) ⁰₁

With Y92A-48F1 attached.
A = {48n - 2.5 + (n-1) x 4} ⁰₁

With Y92A-48 attached.
A = (51n - 5.5) ⁰₁




Installation

■ Terminal Arrangement

Confirm that the power supply meets specifications before use.


H7CX-A/-A4

1-Stage Contact Output



H7CX-AD/-A4D


1-Stage Contact Output



Note: Terminals 1 and 6 are connected internally.


H7CX-AS/-A4S

1-Stage Transistor Output



H7CX-ASD/-A4SD


1-Stage Transistor Output



Note: Terminals 1 and 6 are connected internally.

H7CX-A11/-A114/-A11D1/-A114D1


1-Stage Contact Output



Note: Do not connect unused terminals as relay terminals.


H7CX-A11S/-A114S/-A11SD1

1-Stage Transistor Output




H7CX-AW/-A4W/-AWD1

2-Stage Contact Output



H7CX-AWSD/-A4WSD


2-Stage Transistor Output



Note: 1. Terminals 1 and 6 are connected internally.
2. Do not connect unused terminals as relay terminals

H7CX-AU/-AUD1


1-Stage Contact, 1-Stage Transistor Output



Note: Each output can be flexibly allocated to either stage 1 or 2 by setting in function selection mode.


H7CX-AWS/-A4W/-AWSD1

2-Stage Transistor Output



H7CX-AUSD1


2-Stage Transistor Output



Note: Each output can be flexibly allocated to either stage 1 or 2 in function selection mode.

■ Input Circuits

CP1, CP2, Reset/Reset 1, and Total Reset/Reset 2 Input




Note: The circuit shown above is for no-voltage input (NPN input).

■ Input Connections

The inputs of the H7CX are no-voltage (short-circuit or open) inputs or voltage inputs.


No-voltage Inputs (NPN Inputs)

Open Collector




Operates when the transistor turns ON.

Voltage Output



Operates when the transistor turns ON.

Contact Input



Operates when the contact turns ON.

No-voltage Input Signal Levels


No-contact input	Short-circuit level Transistor ON Residual voltage: 3 V max. Impedance when ON: 1 KΩ max. (The leakage current is 5 to 20 mA when the impedance is 0 Ω.)
	Open level Transistor OFF Impedance when OFF: 100 KΩ min.
Contact input	Use contact which can adequately switch 5 mA at 10 V. Maximum applicable voltage: 30 VDC max.

Applicable Two-wire Sensor

Leakage current: 1.5 mA max.
Switching capacity: 5 mA min.
Residual voltage: 3 VDC max.
Operating voltage: 10 VDC


Voltage Inputs (PNP Inputs)

No-contact Input (NPN Transistor)




Operates when the transistor turns OFF.

No-contact Input (PNP Transistor)



Operates when the transistor turns ON.

Contact Input



Operates when the contact turns ON.

Voltage Input Signal Levels


High level (Input ON): 4.5 to 30 VDC
 Low level (Input OFF): 0 to 2 VDC
 Maximum applicable voltage: 30 VDC max.
 Input resistance: Approx. 4.7 kΩ

Accessories (Order Separately)


Unit: mm

■ Track Mounting/Front Connecting Socket


P2CF11



Terminal Arrangement/
Internal Connections
(Top View)




Surface Mounting Holes



Note: Track mounting is also possible.


P2CF-11-E (Finger-Safe Terminal Type)

Conforming to VDE0106/P100



■ Back Connecting Socket


P3GA-11



Note: Finger protection can be ensured by using in combination with the Y92A-48G Terminal Cover.

■ Finger-Safe Terminal Cover (Conforming to VDE0106/P100)


Y92A-48G (Attachment for P3GA-11 socket)



Hard Cover
Y92A-48



Soft Cover
Y92A-48F1




Note:

1. Depending on the operating environment, the condition of the Soft Cover may deteriorate, and it may shrink or become harder. Therefore, it is recommended that the Soft Cover is replaced regularly.
2. The H7CX's panel surface is water-resistive (conforming to IP66) and so even if drops of water penetrate the gaps between the keys, there will be no adverse effect on internal circuits. If, however, there is a possibility of oil being present on the operator's hands, use the Soft Cover. The Soft Cover ensures protection equivalent to IP54F against oil. Do not, however, use the H7CX in locations where it would come in direct contact with oil.

■ Panel-Mounting Adapter

(Provided with screw-terminal models only)


Y92F-30



■ Waterproof Gasket


(Provided with screw-terminal models)

Y92S-29




■ Mounting Track

PFP-100N, PFP-50N



4.5
1
15 25 10 25 10 25
7.3±0.15
35±0.3 27±0.15
1,000 (500)
(see note)

PFP-100N2



Note: The values shown in parentheses are for the PFP-50N.

■ End Plate

PFP-M



50
11.5
10 M4 x 8
pan head
screw
10 6.2 1.8 1.8 35.5 35.3
1 1.3 4.8

■ Spacer

PFP-S



5
16 12
1 44.3 34.8
1 16.5

Precautions

■ Self-diagnostic Function

The following displays will appear if an error occurs.

Main display	Sub-display	Error	Output status	Correction method	Set value after reset
----- (-----) (See notes 1 and 2.)	No change	Present value underflow (See note 3.)	No change	Either press the reset key or turn ON reset input.	No change
FFFFF (FFFF) (See notes 1 and 2.)	No change	Present value overflow (See note 4.)	No change	Either press the reset key or turn ON reset input. (See note 5.)	No change
E1	Not lit	CPU	OFF	Either press the reset key or reset the power supply.	No change
E2	Not lit	Memory error (RAM)	OFF	Reset the power supply.	No change
E2	5Uñ	Memory error (EEP) (See note 6.)	OFF	Reset to the factory settings using the reset key.	0

Note:

1. The display for 4-digit models is given in parentheses.
2. Display flashes (1-second cycles).
3. Occurs when the present value or the total count value goes below -99,999 (-999 with 4-digit models).
4. Occurs when the present value (or measurement value) reaches 999,999 (9,999 with 4-digit models) under the following conditions:
 - The output mode is K-2, D, L, or H.
 - The H7CX is set for dual counter or tachometer operation.
5. Except when the H7CX is set for tachometer operation.
6. Includes the case where the EEPROM has reached its overwrite lifetime.

■ Response Delay Time When Resetting (Transistor Output)

The following table shows the delay from when the reset signal is input until the output is turned OFF

(Reference values)

Minimum reset signal width	Output delay time
1 ms	0.8 to 1.2 ms
20 ms	15 to 25 ms

■ Output Delay Time

The following table shows the delay from when the present value passes the set value until the output is produced.

Actual measurements in N and K-2 modes. (Reference values)

Control output type	Maximum counting speed	Output delay time
Contact output	30 Hz	16.5 to 24.0 ms
	5 kHz	3.7 to 5.6 ms
Transistor output	30 Hz	12.0 to 20.0 ms
	5 kHz	0.2 to 0.55 ms

Note: The above times may vary slightly depending on the mode or operating conditions.

■ Maximum Counting Speed for Batch Counter

The maximum counting speed for batch counter operation is 5 kHz. The batch counter counts the number of times the count reaches the set value.

■ Wiring


Wiring input lines in the same conduit as power lines or other high-voltage lines may result in malfunction due to noise. Wire the input lines separately, away from lines carrying high-voltages. In addition, make the input wiring as short as possible and use shield lines or metal wiring conduits.

Pay attention to terminal polarity to ensure correct wiring.

■ Mounting

Tighten the two mounting screws on the Adaptor. Tighten them alternately, a little at a time, so as to keep them at an equal tightness.


The H7CX's panel surface is water-resistant (conforming to NEMA 4 and IP66). In order to prevent the internal circuit from water penetration through the space between the timer and operating panel, attach a waterproof packing between the timer and installation panel and secure the waterproof packing with the Y92F-30 Flush-mounting Adapter.



It is recommended that the space between the screw head and the adapter should be 0.5 to 1 mm.

■ Operating Environment

- Use the product within the ratings specified for submerging in water and exposure to oil.
- Do not use the product in locations subject to vibrations or shocks. Using the product in such locations over a long period may result in damage due to stress.
- Do not use the product in locations subject to dust, corrosive gases, or direct sunlight.
- Separate the input signal devices, input signal cables, and the product from the source of noise or high-tension cables producing noise.
- Separate the product from the source of static electricity when using the product in an environment where a large amount of static electricity is produced (e.g., forming compounds, powders, or fluid materials being transported by pipe).
- Organic solvents (such as paint thinner), as well as very acidic or basic solutions might damage the outer casing of the H7CX.
- Use the product within the ratings specified for temperature and humidity.
- Do not use the product in locations where condensation may occur due to high humidity or where temperature changes are severe.
- Store at the specified temperature. If the H7CX has been stored at a temperature of less than -10°C, allow the H7CX to stand at room temperature for at least 3 hours before use.
- Leaving the H7CX with outputs ON at a high temperature for a long time may hasten the degradation of internal parts (such as electrolytic capacitors). Therefore, use the product in combination with relays and avoid leaving the output turned ON for more than one month.



- The load current must be within the rated current.


■ Insulation

- Specifications call for basic insulation between the power supply and input terminals, between the power supply and output terminals, and between the input and output terminals. (The H7CX-A□D is not insulated between the power supply and input terminals.)
- Input and output terminals are connected to devices without exposed charged parts.
- Input and output terminals are connected to devices with basic insulation that is suitable for the maximum operating voltage.

Appendix

■ Using the Operation Keys

Counter Operation



Note:

1. Perform settings using the \nearrow and \searrow keys (\nearrow key only with 6-digit models).
2. The above flowcharts outline the procedures for all models. For more details on each model, refer to *Quick Setup - Basic Counter Function*.

Tachometer Operation

■ Lists of Settings

Fill in your set values in the set value column of the following tables and utilize the tables for quick reference.

Configuration Selection Mode

Parameter name	Parameter	Setting range	Default value	Unit
Configuration selection	<i>FUnC</i>	<i>ICnt/2Cnt/ECnt/BCnt/dCnt/ERCo</i> (See note 1.)	<i>ICnt</i> (See note 2.)	---
DIP switch monitor	<i>dCP</i>	<i>an/0FF</i>	<i>0FF</i>	---

Note: 1. The setting range varies with the model.

2. The default value for H7CX-AW□-A4W□ models is *2Cnt*.

Settings for Counter Operation

Run Mode

1-Stage Counter

Parameter name	Parameter	Setting range	Default value	Unit
Present value, set value	Present value	---	0	--
	Set value	0 to 999999 (0 to 9999) (For conditions other than those described in note 1.) -99999 to 999999 (-999 to 9999) (See note 1.)	0	---

2-Stage Counter

Parameter name	Parameter	Setting range	Default value	Unit
Present value, set value 1	Present value	---	0	---
	Set value 1	0 to 999999 (0 to 9999) (For conditions other than those described in note 1.) -99999 to 999999 (-999 to 9999) (See note 1.)	0	---
	Set value 2	0 to 999999 (0 to 9999) (For conditions other than those described in note 1.) -99999 to 999999 (-999 to 9999) (See note 1.)	0	---
Present value, set value 2	Present value	---	0	---
	Set value 2	0 to 999999 (0 to 9999) (For conditions other than those described in note 1.) -99999 to 999999 (-999 to 9999) (See note 1.)	0	---

Total and Preset Counter

Parameter name	Parameter	Setting range	Default value	Unit
Present value, set value	Present value	---	0	---
	Set value	0 to 999999 (0 to 9999) (For conditions other than those described in note 1.) -99999 to 999999 (-999 to 9999) (See note 1.)	0	---
	Total count value	-99999 to 999999 (-999 to 9999)		0

Batch Counter

Parameter name	Parameter	Setting range	Default value	Unit
Present value, set value	Present value	---	0	---
	Set value	0 to 999999 (0 to 9999) (For conditions other than those described in note 1.) -99999 to 999999 (-999 to 9999) (See note 1.)	0	---
	Batch count value, batch count set value	0 to 999999 (0 to 9999) 0 to 999999 (0 to 9999)	0	---
Batch count value, batch count set value		0 to 999999 (0 to 9999)		0

Dual Counter

Parameter name	Parameter	Setting range	Default value	Unit
Dual count value, dual count set value	Dual count value	---	0	---
	Dual count set value	0 to 999999 (0 to 9999) (For conditions other than those described in note 2.) -99999 to 999999 (-999 to 9999) (See note 2.)	0	---
	CP1 present value, CP2 present value	0 to 999999 (0 to 9999) 0 to 999999 (0 to 9999)	0	---
CP1 present value, CP2 present value		0 to 999999 (0 to 9999)		0

Note: 1. The input mode is increment/decrement mode and the output mode is K-2, D, L, or H.

2. The dual count calculating mode is subtraction mode and the output mode is K-2, D, L, or H.

Function Setting Mode

Parameter name	Parameter	Setting range	Default value	Unit
Input mode	<i>En₀</i>	<i>Up/Up/Up/Up-RI/Up-blUp-L</i> (See note 1.)	<i>Up</i>	---
Dual count calculating mode	<i>CR₀</i>	<i>Rdd/SU_b</i> (See note 1.)	<i>Rdd</i>	---
Output mode	<i>oU₀</i>	<i>n/FIC-I/I⁴-II/P19/R1H-2/1/L1H</i> (See note 2.)	<i>n</i>	---
One-shot output time	<i>oE₀</i>	<i>0.01 to 99.99</i>	<i>0.50</i>	<i>s</i>
One-shot output 2 time	<i>oE₀</i>	<i>0.01 to 99.99</i>	<i>0.50</i>	<i>s</i>
One-shot output 1 time	<i>oE₀</i>	<i>HOLD/0.01 to 99.99</i> (See note 3.)	<i>HOLD</i>	<i>s</i>
Counting speed	<i>En₅</i>	<i>30kE/50kE</i>	<i>30kE</i>	---
Reset input signal width	<i>zFL₀</i>	<i>20ms/1ms</i>	<i>20ms</i>	---
Decimal point position	<i>dP</i>	<i>-----/-/----.-/-/----.-/-/----. (----/-/----.-/-/----/-/----)</i>	<i>----- (----)</i>	
Prescale value	<i>PS₀</i>	<i>0.001 to 99.999 (0.001 to 9.999)</i>	<i>1.000</i>	---
NPN/PNP input mode	<i>En_{0d}</i>	<i>nPn/PnP</i>	<i>nPn</i>	---
Display color	<i>Co₀</i>	<i>rEd/Gn₀r-G/G-r</i>	<i>rEd</i>	---
Output allocation	<i>oE₅</i>	<i>6FF/0n</i>	<i>6FF</i>	---
Key protect level	<i>HP₀</i>	<i>HP-1/HP-2/HP-3/HP-4/HP-5</i>	<i>HP-1</i>	---

Note:

1. The setting range varies with the output mode.
2. The setting range varies with the model and the input mode.
3. HOLD cannot be set when the output mode is K-2.

Settings for Tachometer Operation

Run Mode

Parameter name	Parameter	Setting range	Default value	Unit
Measurement value	---	0 to 999999	0	---
Measurement value, OUT1 set value	Measurement value	0 to 999999	0	---
	OUT1 set value	0 to 999999	0	---
Measurement value, OUT2 set value	Measurement value	0 to 999999	0	---
	OUT2 set value	0 to 999999	0	---

Function Setting Mode

Parameter name	Parameter	Setting range	Default value	Unit
Tachometer output mode	<i>tātēn</i>	<i>Hōld/BrER/HCHC/Lālā</i>	<i>Hōlā</i>	---
Counting speed	<i>čātēs</i>	<i>30HE100HE</i>	<i>30HE</i>	---
Decimal point position	<i>dP</i>	<i>-----/-----./-----./-----</i>	<i>-----</i>	---
Prescale value	<i>PSCL</i>	<i>0.001 to 99.999</i>	<i>1.000</i>	---
Average processing	<i>RuG</i>	<i>6FF/2/4/8</i>	<i>6FF</i>	---
Auto-zero time	<i>RuE</i>	<i>0.1 to 99.9</i>	<i>99.9</i>	---
Startup time	<i>Stār</i>	<i>0.0 to 99.9</i>	<i>0.0</i>	<i>s</i>
NPN/PNP input mode	<i>čāod</i>	<i>nPn/PnP</i>	<i>nPn</i>	<i>s</i>
Display color	<i>čālr</i>	<i>rEd/GraIn-Gra</i>	<i>rEd</i>	---
Output allocation	<i>ātēt</i>	<i>6FF/ān</i>	<i>6FF</i>	---
Key protect level	<i>μypē</i>	<i>μP-1/μP-2/μP-3/μP-4/μP-5</i>	<i>μP-1</i>	---

ALL DIMENSIONS SHOWN ARE IN MILLIMETERS. To convert millimeters into inches, divide by 25.4.

OMRON
OMRON ELECTRONICS LLC
One East Commerce Drive
Schaumburg, IL 60173
1-800-55-OMRON

OMRON ON-LINE
Global - <http://www.omron.com>
USA - <http://www.omron.com/oei>
Canada - <http://www.omron.com/oci>

OMRON CANADA, INC.
885 Milner Avenue
Scarborough, Ontario M1B 5V8
416-286-6465