

CooCox CoLinkEx

User Manual

Version: 2012-6-26

Technical Support:

<http://forum.coocox.org>

master@coocox.com

Business negotiation:

market@coocox.com

CooCox CoLinkEx

CoLinkEx is a hardware debugging adapter which supports SW debugging and supports both ARM Cortex M3 and Cortex M0 devices, it supports debugging in CooCox software and Keil Realview MDK.



Features:

- Free
- Supports Cortex M0 and Cortex M3 devices
- Supports SW debugging
- Supports JTAG debugging
- Supports CoFlash, CoIDE, MDK and IAR

Requirements:

Hardware:

- 512MB memory
- 20MB Disk space

Operating Systems:

- Windows XP / Windows Vista / Windows 7


Support Software

- Keil RealView MDK v4.03 or higher
- CooCox CoIDE v1.4.0 or higher

Support Series:

- Atmel ATSAM3U Series
- Energy Micro EFM32 Series
- TI LM3S Series
- Nuvoton Numicro Series
- NXP LPC17xx LPC13xx LPC12xx LPC11xx Series
- ST STM32F10x STM32F4x Series
- Holtek HT32 Series

Connection Figure:



Preparation:


Before you use this development kit, you need to install CoLinkEx Driver first.

The CoLinkEx USB drivers are different according to the OS of your PC, please visit <http://www.coocox.org/Colinkex.htm> to download the right one and install it as below:


1. Double Click the EXE file, enter the installation interface, click "Next".



2. Select the installation location, click "Next".



3. Click "Install".



4. Click "Finish".





*Please ensure the firmware of your ColinkEx is the latest version. See how to update:
<http://www.coocox.org/CoLinkGuide/CoLinkDIY.htm>.

After that, you can use it in MDK or CoIDE environment.

Configuration:


✧ CooCox CoIDE




✧ **Keil Realview MDK**

Before you use it in MDK, you need to download and install CoMDKPlugin first, please visit <http://www.coocox.org/CoLinkGuide/CoMDKPlugin.html> to get the details. Just install it with the following simple steps:


1. Double Click the EXE file, enter the installation interface, click "Next".




2. Select the installation location, click "Next".



- Click "Install".




- Click "Finish".



Now you need to do the following configurations while use it in MDK:

1. **Debug** -> **Use** of the configuration selects "CooCox Debugger".



2. Click **Settings**, select "ColinkEx" for the Adapter.

