


AB08XX/AB18XX Real Time Clock Family

The ABX8XX Evaluation Kit provides all of the tools needed to assess the complete feature set in the ultra-low power AB08XX and ABX8XX product families. The ABX8XX-I2C-EVK / ABX8XX-SPI-EVK is designed for easy integration via an I²C or SPI serial interface with microcontroller development kits or with custom boards. The ABX8XX-I2C-EVK / ABX8XX-SPI-EVK may be used for both initial evaluation and product development. This document provides an overview of the ABX8XX-I2C-EVK / ABX8XX-SPI-EVK and serves as a user's guide for fast setup. An image of the EVK development board is shown below.

The ABX8XX-I2C-EVK / ABX8XX-SPI-EVK Development Board



The versions of the ABX8XX-I2C-EVK / ABX8XX-SPI-EVK utilize the same printed circuit board but have different population options and support either I²C or SPI bus communication. The ABX8XX-I2C-EVK supports I²C communication. The ABX8XX-SPI-EVK supports SPI communication. The orderable part numbers are as follows:

Orderable Part Number	Availability	Notes
ABX8XX-I2C-EVK	Now	No VBAT or super-cap functions supported
ABX8XX-SPI-EVK	Now	No VBAT or super-cap functions supported

The current version of the Evaluation Kits do not support the VBAT-related functions. Evaluation kits available at the end of Q1-2013 will support these functions.

AB08XX/AB18XX Real Time Clock Family

Table of Contents

The ABX8XX-I2C-EVK / ABX8XX-SPI-EVK Development Board.....	0
1. Kit Contents	2
2. ABX8XX EVK Overview	2
3. Component Locations.....	4
4. Connector Pin-Outs and Probe Points	7
5. VCC and VBAT Current Measurements with SW1 and SW2	9
6. VBAT Backup Power	10
7. External 32 kHz Clock	10
8. Debug LED	11
9. Installation Guide.....	11
9.1 Hardware Setup.....	11
9.2 Software Setup	11
9.3 Measuring Current Draw in the ABX8XX-EVK.....	11
9.4 Measuring Frequency Accuracy in the ABX8XX-EVK	13
10. Schematics and Component List.....	14
11. Component Installation Differences	21

List of Figures

Figure 1 – ABX8XX-EVK Block Diagram.....	3
Figure 2 – EVK Board Top Side Components.....	4
Figure 3 – Top Component Locations	5
Figure 4 – Bottom Component Locations.....	6
Figure 5 – 24 Pin Header Connector Pin-out	7
Figure 6 – 5 x 5 Test Point Array Pin-out	9
Figure 7 – VCC and VBAT Current Measurement	10
Figure 8 – ABX8XX-I2C-EVK Schematic Page 1.....	15
Figure 9 – ABX8XX-I2C-EVK Schematic Page 2.....	16
Figure 10 – ABX8XX-SPI-EVK Schematic Page 1.....	17
Figure 11 – ABX8XX-SPI-EVK Schematic Page 2.....	18

List of Tables

Table 1 – Top Side Board Component Descriptions	4
Table 2 – 24 Pin (2x12) Connector Pin Names and Descriptions.....	7
Table 3 – ABX8XX-I2C-EVK Component List	19
Table 4 – ABX8XX-SPI-EVK Component List.....	20
Table 5 – Component Installation Differences	21

AB08XX/AB18XX Real Time Clock Family

1. Kit Contents

The items included in the ABX8XX EVK kit are listed below.

- Welcome letter
- One ABX8XX SPI or I2C EVK development board.
 - ABX8XX-I2C-EVK with I²C interface
 - ABX8XX-SPI-EVK with SPI interface
- Abracon USB flash-drive containing the following documentation.
 - ABX8XX Evaluation Kit User's Guide (this document)
 - AB08XX Real Time Clock Family Datasheet
 - AB18XX Real Time Clock Family With Power Management Datasheet
 - Compiled and tested C code driver functions for the ABX8XX
 - PCB Component Assembly Drawing - Searchable PDF file
 - PCB Layout Gerber Files
 - PCB Schematics - Searchable PDF file
 - ABX8XX Power Management Application Note

2. ABX8XX EVK Overview

The ABX8XX-EVK should be used with a host microcontroller (e.g., a microcontroller development kit or an existing production system) to control memory reads and writes over the I²C or SPI serial interface. All operations can be initiated over the serial interface including setting time, reading time, setting alarms and timers, clearing alarms and timers, and other functions described in the datasheet documents "AB08XX Real Time Clock Family" and "AB18XX Real Time Clock Family with Power Management." In addition to serial interface access, the EVK provides access to all input and output signals on the ABX8XX. These signals can be set or read by the host microcontroller unit (MCU) or any other component in the system. The ABX8XX RTC family members support either the I²C or SPI serial interface as well as different I/O and power management features. Additional information about product numbering can be found in the document titled, "ABX8XX Part Selection Guide."

The EVK also provides test points for making analog measurements. A pico-ammeter can be inserted in series with the VCC and VBAT supply voltages or between the PCB current measurement test points to measure the ultra-low current consumption in each of the oscillation modes. Additionally, a high accuracy frequency counter can be used to measure frequency stability over extended periods under different calibration settings.

AB08XX/AB18XX Real Time Clock Family

Figure 1 shows a block diagram of a typical EVK use case.




Figure 1 – ABX8XX-EVK Block Diagram

Access to all ABX8XX pins is provided by a 24-pin expansion header connector with 2mm x 2mm pin spacing. The EVK board also comes with 2-pin VCC and VBAT current measurement pins as shown in Figure 2.

AB08XX/AB18XX Real Time Clock Family

3. Component Locations

This section describes key EVK board components and their locations on the top and bottom sides of the board. The top side EVK components are labeled in Figure 2 and are described in Table 1.




Figure 2 – EVK Board Top Side Components

Table 1 – Top Side Board Component Descriptions

Board Component	Description
24-pin header connector	This is the top side of the 24 pin connector used to make power and input/output pin signal connections to the EVK board. This is a 2x12, 2mm pitch connector (see EVK component list for part number). The connector can be used to connect to individual pin headers, ribbon cable connectors, or can be used as a module and plug into a female connector on the host target system.
Super capacitor	Can be used as the VBAT (backup) supply power source of the ABX8XX.
VCC current measurement pins	These pins are in series with the VCC supply pin of the ABX8XX and are used to connect to an external pico-ammeter for measuring the VCC current into the ABX8XX device. The connection polarity is shown in the diagram.
VBAT current measurement pins	These pins are in series with the VBAT supply pin of the ABX8XX and are used to connect to an external pico-ammeter for measuring the VBAT current into the ABX8XX device. The connection polarity is shown in the diagram.

AB08XX/AB18XX Real Time Clock Family

Board Component	Description
LED	A separate pin on the 24-pin socket connector connects to the LED. This LED can be controlled by an MCU GPIO pin or can be connected directly to the VCC or VBAT supply to indicate one of the supplies has power applied.
SW1	This switch is connected in parallel with the VCC current measurement pins. It is used to short across the pins and connect the external VCC supply to the ABX8XX when not measuring current with the pico-ammeter.
SW2	This switch is connected in parallel with the VBAT current measurement pins. It is used to short across the pins and connect the external VBAT supply to the ABX8XX when not measuring current with the pico-ammeter.
32.768kHz crystal	The crystal is connected to the XI and XO pins of the ABX8XX device
AB180X / AB181X	I ² C (AB180X) or SPI (AB181X) real time clock device.
MMCX Footprint	This can be used for providing an external clock input.

The top and bottom component locations and their corresponding reference designators are shown in Figure 3 and Figure 4. A searchable PDF file of the top and bottom board assembly drawings with reference designators is also included in the USB flash drive documentation to allow for quick location of components in the board schematics.




Figure 3 – Top Component Locations

AB08XX/AB18XX Real Time Clock Family




Figure 4 – Bottom Component Locations

AB08XX/AB18XX Real Time Clock Family

4. Connector Pin-Outs and Probe Points

Figure 5 shows the location of the names and numbers each of the pins (pin-out) of the 24-pin header connector.




Figure 5 – 24 Pin Header Connector Pin-out

Table 2 lists the numbers, names, and descriptions for each pin of the 24-pin (2x12) connector. There are also pull-up resistors on the board from the pin to the VCC_IO supply. Pull-up values are indicated in the table.

Table 2 – 24 Pin (2x12) Connector Pin Names and Descriptions

AB08XX/AB18XX Real Time Clock Family

Pin Number	Pin Name	Board Pull-up Resistor	Description
1	nEXTR	10k	Connection to the external interrupt input pin (nEXTR) of the ABX8XX.
2	nRST	10k	Connection to the external reset output pin (nRST) of the ABX8XX.
3	WDI	10k	Connection to the watchdog timer reset input pin (WDI) of the ABX8XX.
4	CLKOUT	--	Connection to the square wave output pin (CLKOUT) of the ABX8XX.
5	GND	--	PCB GND connection. There is a single GND plane net for the PCB.
6	FOUT	10k	Connection to the primary interrupt output pin (FOUT/nIRQ) of the ABX8XX. This pin can also be used to drive the ABX8XX square wave output.
7	EXTI	10k	Connection to the external interrupt input pin (EXTI) of the ABX8XX.
8	PSW	10k	Connection secondary interrupt output pin (PSW/nIRQ2) of the ABX8XX. It can also drive the square wave output or function as the power switch to power gate external devices.
9	SPI_nCE / nTIRQ	10k	ABX8XX-I2C-EVK board: Connection to the timer output pin (nTIRQ) of the ABX8XX. ABX8XX-SPI-EVK board: Connection to the I/O interface SPI chip select input pin (nCE) of the ABX8XX.
10	SPI_MOSI	--	ABX8XX-I2C-EVK board: Not connected. ABX8XX-SPI-EVK board: SPI master out / slave in data signal. Connects to the I/O interface SPI data input pin (SDI) of the ABX8XX.
11	SPI_MISO	--	ABX8XX-I2C-EVK board: Not connected. ABX8XX-SPI-EVK board: SPI master in / slave out data signal. Connects to the I/O interface SPI data output pin (SDO) of the ABX8XX.
12	SPI_SCK	--	ABX8XX-I2C-EVK board: Not connected. ABX8XX-SPI-EVK board: Connects to the I/O interface clock pin (SCL) of the ABX8XX. It provides the clock input for SPI interface mode.
13	GND	--	PCB GND connection. There is a single GND plane net for the PCB.
14	VCC_IO	--	This supply connection pin provides power to the board pull-up resistors and temperature sensor IC. The VCC_AM_IMSR and VCC_IO connector pins should be connected to the same voltage level.
15	I2C_SCL	2.2k	ABX8XX-I2C-EVK board: Connects to the I/O interface clock pin (SCL) of the ABX8XX. It provides the clock input for I ² C interface mode. ABX8XX-SPI-EVK board: Not connected.
16	I2C_SDA	2.2k	ABX8XX-I2C-EVK board: Connects to the I ² C interface data I/O pin (SDA) of the ABX8XX. ABX8XX-SPI-EVK board: Not connected.
17	VCC_AM_IMSR	--	This supply connection pin provides power to VCC supply pin of the ABX8XX through SW1. The VCC_AM_IMSR and VCC_IO connector pins should be connected to the same voltage level.
18	GND	--	PCB GND connection. There is a single GND plane net for the PCB.
19	VBAT_AM_IMSR	--	This supply connection pin provides power to VBAT supply pin of the ABX8XX through SW2. It can be used to provide the backup power source to the ABX8XX.

AB08XX/AB18XX Real Time Clock Family

Pin Number	Pin Name	Board Pull-up Resistor	Description
20	SUCAP_DIS	--	Super capacitor disconnect signal. This signal can be used to connect/disconnect the super capacitor from the ABX8XX VBAT pin. Additional component population changes are required to use this feature.
21	VTEMP	--	This is the analog voltage output from the temperature sensor IC on the board. The temperature sensor IC is not populated on the board by default.
22	LED	--	This pin connects to the debug LED populated on the board through a 510 ohm resistor.
23	VSYS	--	Test point
24	VPP_CON	--	Test point

A 5 x 5 array of probe points for the ABX8XX device is provided on the EVK board around the perimeter of the device package as shown in Figure 6. This enables users to probe or connect wires to the pins of the ABX8XX device for test and debug.




Figure 6 – 5 x 5 Test Point Array Pin-out

5. VCC and VBAT Current Measurements with SW1 and SW2

The ABX8XX VCC and VBAT supply current can be measured by connecting an ammeter to the VCC and VBAT current measurement pins. The VCC and VBAT current measurement pins and +/- polarity are shown in Figure 2. SW1 is connected across the + and – terminals of the VCC current measurement pins and SW2 is connected across the + and – terminals of the VBAT current measurement pins.

AB08XX/AB18XX Real Time Clock Family

SW1 and SW2 are placed in the “open” position by sliding the switch lever to the left side as shown in Figure 7. They are placed in the “closed” position by sliding the switch lever to the right side.

When the switch is placed in the “open” position, the VCC/VBAT connection to the ABX8XX device becomes an open circuit. This forces current to flow through the VCC/VBAT current measurements pins and enables current measurement with an ammeter. When the switch is placed in the “closed” position, a short circuit is placed across the terminals of the VCC/VBAT current measurement pins. If an ammeter is still connected, its terminals will also get shorted together. This allows the ammeter to be removed from the VCC/VBAT current measurement pins without losing power to the ABX8XX device. If an ammeter is not connected to the VCC/VBAT current measurement pins, the switch should be placed in the “closed” position to supply power to the ABX8XX device from the 24-pin connector.




Figure 7 – VCC and VBAT Current Measurement

6. VBAT Backup Power

Backup power to the ABX8XX VBAT pin can be provided using the 24-pin connector or the on-board super capacitor. The super capacitor can be connected to the VBAT pin of the ABX8XX by populating 0 ohm resistors or solder shorts across R10 and R16. This will allow continued time keeping, register/memory state retention, etc. should the VCC supply be removed. Information about using the ABX8XX integrated trickle charger to charge the super capacitor can be found in the datasheet document “ABX8XX Real Time Clock Family with Power Management.”

7. External 32 kHz Clock

An external 32.768 kHz clock can be supplied to the ABX8XX device via the MMCX connector footprint shown in Figure 2. The middle pin of this connector footprint connects to the XO pin of the ABX8XX device. An MMCX connector (part number provide in the component list of Table 3 and Table 4) or other can be soldered to these pins to connect to an external frequency generator. The external clock must not exceed either the VCC supply or 1.8V (maximum input voltage), whichever is less.

AB08XX/AB18XX Real Time Clock Family

To connect the MMCX connector to the XO pin of the ABX8XX device, remove the crystal from the board and populate R28 with a 0 ohm resistor or solder short.

8. Debug LED

A debug/indicator LED is provided on the board and has an individual pin connection to the 24 pin connector. There is a 510 ohm resistor in series with the LED with the cathode of the LED connected to GND. The LED can be connected directly to the VCC_IO supply to indicate when power is supplied to the board or it can be connected to an MCU GPIO pin.

9. Installation Guide

This section provides a guide for setting up the EVK to quickly evaluate the AB08XX and ABX8XX product families. It is assumed in the subsequent discussion that a microcontroller development kit is being used as a Host Controller (HC). It is also assumed that the HC has accessible pins for I²C or SPI communication and accessible GPIO pins for interfacing with the other ABX8XX-EVK pins.

9.1 Hardware Setup

1. Begin with the ABX8XX-EVK and HC development boards powered down.
2. For the ABX8XX-I2C-EVK, connect the I2C_SDA (pin 16) and I2C_SCL (pin 15) pins on the EVK 24 pin connector to the SDA and SCL pins on the HC development board. For the ABX8XX-SPI-EVK, connect the SPI_SCK (pin 12), SPI_MISO (pin 11), SPI_MOSI (pin 10) and SPI_nCE/nTIRQ (pin 9) pins on the EVK connector to the corresponding pins on the HC development board.
3. Connect any other digital inputs/outputs of interest on the ABX8XX-EVK development board connector to GPIO pins on the HC.
4. Connect the VCC, VBAT (if applicable), and VSS pins on the EVK connector to appropriate supply voltages. The VCC supply voltage should be connected to both VCC_AM_IMSR (pin 17) and VCC_IO (pin 14) (see Figure 5). The VBAT supply voltage should be connected to VCC_AM_IMSR (pin 19). The HC VCC and ABX8XX VCC supplies should be the same voltage.
5. Power up the ABX8XX-EVK and HC development boards.

9.2 Software Setup

The ABX8XX-EVK does not require any host PC software installation but does require minimal driver development for the HC. All drivers are simple sequences of I²C or SPI register writes. Detailed information on each register in the ABX8XX products can be found in the datasheet documents titled, "AB08XX Real Time Clock Family" and "ABX8XX Real Time Clock Family with Power Management."

9.3 Measuring Current Draw in the ABX8XX-EVK

To measure current draw on the ABX8XX-EVK, an ammeter must be inserted in series with the ABX8XX part, and the part must then be put into a desired oscillation state. Listed below are the steps required to measure current through the ABX8XX VCC pin in the most energy-efficient setting in crystal (XT) oscillation and RC oscillation modes.

1. Complete Steps 1-4 in Section 9.1.
2. Connect an ammeter in series with the VCC pin on the ABX8XX part. This is done most easily by first connecting an ammeter between the VCC current measurement pins (see Figure 7). Power on the ammeter and set it to a range setting capable of measuring mA or tens of mA. To measure positive current, the ammeter polarity should be connected following the VCC Current Measurement polarity

AB08XX/AB18XX Real Time Clock Family

markers (+/-) shown in Figure 2. Once the ammeter is connected, change the position of SW1 to the open position (see Figure 7).

3. Power up the ABX8XX-EVK and HC development boards.
4. Issue a series of commands to place the ABX8XX part in a typical low current oscillation state. The examples here use the I/O access functions readreg and writereg described in the pseudo code
 - a. Set the OUT bit (register 0x10 bit 4) to 1 and the OUT1S field (register 0x11 bits [1:0]) to 0 to insure the OUT1 pin is high and not drawing current through the pullup resistor. Set the OUTB bit (register 0x10 bit 5) to 1 and the OUT2S field (register 0x11 bits [4:2]) to 0 to insure the OUT2 pin is high and not drawing current through the pullup resistor. Set the RS1E bit (register 0x11 bit 5) to 0 to disable the external reset input. This should force the nRST pin to be high and not draw current through the pullup resistor.

```
temp = readreg(0x10)           // Read the Control1 Register
writereg(0x10, temp | 0x30)    // Set the OUT and OUTB bits
temp = readreg(0x11)           // Read the Control2 Register
writereg(0x11, temp & 0xC0)    // Set the OUT1S, OUT2S and RS1E fields to 0
```

- b. Set the IM field (register 0x12 bits [6:5]) to 0x3. This will minimize the current drawn by the alarm interrupt pulse generator.

```
temp = readreg(0x12)           // Read the Interrupt Mask Register
writereg(0x12, temp | 0x60)    // Set the IM field to 0x3
```

- c. Set the TE bit low and the TFS field to 0x3 by writing the value 0x03 to register 0x13. This will minimize internal current drawn by the Countdown Timer and insure the OUT3 pin is high and not drawing current through the pullup resistor.

```
writereg(0x13, 0x03)          // Set the TE bit to 0 and the TFS field to 0x3
```

- d. Set the SQWE bit (register 0x13 bit 7) to 0 to disable the output square wave generator and insure that the OUT4 pin is not toggling.

```
temp = readreg(0x13)           // Read the SQW Register
writereg(0x13, temp & 0x7F)    // Set the SQWE bit to 0
```

- e. To observe the current with the Crystal oscillator running, set the OSEL bit (register 0x1C bit 7) to 0. Note that register 0x1F MUST be written with the value 0xA1 prior to any attempt to modify register 0x1C.

```
temp = readreg(0x1C)           // Read the Oscillator Control Register
writereg(0x1F, 0xA1)           // Load the Configuration Key Register with 0xA1
writereg(0x1C, temp & 0x7F)    // Set the OSEL bit to 0
```

- f. To observe the current with the RC oscillator running, set the OSEL bit (register 0x1C bit 7) to 1. Note that register 0x1F MUST be written with the value 0xA1 prior to any attempt to modify register 0x1C.

```
temp = readreg(0x1C)           // Read the Oscillator Control Register
writereg(0x1F, 0xA1)           // Load the Configuration Key Register with 0xA1
writereg(0x1C, temp | 0x80)    // Set the OSEL bit to 1
```

AB08XX/AB18XX Real Time Clock Family

- g. The calendar counter registers (registers 0x0 through 0x7) may be read to verify that the internal timing system is operational.
5. Change the ammeter range to a setting capable of measuring nA and observe the current draw. Averaging and filtering functions can help eliminate minor fluctuations in current caused by environmental radiation.

Note that nA current measurements can be influenced by both environmental conditions and equipment selection. Contact Abracon support at tech-support@abracon.com with any questions about measurement conditions.

9.4 Measuring Frequency Accuracy in the ABX8XX-EVK

To measure frequency accuracy on the ABX8XX-EVK, a high-precision universal counter should be used to monitor the frequency output on the CLKOUT pin. Follow the steps below to achieve a high accuracy reading in crystal (XT) oscillation mode, RC oscillation mode, or autocalibration mode.

1. Complete Steps 1-4 in Section 9.1.
2. Connect a universal counter to Pin 4 of the 24-pin expansion connector in Figure 5. Choose a long integration time on the universal counter (e.g., 10 seconds) to ensure that a sufficient number of clock periods are captured.
3. Power up the ABX8XX-EVK and HC development boards.
4. Place the ABX8XX part in a typical oscillation state by setting the SQWE bit (register 0x13 bit 7) to 1, and the SQFS field (register 0x13 bits [4:0]) to select a low frequency used to measure the internal oscillation modes. A frequency of 1 Hz (SQFS = 0xF) allows easy interpretation of the frequency error.

```
writereg(0x13, 0x8F) // Set the SQWE bit to 1 and the SQFS field to 0xF
```

5. Note that if the ABX8XX is driving an external clock signal, the current drawn will be significantly higher than the current observed in low power mode.
6. Observe the frequency reported by the universal counter. For short integration times, the frequency may appear to fluctuate for the RC oscillator, in particular. This is a result of calibration and does not affect long term accuracy. Record frequency measurements over extended periods of hours or days to achieve the most accurate data.

- a. To observe the Crystal oscillator, set the OSEL bit (register 0x1C bit 7) to 0. Note that register 0x1F MUST be written with the value 0xA1 prior to any attempt to modify register 0x1C.

```
temp = readreg(0x1C) // Read the Oscillator Control Register
writereg(0x1F, 0xA1) // Load the Configuration Key Register with 0xA1
writereg(0x1C, temp & 0x7F) // Set the OSEL bit to 0
```

- b. To observe the RC oscillator, set the OSEL bit (register 0x1C bit 7) to 1. Note that register 0x1F MUST be written with the value 0xA1 prior to any attempt to modify register 0x1C.

```
temp = readreg(0x1C) // Read the Oscillator Control Register
writereg(0x1F, 0xA1) // Load the Configuration Key Register with 0xA1
writereg(0x1C, temp | 0x80) // Set the OSEL bit to 1
```

- c. To observe the RC oscillator while autocalibration is active, set the OSEL bit (register 0x1C bit 7) to 1 and the ACAL field (register 1C bits [6:5]) to 0x3. Note that register 0x1F MUST be written with the value 0xA1 prior to any attempt to modify register 0x1C. This will enable autocalibration of the RC oscillator to occur every 512 seconds (roughly every 8.5 minutes). The first autocalibration cycle will begin as soon as ACAL is set to 0x3, and will be completed with a new RC calibration value in the CALRC registers (registers 0x15 and 0x16) within 60 seconds.

AB08XX/AB18XX Real Time Clock Family

```
temp = readreg(0x1C)    // Read the Oscillator Control Register
temp = temp & 0x9F      // Mask the ACAL field
writereg(0x1C, temp | 0x60) // Set the OSEL bit to 1 and the ACAL field to 0x2
```

Note that frequency accuracy measurements are heavily influenced by test equipment. Contact Abracon support at tech-support@abracon.com with any questions about proper test setup.

10. Schematics and Component List

Figure 8 and Figure 9 below show the two pages of the ABX8XX-I2C-EVK board schematics. Figure 10 and Figure 11 show the two pages of the ABX8XX-SPI-EVK board schematics. Table 3 shows the ABX8XX-I2C-EVK board component list and Table 4 shows the ABX8XX-SPI-EVK board component list. Board components labeled as DNP (do not populate) in the schematics are not installed on the board.

AB08XX/AB18XX Real Time Clock Family




Figure 8 – ABX8XX-I2C-EVK Schematic Page 1

AB08XX/AB18XX Real Time Clock Family




Figure 9 – ABX8XX-I2C-EVK Schematic Page 2

AB08XX/AB18XX Real Time Clock Family




Figure 10 – ABX8XX-SPI-EVK Schematic Page 1

AB08XX/AB18XX Real Time Clock Family




Figure 11 – ABX8XX-SPI-EVK Schematic Page 2

AB08XX/AB18XX Real Time Clock Family

Table 3 – ABX8XX-I2C-EVK Component List

ITEM	QTY	REFERENCE	PART	MFG_NAME	MFG_PN	DESCRIPTION
1	1	C4	30mF	TAIYO YUDEN	PAS311HR-VG1	30mF super capacitor
2	4	C7,C8,C9,C10	10nF	TAIYO YUDEN	TMK105B7103KV-F	ceramic capacitor
3	1	D2	LED_GREEN	OSRAM	LG L29K-G2J1-24-Z	green LED
4	2	J25,J26,J27,J28	SKT_1_PIN	SAMTEC	MTMM-102-02-L-S-195	Two pin header
5	4	R5,R6,R8,R11, R33, R34, R35	10.0k	Panasonic	ERJ-2GE0R00C	0402 size 10k ohm
6	3	R4, R10, R12,R15,R25, R32	0 ohm	PANASONIC	ERJ-1GE0R00C	resistor/jumper
7	2	R20,R21	2.2k	Panasonic	ERJ-2RKF2201X	0402 size 2.7k ohm
8	1	R27	510 ohm	PANASONIC	ERJ-2RKF5100X	0402 size 512 ohm
9	2	SW2,SW1	EG1260AS	E SWITCH	EG1260AS	slide switch
10	1	Y2	32.768 kHz	ABRACON CORP	ABS07-32.768KHZ-7-T	3.2 x 1.5mm, 7pF, 32.768kHz crystal
11	1	J1,J2,J3,J4,J5,J6,J7,J8, J9,J10,J11,J12,J13,J14, J15,J16,J17,J18,J19,J20, J21,J22,J23,J24	SKT_1_PIN	SAMTEC	MTMM-112—05-L-D-200	2mm pin headers , 2 x 12
12	1	U3	AB180X	ABRACON	AB180X	AB180X 16 pin QFN
COMPONENTS NOT INSTALLED						
1	2	C2,C1	1.0pF	MURATA	GRM1555C1H1R2CZ01D	1.0pF ceramic
2	1	C6	15mF	PANASONIC	EEC-ER0E153	30mF super capacitor
3	1	C11	0.1uF	MURATA	GRM155F50J104ZA01D	0.1uF ceramic cap
4	1	D1	ESD5V3S1U-02LRH	INFINEON TECHNOLOGIES	ESD5V3S1U-02LRH E6327	5.3V TVS diode
5	1	J29	MMCX-J-P-X-RA-TH1	SAMTEC	MMCX-J-P-X-RA-TH1	right angle MMCX
6	1	J30	HDR_2x20	SAMTEC	LTH-020-01-G-D-A	Samtec 2x20 low profile connector
7	1	J31	HDR_2x10	SAMTEC	LTH-010-01-G-D-A	Samtec 2x10 low profile connector
8	1	Q1	Si1023X	VISHAY SILICONIX	SI1023X-T1-GE3	low leakage PFET
9	17	R1,R2,R3,,R7,R9, R14,R16,R19,R24,R26,R28, R29,R30,R31	0 ohm	PANASONIC	ERJ-1GE0R00C	
10	1	R13	51 ohm	VISHAY	CRCW040251R0FKED	resistor/jumper
11	2	R17,R23	47k	YAGEO	RC0402FR-0747KL	0402 size 47k ohm
12	2	R18, R22	10.0k	YAGEO	RC0402FR-0710KL	0402 size 10k ohm
13	2	SS1,SS3	1/8" STANDOFF	RAF ELECTRONIC HARDWARE	1600A-256-B	round threaded standoff
14	1	U1	ABx80x_SOIC	ABRACON	ABx801/2/3/4	ABx80x SOIC device
15	1	U2	TEST POINTS	N/A	N/A	
16	1	U4	TMP20AIDRL	TEXAS INSTRUMENTS	TMP20AIDRLT	temperature sensor
17	1	Y1	32.768 kHz	ABRACON CORP	ABS07-32.768KHZ-7-T	3.2 x 1.5mm, 7pF, 32.768kHz crystal
18	1	Y3	32.768 kHz	ABRACON CORP	ABS06-32.768KHZ-9-T	2.0 x 1.2mm, 9pF, 32.768kHz crystal

AB08XX/AB18XX Real Time Clock Family

Table 4 – ABX8XX-SPI-EVK Component List

ITEM	QTY	REFERENCE	PART	MFG_NAME	MFG_PN	DESCRIPTION
1	1	C4	30mF	TAIYO YUDEN	PAS311HR-VG1	30mF super capacitor
2	4	C7,C8,C9,C10	10nF	TAIYO YUDEN	TMK105B7103KV-F	ceramic capacitor
3	1	D2	LED_GREEN	OSRAM	LG L29K-G2J1-24-Z	green LED
4	2	J25,J26,J27,J28	SKT_1_PIN	SAMTEC	MTMM-112-05_L_D-200	Two pin headers
5	4	R5,R6,R8,R11, R33, R34, R35	10.0k	PANASONIC	ERJ-2GE0R00C	0402 size 10k ohm
6	3	R4, R9, R10, R14,R24, R32	0 ohm	PANASONIC	ERJ-1GE0R00C	resistor/jumper
7	1	R27	510 ohm	PANASONIC	ERJ-2RKF5100X	0402 size 512 ohm
8	2	SW2,SW1	EG1260AS	E SWITCH	EG1260AS	slide switch
9	1	Y2	32.768 kHz	ABRACON CORP	ABS07-32.768KHZ-7-T	3.2 x 1.5mm, 7pF, 32.768kHz crystal
10	1	J1,J2,J3,J4,J5,J6,J7,J8, J9,J10,J11,J12,J13,J14, J15,J16,J17,J18,J19,J20, J21,J22,J23,J24	SKT_1_PIN	SAMTEC	MTMM-112-05-L-D-200	2mm Pin Headers , 2 x 12
11	1	U3	AB181X	ABRACON	AB181X	AB181X 16 pin QFN
COMPONENTS NOT INSTALLED						
1	2	C2,C1	1.0pF	MURATA	GRM1555C1H1R2CZ01D	1.0pF ceramic
2	1	C6	15mF	PANASONIC	EEC-ER0E153	30mF super capacitor
3	1	C11	0.1uF	MURATA	GRM155F50J104ZA01D	0.1uF ceramic cap
4	1	D1	ESD5V3S1U-02LRH	INFINEON TECHNOLOGIES	ESD5V3S1U-02LRH E6327	5.3V TVS diode
5	1	J29	MMCX-J-P-X-RA-TH1	SAMTEC	MMCX-J-P-X-RA-TH1	right angle MMCX
6	1	J30	HDR_2x20	SAMTEC	LTH-020-01-G-D-A	Samtec 2x20 low profile connector
7	1	J31	HDR_2x10	SAMTEC	LTH-010-01-G-D-A	Samtec 2x10 low profile connector
8	1	Q1	SI1023X	VISHAY SILICONIX	SI1023X-T1-GE3	low leakage PFET
9	17	R1,R2,R3,R7, R12, R15, R16,R19,R25,R26,R28, R29,R30,R31	0 ohm	PANASONIC	ERJ-1GE0R00C	
10	1	R13	51 ohm	VISHAY	CRCW040251R0FKED	resistor/jumper
11	2	R17,R23	47k	YAGEO	RC0402FR-0747KL	0402 size 47k ohm
12	2	R18, R22	10.0k	YAGEO	RC0402FR-0710KL	0402 size 10k ohm
13	2	SS1,SS3	1/8" STANDOFF	RAF ELECTRONIC HARDWARE	1600A-256-B	round threaded standoff
14	1	U1	ABx80x_SOIC	ABRACON	ABx801/2/3/4	ABx80x SOIC device
15	1	U2	TEST POINTS	N/A	N/A	
16	1	U4	TMP20AIDRL	TEXAS INSTRUMENTS	TMP20AIDRLT	temperature sensor
17	1	Y1	32.768 kHz	ABRACON CORP	ABS07-32.768KHZ-7-T	3.2 x 1.5mm, 7pF, 32.768kHz crystal
18	2	R20,R21	2.2k	PANASONIC	ERJ-2RKF2201X	0402 size 2.7k ohm
19	1	Y3	32.768 kHz	ABRACON CORP	ABS06-32.768KHZ-9-T	2.0 x 1.2mm, 9pF, 32.768kHz crystal

AB08XX/AB18XX Real Time Clock Family

11. Component Installation Differences

Table 5 lists the component installation differences between the ABX8XX-I2C-EVK and ABX8XX-SPI-EVK boards.

Table 5 – Component Installation Differences

Component	ABX8XX-I2C-EVK Board	ABX8XX-SPI-EVK Board
R12, R15, R20, R21, R25	Installed	Not Installed
R9, R14, R24	Not Installed	Installed

AB08XX/AB18XX Real Time Clock Family

Legal Information and Disclaimers

ABRACON INTENDS FOR THE CONTENT CONTAINED IN THE DOCUMENT TO BE ACCURATE AND RELIABLE. THIS CONTENT MAY, HOWEVER, CONTAIN TECHNICAL INACCURACIES, TYPOGRAPHICAL ERRORS OR OTHER MISTAKES. ABRACON MAY MAKE CORRECTIONS OR OTHER CHANGES TO THIS CONTENT AT ANY TIME. ABRACON AND ITS SUPPLIERS RESERVE THE RIGHT TO MAKE CORRECTIONS, MODIFICATIONS, ENHANCEMENTS, IMPROVEMENTS AND OTHER CHANGES TO ITS PRODUCTS, PROGRAMS AND SERVICES AT ANY TIME OR TO DISCONTINUE ANY PRODUCTS, PROGRAMS, OR SERVICES WITHOUT NOTICE.

THE CONTENT IN THIS DOCUMENT IS PROVIDED "AS IS". ABRACON AND ITS RESPECTIVE SUPPLIERS MAKE NO REPRESENTATIONS ABOUT THE SUITABILITY OF THIS CONTENT FOR ANY PURPOSE AND DISCLAIM ALL WARRANTIES AND CONDITIONS WITH REGARD TO THIS CONTENT, INCLUDING BUT NOT LIMITED TO, ALL IMPLIED WARRANTIES AND CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE AND NON-INFRINGEMENT OF ANY THIRD PARTY INTELLECTUAL PROPERTY RIGHT.

ABRACON DOES NOT WARRANT OR REPRESENT THAT ANY LICENSE, EITHER EXPRESS OR IMPLIED, IS GRANTED UNDER ANY PATENT RIGHT, COPYRIGHT, MASK WORK RIGHT, OR OTHER INTELLECTUAL PROPERTY RIGHT OF ABRACON COVERING OR RELATING TO THIS CONTENT OR ANY COMBINATION, MACHINE, OR PROCESS TO WHICH THIS CONTENT RELATE OR WITH WHICH THIS CONTENT MAY BE USED.

USE OF THE INFORMATION IN THIS DOCUMENT MAY REQUIRE A LICENSE FROM A THIRD PARTY UNDER THE PATENTS OR OTHER INTELLECTUAL PROPERTY OF THAT THIRD PARTY, OR A LICENSE FROM ABRACON UNDER THE PATENTS OR OTHER INTELLECTUAL PROPERTY OF ABRACON.

INFORMATION IN THIS DOCUMENT IS PROVIDED SOLELY TO ENABLE SYSTEM AND SOFTWARE IMPLEMENTERS TO USE ABRACON PRODUCTS. THERE ARE NO EXPRESS OR IMPLIED COPYRIGHT LICENSES GRANTED HEREUNDER TO DESIGN OR FABRICATE ANY INTEGRATED CIRCUITS OR INTEGRATED CIRCUITS BASED ON THE INFORMATION IN THIS DOCUMENT. ABRACON RESERVES THE RIGHT TO MAKE CHANGES WITHOUT FURTHER NOTICE TO ANY PRODUCTS HEREIN. ABRACON MAKES NO WARRANTY, REPRESENTATION OR GUARANTEE REGARDING THE SUITABILITY OF ITS PRODUCTS FOR ANY PARTICULAR PURPOSE, NOR DOES ABRACON ASSUME ANY LIABILITY ARISING OUT OF THE APPLICATION OR USE OF ANY PRODUCT OR CIRCUIT, AND SPECIFICALLY DISCLAIMS ANY AND ALL LIABILITY, INCLUDING WITHOUT LIMITATION CONSEQUENTIAL OR INCIDENTAL DAMAGES. "TYPICAL" PARAMETERS WHICH MAY BE PROVIDED IN ABRACON DATA SHEETS AND/OR SPECIFICATIONS CAN AND DO VARY IN DIFFERENT APPLICATIONS AND ACTUAL PERFORMANCE MAY VARY OVER TIME. ALL OPERATING PARAMETERS, INCLUDING "TYPICALS" MUST BE VALIDATED FOR EACH CUSTOMER APPLICATION BY CUSTOMER'S TECHNICAL EXPERTS. ABRACON DOES NOT CONVEY ANY LICENSE UNDER NEITHER ITS PATENT RIGHTS NOR THE RIGHTS OF OTHERS. ABRACON PRODUCTS ARE NOT DESIGNED, INTENDED, OR AUTHORIZED FOR USE AS COMPONENTS IN SYSTEMS INTENDED FOR SURGICAL IMPLANT INTO THE BODY, OR OTHER APPLICATIONS INTENDED TO SUPPORT OR SUSTAIN LIFE, OR FOR ANY OTHER APPLICATION IN WHICH THE FAILURE OF THE ABRACON PRODUCT COULD CREATE A SITUATION WHERE PERSONAL INJURY OR DEATH MAY OCCUR. SHOULD BUYER PURCHASE OR USE ABRACON PRODUCTS FOR ANY SUCH UNINTENDED OR UNAUTHORIZED APPLICATION, BUYER SHALL INDEMNIFY AND HOLD ABRACON AND ITS OFFICERS, EMPLOYEES, SUBSIDIARIES, AFFILIATES, AND DISTRIBUTORS HARMLESS AGAINST ALL CLAIMS, COSTS, DAMAGES, AND EXPENSES, AND REASONABLE ATTORNEY FEES ARISING OUT OF, DIRECTLY OR INDIRECTLY, ANY CLAIM OF PERSONAL INJURY OR DEATH ASSOCIATED WITH SUCH UNINTENDED OR UNAUTHORIZED USE, EVEN IF SUCH CLAIM ALLEGES THAT ABRACON WAS NEGLIGENT REGARDING THE DESIGN OR MANUFACTURE OF THE PART.