

# AS –Interface Programmer

User Manual

## *User Manual*



# *AS-Interface Programmer*

### Notice:

#### RESTRICTIONS

THE ZMD AS-INTERFACE PROGRAMMER HARDWARE AND ZMD AS-INTERFACE PROGRAMMER SOFTWARE IS DESIGNED FOR IC EVALUATION, LABORATORY SETUP AND MODULE DEVELOPMENT ONLY.

THE ZMD AS-INTERFACE PROGRAMMER HARD- AND SOFTWARE MUST NOT BE USED FOR MODULE PRODUCTION AND PRODUCTION TEST SETUPS.

ZMD AG SHALL NOT BE LIABLE FOR ANY DAMAGES ARISING OUT OF DEFECTS RESULTING FROM (i) DELIVERED HARD- AND SOFTWARE (ii) NON-OBSERVANCE OF INSTRUCTIONS CONTAINED IN THIS MANUAL, OR (iii) MISUSE, ABUSE, USE UNDER ABNORMAL CONDITIONS OR ALTERATION BY ANYONE OTHER THAN ZMD AG. TO THE EXTENT PERMITTED BY LAW ZMD AG HEREBY EXPRESSLY DISCLAIMS AND USER EXPRESSLY WAIVES ANY AND ALL WARRANTIES, WHETHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING, WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR A PARTICULAR PURPOSE, STATUTORY WARRANTY OF NON-INFRINGEMENT AND ANY OTHER WARRANTY THAT MAY ARISE BY REASON OF USAGE OF TRADE, CUSTOM OR COURSE OF DEALING.

# AS –Interface Programmer

User Manual


Table of Contents	Page
<b>1 HARDWARE .....</b>	<b>3</b>
1.1 BOARD DESCRIPTION.....	3
1.2 HARDWARE SETUP .....	4
1.2.1 ASi Bus powered setup .....	4
1.2.2 Internal ASi power generation .....	5
1.2.3 Master control via CMOS Interface .....	5
<b>2 SOFTWARE .....</b>	<b>6</b>
2.1 SETUP AND INSTALLATION .....	6
2.2 GUI (GRAPHICAL USER INTERFACE) .....	6
2.2.1 Automatic software update .....	6
2.2.2 Main window .....	7
2.2.3 Graphical Input Output Control.....	7
2.2.4 Change parameter data.....	8
2.2.5 Change address .....	10
2.2.6 EEPROM Configuration.....	11
2.2.7 Terminal.....	12
2.3 TELEGRAM STRUCTURE.....	13
2.3.1 Telegram structure of Standard AS-i telegrams in Terminal Mode .....	13
2.3.2 Telegram structure of special functions in Terminal Mode.....	14
<b>3 SCHEMATICS .....</b>	<b>15</b>
3.1 ASi AND MCU .....	15
3.2 PC COMMUNICATION INTERFACE.....	16
<b>4 NOTES .....</b>	<b>17</b>

# AS –Interface Programmer

User Manual

## 1 Hardware

### 1.1 Board description



#### ASI+ / ASI-:

Connection to the ASi network. The Programmer runs as AS-i Master. In AS-i mode (LED5 off) the ASi Programmer can be powered via the ASi network. Otherwise the power supply of the connected ASi network can be provided by the ASi Programmer. Therefore a DC power supply must be connected to the 30V input of the ASi Programmer. In this case the ASi Programmer handle the data decoupling via the onboard decoupling network. Attend there is only one power supply connected to the ASi Programmer, a ASi power supply at the ASi Network **or** a DC Power Supply at the ASi Programmer. (see chapter 1.2)

#### Input 30V +/-:

30V DC Input voltage to supply the AS-i network and the programmer via the on board decoupling network. An additional AS-interface power supply at the AS-i network is not required.  
A supply voltage of 24V DC will be also enough for simply test setups. To prevent the AS-I power generation circuit (decoupling circuit) against a current overload limit the input current at Input 30V connector to 150mA!

#### CMOS Interface:

CMOS output for manchester coded signals for control a ASi-IC in master mode. *See detailed description in chapter 1.2.3.*

# AS –Interface Programmer


User Manual

<b>RS232 interface:</b>	connection to PC (19200 Baud, 8 bit, no parity, 1 stop bit). Connect this port with the enclosed cable to a free serial COM port at your PC. After program start, the ASI Programmer search beginning from COM1 to COM16 for connected hardware. Via menu "Options" the COM port (1-8) can also selected manually.		
<b>µC Interface:</b>	for µC firmware-update (access by ZMD only)		
<b>LED1...4:</b>	status interface:	D1 Programmer power on D3 telegram timeout D4 data flow at ASI/CMOS	
<b>LED 5:</b>	mode ASI/CMOS	off: ASi channel active on: CMOS channel active	

## 1.2 Hardware setup

To supply the system 2 setups are possible. Do not mix both variants.

### 1.2.1 ASi Bus powered setup




The power supply of the complete system, including ASI modules and ASI programmer will be provided by a special AS-interface power supply. No additional power supply at the 30V connector is allowed.

# AS –Interface Programmer

User Manual


## 1.2.2 Internal ASI power generation



The power supply of the complete system, including ASI modules and ASI programmer will be provided by a connected laboratory power supply. No additional ASI power supply may be connected to the ASI network. The data decoupling will be enforced by an data decoupling network, integrated on the ASI Programmer. The DC supply voltage may be 24 VDC and 33VDC. The supply voltage according to AS-Interface Complete Specification is 29,5...31,6V. To prevent the AS-I power generation circuit (decoupling circuit) against a current overload limit the input current at Input 30V connector to 150mA!

## 1.2.3 Master control via CMOS Interface

The following circuit diagram shows the connection of an external ASI master circuit.



**Maximum digital voltage level at CMOS input and output port is limited to 5V DC!!!**

Do not pull up the LED/IRD pin to Uout. Pull up resistors are integrated in the ASI Programmer circuit (R6, R7), no additional pull up resistors are required. The A<sup>2</sup>SI LED pin can be connected to the IN pin at the ASI Programmer and the A<sup>2</sup>SI IRD pin can be connected directly to the OUT pin of the ASI programmer. To activate the ASI Programmer CMOS interface type “CMOS” in the terminal. The LED D5 light red.

To switch back in normal ASI mode type “ASI” in terminal.

# AS –Interface Programmer

User Manual

## 2 Software

### 2.1 Setup and Installation

System requirements: 486 compatible PC, 8MB RAM, 12MB free HDD, free COM port

If the PC do not support a free COM port, the ASI Programmer can be connected via a USB to serial adapter. To use such a adapter a special driver (delivered from USB to serial adapter manufacturer) has to be installed.


Run "Setup ZMD AS-Interface Programmer Vxxx.exe" from your CD-ROM. Follow the instructions of the setup program. Software updates are available via [www.zmd.biz](http://www.zmd.biz).

### 2.2 GUI (Graphical User Interface)

Start the graphical user interface by click at the **ZMD AS-Interface Programmer** Icon in program menu or at desktop. The software search for connected hardware automatically. After a software update a firmware check of the microcontroller firmware will be enforced. In certain cases a firmware update is necessary to use new software features.

#### 2.2.1 Automatic software update

After program start the software check's the  $\mu$ C firmware. To support new features a firmware update is recommended if an old firmware was detected:




- Click on "Yes" to update a new firmware version to the  $\mu$ C. ***The update process may not be interrupted. During the update process do not switch to other PC tasks, do not remove cables or power!***
- Click on "No" to disable the automatically firmware update in future.
- Click on "Cancel" to disable the firmware update for this session.

The update of a new firmware version is also possible via the menu "Options/Settings/Firmware Update". To upload a new file a actual \*.hex file is required.

# AS –Interface Programmer

User Manual

## 2.2.2 Main window



## 2.2.3 Graphical Input Output Control

This module allows to control an AS-Interface network (up to 62 slave modules) bit by bit. Graphical Input Output control runs in a loop mode for permanent data exchange with all slaves. The data transfer rate between programmer and slave modules does not reach ASi real-time mode. The speed of data exchange depends on the PC performance. The minimum cycle time for data exchange with 1 slave is approximately 5,4ms.

**Note:** Resulting of the slower ASi Programmer cycle time a communication error with connected modules may provoked if the ASi module Watchdog activation flag is set.

Handling:


1. Click on "Read Network Configuration" to detect the connected Slaves
2. Click on "Write Parameter" for parameterisation of all detected slave modules. To modify the parameter file click on "Change Parameter File" button. Otherwise default parameters (&B0000) may be used.
3. In order to support the 4 In put / 4 Output mode (4I4O), described in the AS-I Complete Specification 3.0, this mode can be activated for all slaves in extended address mode separately. The special nibble selected transfer protocol (chapter 5.7.4.1 in Complete Specification). To activate this feature in slave modules, the corresponding EEPROM bit has to be programmed further.
4. A Click on „Run“ will start the loop mode for continuous data exchange (non ASi real-time mode!). The loop counter shows the number of completed network data exchange cycles.



# AS –Interface Programmer

User Manual

5. The slave input data are shown by red circles (=“0”) and green circles (=“1”). Output ports can be changed by setting a check mark in the corresponding field.
6. All outputs will be erased by a click on „Clear Outputs“.
7. A Click on „Change Address“ will open the slave addressing window.



Detected Slave

Activation of 4I4O mode (spec 3.0)

bold border parameter bit P1 is set to “1”

loop counter

## 2.2.4 Change parameter data


This module can change parameter data for each slave module bit by bit. After a network scan parameter data can be set to the slave modules. The bits can be changed by setting (=“1”) a check mark in the corresponding box. To send the parameter data to the slaves click on “Write Parameter” or transfer this configuration to the input output control window to set parameters by click at “Write Parameter” in the input output control window. Parameter data will be read back and will be shown by red (=“0”) and green (=“1”) circles. A bold border at an input bit shows the sent parameter data in the parameter window and in the corresponding input output control window.

With a click on “Load Parameter File” or “Save Parameter File” file the parameter settings can be saved or loaded.



# AS –Interface Programmer

User Manual



	INPUT Normal / A-Slave				OUTPUT Normal / A-Slave				INPUT B-Slave				OUTPUT B-Slave				
	D3	D2	D1	D0	I3	I2	I1	I0	D3	D2	D1	D0	I3	I2	I1	I0	
1																	
2																	
3																	
4																	
5																	
6																	
7																	
8																	
9																	
10																	
11																	
12																	
13																	
14																	
15																	
16																	
17																	
18																	
19																	
20																	
21																	
22																	
23																	
24																	
25																	
26																	
27																	
28																	
29																	
30																	
31																	

File utility

Transfer  
parameter  
settings to input  
output control


Parameter  
data input  
from slave

Parameter Data output to  
the slave

# AS –Interface Programmer

User Manual

## 2.2.5 Change address



1. Select a slave to change address
2. Select a new slave address ( the select menus show only free network addresses, witch makes double addressing impossible)
3. Click on „Set Address“ to change the address.

### Note:

Switching between normal addressing mode and extended addressing mode is impossible in this menu. To activate the extended address mode the corresponding EEPROM setting (ID-Code = &H0A) has to be set with EEPROM configuration tool. Changing between A and B slave (through changing of the Bit3 of Extended ID Code 2) will be handled automatically.


# AS –Interface Programmer

User Manual

## 2.2.6 EEPROM Configuration

- To program EEPROM functions only 1 slave with address „0“ should be connected to the network

Bit configuration EEPROM show and modify



	BIT 3	BIT 2	BIT 1	BIT 0	
Address 0	<input type="checkbox"/> Slave Address Bit 3	<input type="checkbox"/> Slave Address Bit 2	<input type="checkbox"/> Slave Address Bit 1	<input type="checkbox"/> Slave Address Bit 0	Address: 0
Address 1				<input type="checkbox"/> Slave Address Bit 4	
Address 2	<input type="checkbox"/> ID Code Extension 1 Bit 3	<input type="checkbox"/> ID Code Extension 1 Bit 2	<input type="checkbox"/> ID Code Extension 1 Bit 1	<input type="checkbox"/> ID Code Extension 1 Bit 0	ID Code Extension 1: 0
Address 8	<input checked="" type="checkbox"/> ID Code Bit 3	<input type="checkbox"/> ID Code Bit 2	<input checked="" type="checkbox"/> ID Code Bit 1	<input type="checkbox"/> ID Code Bit 0	ID Code: A
Address 9	<input type="checkbox"/> ID Code Extension 2 Bit 3	<input type="checkbox"/> ID Code Extension 2 Bit 2	<input type="checkbox"/> ID Code Extension 2 Bit 1	<input type="checkbox"/> ID Code Extension 2 Bit 0	ID Code Extension 2: 0
Address A	<input type="checkbox"/> ID Configuration Bit 3	<input type="checkbox"/> ID Configuration Bit 2	<input type="checkbox"/> ID Configuration Bit 1	<input type="checkbox"/> ID Configuration Bit 0	ID Code: 0
Address B	<input type="checkbox"/> Reserved	<input type="checkbox"/> Reserved	<input type="checkbox"/> PWM_32k_Mode	<input checked="" type="checkbox"/> PWM Enable	
Address C	<input checked="" type="checkbox"/> Invert Data In	<input type="checkbox"/> Watchdog Active	<input type="checkbox"/> Program Mode Disable	<input type="checkbox"/> FID Disable	

Read IC Configuration    Write IC Configuration    Change Address    EXIT

Read EEPROM

Write EEPROM

Bit configuration hexadecimal


- Click on „Read IC Configuration“ to read current EEPROM setting.
- To change EEPROM setting click on the control boxes or select a hexadecimal bit configuration from the select bar.
- To write EEPROM configuration click on „Write IC Configuration“
- After the writing process the programmer software reads the current EEPROM configuration back from the IC.

# AS –Interface Programmer

## User Manual

### 2.2.7 Terminal

The terminal tool allows the communication with an AS-interface network or a single slave module command by command.



1. Type a valid command in the command line. For example “d12 2” – data exchange to slave with address 12 , send data 2 (decimal).
2. Click on “send...” or press return.
3. The terminal window shows the sent command and the corresponding answer.

In case of an error, a timeout or an error description will be send.

“Clear Log” will clear the terminal window. The “↑”- key brings the last send command back to the command line input textbox.

For detailed commands and other control functions, refer to the following command table:

# AS –Interface Programmer

User Manual

## 2.3 Telegram structure

### 2.3.1 Telegram structure of Standard AS-i telegrams in Terminal Mode

Description	Command	Master request 1	Extended Adr.	Separator	Master request 2	End	Remarks
Data Exchange	<b>D</b>	0...31	(a,b)	“ ” “,“ ” “ ”_“ “ ” “,“ ” “ ”_“	0-15	CR	In case of ext. Adr = a or b, no separator is required
Write Parameter	<b>P</b>	0...31	(a,b)	“ ” “,“ ” “ ”_“ “ ” “,“ ” “ ”_“	0-15	CR	
Address Assignment	<b>A</b>	0...31	--		--	CR	only to Adr. 0
Write Extend. ID-Code 1	<b>E</b>	0...15	--		--	CR	only to Adr. 0
Delete Address	<b>C</b>	0...31	(a,b)		--	CR	
Reset Slave	<b>R</b>	0...31	(a,b)		--	CR	
Read IO Configuration	<b>O</b>	0...31	(a,b)		--	CR	
Read ID-Code	<b>I</b>	0...31	(a,b)		--	CR	
Read ID-Code 1	<b>J</b>	0...31	(a,b)		--	CR	
Read ID-Code 2	<b>K</b>	0...31	(a,b)		--	CR	
Read Status	<b>S</b>	0...31	(a,b)		--	CR	
Broadcast	<b>BC</b>	--	--		--	CR	to all slaves
Enter Program Mode	<b>EPM</b>	--	--		--	CR	only to Adr. 0

General remarks:

Every command-structure must be closed with **CR** (return HEX Code 0A) or **ETX** (End of Text, HEX Code 03, Terminal Mode “CTRL+C”)

For commands and extended addressing bytes lower case letters or capitals can be used.

# AS –Interface Programmer

User Manual

## 2.3.2 Telegram structure of special functions in Terminal Mode

Description	Command	Remarks
Scan AS-I Bus	<b>W</b>	Scans the AS-I bus and reads the configuration data of the connected modules
Lock IRD Channel	<b>IRD</b>	Sends a magic Sequence to lock the IRD channel
Lock AS-I channel	<b>ASI</b>	Locks the Programmer board to the AS-I channel (default) - LED5 off – setting keeps alive after power down -
Lock CMOS channel	<b>CMOS</b>	Locks the Programmer board to the CMOS channel - LED5 on – setting keeps alive after power down -
Repeat a command line	<b>Lxxx</b>	Repeats the following command line xxx times
Terminate loop command	<b>@</b>	Terminates the loop command (Lxxx)
Echo mode on	<b>EON</b>	The Programmer repeats received commands character by character, e.g. for standard terminals
Echo mode off	<b>EOF</b>	The Programmer will not repeat received commands (default), a STX (&H02) always initiates a new command line
Read version number	<b>V</b>	Reads the Firmware version of the AS-I Programmer
Read Waitstate configuration	<b>WS</b>	Reads the Waitstate configuration – delay time between receiving a command and executing the command
Write Waitstate configuration	<b>WSxxx</b>	Writes the Waitstate configuration – XXX in milliseconds (0 = default value)
Read IC type	<b>T</b>	Reads the current ASI IC type at address 0



### 3 Schematics

### 3.1 ASi and MCU

Title		Transceiver – MCU		Sheet No. 1	
Project No.		A4990400		Revision No.	
Date		16.02.04		Date 25.05.04	
Author		Gerd Hofmann		phone ext - 393 email: ghofmann@zmd.de	
File		ASL_Programmer_Rev2		08.06.04	


**ZMD AG**  
 Grenzstrasse 28  
 D-01109 Dresden  
 phone +49/351/88220-  
 www.zmd.de



# AS –Interface Programmer

User Manual

## 3.2 PC Communication Interface



Title Galvanic Isolated Interface		Sheet No.2	<b>ZMD AG</b> Grenzstrasse 28 D-01109 Dresden phone +49/351/8822/0 www.zmd.de
Project No.		Revision No.	
Date	18.02.04	Date	
Author	Gerd Hofmann	phone ext - 393	
File	ASI_Programmer_Rev2	email: ghofmann@zmd.de	
		Date	08.06.04

Rev. 1.08, Copyright © 2005, ZMD AG

All rights reserved. The material contained herein may not be reproduced, adapted, merged, translated, stored, or used without the prior written consent of the copyright owner. The Information furnished in this publication is preliminary and subject to changes without notice.

# AS –Interface Programmer

User Manual

## **4**     *Notes*