

MOUNTING LOCATION:

Upper right side of dash

TOOLS REQUIRED:

Phillips screwdriver

PARTS INCLUDED:

(1) S7-1522 Mount

**CELL PHONE & MEDIA MOUNT
INSTALLATION INSTRUCTIONS****PART#: 75144-100****MFG: WESTERN STAR****MODELS & YEARS:****SEMI - ALL 1996-2015****** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

NOTE: Mounts taken off of older model trucks may need to enlarge the screw hole in mount to fit newer models.

- STEP #1 Remove (2) Phillips screws located on top of the right instrument panel located above the dashboard rocker switches.
- STEP #2 Pull woodgrain panel back approximately 2 inches on top. Panel is hinged on the bottom. Locate air vent at upper right-hand corner of panel.
- STEP #3 Slide InDash mount into right corner position and align outside hole of woodgrain panel hole and reassemble factory Phillips screw through panel and InDash Mount into threaded nut of dash.
- STEP #4 Attach phone holder to Mount.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW PANAVISE INDASH MOUNT.



Final install showing location

There may be recent updates to this Instruction Sheet, please visit our website or contact PanaVise Products, Inc. for the latest revision as well as for the most complete up-to-date PanaVise *InDash Applications List*: 7540 Colbert Dr., Reno, NV, Phone: 800.759.7535, 775.850.2900, Fax: 800.395.8002, www.panavise.com © 2014 PanaVise Products, Inc.



04-25-14