

INDASH by PANAVISE®

CELLULAR PHONE MOUNT
INSTALLATION INSTRUCTIONS

I-751101799

Page 1 of 1

MOUNTING LOCATION:

Right side of air vent VJR
next to radio, under Vent
flange and dash tab.

TOOLS REQUIRED:

9/32 nut driver

HARDWARE INCLUDED:

None

PART#: 751101799

MFG: CHEVROLET/GMC/CADILLAC

MODELS & YEARS:

CHEVROLET Silverado & Classic 99-07

2500HD & 3500 HD Silverado 01-06

Tahoe 2000-06, Suburban 01-06 ,

C/K P/U 00-06, Avalanche 02-06.

Silverado Hybrid 2007

GMC Sierra P/U 99-07 Sierra Denali 02-06

1500HD & 2500HD Sierra P/U 02-06,

Yukon 00-06, Yukon XL 00-06

Yukon Denali 01-06, C3 2002

CADILLAC

Escalade 2002-06, EXT 2002-06, ESV 2003-06

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP#1 Remove bezel that surrounds the radio, climate control and extends to the left of the steering wheel column by opening the ashtray. With your hands grasp the bottom portion of the bezel just above the ashtray and pull towards you to release a spring clip. Using the same technique continue working around the bezel to release a total of eleven spring clips. (**NOTE:** For automatic transmission apply the emergency brake and turn ignition on, BUT DO NOT start the vehicle, shift to low gear and tilt steering wheel all the way down.)

STEP#2 Push the bezel toward the left side to remove two screws located on the right side of the air vent with the 9/32" nut driver. The InDash Mount will be mounted ***under** the right side of the air vent mounting hole and ***under** the top hole that holds the dashboard. Lift both the right side of the air vent and the top-hole flange and slide the InDash Mount **under** both holes. Align the pin from the air vent and push the air vent back in place. Install the two screws and tighten. *NOTE: The mount can fit over the Flange. please try both ways to get best fit.

STEP#3 Reinstall the bezel starting from the right side of the air vent and working all the way around the bezel to secure in place. Attach phone holder to Indash Mount. If using a PortaGrip phone holder, adjust to size of phone prior to mounting.

INSTALLATION IS NOW COMPLETE.



Finished Installation Picture



Mounting Under Flange



Mounting Above Flange



10-16-06