

Filling Industry Norm DIN 13 169

The SÖHNGEN® Industrial Norm is based on the German DIN 13 169. All SÖHNGEN® company first-aid kits are equipped with products that adhere to the DIN 13 169. Although SÖHNGEN® first-aid kits meet the requirements laid down in the German Accident Regulations, we exceed these basic requirements in terms of product quantity, quality and design.

Filling Industry Norm DIN 13 169

1 aluderm® Dressing Sheet 40 x 60 cm	DIN 13 152-BR
1 aluderm® Dressing Sheet 60 x 80 cm	DIN 13 152-A
1 DERMOTEKT® Sheet 40 x 60 cm	DIN 13 152-BR
1 DERMOTEKT® Sheet 60 x 80 cm	DIN 13 152-A
4 aluderm® Bandage medium	DIN 13 151-M
2 aluderm® Bandage large	DIN 13 151-G
2 DermaCare® Bandage medium	DIN 13 151-M
2 DermaCare® Bandage large	DIN 13 151-G
4 WS-elast. Gauze Bandage 4 m x 6 cm	DIN 61 634-FB 6
4 WS-elast. Gauze Bandage 4 m x 8 cm	DIN 61 634-FB 8
2 WS-Fixing Bandages 4 m x 6 cm	DIN 61 634-FB 6
2 WS-Fixing Bandages 4 m x 8 cm	DIN 61 634-FB 8
1 WS-fix Net Bandage Size 3	
1 WS-fix Net Bandage Size 4	
4 aluderm® Eye Compress DuOcul	
6 aluderm® Compress, single, 10 x 10 cm	
6 DermaCare® Compress, single, 10 x 10 cm	
2 SÖHNGEN® Plast 5 m x 2,5 cm	DIN 13 019
16 aluderm® aluplast elastic 10 x 6 cm	DIN 13 019
10 aluderm® aluplast Finger band. 18 x 2 cm	DIN 13 019
10 aluderm® aluplast Fingertip bandage	
20 aluderm® aluplast Strips 1,9 x 7,2 cm	
2 Triangular Bandage/Sling	DIN 13 168-D
2 Sirius-Rescue Sheet silver/gold 160 x 210 cm	
20 Non woven towels 20 x 30 cm	
4 Minigrip-Bag 30 x 40 cm	
1 First-Aid Scissors 19 cm	DIN 58 279-B190
8 Vinyl Gloves	DIN-EN 455-1
1 First-Aid Guide	
1 Air-Vita® Bi-Protect Breathing Device	

Additional Set Plus for the Industrial Norm:

1 aluderm® aluface	
1 aluderm® alucap	
2 aluderm® alufinger	
2 aluderm® Cohesive Bandage	
1 Compression Bandage	
1 DermaCare® Dressing Sheet 20 x 30 cm	
50 aluderm® aluplast Wound Plaster	
4 aluderm® aluplast Finger Joint Bandage	
1 aluderm® aluplast Sterile Bandage, small	
1 aluderm® aluplast Sterile bandage, large	
1 Hyperventilation Mask	
1 SÖHNGEN® Cool Spray 100 ml	
1 Hand Disinfectant 100 ml	
1 Splinter Forceps, rust free	
12 Safety Pins	

Additional Set Plus

We offer more than the regulations require.
Ready-to-use bandages for immediate usage.

Air-Vita® Bi-Protect

As an addition for your safety, there is a breathing device in every SÖHNGEN® filling.

Our additional recommendations:

AQUA NIT® + oculav NIT® Immediate Eye Wash

Ready to use 250 ml pump bottle of AquaNIT® Sterile Water or OculavNIT® Sterile Solution for immediate application at the accident scene.

Extra Set Plaster Supplement

You can never have enough plasters.
Plastic box with aluderm®aluplast wound bandages, individually and hygienically sealed, in addition to Silk tape for immediate usage.

Industrial Norm Filling

= 141 parts - high quality dressings
manufactured by SÖHNGEN®
Filling DIN 13 169

03 03 008

Industrial Filling NormPlus

= 221 parts - high quality dressings
manufactured by SÖHNGEN®
Filling DIN 13 169 with Additional Set Plus

03 03 009

