

IN DASH **by** PANAVISE®

MOUNTING LOCATION:

Right or Left side of Radio JR

TOOLS REQUIRED:

Hook tool, Dash Tool

9/32" socket driver,

5/16" wrench, Soft Cloth

PARTS INCLUDED:

(1)S7-2028 Mount,(1)S7-193275001 TOP

(2)-O- 8/32" Acorn Nuts

CELL PHONE & MEDIA MOUNT**INSTALLATION INSTRUCTIONS****PART#:751072411****MFG: FORD / MERCURY / LINCOLN****MODELS & YEARS:**

FORD - Fusion 06-09, MERCURY - Milan 06-09(Pg.1)

FORD - Expedition 07-14, F-150 04-08(Pg.2)

LINCOLN - MarkLT 06-08 (Pg.2)

FORD-500 06-07, Taurus 08-09, LINCOLN - MKX 07-10(Pg.3)

MERCURY - Montego 05-07, Sable 08-09(Pg.3)

F-Super Duty(250,350,450,550) 08-10(Pg.4)

FORD-TaurusX08-09(Pg.5), E-Series Van 09-14(Pg.6)

F-Series SD(250,350,450,550 11-12), (F650, F750 11-15)(Pg.7)

FORD-F250/350/450/550 13-14(w/radio, not 8"NAV) (Pg.8)

FORD - Transit Connect 13(Pg.8)

I-751072411

Page 1 of 8

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1 Start Here for Ford Fusion & Mercury Milan: With hook tool remove the bezel that surrounds the radio and includes the switches/clock. Begin at the bottom of the bezel above the climate control. Pull to release (2) clips, and continue to release a total of (8) clips with (4) at the top of the bezel.

STEP #2 Remove the felt pad from the right side of the radio. With the 9/32" socket driver, remove the (2) screws on the right or left side of the radio. Place the Bottom Part of the InDash by PanaVise Mount over the (2) holes. Hold the mount in place up against the radio, and partially install the (2) screws. Make sure the mount is in place and tighten the screws.

STEP #3: Replace the bezel starting at the top. Install the Top part of the mount with the (2) Acorn Nuts and 5/16" wrench.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



InDash installed showing location on Right Side



Bottom Part in Place, Right Side



02-07-14

IN DASH by PANAVISE®

MOUNTING LOCATION:

Right or Left side of Radio JR

TOOLS REQUIRED:

Hook tool, Dash Tool

9/32" socket driver,

5/16" wrench, Soft Cloth

PARTS INCLUDED:

(1)S7-2028 Mount,(1)S7-1932 75001 TOP

(2)-O- 8/32" Acorn Nuts

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#:751072411

MFG: FORD / MERCURY / LINCOLN

MODELS & YEARS:

FORD-Fusion 06-09, MERCURY-Milan 06-09(Pg.1)

FORD - Expedition 07-14, F-150 04-08(Pg.2)

LINCOLN - Mark LT 06-08 (Pg.2)

FORD-500 06-07, Taurus 08-09, LINCOLN - MKX 07-10(Pg.3)

MERCURY - Montego 05-07, Sable 08-09(Pg.3)

F-Super Duty(250,350,450,550) 08-10(Pg.4)

FORD-TaurusX 08-09(Pg.5), E-Series Van 09-14(Pg.6)

F-Series SD(250,350,450,550 11-12), (F650,F750 11-15)(Pg.7)

FORD-F250/350/450/550 13-14(w/radio,not"NAV") (Pg.8)

FORD - Transit Connect 13(Pg.8)

I-751072411

Page 2 of 8

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Expedition Cover Removal



F-150 With Ashtray



F-150 Without Console



Expedition and F-150 Final Installation Picture

There may be recent updates to this Instruction Sheet, please visit our website or contact PanaVise Products, Inc. for the latest revision as well as for the most complete up-to-date PanaVise *InDash Applications List*: 7540 Colbert Dr., Reno, NV, Phone: 800.759.7535, 775.850.2900, Fax: 800.395.8002, www.panavise.com. © 2002 PanaVise Products, Inc.



02-07-14

IN DASH

by
PANAVISE®

MOUNTING LOCATION:

Right or Left side of Radio JR

TOOLS REQUIRED:

Hook tool, Dash Tool

9/32" socket driver,

5/16" wrench, Soft Cloth

PARTS INCLUDED:

(1)S7-2028 Mount,(1)S7-1932 75001 TOP

(2)-O- 8/32" Acorn Nuts

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#:751072411

MFG: **FORD / MERCURY / LINCOLN**

MODELS & YEARS:

FORD-Fusion06-09, MERCURY-Milan06-09(Pg.1)

FORD - Expedition 07-14, F-150 04-08(Pg.2)

LINCOLN - MarkLT 06-08 (Pg.2)

FORD-500 06-07, Taurus 08-09, LINCOLN - MKX 07-10 (Pg.3)

MERCURY - Montego 05-07, Sable 08-09(Pg.3)

F-Super Duty(250,350,450,550) 08-10(Pg.4)

FORD-TaurusX08-09(Pg.5), E-Series Van09-14(Pg.6)

F-SeriesSD(250,350,450,55011-12),(F650,F75011-15)(Pg.7)

FORD-F250/350/450/550 13-14(w/radio,not8"NAV) (Pg.8)

FORD - Transit Connect 13(Pg.8)

STEP #1: For Taurus , 500, and Montego, Start Here: Carefully remove the trim ring around the shifter with your hands and/or hook tool assist. Open the console box door. With your hands and hook tool lift up on the console top that includes the cup holders from the back by the console door latch. Lift to release a total of (8) clips. Pull back on the console top to release it from under the climate control.

STEP #2: Remove the (2)-9/32 screws from below the radio and climate control bezel. With hook tool pull from the bottom of the bezel to release a total of (4) clips. Set bezel off to the side.

STEP #3: Remove the (2)-9/32 screws from the right side of the radio. Place the BOTTOM part of the InDash by PanaVise Mount over the screw holes and replace screws. Install the TOP part (75001) on to the BOTTOM with the (2) Acorn nuts and a 5/16" wrench. Replace the bezels in reverse order.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.

STEP #1: For Lincoln MKX Start Here: Carefully remove the trim ring around the shifter with your hands and/or hook tool assist. Open the console box door. With your hands and hook tool lift up on the console top that includes the cupholders from the back by the console door latch. Lift to release a total of (6) clips. Pull back on the console top to release it from under the Ash Tray..

STEP #2: Remove the (2)-Phillips screws that hold the ash tray assembly in place. These screws are swedge type that if you push on the screwdriver they will not unscrew. After removing the screws you need to pop out the sleeves. Pull from the bottom of the ash tray assembly to release a (2) clips in the upper Right and Left corners. Set off to the side.

STEP #3: Remove the (2)-9/32 screws from the right side of the radio. Place the the BOTTOM part of the InDash by PanaVise Mount over the screw holes and replace screws. Install the TOP part (75001) on to the BOTTOM with the (2) Acorn nuts and a 5/16" wrench.

STEP #4: Replace the bezels in reverse order.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Final Installation Picture on 500
and Montego



MKX Final Installation Picture



(2) screws below bezel



(2)Clips to Remove Ash Tray



02-07-14

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

IN DASH by PANAVISE®

I-751072411

Page 4 of 8

MOUNTING LOCATION:

Right or Left side of Radio JR

TOOLS REQUIRED:

Hook tool, Dash Tool

9/32" socket driver,

5/16" wrench, Soft Cloth

PARTS INCLUDED:

(1)S7-2028 Mount,(1)S7-1932 75001 TOP

(2)-O- 8/32" Acorn Nuts

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#: 751072411

MFG: FORD / MERCURY / LINCOLN

MODELS & YEARS:

FORD - Fusion 06-09, MERCURY - Milan 06-09(Pg.1)

FORD - Expedition 07-14, F-150 04-08(Pg.2)

LINCOLN - MarkLT 06-08 (Pg.2)

FORD-500 06-07, Taurus 08-09, LINCOLN - MKX 07-10(Pg.3)

MERCURY - Montego 05-07, Sable 08-09(Pg.3)

F-Super Duty(250,350,450,550) 08-10(Pg.4)

FORD-TaurusX 08-09(Pg.5), E-Series Van 09-14(Pg.6)

F-Series SSD(250,350,450,550 11-12), (F650, F750 11-15)(Pg.7)

FORD-F250/350/450/550 13-14(w/radio, not 8" NAV) (Pg.8)

FORD - Transit Connect 13(Pg.8)

STEP #1: Ford F-Series Super Duty (F-250,350,450,550,650,750) Start Here:

With Hook Tool/Dash Tool remove the (2) covers at the lower portion of the Radio/Climate control bezel (Audio Input & Power Outlet). Insert Hook Tool into the slot at the bottom of these corners and pull to release (4) clips on each cover. Pull out covers and let hang down. With 9/32"(7mm) wrench, remove the (2) exposed screws. Remove the coin holder by inserting hook tool into a corner and pry to release (4) clips. Set aside.

STEP #2: To remove the bezel that surrounds Radio/Climate Control/Air Vent bezel, begin at the bottom by pulling with your hands to release the (2) clips at the bottom of the bezel. Continue to release the bezel including (6) more clips mostly positioned around the air vents, with (4) at the top of the bezel. Let bezel hang down to allow access to the radio mounting screws.

STEP #3: Remove the (2)-9/32 screws from the right side of the radio. Place the BOTTOM part of the InDash by PanaVise Mount over the screw holes and replace screws. Install the TOP part (75001) on to the BOTTOM with the (2) Acorn nuts and a 5/16" wrench.

STEP #4: Replace the bezel in reverse order. Note the Trailer Brake will need to be reinstalled after installing the radio/climate control bezel.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.




Final Installation Pictures on Ford- Super Duty

There may be recent updates to this Instruction Sheet, please visit our website or contact PanaVise Products, Inc. for the latest revision as well as for the most complete up-to-date PanaVise InDash Applications List: 7540 Colbert Dr., Reno, NV, Phone: 800.759.7535, 775.850.2900, Fax: 800.395.8002, www.panavise.com. © 2002 PanaVise Products, Inc.

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Right & Left Covers and Screws



Brake Controller Slides Out



Bottom part in place

02-07-14



IN DASH

MOUNTING LOCATION:

Right or Left side of Radio JR

TOOLS REQUIRED:

Hook tool, Dash Tool

9/32" socket driver,

5/16" wrench, Soft Cloth

PARTS INCLUDED:

(1)S7-2028 Mount,(1)S7-1932 75001 TOP

(2)-O- 8/32" Acorn Nuts

by
PANAVISE®

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#:751072411

MFG: FORD / MERCURY / LINCOLN

MODELS & YEARS:

FORD-Fusion 06-09, MERCURY -Milan 06-09(Pg.1)

FORD - Expedition 07-14, F-150 04-08(Pg.2)

LINCOLN - MarkLT 06-08 (Pg.2)

FORD-500 06-07, Taurus 08-09, LINCOLN - MKX 07-10(Pg.3)

MERCURY - Montego 05-07, Sable 08-09(Pg.3)

F-Super Duty(250,350,450,550) 08-10(Pg.4)

FORD-TaurusX 08-09(Pg.5), E-Series Van 09-14(Pg.6)

F-Series SD(250,350,450,550 11-12), (F650, F750 11-15)(Pg.7)

FORD-F250/350/450/550 13-14(w/radio,not 8"NAV) (Pg.8)

FORD - Transit Connect 13(Pg.8)

I-751072411

Page 5 of 8

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

FORD- TaurusX Start Here:

STEP #1: Open compartment cover on top of dash. With your hands pullout on the top of the bezel that surrounds the radio, and includes the air vents, climate control, and switches below climate control. Release (6) total clips on this bezel.

STEP #2: With 9.32" socket driver remove the (2) screws on the right side of the radio. Place the BOTTOM part of the InDash by PanaVise Mount over the screw holes and replace screws.

STEP #3: Replace bezel starting from the bottom. Install the TOP part (75001) on to the BOTTOM with the (2) Acorn nuts and a 5/16" wrench.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Final Installation Picture Ford TaurusX 08

There may be recent updates to this Instruction Sheet, please visit our website or contact PanaVise Products, Inc. for the latest revision as well as for the most complete up-to-date PanaVise *InDash Applications List*: 7540 Colbert Dr., Reno, NV, Phone: 800.759.7535, 775.850.2900, Fax: 800.395.8002, www.panavise.com. © 2002 PanaVise Products, Inc.

02-07-14



INDASH

by
PANAVISE®
CELL PHONE & MEDIA MOUNT

MOUNTING LOCATION:

Right or Left side of Radio JR

TOOLS REQUIRED:

Hook tool, Dash Tool

9/32" socket driver,

5/16" wrench, Soft Cloth

PARTS INCLUDED:

(1)S7-2028 Mount,(1)S7-1932 75001 TOP
(2)-O- 8/32" Acorn Nuts

INSTALLATION INSTRUCTIONS

PART#: 751072411

MFG: FORD / MERCURY / LINCOLN

MODELS & YEARS:

FORD-Fusion 06-09, MERCURY -Milan 06-09(Pg.1)

FORD - Expedition 07-14, F-150 04-08(Pg.2)

LINCOLN - MarkLT 06-08 (Pg.2)

FORD-500 06-07, Taurus 08-09, LINCOLN - MKX 07-10(Pg.3)

MERCURY - Montego 05-07, Sable 08-09(Pg.3)

F-Super Duty(250,350,450,550) 08-10(Pg.4)

FORD - TaurusX 08-09(Pg.5), E-Series Van 09-14(Pg.6)

F-Series SD(250,350,450,550 11-12), (F650, F750 11-15)(Pg.7)

FORD-F250/350/450/550 13-14(w/radio,no 8"NAV) (Pg.8)

FORD - Transit Connect 13(Pg.8)

I-751072411

Page 6 of 8

*** ADVISEMENT ***

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

FORD-E-Series Van Start here:

STEP #1: With your hands, pull off the bezel that goes from the passenger airbag to drivers side airvent. ther are (19) clips. Start from the right side of the bezel working to the left side.

STEP #2: Remove right side radio screws. (Mount can fit on left side, please call for information). Place mount over screw holes and replace the screws. NOTE: may need to to slightly bend the mount to the side to get the bezel completely back in place. Some filing may be necessary also to make a perfect fit.

STEP #3: Place the BOTTOM part of the InDash by PanaVise Mount over the screw holes and replace screws.

STEP #3: Replace bezel. Install the TOP part (75001) on to the BOTTOM with the (2) Acorn nuts and a 5/16" wrench. Replace the bezel.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Finished Install Picture



Bottom Piece Installed

02-07-14



IN DASH by PANAVISE®

I-751072411

Page 7 of 8

MOUNTING LOCATION:

Right or Left side of Radio JR

TOOLS REQUIRED:

Hook tool, Dash Tool

9/32" socket driver,

5/16" wrench, Soft Cloth

PARTS INCLUDED:

(1)S7-2028 Mount,(1)S7-1932 75001 TOP

(2)-O- 8/32" Acorn Nuts

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#:751072411

MFG: FORD / MERCURY / LINCOLN

MODELS & YEARS:

FORD-Fusion 06-09, MERCURY -Milan 06-09(Pg.1)

FORD - Expedition 07-14, F-150 04-08(Pg.2)

LINCOLN - MarkLT 06-08 (Pg.2)

FORD-500 06-07, Taurus 08-09, LINCOLN - MKX 07-10(Pg.3)

MERCURY - Montego 05-07, Sable 08-09(Pg.3)

F-Super Duty(250,350,450,550) 08-10(Pg.4)

FORD-TaurusX 08-09(Pg.5), E-Series Van 09-14(Pg.6)

F-Series SD(250,350,450,550 11-12), (F650, F750 11-15)(Pg.7)

FORD-F250/350/450/550 13-14(w/radio, not 8" NAV) (Pg.8)

FORD - Transit Connect 13(Pg.8)

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Right & Left Covers and Screws



Brake Controller Slides Out



Bottom part in place



Final Installation Picture on 08-10



Final Installation Picture on 2011

02-07-14



INDASH

by
PANAVISE®

MOUNTING LOCATION:

Right or Left side of Radio JR

TOOLS REQUIRED:

Hook tool, Dash Tool

9/32" socket driver,

5/16" wrench, Soft Cloth

PARTS INCLUDED:

(1)S7-2028 Mount,(1)S7-1932 75001 TOP

(2)-O- 8/32" Acorn Nuts

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#:751072411

MFG: FORD / MERCURY / LINCOLN

MODELS & YEARS:

FORD-Fusion 06-09, MERCURY - Milan 06-09(Pg.1)

FORD - Expedition 07-14, F-150 04-08(Pg.2)

LINCOLN - MarkLT 06-08 (Pg.2)

FORD-500 06-07, Taurus 08-09, LINCOLN - MKX 07-10(Pg.3)

MERCURY - Montego 05-07, Sable 08-09(Pg.3)

F-Super Duty(250,350,450,550) 08-10(Pg.4)

FORD-TaurusX 08-09(Pg.5), E-Series Van 09-14(Pg.6)

F-Series SD(250,350,450,550 11-12), (F650,F750 11-15)(Pg.7)

FORD-F250/350/450/550 13-14(w/radio,not 8"NAV) (Pg.8)

FORD - Transit Connect 13(Pg.8)

STEP #1: For Ford F-Series Super Duty Pickup 13-14 (w/o NAV)(F-250,350,450,550) Start Here:

With Hook Tool/Dash Tool remove the (2) covers at the lower portion of the Radio/Climate control bezel (Audio Input & Power Outlet). Insert Hook Tool into the slot at the bottom of these corners and pull to release (4) clips on each cover. Pull out covers and let hang down. With 9/32"(7mm) wrench, remove the (2) exposed screws.

STEP #2: To remove the bezel that surrounds Radio/Climate Control/Air Vent bezel, begin at the bottom by pulling with your hands to release the (2) clips at the bottom of the bezel. Continue to release the bezel including (6) more clips mostly positioned around the air vents, with (4) at the top of the bezel. Let bezel hang down to allow access to the radio mounting screws.

STEP #3: Remove the (2)-9/32 screws from the right side of the radio. Place the BOTTOM part of the InDash by PanaVise Mount over the screw holes and replace screws. Install the TOP part (75001) on to the BOTTOM with the (2) Acorn nuts and a 5/16" wrench.

STEP #4: Replace the bezel in reverse order, Be sure to guide trailer brake back into slot.

Start here for Transit Connect 2013:

STEP #1: With dash tool pry up the bezel that surrounds the radio releasing (4) clips. Disconnect any plugs as necessary.

STEP #2: Remove the (2)-9/32 screws from the right side of the radio. Place the BOTTOM part of the InDash by PanaVise Mount over the screw holes and replace screws.

STEP #3: Replace the bezel by angling it in on the side of the Indash first. Then tilt to snap in all clips completely.

STEP #4: Install the TOP part (75001) on to the BOTTOM with the (2) Acorn nuts and a 5/16" wrench.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.

I-751072411

Page 8 of 8

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Final Installation Picture of
Super Duty 2013 Without NAV



Final Installation Picture of
Transit Connect 2013

02-07-14

