


PICMG Backplane


Non-Server Grade Backplane



PBPE-13A8

13-slot [PCI-E x1 (3), PCI-E x16 (1), PCI (8)]


- Fit for 4U chassis
- Dedicated to ROBO-8912VG2AR
- Four USB ports
- Dual SATA ports
- 24-pin ESP12V power connector



PBPE-12A9

12-slot [PCI-E x16 (1), PCI-E x8 (1, x4 signal), PCI (9)]


- Fit for 4U chassis
- Dedicated to ROBO-8912VG2AR
- Four USB ports
- Dual SATA ports



PBPE-12AA64

12-slot [PCI-X (8), PCI-E x16 (1), PCI (2)]


- Fit for 4U chassis
- Dedicated to ROBO-8912VG2AR
- Four USB ports
- Dual SATA ports
- Two PCI-X buses support eight PCI-X expansion slot



PBPE-07P4

7-slot [PCI-E x4 (1), PCI-E x16 (1), PCI (4)]


- Fit for Node chassis
- Dedicated to ROBO-8912VG2AR
- Four USB ports
- Dual SATA ports



PBPE-06V

Vertical 6-slot [PCI-E x1 (4), PCI-E x16 (1)]


- Fit for 2U chassis
- Dedicated to ROBO-8912VG2AR
- Four USB ports
- Dual SATA ports
- 24-pin ESP 12V power connector



PBPE-06V3

Vertical 6-slot [PCI-E x4 (1), PCI-E x16 (1), PCI (3)]


- Fit for 2U chassis
- Dedicated to ROBO-8912VG2AR
- Four USB ports
- Dual SATA ports



PBPE-06P3

6-slot [PCI-E x16 (1), PCI-E x4 (1), PCI (3)]


- Fit for Node chassis
- Dedicated to ROBO-8912VG2AR
- Four USB ports
- Dual SATA ports



PBPE-06P4

6-slot [PCI-E x8 (1, x4 signal), PCI (4)]

- Fit for Node chassis
- Dedicated to ROBO-8912VG2AR
- Four USB ports
- Dual SATA ports



PBPE-05A364

5-slot [PCI-E x16 (1), PCI-X (2), PCI (1)]

- Fit for Node chassis
- Dedicated to ROBO-8912VG2AR
- Four USB ports
- Dual SATA ports
- Two PCI-X buses support two PCI-X expansion slot