JetPort 5601



## Specification

**Network Interface** 

Ethernet: 2\* 10/100BaseTX, Redundant Dual Ethernet

Connector: RJ-45 Auto MDI/MDI-X Feature: Auto Recovery in less than 200ms

**Protection:** Built-in 1.5 KV magnetic isolation protection **Protocols:** IP, TCP, UDP, ICMP, DHCP, BootP, ARP/RARP,

Telnet, SNMP, HTTP, SNTP, SMTP **Serial Communication** 

Number of Ports: 1

Interface: RS-232/422, 2/4-wire RS485

Connectors: Male DB9

Baud Rates: 110 bps to 460.8K bps

Data Bits: 5, 6, 7, 8 Parity: odd, even, none Stop Bits: 1, 1.5, 2

RS-232: TxD, RxD, RTS, CTS, DTR, DSR, GND, DCD

RS-422: Tx+,Tx-, Rx+, Rx-,GND RS-485 (4-wire): Tx+,Tx-, Rx+, Rx-,GND RS-485 (2-wire): Data+, Data-,GND

Flow Control: XON/XOFF, RTS/CTS, DTR/DSR

Serial Line Protection: 15KV ESD

Long Distance Termination: 2\*pin 120ohm DIP switches

**Features** 

LED

Power 1/Power 2: Startup(Red); Ready(Green) Ethernet 1/Ethernet 2: 10M Link(Orange), 100M

ink(Green)

Serial: Transmitting data(Green), Receiving data(Orange)

Configuration: Windows Utility-JetPort Commander, HTTP,

Telnet

Serial Service: Virtual COM, TCP Server, TCP Client,

TCP Tunnel and UDP

Reset: Software reload default, Hardware reset button

**SNTP:** For time management

Access IP Table: 16 IP addresses to prevent illegal users

Monitor: Devices' status, VCOM status

SNMP: RFC1213 MIB II, RFC1317 RS232\_like and SNMP

Trap

E-Mail Alert: Automatic e-mail warning by pre-defined

events

System Log: Trap to Syslog server or local display

**System Events:** 

Cold/Warm Start, Login Failed, IP and Password Changed, Access IP Blocked, Serial Port DCD/RI/DSR/CTS changed,

Serial Port connected/disconnected.

TTY Driver: Fixed TTY driver for Linux

Windows Utility

JetPort Commander:

Serial Service Mode:

Device Discovery, Auto IP, Network Setting, Device and Serial Port Setting and monitoring, Notification setting, Firmware Upgrade, Configuration Backup and Restore,

Group Configuration Wizards.

Virtual COM, TCP Server, TCP Client, TCP Tunnel and UDP

**Advanced Serial Setting:** 

TCP Alive Check Timeout, Inactivity Idle Timeout, Performance mode, Delimiter, Force TX Timeout for Data

Packing and Force TX interval time **Group Configuration Wizard:** 

JetPort Commander: Group IP Wizard, Group firmware upgrade, Group Backup/Restore, VCOM and TCP Tunnel

Setup Wizard

**Power Requirements** 

System Power:

PWR1: 12~48VDC Terminal Block

PWR2: 9~30VDC Power Jack with Power Adapter

Power Line protection:

1 KV Burst (EFT), EN61000-4-4 0.5 KV Surge, EN61000-4-5

**Mechanical** 

Dimensions: 96.1mm(W)x99mm(D)x29.6mm(H)
Regulatory Approvals: FCC Class A, CE Class A, UL,

RoHS

**Environmental** 

Operating Temperature: -10 ~ 70°C

Operating Humidity: 5% ~ 95%, (non-condensing)

Storage Temperature: -40 ~ 85°C

Warranty: 5 years

## **■** Ordering Information

## JetPort 5601 1-port RS-232/RS422/RS485 Redundant Serial Device Server

Includes:

- 1-port RS-232/RS422/RS485 Redundant Serial Device Server
- Quick Installation Guide
- 100V 240V power adapter
- Din-Rail kit and foot pads
- Documentation and Software CD-ROM