

auxiliaries, remote control and accessories DX³



Technical characteristics **p. 68**

Pack	Cat.Nos	Auxiliaries	No. of modules
		Mounted on the left-hand side of the devices Possible configuration per device: 3 auxiliaries including 1 control auxiliary Auxiliaries common to MCBs, RCBOs RCDs and isolating switches Allow insertion of the supply busbar	
1	4 062 58	Signalling auxiliaries Auxiliary changeover switch, 6 A - 250 V~ Indicates the position of the contacts of the MCB, RCD or isolating switch	0.5
1	4 062 60	Fault signalling changeover switch, 6 A - 250 V~ Indicates opening on a fault	0.5
1	4 062 62	Auxiliary changeover switch, 6 A - 250 V~ Can be changed to a fault signalling changeover switch	0.5
1	4 062 66	Auxiliary changeover switch + fault signalling changeover switch, 6 A - 250 V~ Can be changed to 2 auxiliary changeover switches	1
		Current shunt trips Used for remote tripping of an MCB, RCD, RCBO or isolating switch at the supply end	
1	4 062 76	12 to 48 V~/=	1
1	4 062 78	110 to 415 V~	1
		Undervoltage releases Time delay adjustable from 0 to 300 ms	
1	4 062 80	24 to 48 V~/=	1
1	4 062 82	230 V~	1
		Stand-alone release for N/C push-button Used for positive safety tripping on the control circuit via an N/C push-button Prevents the device with which it is used tripping if there is no supply voltage, while retaining the possibility of tripping via the control circuit for 60 hours minimum Not suitable for the supply circuits of moving machinery (e.g.: machine tools)	
1	4 062 87	Stand-alone release, 230 V~ supplied with battery	1.5
1	4 062 85	Replacement battery for release Cat. No. 4 062 87	

Pack	Cat.Nos	Motorised controls	No. of modules
		For mounting on the left-hand side of 1 module/pole MCBs, RCBOs and RCDs Enable the products with which they are used to be opened and closed remotely Take one control auxiliary and one signalling auxiliary The signalling auxiliary must be placed between the remote control and the control auxiliary	
		Standard	
1	4 062 91	Control voltage 230 V~	1
		With integrated automatic resetting Automatically resets the product with which it is used, thus ensuring continuity of service	
1	4 062 93	24-48 V~/=	2
1	4 062 95	230 V~	2
		Accessories	
		Padlocking	
2	4 063 03	Support for one Ø5 or Ø6 mm padlock for DX ³ MCBs and RCDs or isolating switches	
1	0 227 97	Ø6 shackle type padlock	
3	4 063 13	Ø5 shackle type padlock	
		Sealable screw cover - 4 separable poles	
2	4 063 04	For DX ³ MCBs, 1 module per pole	
2	4 063 12	For DX ³ MCBs, 1.5 module per pole	
		Insulating shields	
		For DX ³ MCBs, 1 module per pole	
1	4 063 05	Pole insulating shield (set of 6)	
		Spacing units with feedthrough	
10	4 063 07	0.5 module	
		Aluminium terminals	
1	4 063 10	50 mm ²	
1	4 063 11	95 mm ² for 1.5 module/pole MCBs	
		Terminal shields	
1	4 063 06	For 1.5 module/pole products (set of 2)	

