

Catalogue Number	Description
------------------	-------------

10 AMP SWITCHES

MC512	1 gang 2 way switch
MC513	Intermediate switch
MC514	1 gang bell push
MC515	10A Triple pole Fan Isolator
MC542	2 gang 2 way switch
MC543	3 gang 2 way switch
MC544	4 gang 2 way switch
MC546	6 gang 2 way switch

20 AMP DOUBLE POLE SWITCHES

MC530	20A double pole switch
MC531	20A double pole switch with neon

20 AMP FLEX OUTLET PLATE

MC558	20A flex outlet
-------	-----------------

45 AMP SWITCHES

MC570	Cooker control unit, switched socket with neon indicator
MC571	Cooker control and socket
MC572	Double pole switch with neon indicator
MC573	Double pole switch
MC574	Double pole switch, single plate with neon indicator
MC575	Double pole switch, single plate

13 AMP SOCKET OUTLETS


MC521	1 gang 13A switched socket outlet
MC522	2 gang 13A switched socket outlet
MC523	1 gang 13A unswitched socket
MC524	2 gang 13A unswitched socket
MC525	1 gang 13A switched socket with neon
MC526	2 gang 13A switched socket with neon

ROUND PIN SOCKET OUTLETS

MC528	1 gang 2A unswitched socket
MC529	1 gang 5A unswitched socket
MC598	1 gang 15A unswitched socket
MC599	1 gang 15A switched socket
MC560	1 gang Co-axial socket

13 AMP FUSED CONNECTION UNITS

MC550	Fused connection unit switched
MC551	Fused connection unit switched with neon
MC552	Fused connection unit
MC554	Fused connection unit with flex outlet
MC555	Fused connection unit switched with flex outlet
MC556	Fused connection unit switched with flex outlet and neon



Catalogue Number	Description
TELEPHONE SOCKETS	
MC51	1 gang master unit
MC52	2 gang master unit
MC53	1 gang slave unit
MC54	2 gang slave unit
MC567	1 gang RJ11 telecom outlet
MC568	2 gang RJ11 telecom outlet
RJ45 DATA OUTLETS	
MC5451	1 gang RJ45 telecom outlet
MC5452	2 gang RJ45 telecom outlet
BLANK PLATES	
MC504	1 gang blank plate
MC505	2 gang blank plate
SURFACE MOUNTING BOXES	
MC501	1 gang surface mounting box
MC502	2 gang surface mounting box