


Fuseholders for GMT Type Indicating Fuses

HLS, HLT, PCT



CATALOG SYMBOL: HLS, HLT, PCT
FUSEHOLDERS FOR GMT TYPE INDICATING FUSES
ELECTRICAL RATING—60V DC, 125V AC
U.L. RECOGNIZED (GUIDE # IZLT2, FILE E14853)
15AMP (60V DC)


Materials:

Body: Thermosplastic, U.L. 94VO flammability rating

Terminals: Tin-plated bifurcated copper

For use with **GMT** Type Indicating Fuses

Multiple Fuseholders with bus bars
Ordering Information—Catalog No.




* **Angle Bar** mounts on common or center terminals only.
† Minimum of 4 Poles Required.


****SL** Version is not available with bus bars.

Dimensional Data

Printed Circuit Board Application
Shown With GMT Fuse Installed





**Note: Similar Body Dimensions
of All Holders Are Identical.**



Wire Wrap Terminals
.025" x .063"
(.64mm) (1.6mm)

 Fuse Terminal
 Alarm Terminal

Panel Mounting Data



Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Eaton:

[BK/HLT](#) [BK/HLS](#) [HLS-C](#) [HLT-10](#) [PCT-1K0796](#) [HLT-10-B2-P2-B](#) [BK/HLS-01-SL](#) [BK/HLS-F](#) [BK/HLT-D](#) [BK/HLT-F](#)
[HLS-01-ML](#) [HLS-01-SL](#) [HLS-02](#) [HLS-02-SL](#) [HLS-03](#) [HLS-03-ML](#) [HLS-03-SL](#) [HLS-04](#) [HLS-04-ML](#) [HLS-04-SL](#)
[HLS-05](#) [HLS-05-ML](#) [HLS-05-SL](#) [HLS-06](#) [HLS-06-SL](#) [HLS-07](#) [HLS-07-SL](#) [HLS-08](#) [HLS-08-SL](#) [HLS-10](#) [HLS-10-ML](#)
[HLS-10-SL](#) [HLS-11-SL](#) [HLS-13](#) [HLS-13-SL](#) [HLS-16](#) [HLS-F](#) [HLT-01-LL](#) [HLT-01-ML](#) [HLT-01-SL](#) [HLT-02](#) [HLT-04](#)
[HLT-04-B3-P4-L](#) [HLT-04-B5-P1-B](#) [HLT-05](#) [HLT-05-B2-P1-B](#) [HLT-05-B2-P3-R](#) [HLT-05-B3-P4-L](#) [HLT-05-B5-P3-R](#)
[HLT-06](#) [HLT-06-B5-P2-B](#) [HLT-10-B3-P1-B](#) [HLT-10-B3-P2-B](#) [HLT-10-B4-P1-B](#) [HLT-10-B5-P1-B](#) [HLT-10-B5-P3-B](#)
[HLT-10-ML](#) [HLT-13](#) [HLT-25-B5-P1-B](#) [HLT-25-B5-P2-B](#) [HLT-D](#) [HLT-F](#) [BK/HLS-02-ML](#) [BK/HLS-07-SL](#) [BK-HLS-03-](#)
[ML](#) [BK/HLS-C](#) [HLT-04-ML](#) [HLT-05-B5-P2-B](#) [HLS](#) [HLT](#)