

8

7

6

5

4

3

2

1

THIS DRAWING IS UNPUBLISHED.

RELEASED FOR PUBLICATION

© COPYRIGHT -

BY TYCO ELECTRONICS CORPORATION.

ALL INTERNATIONAL RIGHTS RESERVED.

PART NUMBER

REV

FIRST USED

687395-1

AC

854400-1

7-687395-7

AC

SPARE PARTS KIT

TERMINAL NAME: .250 FLAG FASTON™

TE P/N	MFG P/N	.018 THK	.018 THK	.016 THK
1949687	SFO-61T-250A	60645	141697	63604
		41531	61156	42511
		41532	63517	42742
		41799	63555	60641
		41800	63651	60712
		41801	100646	63445
		41802		150561
		42041		
		150560		STEEL
				42404
				1742543
				1742460
TERM APPL SPEC 114-2078				

CRIMPING DATA

PAD LTR	CRIMP HEIGHT	WIRE SIZE
A	.070 ±.002 [1.78mm±0.05mm]	12
B	.060 ±.002 [1.52mm±0.05mm]	14
C	.052 ±.002 [1.32mm±0.05mm]	16
D	.048 ±.002 [1.22mm±0.05mm]	18
CRIMP	SIZE	TYPE
WIRE	.160 [4.06mm]	TAB LOCK
INSUL	.180 [4.57mm]	0
FEED	.767	APPL INST
.767	Δ18031	SET UP GAGE
		LAYOUT
WIRE STRIP LENGTH	-	

LOC A

DIST 66

REV LTR

DESCRIPTION

DATE

DWN

APVD

AC

ECR-08-032566

02-2009

CC

ND

-1

LEADMAKER G

MECH POST FEED

-77

-

SPARE PARTS KIT

-	1	-	22594-8	NUT, HEX	70
-	1	-	240628-1	PLATE, ADJ	69
-	1	-	240626-1	SHAFT, PIVOT	68
-	1	-	240633-1	BUSHING	67
-	1	-	240630-1	LEVER, INTERMEDIATE	66
-	1	-	1804317-1	BLOCK, PIVOT	65
-	1	-	1633286-1	SCR, ADJ	64
-	1	-	240659-3	PIN, CAM ROLLER	63
-	1	-	240658-1	ROLER, CAM	62
-	1	-	240631-1	ROD, FEED	61
-	1	-	455164-1	CAP ASSEMBLY	59
-	1	-	455162-1	HOUSING	58
-	1	-	1804319-1	GUIDE,FEED ROD	56
-	1	-	240624-1	PIN, FEED FINGER	55
-	1	-	691499-1	SPRING, FEED FINGER	54
-	1	-	454568-1	FINGER, FEED	53
-	1	-	240634-1	LEVER, TERMINAL	52
-	1	-	22353-8	SCREW, SHOULDER	50
-	1	-	3-21002-5	BOLT, CRIMPER	49
-	1	-	238015-1	CAM, POST-FEED 1 5/8 ST	47
-	1	-	690578-1	BLOCK, INSULATION ADJUST	46
-	1	-	690191-1	PLUG, NYLON	45
-	1	-	454574-1	RAM	44
-	1	-	690125-1	WASHER, LAMINATED	43
-	1	-	690124-4	WASHER, RAM	42
-	1	-	23241-6	BALL, STEEL	40
-	1	-	690170-1	SPRING, COMPRESSION	39
-	1	-	690142-1	DISC, INSULATION	38
-	1	-	354777-1	WIRE DISC, PLASTIC	37
-	1	-	22480-5	WASHER, SPRING	36
-	1	-	690212-1	POST, RAM	35
-	1	-	3-23846-5	SPRING, HINGE BAR	34
-	1	-	690573-1	SPACER, SPRING	32
-	1	-	454569-1	MOUNT, DRAG	31
-	1	-	1-22354-8	STUD, DRAG	30
-	1	-	21030-2	PIN, MOUNT, DRAG	29
-	1	-	1633530-1	PIN, HINGE	28
-	1	-	684905-1	PLATE, BASE	26
-	1	-	454579-2	HINGE BAR	25
-	1	-	690571-1	BLOCK, STABILIZER	24
-	1	-	690585-1	BLOCK, PRESSURE	23
-	1	-	22282-5	SPRING, DRAG	22
-	1	-	21030-6	LEVER, DRAG	21
-	1	-	454570-1	DRAG, STOCK	20
-	1	-	454573-1	GUIDE, STRIP (REAR)	19
-	1	-	454571-1	GUIDE, STRIP (FRONT)	18
-	1	-	4-22284-9	SPRING, FEED RETURN	16
-	1	-	1-692134-3	POSITIONER,TERMINAL	14
-	1	-	692134-1	POSITIONER,TERMINAL	13
-	1	-	5-22280-5	SPRING,TERM. POSITIONER	12
-	1	-	454711-1	PLATE, REAR SHEAR	11
-	1	-	454709-1	ANVIL INSERT	10
-	1	-	690569-1	PLATE, FRONT SHEAR	9
-	1	-	690575-1	ANVIL	8
-	1	-	454575-4	BLADE, SLUG	7
-	1	-	684906-1	PLATE,ANVIL RETAINING	5
-	1	-	690574-1	SPACER,TUBULAR INSUL CRIMPER	4
-	1	-	690588-2	CRIMPER, INSULATION	3
-	1	-	690587-1	CRIMPER, WIRE	1

POST-FEED 1 5/8 STROKE

REF

100

44

47

2

1

RECOMMENDED SPARE PARTS.

2

GREASE LIGHTLY.

3

LUBRICATE DAILY USING NO. 20 MACHINE OIL.

4.

DO NOT EXCEED 80 C.P.M. WITH THIS APPLICATOR.

5.

AFTER ASSEMBLY OF APPLICATOR, PROPER SPRING PRESSURE (ITEM 34) CAN BE OBTAINED BY TIGHTENING SET SCREW (ITEM 105) UNTIL CONTACT IS MADE WITH SPACER (ITEM 32) THEN TIGHTEN AN ADDITIONAL 5 1/2 - 6 REVOLUTIONS.

6

APPLY LOCTITE TO ITEM 93.

7

CHANGE POSITIONER AS REQUIRED TO CENTER TERMINAL OVER ANVIL. FASTEN EXTRA POSITIONER TO APPLICATOR.

THIS DRAWING IS A CONTROLLED DOCUMENT.

DWN B HIGMAN 09-14-99

CHK C.ERISMAN 09-14-99

APVD J.ELBIN 09-14-99

NAME

END FEED HINGE BAR APPLICATOR

SIZE

CAGE CODE

DRAWING NO

RESTRICTED TO

WEIGHT

100779

687395-1

CUSTOMER DRAWING

SCALE

NTS

SHEET

1

OF

1

REV

AC

4805 (1/08)

12NOV2008 1:33pm