

Push Buttons & Operator Interface - XB4 22 mm Die Cast Chrome Plated Selector Switches

Non-Illuminated Selector Switches ■▲



ZB4BD4



ZB4BJ3

Shape of Head	Type of Operator	Number and Type of Positions		Catalog Number
	Standard lever, black For colored lever add the following code to end of part number: 01 - white 03 - green 04 - red 05 - yellow 06 - blue (Example: ZB4BD204)	2 - maintained		ZB4BD2
		2 - momentary from right to left		ZB4BD4
		3 - maintained		ZB4BD3
		3 - momentary to center		ZB4BD5
		3 - momentary from left to center		ZB4BD7
		3 - momentary from right to center		ZB4BD8
	Extended lever, black	2 - maintained		ZB4BJ2
		2 - momentary from right to left		ZB4BJ4
		3 - maintained		ZB4BJ3
		3 - momentary to center		ZB4BJ5
		3 - momentary from left to center		ZB4BJ7
		3 - momentary from right to center		ZB4BJ8

Non-Illuminated Key Switches



ZB4BG8

Shape of Head	Type of Operator	Number and Type of Positions		Catalog Number ●
	Key (No. 455)	2 - maintained		ZB4BG2
				ZB4BG4
		2 - momentary from right to left		ZB4BG6
		3 - maintained		ZB4BG0
				ZB4BG3
				ZB4BG5
				ZB4BG9
				ZB4BG09
		3 - momentary from left to center		ZB4BG1
		3 - momentary to center		ZB4BG7
		3 - momentary from right to center		ZB4BG8
				ZB4BG08

The symbol indicates key withdrawal position(s).

■ For actuation of outside contacts only.

▲ See selector switch sequence charts on page 56.

● Other key numbers:

- key No. 421E: add the suffix 12 to the reference.

- key No. 458A: add the suffix 10 to the reference.

- key No. 520E: add the suffix 14 to the reference.

- key No. 3131A: add the suffix 20 to the reference.

Example:

The catalog number for a head with key No. 421E for a 2 position maintained, lockable selector switch, with key withdrawal from the left-hand position, becomes: ZB4BG212.