


CD & DVD Repair Systems
SkipDoctor®



Uses a patented radial wheel to effortlessly fix scratched audio CDs, movie DVDs, game, photo and data discs by resurfacing the play side of the disc while leaving music, movie, data or game information unaffected.

- Restores any type of scratched disc to perfect working order
- Works in under a minute
- Integrated storage for the accompanying accessories
- Supplied with resurfacing fluid, drying cloth, buffing square and operating instructions
- Safe to use - does not damage data layer of disc

SkipDoctor Advanced

Simply spray the disc with the resurfacing fluid provided, spin the disc using the handle at the side of the device, dry with the drying cloth and buff with the buffing square.

Motorised SkipDoctor

A motorised version of the SkipDoctor advanced.

SkipDoctor Automax

Features a completely automatic design - the device turns on, repairs the disc and ejects when complete using a smooth motorised action, it restores your discs to perfect working order in under a minute. Requires 6 x AA batteries (not included).

Accessory kit: Consists of replacement fluid, replacement wheel, drying cloth and buffering felt.

447637.342423

Description	Order Code	Price Each
SkipDoctor Advanced®	127-7634	
Motorized SkipDoctor®	127-7638	
Accessory Kit	127-7618	