

# SxV Soldering Tips



Compatible with: PS-900, MFR-1120, MFR-2220, MFR-2222 Systems,  
PS-HC3 and MFR-H2-ST hand-pieces, PS-CA3 and MFR-CA2 Coil Assemblies

| SxV SOLDERING TIPS |  | NEW                                       |  |
|--------------------|--|-------------------------------------------|--|
| CHISEL             |  | SFV-CH10A<br>STV-CH10A<br>SCV-CH10A       |  |
|                    |  | SFV-CH10AR<br>STV-CH10AR<br>SCV-CH10AR    |  |
|                    |  | SFV-CH10<br>STV-CH10<br>SCV-CH10          |  |
|                    |  | SFV-CH15A<br>STV-CH15A<br>SCV-CH15A       |  |
|                    |  | SFV-CH15AR<br>STV-CH15AR<br>SCV-CH15AR    |  |
| CHISEL             |  | SFV-CHB15<br>STV-CHB15<br>SCV-CHB15       |  |
|                    |  | SFV-CH18AR<br>STV-CH18AR<br>SCV-CH18AR    |  |
|                    |  | SFV-CH20<br>STV-CH20<br>SCV-CH20          |  |
|                    |  | SFV-CH24A<br>STV-CH24A<br>SCV-CH24A       |  |
|                    |  | SFV-CH25AR<br>STV-CH25AR<br>SCV-CH25AR    |  |
|                    |  | NEW                                       |  |
|                    |  | CHISEL                                    |  |
|                    |  | SFV-CH25<br>STV-CH25<br>SCV-CH25          |  |
|                    |  | SFV-CH30AR<br>STV-CH30AR<br>SCV-CH30AR    |  |
|                    |  | NEW                                       |  |
|                    |  | SFV-CH50A<br>STV-CH50A<br>SCV-CH50A       |  |
|                    |  | SFV-CH50AR<br>STV-CH50AR<br>SCV-CH50AR    |  |
|                    |  | SFV-CH50<br>STV-CH50<br>SCV-CH50          |  |
|                    |  | CONICAL                                   |  |
|                    |  | SFV-CNL03AR<br>STV-CNL03AR<br>SCV-CNL03AR |  |
|                    |  | NEW                                       |  |
|                    |  | SFV-CNB04A<br>STV-CNB04A<br>SCV-CNB04A    |  |
|                    |  | NEW                                       |  |
|                    |  | SFV-CN05A<br>STV-CN05A<br>SCV-CN05A       |  |
|                    |  | SFV-CNB04AR<br>STV-CNB04AR<br>SCV-CNB04AR |  |
|                    |  | SFV-CNL04<br>STV-CNL04<br>SCV-CNL04       |  |

F = FR4 / Fiber Glass, for most standard applications T = Temperature Sensitive C = Ceramic for high thermal demand applications.

# SxV Soldering Tips

## CxV Blade Tips



Compatible with: PS-900, MFR-1120, MFR-2220, MFR-2222 Systems,  
PS-HC3 and MFR-H2-ST hand-pieces, PS-CA3 and MFR-CA2 Coil Assemblies



CONICAL

| SxV SOLDERING TIPS |                                           |
|--------------------|-------------------------------------------|
|                    | SFV-CN05AR<br>STV-CN05AR<br>SCV-CN05AR    |
|                    | SFV-CN05<br>STV-CN05<br>SCV-CN05          |
|                    | SFV-CNB05<br>STV-CNB05<br>SCV-CNB05       |
|                    | SFV-CNL10A<br>STV-CNL10A<br>SCV-CNL10A    |
|                    | SFV-CNL10AR<br>STV-CNL10AR<br>SCV-CNL10AR |
|                    | SFV-CNL10<br>STV-CNL10<br>SCV-CNL10       |
|                    | SFV-CNL14<br>STV-CNL14<br>SCV-CNL14       |
|                    | SFV-DRH20<br>STV-DRH20<br>SCV-DRH20       |
|                    | SFV-CNL20<br>STV-CNL20<br>SCV-CNL20       |
|                    | SFV-WV20<br>STV-WV20<br>SCV-WV20          |
|                    | SFV-DRK45A<br>STV-DRK45A<br>SCV-DRK45A    |
|                    | SFV-DRK50<br>STV-DRK50<br>SCV-DRK50       |

KNIFE

HOOF

|  |                                              |
|--|----------------------------------------------|
|  | SFV-DRH420AR<br>STV-DRH420AR<br>SCV-DRH420AR |
|  | SFV-DRH20CP<br>STV-DRH20CP<br>SCV-DRH20CP    |
|  | SFV-DRH430AR<br>STV-DRH430AR<br>SCV-DRH430AR |
|  | SFV-DRH630AR<br>STV-DRH630AR<br>SCV-DRH630AR |
|  | SFV-DRH420A<br>STV-DRH420A<br>SCV-DRH420A    |
|  | SFV-DRH30CP<br>STV-DRH30CP<br>SCV-DRH30CP    |
|  | SFV-DRH440R<br>STV-DRH440R<br>SCV-DRH440R    |
|  | SFV-DRH640AR<br>STV-DRH640AR<br>SCV-DRH640AR |
|  | SFV-DRH40CP<br>STV-DRH40CP<br>SCV-DRH40CP    |
|  | SFV-DRH440A<br>STV-DRH440A<br>SCV-DRH440A    |
|  | SFV-DRK30AR<br>STV-DRK30AR<br>SCV-DRK30AR    |
|  | SFV-DRK45AR<br>STV-DRK45AR<br>SCV-DRK45AR    |

| CxV BLADE TIPS                                                                                                                                                                                                         |           | A         |             |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|-----------|-------------|
| <div><div>NEW</div><div></div></div> <div></div> | CFV-BL100 | CCV-BL100 | 10mm (.40") |
|                                                                                                                                                                                                                        | CFV-BL250 | CCV-BL250 | 25mm (1")   |
|                                                                                                                                                                                                                        | CFV-BL350 | CCV-BL350 | 35mm (1.4") |
|                                                                                                                                                                                                                        | CFV-BL400 | CCV-BL400 | 40mm (1.6") |
|                                                                                                                                                                                                                        | CFV-BL500 | CCV-BL500 | 50mm (2")   |

F = FR4 / Fiber Glass, for most standard applications T = Temperature Sensitive C = Ceramic for high thermal demand applications.