

## Spanner Tool for Tightening Series 80 Jam Nuts

Use these tools to tighten Series 80 jam nuts. 1/4" or 3/8" square drive for use with torque wrenches. Heat-treated steel, nickel plated.



| Shell Size | Spanner Tool Part Number |            |            |                     |                     |            |
|------------|--------------------------|------------|------------|---------------------|---------------------|------------|
|            | Series 800               | Series 801 | Series 803 | Series 804 Style 07 | Series 804 Style 00 | Series 805 |
| 5          | 600-146-01               | 600-146-02 | 600-137-05 | 600-146-03          | 600-147-5           | —          |
| 6          | 600-146-02               | 600-146-03 | 600-137-06 | 600-146-04          | 600-147-6           | —          |
| 7          | 600-146-03               | 600-146-05 | 600-137-07 | 600-146-06          | 600-147-7           | —          |
| 8          | 600-146-04               | 600-146-05 | 600-137-08 | 600-146-06          | 600-147-7           | 600-154-08 |
| 9          | 600-146-05               | 600-146-06 | 600-137-09 | 600-146-07          | 600-147-9           | 600-154-09 |
| 10         | 600-146-06               | 600-146-07 | 600-137-10 | 600-146-08          | 600-147-10          | 600-154-09 |
| 11         | —                        | —          | —          | —                   | —                   | 600-154-11 |
| 12         | 600-146-08               | —          | 600-137-12 | 600-146-10          | 600-147-12          | 600-154-12 |
| 13         | —                        | 600-146-10 | —          | —                   | —                   | —          |
| 14         | 600-146-10               | —          | 600-137-14 | 600-146-12          | 600-147-14          | —          |
| 15         | 600-146-11               | —          | 600-137-15 | 600-146-13          | 600-147-15          | 600-154-15 |
| 16         | —                        | 600-146-13 | —          | —                   | —                   | —          |
| 17         | —                        | 600-146-14 | —          | —                   | —                   | —          |
| 18         | —                        | —          | —          | —                   | —                   | 600-154-18 |
| 19         | —                        | —          | —          | —                   | —                   | 600-154-19 |
| 21         | —                        | 600-146-17 | —          | —                   | —                   | —          |
| 23         | —                        | —          | —          | —                   | —                   | 600-154-23 |

## Connector Holding Tool for Tightening Backshells and Accessories



**1** Plug tool for holding Series 80 plug connectors. Heat-treated steel, nickel plated.

**2** Receptacle tool for holding Series 80 receptacle connectors. Heat-treated steel, nickel plated.



| Shell Size | Holding Tool Part Number (Add P or R) |   |             |   |            |            |            |
|------------|---------------------------------------|---|-------------|---|------------|------------|------------|
|            | Series 800                            |   | Series 801  |   | Series 803 | Series 804 | Series 805 |
| 5          | 600M005-05                            | ★ | 600MM005-05 | ◆ | 600-140-5  | ★          | 600-141-5  |
| 6          | 600M005-06                            | ★ | 600MM005-06 | ◆ | 600-140-6  | ★          | 600-141-6  |
| 7          | 600M005-07                            | ★ | 600MM005-07 | ◆ | 600-140-7  | ★          | 600-141-7  |
| 8          | 600M005-08                            | ★ | 600MM005-08 | ◆ | 600-140-8  | ★          | 600-141-8  |
| 9          | 600M005-09                            | ★ | 600MM005-09 | ◆ | 600-140-9  | ★          | 600-141-9  |
| 10         | 600M005-10                            | ★ | 600MM005-10 | ◆ | 600-140-10 | ★          | 600-141-10 |
| 11         | —                                     | — | —           | — | —          | —          | 600-155-11 |
| 12         | 600M005-12                            | ★ | —           | — | 600-140-12 | ★          | 600-141-12 |
| 13         | —                                     | — | 600MM005-13 | ◆ | —          | —          | —          |
| 14         | —                                     | — | —           | — | 600-140-14 | ★          | 600-141-14 |
| 15         | —                                     | — | —           | — | 600-140-15 | ★          | 600-141-15 |
| 16         | —                                     | — | 600MM005-16 | ◆ | —          | —          | —          |
| 17         | —                                     | — | 600MM005-17 | ◆ | —          | —          | —          |
| 18         | —                                     | — | —           | — | —          | —          | 600-155-18 |
| 19         | —                                     | — | —           | — | —          | —          | 600-155-19 |
| 21         | —                                     | — | 600MM005-21 | ◆ | —          | —          | —          |
| 23         | —                                     | — | —           | — | —          | —          | 600-155-23 |

★ Add **P** for plug holder or **R** for receptacle holder, followed by polarizing position (**N,X,Y,Z**).  
 ◆ Add **P** for plug holder or **R** for receptacle holder, followed by polarizing position (**A,B,C,D**).  
 ■ Add **P** for plug holder or **R** for receptacle holder.

# Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Glenair:

[600-155-10P](#) [600-155-11R](#) [600-155-12P](#) [600-155-15P](#) [600-155-15R](#) [600-155-9R](#)