

PRODUCTS

- Appliance Parts & Motors
 - Batteries: Consumer
 - Batteries: OEM & Industrial
 - Computer Components
 - Passive & Electromechanical
 - Satellite Communication
 - Semiconductor
 - Telecommunications Industry
 - Other OEM Components
- + Sales Reps / Distributors
- + Industrial Home
- + Factory Automation Home

INDUSTRIAL SOLUTIONS

Search

Your Search returned the Following Part Numbers
Please Select Desired Part or re-enter Part Number

Part Number	Part Description
ECUV1H010BCV	ECU-V1H010BCV
ECUV1H020CCN	DISCONT: USE ALT ECJ2VC1H020C
ECUV1H020CCV	DISCONT: USE ALT ECJ1VC1H020C
ECUV1H030CCN	ECU-V1H030CCN
ECUV1H040CCN	ECU-V1H040CCN
ECUV1H040CCV	DISCONT: USE ALT ECJ1VC1H040C
ECUV1H050CCV	DISCONT: USE ALT ECJ1VC1H050C
ECUV1H070DCN	DISCONT: USE ALT ECJ2VC1H070D
ECUV1H080DCV	DISCONT: USE ALT ECJ1VC1H080D
ECUV1H100CCV	ECU-V1H100CCV
ECUV1H100DCV	DISCONT: USE ALT ECJ1VC1H100D
ECUV1H101JCG	DISCONT: USE ALT ECJ2VC1H101J
ECUV1H101JCV	DISCONT: USE ALT ECJ1VC1H101J
ECUV1H102JCH	Discontinued No Alternate
ECUV1H102JCX	DISCONT: USE ALT ECJ2VC1H102J
ECUV1H102KBM	Discontinued No Alternate
ECUV1H102KBN	DISCONT: USE ALT ECJ2VB1H102K
ECUV1H102KBV	DISCONT: USE ALT ECJ1
ECUV1H102ZFB	DISCONT:
ECUV1H103KBG	DISCONT: USE ALT ECJ2VB1H103K
ECUV1H103KBM	Discontinued No Alternate
ECUV1H103KBV	DISCONT: USE ALT ECJ1
ECUV1H120JCM	Discontinued No Alternate
ECUV1H121JCG	DISCONT: USE ALT ECJ2VC1H121J
ECUV1H121JCV	DISCONT: USE ALT ECJ1VC1H121J
ECUV1H122JBV	ECU-V1H122JBV
ECUV1H122KBM	DISCONTINUED NO RPLCMNT
ECUV1H122KBV	DISCONT: USE ALT ECJ1
ECUV1H123KBM	DISCONTINUED NO RPLCMNT
ECUV1H150JCN	DISCONT: USE ALT ECJ2VC1H150J
ECUV1H150JCV	DISCONT: USE ALT ECJ1VC1H150J
ECUV1H152JCX	DISCONT: USE ALT ECJ2VC1H152J
ECUV1H152KBM	Discontinued No Alternate
ECUV1H152KBV	DISCONT: USE ALT ECJ1
ECUV1H153KBV	DISCONT: USE ALT ECJ1
ECUV1H180JCM	Discontinued No Alternate
ECUV1H180JPN	ECU-V1H180JPN

ECUV1H182KBM	DISCONTINUED NO RPLCMNT
ECUV1H182KBV	DISCONT: USE ALT ECJ1
ECUV1H183KBM	DISC NO RPLCMNT
ECUV1H1R5CCN	DISCONT: USE ALT ECJ2VC1H1R5C
ECUV1H200GCV	ECU-V1H200GCV
ECUV1H200JCV	ECU-V1H200JCV
ECUV1H201GCG	ECUV1H201GCG
ECUV1H220JCM	Discontinued No Alternate
ECUV1H220JCN	ECU-V1H220JCN
ECUV1H220JCV	DISCONT: USE ALT ECJ1VC1H220J
ECUV1H221JCG	DISCONT: USE ALT ECJ2VC1H221J
ECUV1H221JCV	DISCONT: USE ALT ECJ1VC1H221J
ECUV1H221KCV	Discontinued No Alternate
ECUV1H222JBV	ECU-V1H222JBV
ECUV1H222KBN	MLC CERAMIC SMT CAP 50V 2200PF 10% TOL
ECUV1H222MBN	ECU-V1H222MBN
ECUV1H223KBM	Discontinued No Alternate
ECUV1H240GCV	ECU-V1H240GCV
ECUV1H240JCV	ECU-V1H240JCV
ECUV1H270GCV	ECU-V1H270GCV
ECUV1H271JCV	DISCONT: USE ALT ECJ1VC1H271J
ECUV1H271KBN	DISC NO RPLCMNT
ECUV1H272KBM	DISC NO RPLCMNT
ECUV1H272KBV	DISCONT:USE ALT ECJ1
ECUV1H273KBW	DISC NO RPLCMNT
ECUV1H330JCG	MLCC CER CAP 0805 50V PAP TAPE 4MM NPO
ECUV1H331KBV	DISCONT:
ECUV1H332KBM	Discontinue No Alternate
ECUV1H332KBV	Discontinue No Alternate
ECUV1H390JCM	Discontinue No Alternate
ECUV1H391KBM	DISC NO RPLCMNT
ECUV1H391KCV	Discontinue No Alternate
ECUV1H392KBM	Discontinue No Alternate
ECUV1H470JCG	ECU-V1H470JCG
ECUV1H470JCM	Discontinue No Alternate
ECUV1H470JCV	DISCONT: USE ALT ECJ1VC1H470J
ECUV1H470JUV	DISCONT:
ECUV1H471JCV	ECU-V1H471JCV
ECUV1H471JCXEMS	DISCONT: USE ALT ECJ2VC1H471J
ECUV1H471KBN	Discontinue No Alternate
ECUV1H471KBV	DISCONT:
ECUV1H472JBV	ECU-V1H472JBV
ECUV1H472ZFB	Discontinued
ECUV1H473KBW	Discontinue No Alternate
ECUV1H4R7CCM	Discontinue No Alternate
ECUV1H560JCG	DISCONT: USE ALT ECJ2VC1H560J
ECUV1H560JPN	ECU-V1H560JPN
ECUV1H561KBN	DISC NO RPLCMNT
ECUV1H562KBV	DISCONT: USE ALT ECJ1

ECUV1H622JBV	ECU-V1H622JBV
ECUV1H681JCX	DISCONT: USE ALT ECJ2VC1H681J
ECUV1H681KBN	DISC NO RPLCMNT
ECUV1H681KBV	DISCONT:
ECUV1H682KBM	Discontinue No Alternate
ECUV1H6R2CCV	ECU-V1H6R2CCV
ECUV1H820JCG	ECU-V1H820JCG
ECUV1H821KBM	DISC NO RPLCMNT
ECUV1H821KBN	DICS NO RPLCMNT
ECUV1H821KBV	DISCONT: