Series 800 Mighty Mouse UN Mating Thread
Inline and Panel Mount Receptacles
800-010 and 800-011 Ordering Information

Integral Band Platform for direct attachment of a cable shield using a Band-Master™ ATS strap. Install a boot, or overmold onto the band platform. An accessory thread is available for attaching strain reliefs and backshells.

Three Shell Options: Jam nut with o-ring for rear panel mounting, square flange or in-line receptacle for free-hanging cables.

| *In-Line* | *Square Flange* | *Rear Panel Jam Nut* |

C

How To Order						
Sample Part Number		**800-011**	**-01**	**M**	**6-7**	**P**	**N**

Series (See Table I)	**800-010** = With Banding Platform **800-011** = With Accessory Thread
Shell Style (See Table II)	**-01** = In-Line **-02** = Square Flange for Front or Rear Mounting **-07** = Jam Nut for Rear Panel Mounting *(See Jam Nut Panel Cutout Dimensions Page C-3)*
Shell Material and Finish	**C** = Aluminum / Black Anodize (Non-Conductive) RoHS Compliant **M** = Aluminum / Electroless Nickel RoHS Compliant **NF** = Aluminum / Cadmium with Olive Drab Chromate **ZNU** = Aluminum / Zinc-Nickel with Black Chromate **MT** = Aluminum / Nickel-PTFE RoHS Compliant **Z1** = Stainless Steel / Passivated RoHS Compliant
Shell Size - Insert Arrangement	See Contact Arrangements page C-2
Contact Type	**Connector supplied with crimp contacts** **P** = Pin **S** = Socket **Connector supplied without contacts** **A** = Pin Connector **B** = Socket Connector **Connector supplied with 30 AWG crimp contacts** **G** = Pin **H** = Socket Connectors with contacts are supplied with signal and/or power crimp contacts. These contacts are not installed. Coaxial contacts and non-standard signal contacts are ordered separately.
Shell Key Position (See Table III)	**N** = Normal **X** = Pos. X **Y** = Pos. Y **Z** = Pos. Z

Table I: Series	
800-010 Receptacle with Banding Platform	**800-011** Receptacle with Accessory Thread

Table II: Shell Style		
-01 In-Line	**-02** Square Flange or Rear Mounting	**-07** Jam Nut for Rear Panel Mounting

Dimensions in Inches (millimeters) are subject to change without notice.

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[Glenair]():
  [800-011-07ZB12-37PN]() [800-011-07ZB9-19SN]() [800-010-07ZB6-7SN]() [800-010-01NF12-37PN]()