

## Push Buttons & Operator Interface - XB4 22 mm Die Cast Chrome Plated Selector Switches

### Non-Illuminated Selector Switches ■▲



ZB4BD4



ZB4BJ3

| Shape of Head | Type of Operator                                                                                                                                                                               | Number and Type of Positions       |  | Catalog Number |
|---------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------|--|----------------|
|               | <b>Standard lever, black</b><br><br>For colored lever add the following code to end of part number:<br>01 - white<br>03 - green<br>04 - red<br>05 - yellow<br>06 - blue<br>(Example: ZB4BD204) | 2 - maintained                     |  | ZB4BD2         |
|               |                                                                                                                                                                                                | 2 - momentary from right to left   |  | ZB4BD4         |
|               |                                                                                                                                                                                                | 3 - maintained                     |  | ZB4BD3         |
|               |                                                                                                                                                                                                | 3 - momentary to center            |  | ZB4BD5         |
|               |                                                                                                                                                                                                | 3 - momentary from left to center  |  | ZB4BD7         |
|               |                                                                                                                                                                                                | 3 - momentary from right to center |  | ZB4BD8         |
|               | <b>Extended lever, black</b>                                                                                                                                                                   | 2 - maintained                     |  | ZB4BJ2         |
|               |                                                                                                                                                                                                | 2 - momentary from right to left   |  | ZB4BJ4         |
|               |                                                                                                                                                                                                | 3 - maintained                     |  | ZB4BJ3         |
|               |                                                                                                                                                                                                | 3 - momentary to center            |  | ZB4BJ5         |
|               |                                                                                                                                                                                                | 3 - momentary from left to center  |  | ZB4BJ7         |
|               |                                                                                                                                                                                                | 3 - momentary from right to center |  | ZB4BJ8         |

### Non-Illuminated Key Switches



ZB4BG8

| Shape of Head | Type of Operator         | Number and Type of Positions       |  | Catalog Number ● |
|---------------|--------------------------|------------------------------------|--|------------------|
|               | <b>Key<br/>(No. 455)</b> | 2 - maintained                     |  | ZB4BG2           |
|               |                          |                                    |  | ZB4BG4           |
|               |                          | 2 - momentary from right to left   |  | ZB4BG6           |
|               |                          | 3 - maintained                     |  | ZB4BG0           |
|               |                          |                                    |  | ZB4BG3           |
|               |                          |                                    |  | ZB4BG5           |
|               |                          |                                    |  | ZB4BG9           |
|               |                          |                                    |  | ZB4BG09          |
|               |                          | 3 - momentary from left to center  |  | ZB4BG1           |
|               |                          | 3 - momentary to center            |  | ZB4BG7           |
|               |                          | 3 - momentary from right to center |  | ZB4BG8           |
|               |                          |                                    |  | ZB4BG08          |

The symbol indicates key withdrawal position(s).

■ For actuation of outside contacts only.

▲ See selector switch sequence charts on page 56.

● Other key numbers:

- key No. 421E: add the suffix 12 to the reference.

- key No. 458A: add the suffix 10 to the reference.

- key No. 520E: add the suffix 14 to the reference.

- key No. 3131A: add the suffix 20 to the reference.

Example:

The catalog number for a head with key No. 421E for a 2 position maintained, lockable selector switch, with key withdrawal from the left-hand position, becomes: ZB4BG212.