

Class J Fuseblocks(600V) Catalog Data

Catolog Number	Covers		Voltage	Current	Number of Poles	Label
Class J	w/o Indication	w/ Indication				
JM60100-1CR	CVR-J-60100	CVRI-J-60100	600	100	1	JM60100-1CR
JM60100-2CR					2	JM60100-2CR
JM60100-3CR					3	JM60100-3CR
JM60200-1CR	CVR-J-60200	CVRI-J-60200		200	1	JM60200-1CR
JM60200-2CR					2	JM60200-2CR
JM60200-3CR					3	JM60200-3CR
JM60400-1CR	CVR-J-60400	CVRI-J-60400		400	1	JM60400-1CR
JM60400-2CR					2	JM60400-2CR
JM60400-3CR					3	JM60400-3CR
JM60600-1CR	CVR-J-60600	CVRI-J-60600		600	1	JM60600-1CR
JM60600-2CR					2	JM60600-2CR
JM60600-3CR					3	JM60600-3CR





St. Louis MO 63178

TITLE:

Class J fuse holder-CUST

SCALE: 1:5 SIZE: A3 SHEET: 1 OF 14

www.Bussmann.com



COOPER Bussmann
St. Louis MO 63178

TITLE:




Class J fuse holder-CUST

SCALE:
1:2



SIZE:
A3

SHEET:
2 OF 14



JM60100-1CR





JM60100-1CR WITH CVR-J-60100 INSTALLED




CVR-J-60100



JM60100-1CR WITH CVRI-J-60100 INSTALLED



CVRI-J-60100



CUT OPEN ALONG THIS DOTTED LINE FOR WIRES ABOVE 6 AWG

COOPER Bussmann
St. Louis MO 63178









Class J fuse holder-CUST

SCALE: 1:1 SIZE: A3 SHEET: 3 OF 14

JM60100-2CR

JM60100-2CR WITH CVR-J-60100 INSTALLED

JM60100-2CR WITH CVRI-J-60100 INSTALLED






COOPER Bussmann
St. Louis MO 63178




Class J fuse holder-CUST

SCALE: 1:1 SIZE: A3 SHEET: 4 OF 14



JM60100-3CR



JM60100-3CR WITH CVR-J-60100 INSTALLED



JM60100-3CR WITH CVRI-J-60100 INSTALLED






COOPER Bussmann
St. Louis MO 63178




Class J fuse holder-CUST

SCALE: 1:1 SIZE: A3 SHEET: 5 OF 14


JM60200-1CR





JM60200-1CR WITH CVR-J-60200 INSTALLED





CVR-J-60200



JM60200-1CR WITH CVRI-J-60200 INSTALLED



CVRI-J-60200






CUT OPEN ALONG THIS DOTTED LINE FOR WIRES ABOVE 2 AWG

COOPER Bussmann
St. Louis MO 63178




Class J fuse holder-CUST

SCALE: 1:2 SIZE: A3 SHEET: 6 OF 14



JM60200-2CR



JM60200-2CR WITH CVR-J-60200 INSTALLED



JM60200-2CR WITH CVRI-J-60200 INSTALLED




COOPER Bussmann
St. Louis MO 63178


Class J fuse holder-CUST

SCALE: 1:2 SIZE: A3 SHEET: 7 OF 14







JM60200-3CR



JM60200-3CR WITH CVR-J-60200 INSTALLED



JM60200-3CR WITH CVRI-J-60200 INSTALLED



COOPER Bussmann
St. Louis MO 63178










Class J fuse holder-CUST

SCALE: 1:2 SIZE: A3 SHEET: 8 OF 14

JM60400-1CR

JM60400-1CR WITH CVR-J-60400 INSTALLED

JM60400-1CR WITH CVRI-J-60400 INSTALLED






CUT OPEN ALONG
THIS DOTTED LINE
FOR WIRES ABOVE
250 KCMIL

COOPER Bussmann
St. Louis MO 63178




Class J fuse holder-CUST

SCALE: 1:5 SIZE: A3 SHEET: 9 OF 14



JM60400-3CR



JM60400-3CR WITH CVR-J-60400 INSTALLED



JM60400-3CR WITH CVRI-J-60400 INSTALLED




REMOVE FOR WIRES
ABOVE 250 KCMIL

COOPER Bussmann
St. Louis MO 63178



Class J fuse holder-CUST

SCALE: 1:5 SIZE: A3 SHEET: 11 OF 14



JM60600-1CR






ALLEN KEY #:
3/8"(10.0MM)



JM60600-1CR WITH CVR-J-60600 INSTALLED




CVR-J-60600




CUT OPEN ALONG
THIS DOTTED LINE
FOR WIRES ABOVE
250 KCMIL

JM60600-1CR WITH CVRI-J-60600 INSTALLED



CVRI-J-60600






COOPER Bussmann
St. Louis MO 63178




Class J fuse holder-CUST

SCALE: 1:5 SIZE: A3 SHEET: 12 OF 14



JM60600-2CR



JM60600-2CR WITH CVR-J-60600 INSTALLED



JM60600-2CR WITH CVRI-J-60600 INSTALLED






COOPER Bussmann
St. Louis MO 63178




Class J fuse holder-CUST

SCALE: 1:5 SIZE: A3 SHEET: 13 OF 14



JM60600-3CR



JM60600-3CR WITH CVR-J-60600 INSTALLED



JM60600-3CR WITH CVRI-J-60600 INSTALLED



COOPER Bussmann
St. Louis MO 63178

Class J fuse holder-CUST

SCALE: 1:5 SIZE: A3 SHEET: 14 OF 14

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[Cooper Bussmann:](#)

[JM60400-1CR](#)