



Agilent Technologies

Agilent U1179A IR Connectivity Bracket

Operating Instructions

The Agilent U1179A IR Connectivity Bracket is designed for use with the Agilent U1177A IR-to-Bluetooth[®] [1] adapter or the Agilent U1173A IR-to-USB Cable.

Assistance

For technical assistance, contact your nearest Agilent Sales Office or visit the Agilent website at www.agilent.com/find/assist for further information.

[1] The **Bluetooth**[®] word mark and logos are registered trademark owned by **Bluetooth** SIG, Inc and any use of such marks by Agilent is under license. Other trademark and trade names are those of their respective owners.

Instructions

①



The Agilent U1240 Series Handheld Digital Multimeter without the U1179A IR Connectivity Bracket.

②



Insert the U1179A IR Connectivity Bracket into the corresponding slot on the Agilent U1240 Series Handheld Digital Multimeter as shown in the picture.

③



Use both thumbs to fasten the bracket securely to the back of the Agilent U1240 Series Handheld Digital Multimeter.

④



The Agilent U1240 Series Handheld Digital Multimeter with the U1179A IR Connectivity Bracket.



U1179-90000



Agilent Technologies

©Agilent Technologies, Inc., 2012
Printed in Malaysia
July 1, 2012