

Optional Hardware

Rubber Washer (AT401-P) for Panel Seal

Black



Insert switch from rear of the panel with rubber washer between panel and switch. Install hex face nut from the front of the panel. Mounting torque 901mN·m maximum.