

## TL-94 Cam Latch



### Characteristic

Use a screwdriver or a coin to turn this simple lock.


### Application

Measuring instruments /  
Distribution panels


### Specification

| Model No. | Part Name       | Material | Finish | Quantity | Net Weight(g) | Code No. |
|-----------|-----------------|----------|--------|----------|---------------|----------|
| TL-94-1   | Handle ①        | C3604    | Ni     | 1        | 10.2          | 1080     |
| TL-94-2   | Fixing Plate ②  | SPCC     | Zn     | 1        | 9.0           | 1080A    |
| TL-94-3   | Spring Washer ③ | S        |        | 1        | 0.9           | 1080B    |
| TL-94-4   | Hexagon Nut ④   |          |        | 1        | 2.2           | 1080C    |
| TL-94-5A  | Pawl ㉕A         | SPCC     |        | Order    | 10.0          | 1081     |
| TL-94-5B  | Pawl ㉕B         |          |        | Order    | 16.0          | 1082     |
| TL-94-5C  | Pawl ㉕C         |          |        | Order    | 14.0          | 1083     |
| TL-94-6   | Spacer ⑥        | C3603    | —      | 1        | 1.9           | 1080D    |
| TL-94-001 | Set ①②③④⑤⑥      | —        | —      | —        | 34.2          | 1902     |
| TL-94-002 | Set ①②③④㉕⑥      |          |        | —        | 40.2          | 1903     |
| TL-94-003 | Set ①②③④㉕⑥      |          |        | —        | 38.2          | 1904     |
| TL-94-004 | Set ①②③④⑥       |          |        | —        | 24.2          | 1905     |

※Pawl is not included.



Layout of Holes  
for  
Installation



Installation Example

