



8 button membrane SW to OSD Control Board CN2 Pin Assignment	
pin #	description
10	Common Ground
9	Select Up
8	Select Down
7	Adjust Up/Increase/Right
6	Adjust Down/Decrease/Left
5	Menu
4	Brightness Down
3	Brightness Up
2	ON/OFF
1	Common Ground



Membrane Switch:
P/N:356301021-3



PCB OSD INTERFACE:
P/N:416100110-3

PCB OSD Control Board CN1 Pin Assignment	
pin #	description
12	no connection
11	OSD Select UP
10	OSD Select Down
9	OSD Plus/Right
8	OSD Minus/Left
7	OSD Menu
6	Ground
5	Backlight Brightness VR pin B
4	Backlight Brightness VR pin WIP
3	Backlight Brightness VR pin A
2	Power Switch B
1	Power Switch A

Jumper setting on OSD interface
DEFAULT POWER
JP1 : 1-2 closed - OFF
2-3 closed - ON
BRIGHTNESS INC/DEC SWITCH
JP2 : 1-3 & 2-4 closed - SWAP
1-2 & 3-4 closed - NORMAL

OSD Cable:
P/N:420680260-3 (12/12WAY), 150mm



Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[Digital View:](#)

[KIT 60120-3](#)