


094



PCB Layout

PCB Layout



www.mpe-connector.de

0	9	4	-	?	-	?	?	?	-	0	-	N	?	X	-	Y	S	0
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

087	089	090	585	088	334	368	296
3-37	3-38	3-39	3-40	3-41	3-42	3-43	3-53