


Possible installation positions A500



Batteries ≤ 10 Ah

A is the standard installation position for cycle and float - service

B is a possible installation for cycle and float - service (A506/4,2:position C)

C is a possible installation for cycle - service (A506/4,2:position B)

For portable application every position also D, is possible for the discharge
Charging in position D is not permitted

Batteries > 10 Ah

A is the standard installation position for cycle and float - service

C is a possible installation for cycle - service *

* in float-service, there must a capacity loss upto 10% be taken into account