



Stop pushbutton actuator



Essential Accessories:

 Switching element for Emergency-stop pushbutton page 52

	Front protection	Switching action	Front ring	Mushroom had cap	Marking	Ø 40 mm Typ-Nr.	Mounting dimensions	Technical drawing	Circuit drawing	
<b>Stop pushbutton actuator</b> Key to unlock clockwise Standard lock 251	IP 65	MA	Aluminium natural	Plastic red	without	<b>704.078.0</b>	9	17	7	0.063
			Plastic grey	Plastic red	without	<b>704.076.0</b>	9	17	7	0.063
Twist to unlock clockwise	IP 65	MA	Aluminium natural	Plastic red	Arrows	<b>704.075.2</b>	9	12	7	0.047
					Stop	<b>704.075.3</b>	9	12	7	0.047
			Plastic grey	Plastic red	Arrows	<b>704.074.2</b>	9	12	7	0.047
					Stop	<b>704.074.3</b>	9	12	7	0.047

Switching action: MA = Maintained action  
Mounting dimensions from page 87, Technical drawing from page 91, Circuit drawing from page 110