




























Kunststoff-Drehknopf-System mit Spannzangenbefestigung

Plastic Turning Knob System with Collet Fixing

Knöpfe · Knobs		Abdeckkappen · Caps		
Farbschlüssel · Color Key ● rot · red ● blau · blue ● schwarz · black ● gelb · yellow ● grau · grey ● grün · green				
	Ø d		ohne Markierung without marking	mit Markierung with marking
		4 4 6 6 ■ 4231.403 ■ 4231.404 ■ 4231.603 ■ 4231.604	■ 4131.063 ■ 4131.064	■ 4131.073 ■ 4131.074
		6 6 ■ 4232.603 ■ 4232.604	■ 4132.063 ■ 4132.064	■ 4132.073 ■ 4132.074
		6 6 ■ 4233.603 ■ 4233.604	■ 4133.063 ■ 4133.064	■ 4133.073 ■ 4133.074
		6 6 ■ 4234.603 ■ 4234.604	■ 4134.063 ■ 4134.064	■ 4134.073 ■ 4134.074
		6 6 ■ 4235.603 ■ 4235.604	■ 4135.063 ■ 4135.064	■ 4135.073 ■ 4135.074

Zubehör

Accessories

Mutterabdeckungen · Nut Coverings		Zeiger · Pointers	Zeigerscheiben · Pointer Dials		Grundplatten · Base Plates
 ohne Zeiger without Pointer mit Zeiger with Pointer					
 ■ 331.120	 ■ 331.130 ■ 331.132	 ■ 331.100 ■ 331.101 ■ 331.102	 ■ 331.250	 A ... 331.200 B ... 331.201 C ... 331.202 D ... 331.203 E ... 331.204 F ... 331.205	 ■ 331.300
 ■ 332.120	 ■ 332.100 ■ 332.101 ■ 332.102	 ■ 4332.100	 ■ 332.250	 A ... 332.200 B ... 332.201 C ... 332.202 D ... 332.203 E ... 332.204 F ... 332.205	 ■ 332.300
			 ■ 333.250	 A ... 333.200 B ... 333.201 C ... 333.202 D ... 333.203 E ... 333.204 F ... 333.205	 ■ 333.300
				 A ... 334.200 B ... 334.201	Feststeller · Arrestor 
				 A ... 335.200 B ... 335.201	mit Anzeige with indication h = 7,5 329.15 h = 12 329.14 ohne Anzeige without indication h = 7,5 329.05 h = 12 329.04