



General ordering data

Order No.	1053660000
Part designation	WQV 2.5/2
Version	Cross-connector / link for modular terminal, Cross-connection pre-installed, No. of poles: 2
EAN	4008190031121
Qty	50 pc(s).

Additional technical data

Explosion-tested version "Ex e"	No
---------------------------------	----

Cross-connector

No. of cross-connected terminals	2
Pitch	5.1 mm
Rated current, 2-pole	32 A
Rated current, multi-pole	32 A
Rated voltage	0 V
Type	Cross-connector
Type of fixing	screwed
Function	Cross-connection pre-installed
No. of poles	2

Rating data

Rated voltage	0 V
Rated current	32

Downloads

STEP	1053660000_14685_WQV_2.5-2_STP.stp
------	------------------------------------

Classifications

ETIM 2.0	EC000489
ETIM 3.0	EC000489
eClass 4.1	27-14-11-99
eClass 5.0	27-14-11-40
eClass 5.1	27-14-11-40

Classifications

Similar products

Order No.	Part designation	Version
1053860000	WQV 2.5/4	Cross-connector / link for modular terminal, Cross-connection pre-installed, No. of poles: 4
1054260000	WQV 2.5/8	Cross-connector / link for modular terminal, Cross-connection pre-installed, No. of poles: 8
1053960000	WQV 2.5/5	Cross-connector / link for modular terminal, Cross-connection pre-installed, No. of poles: 5
1059660000	WQV 2.5/15	Cross-connector / link for modular terminal, Cross-connection pre-installed, No. of poles: 15
1577600000	WQV 2.5/32	Cross-connector / link for modular terminal, Cross-connection pre-installed, No. of poles: 32
1053760000	WQV 2.5/3	Cross-connector / link for modular terminal, Cross-connection pre-installed, No. of poles: 3
1059560000	WQV 2.5/14	Cross-connector / link for modular terminal, Cross-connection pre-installed, No. of poles: 14
1054160000	WQV 2.5/7	Cross-connector / link for modular terminal, Cross-connection pre-installed, No. of poles: 7
1054060000	WQV 2.5/6	Cross-connector / link for modular terminal, Cross-connection pre-installed, No. of poles: 6
1577570000	WQV 2.5/20	Cross-connector / link for modular terminal, Cross-connection pre-installed, No. of poles: 20
1053660000	WQV 2.5/2	Cross-connector / link for modular terminal, Cross-connection pre-installed, No. of poles: 2
1054360000	WQV 2.5/9	Cross-connector / link for modular terminal, Cross-connection pre-installed, No. of poles: 9
1059360000	WQV 2.5/12	Cross-connector / link for modular terminal, Cross-connection pre-installed, No. of poles: 12
1067500000	WQV 2.5/30	Cross-connector / link for modular terminal, Cross-connection pre-installed, No. of poles: 30
1054460000	WQV 2.5/10	Cross-connector / link for modular terminal, Cross-connection pre-installed, No. of poles: 10