

Between Series Adapters solve a variety of connection problems where connectors of different types ordinarily could not be mated together. Each adapter has a different type coupling at each end allowing for a wide variety of interconnections to fit almost all interconnection situations. All adapters are constructed of machined brass and are nickel plated.

N to BNC

Part Number	RoHS	Description	Fig. No.
1301505	✓	N Male - BNC Male	145
1313505	✓	N Male - BNC Female	146
1323505	✓	N Female - BNC Female	147
8311505	✓	N Female - BNC Male	N/S

RoHS compliant



Fig. 145



Fig. 146



Fig. 147

N to UHF

Part Number	RoHS	Description	Fig. No.
1307505	✓	N Male - UHF Male	148
1317505	✓	N Male - UHF Female	149
1325505	✓	N Female - UHF Female	150
7311505	✓	N Female - UHF Male	151

RoHS compliant



Fig. 148



Fig. 149



Fig. 150



Fig. 151

N to F

Part Number	RoHS	Description	Fig. No.
1308505	✓	N Male - F Male	152
1318505	✓	N Male - F Female	153
1328505	✓	N Female - F Female	154
8311505	✓	N Female - F Male	N/S

RoHS compliant



Fig. 152



Fig. 153



Fig. 154

N to SMA

Part Number	RoHS	Description	Fig. No.
1309505	✓	N Male - SMA Male	155
1319505	✓	N Male - SMA Female	156
1329505	✓	N Female - SMA Female	157
9311505	✓	N Female - SMA Male	158

RoHS compliant



Fig. 155



Fig. 156



Fig. 157




Fig. 158

N to TNC

Part Number	RoHS	Description	Fig. No.
1325505	✓	N Female - TNC Female	159
1311505	✓	N Female - TNC Male	160
1305505	✓	N Male - TNC Male	N/S
1315505	✓	N Male - TNC Female	N/S

RoHS compliant



Fig. 159



Fig. 160

N to 7/16

Part Number	RoHS	Description	Fig. No.
131150011	✓	N Male - 7/16 Female (Ti-Plate)	155A
153115011	✓	N Male - 7/16 Male (Ti-Plate)	156A
153150011	✓	N Female - 7/16 Male (Ti-Plate)	157A
153215011	✓	N Female - 7/16 Female (Ti-Plate)	158A



Fig. 155A




Fig. 156A



Fig. 157A



Fig. 158

7/16 to 7/16

Part Number	RoHS	Description	Fig. No.
1513A5011	✓	7/16 Male - 7/16 Female R/A (Ti-Plate)	155B
1532A5011	✓	7/16 Female - 7/16 Female (Ti-Plate)	156B



Fig. 155B



Fig. 156B

FOR TECHNICAL SUPPORT: PHONE 973-347-4040 / FAX 973-347-2111

28

- Page 29 -

Between Series Adapters

BNC to TNC

Part Number	RoHS	Description	Fig. No.
3315505	✓	BNC Male - TNC Female	162
3325505	✓	BNC Female - TNC Female	163
3315505	✓	BNC Female - TNC Male	164

RoHS compliant



Fig. 162



Fig. 163



Fig. 164

BNC to Mini-UHF

Part Number	RoHS	Description	Fig. No.
3316505	✓	BNC Male - Mini-UHF Female	165
6313505	✓	BNC Female - Mini-UHF Male	166

RoHS compliant



Fig. 165



Fig. 166

BNC to UHF

Part Number	RoHS	Description	Fig. No.
3307505	✓	BNC Male - UHF Male	167
3317505	✓	BNC Male - UHF Female	168
3325505	✓	BNC Female - UHF Female	169
9311505	✓	BNC Female - UHF Male	170

RoHS compliant



Fig. 167



Fig. 168



Fig. 169



Fig. 170

BNC to F

Part Number	RoHS	Description	Fig. No.
3318505	✓	BNC Male - F Female	172
3328505	✓	BNC Female - F Female	173
8311505	✓	BNC Female - F Male	174

RoHS compliant



Fig. 172



Fig. 173



Fig. 174

BNC to SMA

Part Number	RoHS	Description	Fig. No.
3309505	✓	BNC Male - SMA Male	175
3329505	✓	BNC Female - SMA Female	176
9311505	✓	BNC Female - SMA Male	177

RoHS compliant



Fig. 175



Fig. 176




Fig. 177

UHF to SMA

Part Number	RoHS	Description	Fig. No.
7309505	✓	UHF Male - SMA Male	189
7319505	✓	UHF Female - SMA Male	190
9317505	✓	UHF Male - SMA Female	191

RoHS compliant



Fig. 189



Fig. 190



Fig. 191

FOR TECHNICAL SUPPORT: PHONE 973-347-4040 / FAX 973-347-2111

29

- Page 30 -

Between Series Adapters

TNC to Mini-UHF

Part Number	RoHS	Description	Fig. No.
5316505	✓	TNC Male - Mini-UHF Female	178

RoHS compliant



Fig. 178

TNC to UHF

Part Number	RoHS	Description	Fig. No.
5317505	✓	TNC Male - UHF Female	179
7315505	✓	TNC Female - UHF Female	NA

RoHS compliant



Fig. 179

TNC to SMA

Part Number	RoHS	Description	Fig. No.
5309505	✓	TNC Male - SMA Male	180
5319505	✓	TNC Male - SMA Female	181
5329505	✓	TNC Female - SMA Female	182
9315505	✓	TNC Female - SMA Male	183

RoHS compliant



Fig. 180



Fig. 181




Fig. 182



Fig. 183

Mini UHF to N

Part Number	RoHS	Description	Fig. No.
6311505	✓	Mini-UHF Male - N Female	184
1316505	✓	Mini-UHF Female - N Male	N/S

RoHS compliant



Fig. 184

Mini-UHF to UHF

Part Number	RoHS	Description	Fig. No.
6317505	✓	Mini-UHF Male - UHF Female	185
7316505	✓	Mini-UHF Female - UHF Male	186

RoHS compliant




Fig. 185




Fig. 186

SMA to Mini-UHF

Part Number	RoHS	Description	Fig. No.
9306505	✓	SMA Male - Mini-UHF Male	187
9316505	✓	SMA Male - Mini-UHF Female	188

RoHS compliant



Fig. 187




Fig. 188

FOR TECHNICAL SUPPORT: PHONE 973-347-4040 / FAX 973-347-2111

30

- Page 31 -

Between Series Adapters

UHF to F

Part Number	RoHS	Description	Fig. No.
7318505	✓	UHF Male - F Female	200

RoHS compliant



Fig. 200

RCA to BNC

Part Number	RoHS	Description	Fig. No.
R0842	✓	RCA Male - BNC Male	192
R0843	✓	RCA Female - BNC Male	193
R0844	✓	RCA Male - BNC Female	194

RoHS compliant




Fig. 192



Fig. 193




Fig. 194

RCA to F

Part Number	RoHS	Description	Fig. No.
R0847	✓	RCA Male - F Male	195
R0849	✓	RCA Female - F Female	196
R0851	✓	RCA Female - F Male	197

RoHS compliant



Fig. 195



Fig. 196



Fig. 197

RCA to UHF

Part Number	RoHS	Description	Fig. No.
R0811	☑	RCA Female - UHF Male	198
R0822	☑	RCA Male - UHF Female	199