






SECTION A-A
(Side View Inside Assembly)



SECTION B-B
(Inside of Bottom Cover)



Maximum P.C. Board Size



This diagram illustrates the exploded view of the HP-41C calculator case assembly. The components shown are:

- Top Cover:** The uppermost dark grey plastic piece.
- P.C. Board (Not Supplied):** A light grey printed circuit board with several circular holes, positioned between the top and bottom covers.
- Front Panel:** A dark grey plastic piece that fits into the front of the bottom cover.
- Bottom Cover:** The lower dark grey plastic piece of the case.
- Cover Screws:** Five screws shown at the bottom, used to secure the bottom cover to the top cover.

Purchased assembly includes top and bottom cover, front plastic panel and 4 cover screws.

