








GENERAL INSTRUCTIONS

INSTRUCTIONS GENERALES
ALLGEMEINE ANWEISUNGEN
INSTRUCCIONES GENERALES
ISTRUZIONI
ALLMANNA INSTRUKTIONER
ALGEMENE INSTRUCTIE
綜合概論



MHH ENGINEERING Co. Ltd.

Bramley, Guildford,
Surrey GU5 0AJ, England

☎ ** (0)1483 892772

 ** (0)1483 898555

WWW.Torqueleader.com

DIAL INDICATING TORQUE WRENCHES

CLES DYNAMOMETRIQUES A LECTURE DIRECTE

DREHMOMENTWERKZEUGE MIT ANZEIGESKALA

LLAVES DINAMOMETRICAS CON DIAL INDICADOR

VISARINDIKERANDE MOMENTNYCKLAR

MOMENTSLEUTEL MET WIJZERPLAAT

針 錶 式 扭 力 扳 手

