


## SERIES 90HB

### SPST, Low Profile




#### FEATURES

- Compatible with SMT Assembly, Including Infrared Reflow and Vapor-Phase
- Reliable Spring and Ball Contact




#### DIMENSIONS In inches (and millimeters)


##### Top View—Gull Wing




##### Recommended PC Pad Dimensions—Gull Wing




##### Recommended PC Pad Dimensions—J-Bend



##### Gull Wing



##### J-Bend



#### CIRCUITRY

As viewed from the top of the switch in the positions shown in the drawing.





# Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

## Grayhill:

[90HBJ03PT](#) [90HBJ04PRT](#) [90HBJ04PT](#) [90HBJ08PRT](#) [90HBJ08PT](#) [90HBW02PRT](#) [90HBW02PT](#) [90HBW03PRT](#)  
[90HBW03PT](#) [90HBW04PRT](#) [90HBW04PT](#) [90HBW04RT](#) [90HBW05PRT](#) [90HBW05PT](#) [90HBW06PRT](#) [90HBW06PT](#)  
[90HBW08PRT](#) [90HBW08PT](#) [90HBW08T](#) [90HBW10PRT](#) [90HBW10PT](#) [90HGBW06T](#) [90HGBW06PRT](#) [90HBJ04T](#)  
[90HGBW03RT](#) [90HGBW02RT](#) [90HBW07PRT](#) [90HBJ02RT](#) [90HBW03RT](#) [90HGBW08RT](#) [90HGBW08PRT](#)  
[90HBJ10PRT](#) [90HBW06RT](#) [90HGBW10PRT](#) [90HBJ03PRT](#) [90HBJ05PRT](#) [90HBW05T](#) [90HBW07PT](#) [90HBJ06PRT](#)  
[90HBW10T](#) [90HGBW10PT](#) [90HBW06T](#) [90HBJ02PT](#) [90HGBW08PT](#) [90HBW04T](#) [90HBJ06RT](#) [90HGBW02PRT](#)  
[90HBW02RT](#) [90HBJ08RT](#) [90HGBW04PT](#) [90HBJ06PT](#) [90HGBW05PT](#) [90HGBW03PRT](#) [90HGBW02PT](#)  
[90HBJ10RT](#) [90HGBW03PT](#) [90HBJ07PT](#) [90HGBW06RT](#) [90HBJ04RT](#) [90HBW10RT](#) [90HBJ02PRT](#) [90HGBW04PRT](#)  
[90HGBW05PRT](#) [90HBJ06T](#) [90HBJ10PT](#) [90HBW08RT](#) [90HGBW06PT](#) [90HBW07T](#) [90HBW02T](#) [90HBJ08T](#)  
[90HGBW04RT](#) [90HBJ05RT](#) [90HBW03T](#) [90HGBW05RT](#) [90HGBW10RT](#) [90HBJ03RT](#) [90HBJ05PT](#) [90HBW05RT](#)