

APPLICATOR PARTS LIST

TYPE

SIDEWISE

STRAIN RELIEF
WINGAMP INCORPORATED
HARRISBURG, PENNA.

				WING				HARRISBURG, PENNA.			
NO.	DESCRIPTION	REQ.	PART NO.	NO.	DESCRIPTION	REQ.	PART NO.	CRIMPING DATA			TERMINALS
1	■ WIRE CRIMPER			42	SHEAR DEPRESSOR	1	810955-5	TO APPLY TERMINAL			61987
2	■ INS. CRIMPER	1	453671-3	43	■ SPRING, SHEAR	1	386455				
3	■ ANVIL	1	453673-3	44	SPRING SEAT	1	386443	WIRE SIZE	CRIMP HEIGHT	TILL TIGHT	
4	ANVIL SPACER			45	SHEAR BEARING PL. FT.	1	386409-1				
5	■ SHEAR BLADE FLOATING	1	473243-2	46	REAR OILITE BEARING PL.	1	386408				
6	■ REAR SHEAR PLATE			47	LEFT OILITE BEARING PL.	1	386406				
7	SHEAR BLADE SPACER MT.	1	386442	48	RIGHT OILITE BEARING PL.	1	386407				
8	■ FRONT SHEAR PLATE	1	386414	49							
9	REAR ANVIL SPACER PLT.			50				CRIMP	SIZE	TYPE	FEED
10	FRONT ANVIL SPACER PLT.			51	STRIP HOLD Δ	1	692871-1				
11	TOOL SPACER	1	370691	52				INSUL.	360	ϕ	.908
12	CRIMP SPACER			53				STEEL	DIAMOND		
13	FRONT STRIP GUIDE	1	386444-3	54				INSULATION RANGE		WIRE RANGE	
14	REAR STRIP GUIDE	1	386445	55				.275-.290		---	
				56				EXPLODED VIEW			
15	RAM	1	473699	57				A-6009-3			
16	TOOL HOLDER			58				REMARKS:			
17	ADJ. CRIMP MOUNT			59				Δ MT. ON ITEM 14			
18	ADJ. BLOCK			60				Δ MT. ON TOP SCREW OF			
19	APPLICATOR MOUNT ASSY.			61				SHEAR BEARING PL. 45			
20	BASE PLATE	1	473228	62				TOP TOOL MT. 42, 11 & 2			
21	BASE BLOCK	1	473227	63							
22	STRIP GUIDE PLATE	1	473226	64	MECH FEED	1	692140-2				
23	ANVIL HOLDER			65	TENSION ADJ. PLATE	1	374999				
24	AUX. ANVIL HOLDER			MISCELLANEOUS							
25	STRIPPER	1	694924-1	66	2" DIA. REEL SUPPORT	1	565050-2				
26	STRIPPER MOUNT			67	LUBRICATOR ASSY	1	465184-2				
27	RETAINER PLATE			68	SYNTHETIC OIL	1	22014-1				
28	STRIPPER MOUNT BRACKET			69							
29	STRIPPER BUSHING			70							
30	STOCK DRAG ASSY.	1	473229-1	71							
31	STOCK DRAG HANDLE			72							
32	STOCK DRAG STUD	1	388648-7	REV. 0 REVISION RECORD 8-17-71				DATE	BY	ECN	
33	STOCK DRAG SPRING	1	1-23847-1	A PER ECN				1-24-72	BM	1-8680	
34	STOCK DRAG ADJ. SCREW			B REV GUARD				10-1-74	W	2818	
35	FEED FINGER HOLDER			B INACTIVE FRG				2-24-77	CC	B R1983	
36	FEED FINGER	1	388477								
37	FEED FINGER TIP	1	386447								
38	FEED FINGER SPACER GUIDE Δ	1	1-471716-3								
39	BASE CASTING	1	570238								
40	GUARD ASSY	1	461343-1								
41	LOWER GUARD	1	694454-1								

— INACTIVE —			
FOR REPLACEMENT ONLY			
■ DENOTES WEARING PARTS RECOMMEND PURCHASE REPLACEMENT			
THIS APPLICATOR IS TO BE USED ON AMP-O-LECTRIC 1-471273-3 MECH FEED MECH FEED			
SERIAL NO.		DATE SHIPPED	
CUSTOMER NAME AND ADDRESS		DESIGNED R.B. 8-17-71	
APPLICATOR NUMBER		CHK'D 1-14-11	
REV. 31		APP'D 2-24-71	
566053-2		SHEET 1 OF 1	

— INACTIVE —
FOR REPLACEMENT ONLY

☐ DENOTES WEARING PARTS
RECOMMEND PURCHASE REPLACEMENT

THIS APPLICATOR IS TO BE USED ON

AMP-O-ELECTRIC 1-471273-3

~~MECH FEED~~

DIST. 4

SERIAL NO.

DATE SHIPPED

DESIGNED
R.B. 8-17-71

CUSTOMER NAME AND ADDRESS

CHK'D
1-14-71APPLICATOR
NUMBER

REV.

B1 566053-2

SHEET

1 OF 1

FOR HARDWARE
SEE 687514-1

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[TE Connectivity:](#)

[566053-2](#)