





## Install Software

1. Insert the kit CD/DVD into the CD/DVD drive of your PC.
2. Install the kit contents.




## Configure DVK Board in Debug Mode

1. Set SW6 as shown; place a jumper on J29.
2. Select VBUS using J78; select 3.3 V using J13.
3. Ensure SW2, SW3, and SW7 are in the OFF position.



## Install Driver and Run CyConsole Utility


1. Connect the DVK board to your PC using the USB cable. Set J18 in the ON position.
2. Select the appropriate driver from <Install\_Directory>:\Cypress\West Bridge Astoria\<version>\USB Drivers depending on the operating system and architecture (32/64-bit). The device enumerates as "Cypress Astoria - DEBUG MODE PID=0x00A2".
3. Insert the SD card in one or both sockets.
4. Run the CyConsole utility from the <CD/DVD>\Demo folder.



## Run Demo Procedure for Dual SD

1. Click Options > EZ USB Interface in the Cypress CyConsole utility.
2. In the new window, click Download.
3. Select the firmware image from the <CD/DVD>\Demo folder or the installed path. Click Open.
4. After the firmware image downloads to Astoria, two removable drives appear. Try downloading data to and from the devices.

## Board Details



Note: West Bridge Astoria firmware no longer supports NAND flash memories. The NAND slots are unused.

For the latest information about this kit, visit  
<http://www.cypress.com/go/CYWBDVK002AB>

© 2008-2012 Cypress Semiconductor Corporation. All rights reserved. All trademarks or registered trademarks referenced herein are the properties of their respective owners.