


M58LT256GT M58LT256GB

256 Mbit (16Mb x16, Multiple Bank, Multi-Level, Burst) 1.8V Supply Flash Memory

Features summary

- Supply voltage
 - V_{DD} = 1.7V to 2.0V for Program, Erase and Read
 - V_{DDQ} = 2.7V to 3.6V for I/O buffers
 - V_{PP} = 9V for fast program
- Synchronous/Asynchronous Read
 - Synchronous Burst Read mode: 52MHz
 - Asynchronous Page Read mode: 25ns
 - Random Access: 110ns
- Synchronous Burst Read Suspend
- Programming time
 - 10µs typical Word program time using Buffer Enhanced Factory Program command
- memory organization
 - Multiple Bank Memory Array: 16 Mbit Banks
 - Parameter blocks (Top or Bottom location)
- Dual operations
 - Program/Erase in one Bank while read in others
 - No delay between read and write operations
- Block locking
 - All blocks locked at power-up
 - Any combination of blocks can be locked with zero latency
 - Absolute Write Protection with V_{PP} = V_{SS}
- Security
 - 64 bit unique device number
 - 2112 bit user programmable OTP Cells
- Common Flash Interface (CFI)



- 100,000 Program/Erase cycles per block
- Electronic Signature

Manufacturer code: 20hTop Device code: 8870hBottom Device code: 8871h

■ ECOPACK[®] package available

Contents

1	Sum	mary description	. 8
2	Sign	al descriptions	13
	2.1	Address Inputs (A0-A23)	13
	2.2	Data Input/Output (DQ0-DQ15)	13
	2.3	Chip Enable (E)	13
	2.4	Output Enable (G)	13
	2.5	Write Enable (W)	13
	2.6	Reset (RP)	13
	2.7	Latch Enable (L)	14
	2.8	Clock (K)	14
	2.9	Wait (WAIT)	14
	2.10	V _{DD} Supply Voltage	14
	2.11	V _{DDQ} Supply Voltage	14
	2.12	V _{PP} Program Supply Voltage	14
	2.13	V _{SS} Ground	15
	2.14	V _{SSQ} Ground	15
3	Bus	operations	16
	3.1	Bus Read	16
	3.2	Bus Write	16
	3.3	Address Latch	16
	3.4	Output Disable	16
	3.5	Standby	17
	3.6	Reset	17
4	Com	mand Interface	18
	4.1	Read Array command	19
	4.2	Read Status Register command	19
	4.3	Read Electronic Signature command	19
	4.4	Read CFI Query command	20
	4.5	Clear Status Register command	20
2/101		DocRev1	7 /

	4.6	Block Erase command
	4.7	Program command
	4.8	Buffer Program command
	4.9	Buffer Enhanced Factory Program command
		4.9.1 Setup phase
		4.9.2 Program and Verify phase
		4.9.3 Exit phase
	4.10	Program/Erase Suspend command
	4.11	Program/Erase Resume command
	4.12	Protection Register Program command
	4.13	Set Configuration Register command
	4.14	Block Lock command
	4.15	Block Unlock command
5	Statu	ıs Register
	5.1	Program/Erase Controller Status bit (SR7)
	5.2	Erase Suspend Status bit (SR6)
	5.3	Erase Status bit (SR5)
	5.4	Program Status bit (SR4)
	5.5	V _{PP} Status bit (SR3)
	5.6	Program Suspend Status bit (SR2)
	5.7	Block Protection Status bit (SR1)
	5.8	Bank Write/Multiple Word Program Status bit (SR0) 34
6	Conf	iguration Register
	6.1	Read Select bit (CR15)
	6.2	X-Latency bits (CR13-CR11)
	6.3	Wait Polarity bit (CR10)
	6.4	Data Output Configuration bit (CR9)
	6.5	Wait Configuration bit (CR8)
	6.6	Burst Type bit (CR7)
	6.7	Valid Clock Edge bit (CR6)
	6.8	Wrap Burst bit (CR3)
	6.9	Burst length bits (CR2-CR0)

7	Rea	nd modes	43
	7.1	Asynchronous Read mode	43
	7.2	Synchronous Burst Read mode	43
		7.2.1 Synchronous Burst Read Suspend	. 44
	7.3	Single Synchronous Read mode	45
8	Dua	al Operations and Multiple Bank architecture	46
9	Blo	ck locking	48
	9.1	Reading a Block's Lock status	48
	9.2	Locked state	48
	9.3	Unlocked state	48
	9.4	Locking operations during Erase Suspend	49
10	Pro	gram and Erase times and endurance cycles	50
11	Max	kimum rating	52
12	DC	and AC parameters	53
13	Pac	kage mechanical	68
14	Par	t numbering	69
Appendix	Α	Block address tables	70
	To c	calculate the block base address from the block number:	70
	To c	calculate the bank and the block number from the block base address:	70
Appendix	В	Common Flash Interface	75
Appendix	С	Flowcharts and pseudo codes	85
Appendix	D	Command Interface state tables	93
15	Rev	rision history1	100

List of tables

Table 1.	Signal Names	10
Table 2.	Bank Architecture	11
Table 3.	Bus Operations	
Table 4.	Command Codes	
Table 5.	Standard Commands	28
Table 6.	Factory Program Command	29
Table 7.	Electronic Signature Codes	29
Table 8.	Protection Register Locks	31
Table 9.	Status Register Bits	35
Table 10.	Configuration Register	39
Table 11.	Burst Type Definition	40
Table 12.	Wait at the Boundary	41
Table 13.	Dual Operations Allowed In Other Banks	46
Table 14.	Dual Operations Allowed In Same Bank	47
Table 15.	Dual Operation Limitations	47
Table 16.	Block Lock Status	49
Table 17.	Program/Erase Times and Endurance Cycles	50
Table 18.	Absolute Maximum Ratings	52
Table 19.	Operating and AC Measurement Conditions	53
Table 20.	Capacitance	54
Table 21.	DC characteristics - currents	54
Table 22.	DC Characteristics - Voltages	55
Table 23.	Asynchronous Read AC Characteristics	58
Table 24.	Synchronous Read AC Characteristics	62
Table 25.	Write AC Characteristics, Write Enable Controlled	64
Table 26.	Write AC Characteristics, Chip Enable Controlled	66
Table 27.	Reset and Power-up AC Characteristics	
Table 28.	TBGA64 10x13mm - 8x8 active ball array, 1mm pitch, Package Mechanical Data	
Table 29.	Ordering Information Scheme	
Table 30.	M58LR256GT - Parameter Bank block addresses	71
Table 31.	M58LR256GT - Main Bank base addresses	71
Table 32.	M58LR256GT - Block Addresses in Main Banks	72
Table 33.	M58LR256GB - Parameter Bank block addresses	72
Table 34.	M58LR256GB - Main Bank base addresses	73
Table 35.	M58LR256GB - block addresses in Main Banks	73
Table 36.	Query Structure Overview	75
Table 37.	CFI Query Identification String	
Table 38.	CFI Query System Interface Information	
Table 39.	Device Geometry Definition	
Table 40.	Primary Algorithm-Specific Extended Query Table	
Table 41.	Protection Register Information	
Table 42.	Burst Read Information	
Table 43.	Bank and Erase Block Region Information	80
Table 44.	Bank and Erase Block Region 1 Information	
Table 45.	Bank and Erase Block Region 2 Information	
Table 46.	Command Interface States - Modify Table, Next State	
Table 47.	Command Interface States - Modify Table, Next Output	
Table 48.	Command Interface States - Lock Table, Next State	



Table 49.	Command Interface States - Lock Table, Next Output	98
Table 50.	Document Revision History	100

577

DocRev1

List of figures

Figure 1.	Logic diagram	9
Figure 2.	TBGA Connections (Top view through package)	11
Figure 3.	Memory Map	12
Figure 4.	Protection Register Memory Map	
Figure 5.	X-Latency and Data Output configuration example	41
Figure 6.	Wait configuration example	42
Figure 7.	AC Measurement I/O waveform	53
Figure 8.	AC measurement load circuit	54
Figure 9.	Asynchronous Random Access Read AC waveforms	56
Figure 10.	Asynchronous Page Read AC waveforms	57
Figure 11.	Synchronous Burst Read AC waveforms	59
Figure 12.	Single Synchronous Read AC waveforms	60
Figure 13.	Synchronous Burst Read Suspend AC waveforms	61
Figure 14.	Clock input AC waveform	
Figure 15.	Write AC Waveforms, Write Enable Controlled	63
Figure 16.	Write AC Waveforms, Chip Enable Controlled	65
Figure 17.	Reset and Power-up AC waveforms	66
Figure 18.	TBGA64 10x13mm - 8x8 ball array, 1mm pitch, bottom view package outline	68
Figure 19.	Program flowchart and pseudo code	
Figure 20.	Buffer Program flowchart and pseudo code	86
Figure 21.	Program Suspend & Resume flowchart and pseudo code	
Figure 22.	Block Erase flowchart and pseudo code	88
Figure 23.	Erase Suspend & Resume flowchart and pseudo code	
Figure 24.	Locking operations flowchart and pseudo code	
Figure 25.	Protection Register Program flowchart and pseudo code	
Figure 26.	Buffer Enhanced Factory Program Flowchart and Pseudo Code	92

1 Summary description

The M58LT256GT/B is a 256 Mbit (16 Mbit x16) non-volatile Flash memory that may be erased electrically at block level and programmed in-system on a Word-by-Word basis using a 1.7V to 2.0V V_{DD} supply for the circuitry and a 2.7V to 3.6V V_{DDQ} supply for the Input/Output pins. An optional 9V V_{PP} power supply is provided to speed up factory programming.

The device features an asymmetrical block architecture and is based on a multi-level cell technology. M58LT256GT/B has an array of 259 blocks, and is divided into 16 Mbit banks. There are 15 banks each containing 16 main blocks of 64 KWords, and one parameter bank containing 4 parameter blocks of 16 KWords and 15 main blocks of 64 KWords. The Multiple Bank Architecture allows Dual Operations, while programming or erasing in one bank, read operations are possible in other banks. Only one bank at a time is allowed to be in program or erase mode. It is possible to perform burst reads that cross bank boundaries. The bank architecture is summarized in *Table 2*, and the memory maps are shown in *Figure 3*. The Parameter Blocks are located at the top of the memory address space for the M58LT256GT, and at the bottom for the M58LT256GB.

Each block can be erased separately. Erase can be suspended, in order to perform a program or read operation in any other block, and then resumed. Program can be suspended to read data at any memory location except for the one being programmed, and then resumed. Each block can be programmed and erased over 100,000 cycles using the supply voltage V_{DD} . There is a Buffer Enhanced Factory programming command available to speed up programming.

Program and erase commands are written to the Command Interface of the memory. An internal Program/Erase Controller takes care of the timings necessary for program and erase operations. The end of a program or erase operation can be detected and any error conditions identified in the Status Register. The command set required to control the memory is consistent with JEDEC standards.

The device supports Synchronous Burst Read and Asynchronous Read from all blocks of the memory array; at power-up the device is configured for Asynchronous Read. In Synchronous Burst Read mode, data is output on each clock cycle at frequencies of up to 52MHz. The Synchronous Burst Read operation can be suspended and resumed.

The device features an Automatic Standby mode. When the bus is inactive during Asynchronous Read operations, the device automatically switches to the Automatic Standby mode. In this condition the power consumption is reduced to the standby value and the outputs are still driven.

The M58LT256GT/B features an instant, individual block locking scheme that allows any block to be locked or unlocked with no latency, enabling instant code and data protection. All blocks have three levels of protection. They can be locked individually preventing any accidental programming or erasure. There is an additional hardware protection against program and erase. When $V_{PP} \leq V_{PPLK}$ all blocks are protected against program or erase. All blocks are locked at power- up.

The device includes 17 Protection Registers and 2 Protection Register locks, one for the first Protection Register and the other for the 16 One-Time-Programmable (OTP) Protection Registers of 128 bits each. The first Protection Register is divided into two segments: a 64 bit segment containing a unique device number written by ST, and a 64 bit segment One-

Time-Programmable (OTP) by the user. The user programmable segment can be permanently protected. *Figure 4*, shows the Protection Register Memory Map.

The memory is offered in a TBGA64 10 x 13mm, 1mm pitch package with all the bits erased (set to '1').

In order to meet environmental requirements, ST offers the M58LT256GT in ECOPACK[®] packages. ECOPACK packages are Lead-free. The category of second Level Interconnect is marked on the package and on the inner box label, in compliance with JEDEC Standard JESD97. The maximum ratings related to soldering conditions are also marked on the inner box label.

ECOPACK is an ST trademark. ECOPACK specifications are available at: www.st.com.






Table 1. Signal Names

A0-A23	Address Inputs
DQ0-DQ15	Data Input/Outputs, Command Inputs
Ē	Chip Enable
G	Output Enable
W	Write Enable
RP	Reset
К	Clock
Ī	Latch Enable
WAIT	Wait
V_{DD}	Supply Voltage
V _{DDQ}	Supply Voltage for Input/Output Buffers
V _{PP}	Optional Supply Voltage for Fast Program & Erase
V _{SS}	Ground
V _{SSQ}	Ground Input/Output Supply
NC	Not Connected Internally

Figure 2. TBGA Connections (Top view through package)





Table 2. Bank Architecture

Number	Bank Size	Parameter Blocks	Main Blocks
Parameter Bank	16 Mbits	4 blocks of 16 KWords	15 blocks of 64 KWords
Bank 1	16 Mbits	-	16 blocks of 64 KWords
Bank 2	16 Mbits	-	16 blocks of 64 KWords
Bank 3	16 Mbits	-	16 blocks of 64 KWords
Bank 14	16 Mbits	-	16 blocks of 64 KWords
Bank 15	16 Mbits	-	16 blocks of 64 KWords

Figure 3. Memory Map



57

2 Signal descriptions

See Figure 1: Logic diagram and Table 1: Signal Names, for a brief overview of the signals connected to this device.

2.1 Address Inputs (A0-A23)

The Address Inputs select the cells in the memory array to access during Bus Read operations. During Bus Write operations they control the commands sent to the Command Interface of the Program/Erase Controller.

2.2 Data Input/Output (DQ0-DQ15)

The Data I/O output the data stored at the selected address during a Bus Read operation or input a command or the data to be programmed during a Bus Write operation.

2.3 Chip Enable (\overline{E})

The Chip Enable input activates the memory control logic, input buffers, decoders and sense amplifiers. When Chip Enable is at V_{IL} and Reset is at V_{IH} the device is in active mode. When Chip Enable is at V_{IH} the memory is deselected, the outputs are high impedance and the power consumption is reduced to the stand-by level.

2.4 Output Enable (G)

The Output Enable input controls data outputs during the Bus Read operation of the memory.

2.5 Write Enable (\overline{W})

The Write Enable input controls the Bus Write operation of the memory's Command Interface. The data and address inputs are latched on the rising edge of Chip Enable or Write Enable whichever occurs first.

2.6 Reset (RP)

The Reset input provides a hardware reset of the memory. When Reset is at V_{IL} , the memory is in reset mode: the outputs are high impedance and the current consumption is reduced to the Reset Supply Current I_{DD2} . Refer to *Table 21: DC characteristics - currents*, for the value of I_{DD2} . After Reset all blocks are in the Locked state and the Configuration Register is reset. When Reset is at V_{IH} , the device is in normal operation. Exiting reset mode the device enters asynchronous read mode, but a negative transition of Chip Enable or Latch Enable is required to ensure valid data outputs.

The Reset pin can be interfaced with 3V logic without any additional circuitry. It can be tied to V_{RPH} (refer to *Table 22: DC Characteristics - Voltages*).

2.7 Latch Enable (\overline{L})

Latch Enable latches the address bits on its rising edge. The address latch is transparent when Latch Enable is at V_{IL} and it is inhibited when Latch Enable is at V_{IH} . Latch Enable can be kept Low (also at board level) when the Latch Enable function is not required or supported.

2.8 Clock (K)

The clock input synchronizes the memory to the microcontroller during synchronous read operations; the address is latched on a Clock edge (rising or falling, according to the configuration settings) when Latch Enable is at $V_{\rm IL}$. Clock is ignored during asynchronous read and in write operations.

2.9 Wait (WAIT)

Wait is an output signal used during synchronous read to indicate whether the data on the output bus are valid. This output is high impedance when Chip Enable is at V_{IH} , Output Enable is at V_{IH} , or Reset is at V_{IL} . It can be configured to be active during the wait cycle or one data cycle in advance.

2.10 V_{DD} Supply Voltage

V_{DD} provides the power supply to the internal core of the memory device. It is the main power supply for all operations (Read, Program and Erase).

2.11 V_{DDQ} Supply Voltage

 V_{DDQ} provides the power supply to the I/O pins and enables all Outputs to be powered independently of V_{DD} . V_{DDQ} can be tied to V_{DD} or can use a separate supply.

2.12 V_{PP} Program Supply Voltage

 V_{PP} is both a control input and a power supply pin. The two functions are selected by the voltage range applied to the pin.

If V_{PP} is kept in a low voltage range (0V to V_{DDQ}) V_{PP} is seen as a control input. In this case a voltage lower than V_{PPLK} gives an absolute protection against program or erase, while $V_{PP} > V_{PP1}$ enables these functions (see *Table 21* and *Table 22*, DC Characteristics for the relevant values). V_{PP} is only sampled at the beginning of a program or erase; a change in its value after the operation has started does not have any effect and program or erase operations continue.

If V_{PP} is in the range of V_{PPH} it acts as a power supply pin. In this condition V_{PP} must be stable until the Program/Erase algorithm is completed.

2.13 V_{SS} Ground

V_{SS} ground is the reference for the core supply. It must be connected to the system ground.

2.14 V_{SSQ} Ground

 $\rm V_{SSQ}$ ground is the reference for the input/output circuitry driven by $\rm V_{DDQ}.~V_{SSQ}$ must be connected to $\rm V_{SS}$

Note:

Each device in a system should have V_{DD} , V_{DDQ} and V_{PP} decoupled with a 0.1 μ F ceramic capacitor close to the pin (high frequency, inherently low inductance capacitors should be as close as possible to the package). See Figure 8: AC measurement load circuit. The PCB track widths should be sufficient to carry the required V_{PP} program and erase currents.

3 Bus operations

There are six standard bus operations that control the device. These are Bus Read, Bus Write, Address Latch, Output Disable, Standby and Reset. See *Table 3: Bus Operations*, for a summary.

Typically glitches of less than 5ns on Chip Enable or Write Enable are ignored by the memory and do not affect Bus Write operations.

3.1 Bus Read

Bus Read operations are used to output the contents of the Memory Array, the Electronic Signature, the Status Register and the Common Flash Interface. Both Chip Enable and Output Enable must be at $V_{\rm IL}$ in order to perform a read operation. The Chip Enable input should be used to enable the device. Output Enable should be used to gate data onto the output. The data read depends on the previous command written to the memory (see Command Interface section). See *Figure 9*, *Figure 10*, *Figure 11* and *Figure 12*. for a description of Read AC waveforms, and *Table 23* and *Table 24* for details on Read AC characteristics, for details of when the output becomes valid.

3.2 Bus Write

Bus Write operations write Commands to the memory or latch Input Data to be programmed. A bus write operation is initiated when Chip Enable and Write Enable are at V_{IL} with Output Enable at V_{IH} . Commands, Input Data and Addresses are latched on the rising edge of Write Enable or Chip Enable, whichever occurs first. The addresses can also be latched prior to the write operation by toggling Latch Enable. In this case the Latch Enable should be tied to V_{IH} during the bus write operation.

See *Figure 15* and *Figure 16*, Write AC Waveforms, and *Table 25* and *Table 26*, Write AC Characteristics, for details of the timing requirements.

3.3 Address Latch

Address latch operations input valid addresses. Both Chip enable and Latch Enable must be at $V_{\rm IL}$ during address latch operations. The addresses are latched on the rising edge of Latch Enable.

3.4 Output Disable

The outputs are high impedance when the Output Enable is at V_{IH}.

3.5 Standby

Standby disables most of the internal circuitry allowing a substantial reduction of the current consumption. The memory is in standby when Chip Enable and Reset are at V_{IH} . The power consumption is reduced to the standby level I_{DD3} and the outputs are set to high impedance, independently from the Output Enable or Write Enable inputs. If Chip Enable switches to V_{IH} during a program or erase operation, the device enters Standby mode when finished.

3.6 Reset

During Reset mode the memory is deselected and the outputs are high impedance. The memory is in Reset mode when Reset is at V_{IL} . The power consumption is reduced to the Reset level, independently from the Chip Enable, Output Enable or Write Enable inputs. If Reset is pulled to V_{SS} during a Program or Erase, this operation is aborted and the memory content is no longer valid.

Table 3. Bus Operations⁽¹⁾

Operation	Ē	G	W	Ī	RP	WAIT ⁽²⁾	DQ15-DQ0
Bus Read	V_{IL}	V_{IL}	V _{IH}	V _{IL} (3)	V_{IH}		Data Output
Bus Write	V_{IL}	V_{IH}	V_{IL}	V _{IL} ⁽³⁾	V_{IH}		Data Input
Address Latch	V _{IL}	Х	V _{IH}	V _{IL}	V _{IH}		Data Output or Hi-Z ⁽⁴⁾
Output Disable	V_{IL}	V_{IH}	V _{IH}	Х	V_{IH}	Hi-Z	Hi-Z
Standby	V_{IH}	Х	Х	Х	V_{IH}	Hi-Z	Hi-Z
Reset	Х	Х	Х	Х	V _{IL}	Hi-Z	Hi-Z

^{1.} X = Don't care.

^{2.} WAIT signal polarity is configured using the Set Configuration Register command.

^{3.} \overline{L} can be tied to V_{IH} if the valid address has been previously latched.

^{4.} Depends on \overline{G} .

4 Command Interface

All Bus Write operations to the memory are interpreted by the Command Interface. Commands consist of one or more sequential Bus Write operations. An internal Program/Erase Controller handles all timings and verifies the correct execution of the program and erase commands. The Program/Erase Controller provides a Status Register whose output may be read at any time to monitor the progress or the result of the operation.

The Command Interface is reset to read mode when power is first applied, when exiting from Reset or whenever V_{DD} is lower than V_{LKO} . Command sequences must be followed exactly. Any invalid combination of commands will be ignored.

Refer to *Table 4: Command Codes*, *Table 5: Standard Commands*, *Table 6: Factory Program Command*, and *Appendix D: Command Interface state tables*, for a summary of the Command Interface.

Table 4. Command Codes

Hex Code	Command
01h	Block Lock Confirm
03h	Set Configuration Register Confirm
10h	Alternative Program Setup
20h	Block Erase Setup
40h	Program Setup
50h	Clear Status Register
60h	Block Lock Setup, Block Unlock Setup, and Set Configuration Register Setup
70h	Read Status Register
80h	Buffer Enhanced Factory Program
90h	Read Electronic Signature
98h	Read CFI Query
B0h	Program/Erase Suspend
C0h	Protection Register Program
D0h	Program/Erase Resume, Block Erase Confirm, Block Unlock Confirm or Buffer Program Confirm
E8h	Buffer Program
FFh	Read Array

4.1 Read Array command

The Read Array command returns the addressed bank to Read Array mode.

One Bus Write cycle is required to issue the Read Array command. Once a bank is in Read Array mode, subsequent read operations will output the data from the memory array.

A Read Array command can be issued to any banks while programming or erasing in another bank.

If the Read Array command is issued to a bank currently executing a program or erase operation, the bank will return to Read Array mode but the program or erase operation will continue, however the data output from the bank is not guaranteed until the program or erase operation has finished. The read modes of other banks are not affected.

4.2 Read Status Register command

The device contains a Status Register that is used to monitor program or erase operations.

The Read Status Register command is used to read the contents of the Status Register for the addressed bank.

One Bus Write cycle is required to issue the Read Status Register command. Once a bank is in Read Status Register mode, subsequent read operations will output the contents of the Status Register.

The Status Register data is latched on the falling edge of the Chip Enable or Output Enable signals. Either Chip Enable or Output Enable must be toggled to update the Status Register data

The Read Status Register command can be issued at any time, even during program or erase operations. The Read Status Register command will only change the read mode of the addressed bank. The read modes of other banks are not affected. Only Asynchronous Read and Single Synchronous Read operations should be used to read the Status Register. A Read Array command is required to return the bank to Read Array mode.

See *Table 9* for the description of the Status Register Bits.

4.3 Read Electronic Signature command

The Read Electronic Signature command is used to read the Manufacturer and Device Codes, the Lock Status of the addressed bank, the Protection Register, and the Configuration Register.

One Bus Write cycle is required to issue the Read Electronic Signature command. Once a bank is in Read Electronic Signature mode, subsequent read operations in the same bank will output the Manufacturer Code, the Device Code, the Lock Status of the addressed bank, the Protection Register, or the Configuration Register (see *Table 7*).

The Read Electronic Signature command can be issued at any time, even during program or erase operations, except during Protection Register Program operations. Dual operations between the Parameter bank and the Electronic Signature locations are not allowed (see *Table 15: Dual Operation Limitations* for details).

If a Read Electronic Signature command is issued to a bank that is executing a program or erase operation the bank will go into Read Electronic Signature mode. Subsequent Bus

Read cycles will output the Electronic Signature data and the Program/Erase controller will continue to program or erase in the background.

The Read Electronic Signature command will only change the read mode of the addressed bank. The read modes of other banks are not affected. Only Asynchronous Read and Single Synchronous Read operations should be used to read the Electronic Signature. A Read Array command is required to return the bank to Read Array mode.

4.4 Read CFI Query command

The Read CFI Query command is used to read data from the Common Flash Interface (CFI).

One Bus Write cycle is required to issue the Read CFI Query command. Once a bank is in Read CFI Query mode, subsequent Bus Read operations in the same bank will output the contents of the Common Flash Interface.

The Read CFI Query command can be issued at any time, even during program or erase operations.

If a Read CFI Query command is issued to a bank that is executing a program or erase operation the bank will go into Read CFI Query mode. Subsequent Bus Read cycles will output the CFI data and the Program/Erase controller will continue to program or erase in the background.

The Read CFI Query command will only change the read mode of the addressed bank. The read modes of other banks are not affected. Only Asynchronous Read and Single Synchronous Read operations should be used to read from the CFI. A Read Array command is required to return the bank to Read Array mode.

Dual operations between the Parameter Bank and the CFI memory space are not allowed (see *Table 15: Dual Operation Limitations* for details).

See Appendix B: Common Flash Interface, Table 36, Table 37, Table 38, Table 39, Table 40, Table 42, Table 43, Table 44 and Table 45 for details on the information contained in the Common Flash Interface memory area.

4.5 Clear Status Register command

The Clear Status Register command can be used to reset (set to '0') all error bits (SR1, 3, 4 and 5) in the Status Register.

One Bus Write cycle is required to issue the Clear Status Register command. The Clear Status Register command does not affect the read mode of the bank.

The error bits in the Status Register do not automatically return to '0' when a new command is issued. The error bits in the Status Register should be cleared before attempting a new program or erase command.

4.6 Block Erase command

The Block Erase command is used to erase a block. It sets all the bits within the selected block to '1'. All previous data in the block is lost. If the block is protected then the erase operation will abort, the data in the block will not be changed and the Status Register will output the error.

Two Bus Write cycles are required to issue the command.

- 1. The first bus cycle sets up the Block Erase command.
- 2. The second latches the block address and starts the Program/Erase Controller.

If the second bus cycle is not the Block Erase Confirm code, Status Register bits SR4 and SR5 are set and the command is aborted.

Once the command is issued the bank enters Read Status Register mode and any read operation within the addressed bank will output the contents of the Status Register. A Read Array command is required to return the bank to Read Array mode.

During Block Erase operations the bank containing the block being erased will only accept the Read Array, Read Status Register, Read Electronic Signature, Read CFI Query and the Program/Erase Suspend command, all other commands will be ignored.

The Block Erase operation aborts if Reset, \overline{RP} , goes to V_{IL} . As data integrity cannot be guaranteed when the Block Erase operation is aborted, the block must be erased again.

Refer to Dual Operations section for detailed information about simultaneous operations allowed in banks not being erased. Typical Erase times are given in *Table 17:*Program/Erase Times and Endurance Cycles. See Appendix C, Figure 22: Block Erase flowchart and pseudo code, for a suggested flowchart for using the Block Erase command.

4.7 Program command

The program command is used to program a single Word to the memory array. Two Bus Write cycles are required to issue the Program Command.

- 1. The first bus cycle sets up the Program command.
- 2. The second latches the address and data to be programmed and starts the Program/Erase Controller.

Once the programming has started, read operations in the bank being programmed output the Status Register content. During a Program operation, the bank containing the Word being programmed will only accept the Read Array, Read Status Register, Read Electronic Signature, Read CFI Query and the Program/Erase Suspend command, all other commands will be ignored. A Read Array command is required to return the bank to Read Array mode.

Refer to Dual Operations section for detailed information about simultaneous operations allowed in banks not being programmed.

Typical Program times are given in Table 17: Program/Erase Times and Endurance Cycles.

The Program operation aborts if Reset, \overline{RP} , goes to V_{IL} . As data integrity cannot be guaranteed when the Program operation is aborted, the Word must be reprogrammed.

See Appendix C, Figure 19: Program flowchart and pseudo code, for the flowchart for using the Program command.

4.8 Buffer Program command

The Buffer Program Command makes use of the device's 32-Word Write Buffer to speed up programming. Up to 32 Words can be loaded into the Write Buffer. The Buffer Program command dramatically reduces in-system programming time compared to the standard non-buffered Program command.

Four successive steps are required to issue the Buffer Program command.

- 1. The first Bus Write cycle sets up the Buffer Program command. The setup code can be addressed to any location within the targeted block.
 - After the first Bus Write cycle, read operations in the bank will output the contents of the Status Register. Status Register bit SR7 should be read to check that the buffer is available (SR7 = 1). If the buffer is not available (SR7 = 0), re-issue the Buffer Program command to update the Status Register contents.
- The second Bus Write cycle sets up the number of Words to be programmed. Value n
 is written to the same block address, where n+1 is the number of Words to be
 programmed.
- 3. Use n+1 Bus Write cycles to load the address and data for each Word into the Write Buffer. Addresses must lie within the range from the start address to the start address + n. Optimum performance is obtained when the start address corresponds to a 32 Word boundary. If the start address is not aligned to a 32 word boundary, the total programming time is doubled.
- 4. The final Bus Write cycle confirms the Buffer Program command and starts the program operation.

All the addresses used in the Buffer Program operation must lie within the same block.

Invalid address combinations or failing to follow the correct sequence of Bus Write cycles will set an error in the Status Register and abort the operation without affecting the data in the memory array.

If the Status Register bits SR4 and SR5 are set to '1', the Buffer Program Command is not accepted. Clear the Status Register before re-issuing the command.

If the block being programmed is protected an error will be set in the Status Register and the operation will abort without affecting the data in the memory array.

During Buffer Program operations the bank being programmed will only accept the Read Array, Read Status Register, Read Electronic Signature, Read CFI Query and the Program/Erase Suspend command, all other commands will be ignored.

Refer to Dual Operations section for detailed information about simultaneous operations allowed in banks not being programmed.

See *Appendix C*, *Figure 20: Buffer Program flowchart and pseudo code*, for a suggested flowchart on using the Buffer Program command.

4.9 Buffer Enhanced Factory Program command

The Buffer Enhanced Factory Program command has been specially developed to speed up programming in manufacturing environments where the programming time is critical.

It is used to program one or more Write Buffer(s) of 32 Words to a block. Once the device enters Buffer Enhanced Factory Program mode, the Write Buffer can be reloaded any number of times as long as the address remains within the same block. Only one block can be programmed at a time.

The use of the Buffer Enhanced Factory Program command requires certain operating conditions:

- V_{PP} must be set to V_{PPH}
- V_{DD} must be within operating range
- Ambient temperature T_A must be 30°C ± 10°C
- The targeted block must be unlocked
- The start address must be aligned with the start of a 32 Word buffer boundary
- The address must remain the Start Address throughout programming

Dual operations are not supported during the Buffer Enhanced Factory Program operation and the command cannot be suspended.

The Buffer Enhanced Factory Program Command consists of three phases: the Setup Phase, the Program and Verify Phase, and the Exit Phase, Please refer to *Table 6: Factory Program Command* for detail information.

4.9.1 Setup phase

The Buffer Enhanced Factory Program command requires two Bus Write cycles to initiate the command.

- 1. The first Bus Write cycle sets up the Buffer Enhanced Factory Program command.
- 2. The second Bus Write cycle confirms the command.

After the confirm command is issued, read operations output the contents of the Status Register. The read Status Register command must not be issued as it will be interpreted as data to program.

The Status Register P/E.C. Bit SR7 should be read to check that the P/E.C. is ready to proceed to the next phase.

If an error is detected, SR4 goes high (set to '1') and the Buffer Enhanced Factory Program operation is terminated. See Status Register section for details on the error.

4.9.2 Program and Verify phase

The Program and Verify Phase requires 32 cycles to program the 32 Words to the Write Buffer. The data is stored sequentially, starting at the first address of the Write Buffer, until the Write Buffer is full (32 Words). To program less than 32 Words, the remaining Words should be programmed with FFFFh.

Three successive steps are required to issue and execute the Program and Verify Phase of the command.

- Use one Bus Write operation to latch the Start Address and the first Word to be programmed. The Status Register Bank Write Status bit SR0 should be read to check that the P/E.C. is ready for the next Word.
- 2. Each subsequent Word to be programmed is latched with a new Bus Write operation. The address must remain the Start Address as the P/E.C. increments the address location. If any address that is not in the same block as the Start Address is given, the Program and Verify Phase terminates. Status Register bit SR0 should be read between each Bus Write cycle to check that the P/E.C. is ready for the next Word.
 - Once the Write Buffer is full, the data is programmed sequentially to the memory array. After the program operation the device automatically verifies the data and reprograms if necessary.
 - The Program and Verify phase can be repeated, without re-issuing the command, to program additional 32 Word locations as long as the address remains in the same block.
- 3. Finally, after all Words, or the entire block have been programmed, write one Bus Write operation to any address outside the block containing the Start Address, to terminate Program and Verify Phase.

Status Register bit SR0 must be checked to determine whether the program operation is finished. The Status Register may be checked for errors at any time but it must be checked after the entire block has been programmed.

4.9.3 Exit phase

Status Register P/E.C. bit SR7 set to '1' indicates that the device has exited the Buffer Enhanced Factory Program operation and returned to Read Status Register mode. A full Status Register check should be done to ensure that the block has been successfully programmed. See the section on the Status Register for more details.

For optimum performance the Buffer Enhanced Factory Program command should be limited to a maximum of 100 program/erase cycles per block. If this limit is exceeded the internal algorithm will continue to work properly but some degradation in performance is possible. Typical program times are given in *Table 17*

See Appendix C, Figure 26: Buffer Enhanced Factory Program Flowchart and Pseudo Code, for a suggested flowchart on using the Buffer Enhanced Factory Program command.

4.10 Program/Erase Suspend command

The Program/Erase Suspend command is used to pause a Program or Block Erase operation. The command can be addressed to any bank.

The Program/Erase Resume command is required to restart the suspended operation.

One bus write cycle is required to issue the Program/Erase Suspend command. Once the Program/Erase Controller has paused bits SR7, SR6 and/ or SR2 of the Status Register will be set to '1'.

The following commands are accepted during Program/Erase Suspend:

- Program/Erase Resume
- Read Array (data from erase-suspended block or program-suspended Word is not valid)
- Read Status Register
- Read Electronic Signature
- Read CFI Query.

Additionally, if the suspended operation was a Block Erase then the following commands are also accepted:

- Clear Status Register
- Program (except in erase-suspended block)
- Buffer Program (except in erase suspended blocks)
- Block Lock
- Block Unlock.

During an erase suspend the block being erased can be protected by issuing the Block Lock command. When the Program/Erase Resume command is issued the operation will complete.

It is possible to accumulate multiple suspend operations. For example: suspend an erase operation, start a program operation, suspend the program operation, then read the array.

If a Program command is issued during a Block Erase Suspend, the erase operation cannot be resumed until the program operation has completed.

The Program/Erase Suspend command does not change the read mode of the banks. If the suspended bank was in Read Status Register, Read Electronic signature or Read CFI Query mode the bank remains in that mode and outputs the corresponding data.

Refer to Dual Operations section for detailed information about simultaneous operations allowed during Program/Erase Suspend.

During a Program/Erase Suspend, the device can be placed in standby mode by taking Chip Enable to V_{IH} . Program/erase is aborted if Reset, \overline{RP} , goes to V_{II} .

See Appendix C, Figure 21: Program Suspend & Resume flowchart and pseudo code, and Figure 23: Erase Suspend & Resume flowchart and pseudo code, for flowcharts for using the Program/Erase Suspend command.

4.11 Program/Erase Resume command

The Program/Erase Resume command is used to restart the program or erase operation suspended by the Program/Erase Suspend command. One Bus Write cycle is required to issue the command. The command can be issued to any address.

The Program/Erase Resume command does not change the read mode of the banks. If the suspended bank was in Read Status Register, Read Electronic signature or Read CFI Query mode the bank remains in that mode and outputs the corresponding data.

If a Program command is issued during a Block Erase Suspend, then the erase cannot be resumed until the program operation has completed.

See Appendix C, Figure 21: Program Suspend & Resume flowchart and pseudo code, and Figure 23: Erase Suspend & Resume flowchart and pseudo code, for flowcharts for using the Program/Erase Resume command.

4.12 Protection Register Program command

The Protection Register Program command is used to program the user One-Time-Programmable (OTP) segments of the Protection Register and the two Protection Register Locks.

The device features 16 OTP segments of 128 bits and one OTP segment of 64 bits, as shown in *Figure 4: Protection Register Memory Map*.

The segments are programmed one Word at a time. When shipped all bits in the segment are set to '1'. The user can only program the bits to '0'.

Two Bus Write cycles are required to issue the Protection Register Program command.

- 1. The first bus cycle sets up the Protection Register Program command.
- 2. The second latches the address and data to be programmed to the Protection Register and starts the Program/Erase Controller.

Read operations to the bank being programmed output the Status Register content after the program operation has started.

Attempting to program a previously protected Protection Register will result in a Status Register error.

The Protection Register Program cannot be suspended. Dual operations between the Parameter Bank and the Protection Register memory space are not allowed (see *Table 15: Dual Operation Limitations* for details).

The two Protection Register Locks are used to protect the OTP segments from further modification. The protection of the OTP segments is not reversible. Refer to *Figure 4: Protection Register Memory Map*, and *Figure 4: Protection Register Memory Map*, for details on the Lock bits.

See Appendix C, Figure 25: Protection Register Program flowchart and pseudo code, for a flowchart for using the Protection Register Program command.

4.13 Set Configuration Register command

The Set Configuration Register command is used to write a new value to the Configuration Register.

Two Bus Write cycles are required to issue the Set Configuration Register command.

- 1. The first cycle sets up the Set Configuration Register command and the address corresponding to the Configuration Register content.
- 2. The second cycle writes the Configuration Register data and the confirm command.

The Configuration Register data must be written as an address during the bus write cycles, that is A0 = CR0, A1 = CR1, ..., A15 = CR15. Addresses A16- A23 are ignored.

Read operations output the array content after the Set Configuration Register command is issued.

The Read Electronic Signature command is required to read the updated contents of the Configuration Register.

4.14 Block Lock command

The Block Lock command is used to lock a block and prevent program or erase operations from changing the data in it. All blocks are locked after power-up or reset.

Two Bus Write cycles are required to issue the Block Lock command.

- The first bus cycle sets up the Block Lock command.
- 2. The second Bus Write cycle latches the block address and locks the block.

The lock status can be monitored for each block using the Read Electronic Signature command. *Table 16* shows the Lock Status after issuing a Block Lock command.

Once set, the Block Lock bits remain set even after a hardware reset or power-down/power-up. They are cleared by a Block Unlock command.

Refer to the section, Block Locking, for a detailed explanation. See *Appendix C*, *Figure 24: Locking operations flowchart and pseudo code*, for a flowchart for using the Lock command.

4.15 Block Unlock command

The Block Unlock command is used to unlock a block, allowing the block to be programmed or erased.

Two Bus Write cycles are required to issue the Block Unlock command.

- 1. The first bus cycle sets up the Block Unlock command.
- The second Bus Write cycle latches the block address and unlocks the block.

The lock status can be monitored for each block using the Read Electronic Signature command. *Table 16* shows the protection status after issuing a Block Unlock command.

Refer to Section 9: Block locking, for a detailed explanation and Appendix C, Figure 24: Locking operations flowchart and pseudo code, for a flowchart for using the Block Unlock command.

Table 5. Standard Commands

		Bus Operations ⁽¹⁾									
Commands	Cycles		1st Cycle		2nd Cycle						
	S	Op.	Add	Data	Op.	Add	Data				
Read Array	1+	Write	BKA	FFh	Read	WA	RD				
Read Status Register	1+	Write	BKA	70h	Read	BKA ⁽²⁾	SRD				
Read Electronic Signature	1+	Write	BKA	90h	Read	BKA ⁽²⁾	ESD				
Read CFI Query	1+	Write	BKA	98h	Read	BKA ⁽²⁾	QD				
Clear Status Register	1	Write	BKA	50h							
Block Erase	2	Write	BKA or BA ⁽³⁾	20h	Write	ВА	D0h				
Program	2	Write	BKA or WA ⁽³⁾	40h or 10h	Write	WA	PD				
		Write	BA	E8h	Write	BA	n				
Buffer Program	n+4	Write	PA ₁	PD ₁	Write	PA ₂	PD ₂				
		Write	PA _{n+1} ⁽⁴⁾	PD _{n+1} ⁽⁴⁾	Write	Х	D0h				
Program/Erase Suspend	1	Write	Х	B0h							
Program/Erase Resume	1	Write	Х	D0h							
Protection Register Program	2	Write	PRA	C0h	Write	PRA	PRD				
Set Configuration Register	2	Write	CRD	60h	Write	CRD	03h				
Block Lock	2	Write	BKA or BA ⁽³⁾	60h	Write	ВА	01h				
Block Unlock	2	Write	BKA or BA ⁽³⁾	60h	Write	ВА	D0h				

^{1.} X = Don't Care, WA=Word Address in targeted bank, RD=Read Data, SRD=Status Register Data, ESD=Electronic Signature Data, QD=Query Data, BA=Block Address, BKA= Bank Address, PD=Program Data, PRA=Protection Register Address, PRD=Protection Register Data, CRD=Configuration Register

^{2.} Must be same bank as in the first cycle. The signature addresses are listed in *Table 7*.

^{3.} Any address within the bank can be used.

^{4.} n+1 is the number of Words to be programmed.

Table 6. Factory Program Command

		(0	Bus Write Operations ⁽¹⁾											
Command	Phase	Phase	Phase Shase		1st		2nd		3rd		Fin	al -1	Final	
		0	Add	Data	Add	Data	Add	Data	-	Add	Data	Add	Data	
Buffer	Setup	2	BKA or WA ⁽²⁾	80h	WA ₁	D0h								
Enhanced Factory	Program/ Verify ⁽³⁾	≥32	WA ₁	PD ₁	WA ₁	PD ₂	WA ₁	PD ₃		WA ₁	PD ₃₁	WA ₁	PD ₃₂	
Program	Exit	1	NOT BA ₁	Х										

WA=Word Address in targeted bank, BKA= Bank Address, PD=Program Data, BA=Block Address, X = Don't Care.

Table 7. Electronic Signature Codes⁽¹⁾

	Code	Address (h)	Data (h)
Manufacturer Code		Bank Address + 00	0020
Device Code	Тор	Bank Address + 01	8870
	Bottom	Bank Address + 01	8871
Block Protection	Locked	Block Address + 02	0001
	Unlocked	Block Address + 02	0000
Configuration Register		Bank Address + 05	CR
Protection Register PR0 Lock	ST Factory Default	Bank Address + 80	0002
	OTP Area Permanently Locked	Balik Addless + 60	0000
Protection Register PR0		Bank Address + 81 Bank Address + 84	Unique Device Number
		Bank Address + 85 Bank Address + 88	OTP Area
Protection Register PR1	through PR16 Lock	Bank Address + 89	PRLD
Protection Registers PR	Bank Address + 8A Bank Address + 109		OTP Area

^{1.} CR = Configuration Register, PRLD = Protection Register Lock Data.

^{2.} Any address within the bank can be used.

^{3.} The Program/Verify phase can be executed any number of times as long as the data is to be programmed to the same block.

^{4.} WA_1 is the Start Address, NOT BA_1 = Not Block Address of WA_1 .




Figure 4. Protection Register Memory Map

Table 8. Protection Register Locks

Lock			Doscription	
Number	Address	Bits	Description	
Lock 1	80h	Bit 0	preprogrammed to protect Unique Device Number, address 81h to 84h in PR0	
		Bit 1	protects 64bits of OTP segment, address 85h to 88h in PR0	
		Bits 2 to 15	reserved	
Lock 2	89h	Bit 0	protects 128bits of OTP segment PR1	
		Bit 1	protects 128bits of OTP segment PR2	
		Bit 2	protects 128bits of OTP segment PR3	
		-		
		Bit 13	protects 128bits of OTP segment PR14	
		Bit 14	protects 128bits of OTP segment PR15	
		Bit 15	protects 128bits of OTP segment PR16	

5 Status Register

The Status Register provides information on the current or previous program or erase operations. Issue a Read Status Register command to read the contents of the Status Register, refer to Read Status Register Command section for more details. To output the contents, the Status Register is latched and updated on the falling edge of the Chip Enable or Output Enable signals and can be read until Chip Enable or Output Enable returns to V_{IH} . The Status Register can only be read using single Asynchronous or Single Synchronous reads. Bus Read operations from any address within the bank, always read the Status Register during program and erase operations.

The various bits convey information about the status and any errors of the operation. Bits SR7, SR6, SR2 and SR0 give information on the status of the device and are set and reset by the device. Bits SR5, SR4, SR3 and SR1 give information on errors, they are set by the device but must be reset by issuing a Clear Status Register command or a hardware reset. If an error bit is set to '1' the Status Register should be reset before issuing another command.

Refer to Table 9: Status Register Bits in conjunction with the following text descriptions.

5.1 Program/Erase Controller Status bit (SR7)

The Program/Erase Controller Status bit indicates whether the Program/Erase Controller is active or inactive in any bank.

When the Program/Erase Controller Status bit is Low (set to '0'), the Program/Erase Controller is active; when the bit is High (set to '1'), the Program/Erase Controller is inactive, and the device is ready to process a new command.

The Program/Erase Controller Status bit is Low immediately after a Program/Erase Suspend command is issued until the Program/Erase Controller pauses. After the Program/Erase Controller pauses the bit is High.

5.2 Erase Suspend Status bit (SR6)

The Erase Suspend Status bit indicates that an erase operation has been suspended in the addressed block. When the Erase Suspend Status bit is High (set to '1'), a Program/Erase Suspend command has been issued and the memory is waiting for a Program/Erase Resume command.

The Erase Suspend Status bit should only be considered valid when the Program/Erase Controller Status bit is High (Program/Erase Controller inactive). SR6 is set within the Erase Suspend Latency time of the Program/Erase Suspend command being issued therefore the memory may still complete the operation rather than entering the Suspend mode.

When a Program/Erase Resume command is issued the Erase Suspend Status bit returns Low.

5.3 Erase Status bit (SR5)

The Erase Status bit is used to identify if there was an error during a block or bank erase operation. When the Erase Status bit is High (set to '1'), the Program/Erase Controller has applied the maximum number of pulses to the block or bank and still failed to verify that it has erased correctly.

The Erase Status bit should be read once the Program/Erase Controller Status bit is High (Program/Erase Controller inactive).

Once set High, the Erase Status bit must be set Low by a Clear Status Register command or a hardware reset before a new erase command is issued, otherwise the new command will appear to fail.

5.4 Program Status bit (SR4)

The Program Status bit is used to identify if there was an error during a program operation.

The Program Status bit should be read once the Program/Erase Controller Status bit is High (Program/Erase Controller inactive).

When the Program Status bit is High (set to '1'), the Program/Erase Controller has applied the maximum number of pulses to the Word and still failed to verify that it has programmed correctly.

Attempting to program a '1' to an already programmed bit while $V_{PP} = V_{PPH}$ will also set the Program Status bit High. If V_{PP} is different from V_{PPH} , SR4 remains Low (set to '0') and the attempt is not shown.

Once set High, the Program Status bit must be set Low by a Clear Status Register command or a hardware reset before a new program command is issued, otherwise the new command will appear to fail.

5.5 V_{PP} Status bit (SR3)

The V_{PP} Status bit is used to identify an invalid voltage on the V_{PP} pin during program and erase operations. The V_{PP} pin is only sampled at the beginning of a program or erase operation. Program and erase operations are not guaranteed if V_{PP} becomes invalid during an operation.

When the V_{PP} Status bit is Low (set to '0'), the voltage on the V_{PP} pin was sampled at a valid voltage.

when the V_{PP} Status bit is High (set to '1'), the V_{PP} pin has a voltage that is below the V_{PP} Lockout Voltage, V_{PPLK} , the memory is protected and program and erase operations cannot be performed.

Once set High, the V_{PP} Status bit must be set Low by a Clear Status Register command or a hardware reset before a new program or erase command is issued, otherwise the new command will appear to fail.

5.6 Program Suspend Status bit (SR2)

The Program Suspend Status bit indicates that a program operation has been suspended in the addressed block. The Program Suspend Status bit should only be considered valid when the Program/Erase Controller Status bit is High (Program/Erase Controller inactive).

When the Program Suspend Status bit is High (set to '1'), a Program/Erase Suspend command has been issued and the memory is waiting for a Program/Erase Resume command.

SR2 is set within the Program Suspend Latency time of the Program/Erase Suspend command being issued therefore the memory may still complete the operation rather than entering the Suspend mode.

When a Program/Erase Resume command is issued the Program Suspend Status bit returns Low.

5.7 Block Protection Status bit (SR1)

The Block Protection Status bit is used to identify if a Program or Block Erase operation has tried to modify the contents of a locked block.

When the Block Protection Status bit is High (set to '1'), a program or erase operation has been attempted on a locked block.

Once set High, the Block Protection Status bit must be set Low by a Clear Status Register command or a hardware reset before a new program or erase command is issued, otherwise the new command will appear to fail.

5.8 Bank Write/Multiple Word Program Status bit (SR0)

The Bank Write Status bit indicates whether the addressed bank is programming or erasing. In Buffer Enhanced Factory Program mode the Multiple Word Program bit shows if the device is ready to accept a new Word to be programmed to the memory array.

The Bank Write Status bit should only be considered valid when the Program/Erase Controller Status SR7 is Low (set to '0').

When both the Program/Erase Controller Status bit and the Bank Write Status bit are Low (set to '0'), the addressed bank is executing a program or erase operation. When the Program/Erase Controller Status bit is Low (set to '0') and the Bank Write Status bit is High (set to '1'), a program or erase operation is being executed in a bank other than the one being addressed.

In Buffer Enhanced Factory Program mode if Multiple Word Program Status bit is Low (set to '0'), the device is ready for the next Word, if the Multiple Word Program Status bit is High (set to '1') the device is not ready for the next Word.

For further details on how to use the Status Register, see the flowcharts and pseudocodes provided in *Appendix C*.

Table 9. Status Register Bits

Bit	Name	Туре	Logic Level ⁽¹⁾	Definition	
SR7	P/E.C. Status	Status	'1'	Ready	
SINT			'0'	Busy	
SR6	Erase Suspend Status	Status	'1'	Erase Suspended	
5110			'0'	Erase In progress or Completed	
SR5	Erase Status	Error	'1'	Erase Error	
513			'0'	Erase Success	
SR4	Program Status	Error	'1'	Program Error	
5114			'0'	Program Success	
SR3	V _{PP} Status	Error	'1'	V _{PP} Invalid, Abort	
513			'0'	V _{PP} OK	
SR2	Program Suspend Status	Status	'1'	Program Suspended	
OIXZ			'0'	Program In Progress or Completed	
SR1	Block Protection Status	Error	'1'	Program/Erase on protected Block, Abort	
SIXT			'0'	No operation to protected blocks	
	Bank Write Status	Status	'1'	SR7 = '1'	Not Allowed
				SR7 = '0'	Program or erase operation in a bank other than the addressed bank
SR0			'0'	SR7 = '1'	No Program or erase operation in the device
				SR7 = '0'	Program or erase operation in addressed bank
	Multiple Word Program Status (Enhanced Factory Program mode)	Status	'1'	SR7 = '1'	Not Allowed
				SR7 = '0'	the device is NOT ready for the next Word
			'0'	SR7 = '1'	the device is exiting from BEFP
				SR7 = '0'	the device is ready for the next Word

^{1.} Logic level '1' is High, '0' is Low.

6 Configuration Register

The Configuration Register is used to configure the type of bus access that the memory will perform. Refer to Read Modes section for details on read operations. The Configuration Register is set through the Command Interface using the Set Configuration Register command. After a reset or power-up the device is configured for asynchronous read (CR15 = 1). The Configuration Register bits are described in *Table 10* They specify the selection of the burst length, burst type, burst X latency and the read operation. Refer to *Figure 5* and *Figure 6* for examples of synchronous burst configurations.

6.1 Read Select bit (CR15)

The Read Select bit, CR15, is used to switch between Asynchronous and Synchronous Read operations.

When the Read Select bit is set to '1', read operations are asynchronous; when the Read Select bit is set to '0', read operations are synchronous.

Synchronous Burst Read is supported in both parameter and main blocks and can be performed across banks.

On reset or power-up the Read Select bit is set to '1' for asynchronous access.

6.2 X-Latency bits (CR13-CR11)

The X-Latency bits are used during Synchronous Read operations to set the number of clock cycles between the address being latched and the first data becoming available.

For correct operation the X-Latency bits can only assume the values in *Table 10: Configuration Register.*

The correspondence between X-Latency settings and the maximum sustainable frequency must be calculated taking into account some system parameters. Two conditions must be satisfied:

 Depending on whether t_{AVK_CPU} or t_{DELAY} is supplied either one of the following two equations must be satisfied:

```
 (n + 1) \ t_{K} \ge t_{AVQV} - t_{AVK\_CPU} + t_{QVK\_CPU} 
 (n + 2) \ t_{K} \ge t_{AVQV} + t_{DELAY} + t_{QVK\_CPU}
```

2. and also $t_K > t_{KQV} + t_{QVK}$ CPU

where

- n is the chosen X-Latency configuration code
- t_k is the clock period
- t_{AVK} CPU is clock to address valid, \overline{L} Low, or \overline{E} Low, whichever occurs last
- t_{DELAY} is address valid, \overline{L} Low, or \overline{E} Low to clock, whichever occurs last
- t_{OVK CPU} is the data setup time required by the system CPU,
- t_{KOV} is the clock to data valid time
- t_{AVQV} is the random access time of the device.

Refer to Figure 5: X-Latency and Data Output configuration example.

6.3 Wait Polarity bit (CR10)

The Wait Polarity bit is used to set the polarity of the Wait signal used in Synchronous Burst Read mode. During Synchronous Burst Read mode the Wait signal indicates whether the data output are valid or a WAIT state must be inserted.

When the Wait Polarity bit is set to '0' the Wait signal is active Low. When the Wait Polarity bit is set to '1' the Wait signal is active High.

6.4 Data Output Configuration bit (CR9)

The Data Output Configuration bit is used to configure the output to remain valid for either one or two clock cycles during synchronous mode.

When the Data Output Configuration Bit is '0' the output data is valid for one clock cycle, when the Data Output Configuration Bit is '1' the output data is valid for two clock cycles.

The Data Output Configuration must be configured using the following condition:

t_K > t_{KQV} + t_{QVK} CPU

where

- t_K is the clock period
- t_{QVK CPU} is the data setup time required by the system CPU
- t_{KOV} is the clock to data valid time.

If this condition is not satisfied, the Data Output Configuration bit should be set to '1' (two clock cycles). Refer to *Figure 5: X-Latency and Data Output configuration example*.

6.5 Wait Configuration bit (CR8)

The Wait Configuration bit is used to control the timing of the Wait output pin, WAIT, in Synchronous Burst Read mode.

When WAIT is asserted, Data is Not Valid and when WAIT is deasserted, Data is Valid.

When the Wait Configuration bit is Low (set to '0') the Wait output pin is asserted during the WAIT state. When the Wait Configuration bit is High (set to '1'), the Wait output pin is asserted one data cycle before the WAIT state.

6.6 Burst Type bit (CR7)

The Burst Type bit determines the sequence of addresses read during Synchronous Burst Reads.

The Burst Type bit is High (set to '1'), as the memory outputs from sequential addresses only.

See *Table 11: Burst Type Definition*, for the sequence of addresses output from a given starting address in sequential mode.

6.7 Valid Clock Edge bit (CR6)

The Valid Clock Edge bit, CR6, is used to configure the active edge of the Clock, K, during synchronous read operations. When the Valid Clock Edge bit is Low (set to '0') the falling edge of the Clock is the active edge. When the Valid Clock Edge bit is High (set to '1') the rising edge of the Clock is the active edge.

6.8 Wrap Burst bit (CR3)

The Wrap Burst bit, CR3, is used to select between wrap and no wrap. Synchronous burst reads can be confined inside the 4, 8 or 16 Word boundary (wrap) or overcome the boundary (no wrap).

When the Wrap Burst bit is Low (set to '0') the burst read wraps. When it is High (set to '1') the burst read does not wrap.

6.9 Burst length bits (CR2-CR0)

The Burst Length bits are used to set the number of Words to be output during a Synchronous Burst Read operation as result of a single address latch cycle.

They can be set for 4 Words, 8 Words, 16 Words or continuous burst, where all the Words are read sequentially. In continuous burst mode the burst sequence can cross bank boundaries.

In continuous burst mode, in 4, 8 or 16 Words no-wrap, depending on the starting address, the device asserts the WAIT signal to indicate that a delay is necessary before the data is output.

If the starting address is aligned to an 8 Word boundary no WAIT states are needed and the WAIT output is not asserted.

If the starting address is not aligned to the 8 Word boundary, WAIT will be asserted when the burst sequence crosses the first 16 Word boundary to indicate that the device needs an internal delay to read the successive Words in the array.

In the worst case, the number of WAIT states is one clock cycle less than the latency setting. The exact number is reported in *Table 12: Wait at the Boundary*.

WAIT will be asserted only once during a continuous burst access. See also *Table 11: Burst Type Definition*.

CR14, CR5 and CR4 are reserved for future use.

Table 10. Configuration Register

Bit	Description	Value	Description
CR15	Read Select	0	Synchronous Read
CKIS	Read Select	1	Asynchronous Read (Default at power-on)
CR14	Reserved		
		010	2 clock latency ⁽¹⁾
		011	3 clock latency
		100	4 clock latency
CR13-CR11	X-Latency	101	5 clock latency
		110	6 clock latency
		111	7 clock latency (default)
		Other co	onfigurations reserved
CR10	Wait Polarity	0	WAIT is active Low
CKIU	Wall Folamly	1	WAIT is active high (default)
CR9	Data Output Configuration	0	Data held for one clock cycle
CK9		1	Data held for two clock cycles (default) ⁽¹⁾
	Wait Configuration	0	WAIT is active during WAIT state
CR8		1	WAIT is active one data cycle before WAIT state (default) ⁽¹⁾
CD7	Durat Tuna	0	Reserved
CR7	Burst Type	1	Sequential (default)
CR6	Valid Clock Edge	0	Falling Clock edge
CKO	Valid Clock Edge	1	Rising Clock edge (default)
CR5-CR4	Reserved		
CR3	Wrap Burst	0	Wrap
UNO	vviap buist	1	No Wrap (default)
		001	4 Words
CR2-CR0	Burst Length	010	8 Words
UNZ-UNU	Duist Length	011	16 Words
		111	Continuous (default)

The combination X-Latency=2, Data held for two clock cycles and Wait active one data cycle before the WAIT state is not supported.


Table 11. Burst Type Definition

e	Start		Se	quential		
Mode	Add.	4 Words	8 Words	16 Words	Continuous Burst	
	0	0-1-2-3	0-1-2-3-4-5-6-7	0-1-2-3-4-5-6-7-8-9-10-11-12-13-14-15	0-1-2-3-4-5-6	
	1	1-2-3-0	1-2-3-4-5-6-7-0	1-2-3-4-5-6-7-8-9-10-11-12-13-14-15-0	1-2-3-4-5-6-7	
	2	2-3-0-1	2-3-4-5-6-7-0-1	2-3-4-5-6-7-8-9-10-11-12-13-14-15-0-1	2-3-4-5-6-7-8	
	3	3-0-1-2	3-4-5-6-7-0-1-2	3-4-5-6-7-8-9-10-11-12-13-14-15-0-1-2	3-4-5-6-7-8-9	
	7	7-4-5-6	7-0-1-2-3-4-5-6	7-8-9-10-11-12-13-14-15-0-1-2-3-4-5-6	7-8-9-10-11-12-13	
Wrap						
>	12	12-13-14-15	12-13-14-15-8-9-10- 11	12-13-14-15-0-1-2-3-4-5-6-7-8-9-10-11	12-13-14-15-16-17	
	13	13-14-15-12	13-14-15-8-9-10-11- 12	13-14-15-0-1-2-3-4-5-6-7-8-9-10-11-12	13-14-15-16-17-18	
	14	14-15-12-13	14-15-8-9-10-11-12- 13	14-15-0-1-2-3-4-5-6-7-8-9-10-11-12-13	14-15-16-17-18-19	
	15	15-12-13-14	15-8-9-10-11-12-13- 14	15-0-1-2-3-4-5-6-7-8-9-10-11-12-13-14	15-16-17-18-19-20	
	0	0-1-2-3	0-1-2-3-4-5-6-7	0-1-2-3-4-5-6-7-8-9-10-11-12-13-14-15		
	1	1-2-3-4	1-2-3-4-5-6-7-8	1-2-3-4-5-6-7-89-10-11-12-13-14-15-16		
	2	2-3-4-5	2-3-4-5-6-7-8-9	2-3-4-56-7-8-9-10-11-12-13-14-15-16-17		
	3	3-4-5-6	3-4-5-6-7-8-9-10	3-4-5-6-7-8-9-10-11-12-13-14-15-16-17-18		
ар	7	7-8-9-10	7-8-9-10-11-12-13-14	7-8-9-10-11-12-13-14-15-16-17-18-19-20- 21-22	Same as for Wrap	
No-wrap					(Wrap /No Wrap has no effect on	
ž	12	12-13-14-15	12-13-14-15-16-17- 18-19	12-13-14-15-16-17-18-19-20-21-22-23-24- 25-26-27	Continuous Burst)	
	13	13-14-15-16	13-14-15-16-17-18- 19-20	13-14-15-16-17-18-19-20-21-22-23-24-25- 26-27-28		
	14	14-15-16-17	14-15-16-17-18-19- 20-21	14-15-16-17-18-19-20-21-22-23-24-25-26- 27-28-29		
	15	15-16-17-18	15-16-17-18-19-20- 21-22	15-16-17-18-19-20-21-22-23-24-25-26-27- 28-29-30		

Table 12. Wait at the Boundary


Start	Number of WAIT states								
Address	X-Latency = 7	X-Latency = 6	X-Latency = 5	X-Latency = 4	X-Latency = 3	X-Latency = 2			
0	0	0	0	0	0	0			
1	0	0	0	0	0	0			
2	1	0	0	0	0	0			
3	2	1	0	0	0	0			
4	3	2	1	0	0	0			
5	4	3	2	1	0	0			
6	5	4	3	2	1	0			
7	6	5	4	3	2	1			

Figure 5. X-Latency and Data Output configuration example



1. The settings shown are X-latency = 4, Data Output held for one clock cycle.

Figure 6. Wait configuration example



7 Read modes

Read operations can be performed in two different ways depending on the settings in the Configuration Register. If the clock signal is 'don't care' for the data output, the read operation is asynchronous; if the data output is synchronized with clock, the read operation is synchronous.

The read mode and format of the data output are determined by the Configuration Register. (See Configuration Register section for details). All banks support both asynchronous and synchronous read operations.

7.1 Asynchronous Read mode

In Asynchronous Read operations the clock signal is 'don't care'. The device outputs the data corresponding to the address latched, that is the memory array, Status Register, Common Flash Interface or Electronic Signature depending on the command issued. CR15 in the Configuration Register must be set to '1' for asynchronous operations.

Asynchronous Read operations can be performed in two different ways, Asynchronous Random Access Read and Asynchronous Page Read. Only Asynchronous Page Read takes full advantage of the internal page storage so different timings are applied.

In Asynchronous Read mode a Page of data is internally read and stored in a Page Buffer. The Page has a size of 8 Words and is addressed by address inputs A0, A1 and A2.

The first read operation within the Page has a longer access time (t_{AVQV} , Random access time), subsequent reads within the same Page have much shorter access times (t_{AVQV1} , Page access time). If the Page changes then the normal, longer timings apply again.

The device features an Automatic Standby mode. During Asynchronous Read operations, after a bus inactivity of 150ns, the device automatically switches to the Automatic Standby mode. In this condition the power consumption is reduced to the standby value and the outputs are still driven.

In Asynchronous Read mode, the WAIT signal is always deasserted.

See Table 23: Asynchronous Read AC Characteristics, Figure 9: Asynchronous Random Access Read AC waveforms, and Figure 10: Asynchronous Page Read AC waveforms, for details.

7.2 Synchronous Burst Read mode

In Synchronous Burst Read mode the data is output in bursts synchronized with the clock. It is possible to perform burst reads across bank boundaries.

Synchronous Burst Read mode can only be used to read the memory array. For other read operations, such as Read Status Register, Read CFI and Read Electronic Signature, Single Synchronous Read or Asynchronous Random Access Read must be used.

In Synchronous Burst Read mode the flow of the data output depends on parameters that are configured in the Configuration Register.

A burst sequence starts at the first clock edge (rising or falling depending on Valid Clock Edge bit CR6 in the Configuration Register) after the falling edge of Latch Enable or Chip

Enable, whichever occurs last. Addresses are internally incremented and data is output on each data cycle after a delay which depends on the X latency bits CR13-CR11 of the Configuration Register.

The number of Words to be output during a Synchronous Burst Read operation can be configured as 4 Words, 8 Words, 16 Words or Continuous (Burst Length bits CR2-CR0). The data can be configured to remain valid for one or two clock cycles (Data Output Configuration bit CR9).

The order of the data output can be modified through the Wrap Burst bit in the Configuration Register. The burst sequence is sequential and can be confined inside the 4, 8 or 16 Word boundary (Wrap) or overcome the boundary (No Wrap).

The WAIT signal may be asserted to indicate to the system that an output delay will occur. This delay will depend on the starting address of the burst sequence and on the burst configuration.

WAIT is asserted during the X latency, the WAIT state and at the end of a 4, 8 and 16 Word burst. It is only deasserted when output data are valid. In Continuous Burst Read mode a WAIT state will occur when crossing the first 16 Word boundary. If the starting address is aligned to the Burst Length (4, 8 or 16 Words) the wrapped configuration has no impact on the output sequence.

The WAIT signal can be configured to be active Low or active High by setting CR10 in the Configuration Register.

See Figure 24: Synchronous Read AC Characteristics, and Figure 11: Synchronous Burst Read AC waveforms, for details.

7.2.1 Synchronous Burst Read Suspend

A Synchronous Burst Read operation can be suspended, freeing the data bus for other higher priority devices. It can be suspended during the initial access latency time (before data is output) in which case the initial latency time can be reduced to zero, or after the device has output data. When the Synchronous Burst Read operation is suspended, internal array sensing continues and any previously latched internal data is retained. A burst sequence can be suspended and resumed as often as required as long as the operating conditions of the device are met.

A Synchronous Burst Read operation is suspended when Chip Enable, \overline{E} , is Low and the current address has been latched (on a Latch Enable rising edge or on a valid clock edge). The Clock signal is then halted at V_{IH} or at V_{IL} , and Output Enable, \overline{G} , goes High.

When Output Enable, \overline{G} , becomes Low again and the Clock signal restarts, the Synchronous Burst Read operation is resumed exactly where it stopped.

WAIT will revert to high-impedance when Output Enable, \overline{G} , or Chip Enable, \overline{E} , goes High.

See Table 24: Synchronous Read AC Characteristics, and Figure 13: Synchronous Burst Read Suspend AC waveforms, for details.

7.3 Single Synchronous Read mode

Single Synchronous Read operations are similar to Synchronous Burst Read operations except that the memory outputs the same data to the end of the operation.

Synchronous Single Reads are used to read the Electronic Signature, Status Register, CFI, Block Protection Status, Configuration Register Status or Protection Register. When the addressed bank is in Read CFI, Read Status Register or Read Electronic Signature mode, the WAIT signal is asserted during the X latency, the WAIT state and at the end of a 4, 8 and 16 Word burst. It is only deasserted when output data are valid.

See Table 24: Synchronous Read AC Characteristics, and Figure 11: Synchronous Burst Read AC waveforms, for details.

8 Dual Operations and Multiple Bank architecture

The Multiple Bank Architecture of the M58LT256GT/B gives greater flexibility for software developers to split the code and data spaces within the memory array. The Dual Operations feature simplifies the software management of the device by allowing code to be executed from one bank while another bank is being programmed or erased.

The Dual Operations feature means that while programming or erasing in one bank, read operations are possible in another bank with zero latency (only one bank at a time is allowed to be in program or erase mode).

If a read operation is required in a bank, which is programming or erasing, the program or erase operation can be suspended.

Also if the suspended operation was erase then a program command can be issued to another block, so the device can have one block in Erase Suspend mode, one programming and other banks in read mode.

Bus Read operations are allowed in another bank between setup and confirm cycles of program or erase operations.

By using a combination of these features, read operations are possible at any moment in the M58LT256GT/B device.

Dual operations between the Parameter Bank and either of the CFI, the OTP or the Electronic Signature memory space are not allowed. *Table 15* shows which dual operations are allowed or not between the CFI, the OTP, the Electronic Signature locations and the memory array.

Table 13 and *Table 14* show the dual operations possible in other banks and in the same bank.

Table 13. Dual Operations Allowed In Other Banks

	Commands allowed in another bank								
Status of bank	Read Array	Read Status Register	Read CFI Query	Read Electronic Signature	Program, Buffer Program	Block Erase	Program/ Erase Suspend	Program/ Erase Resume	
Idle	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
Programming	Yes	Yes	Yes	Yes	_	-	Yes	_	
Erasing	Yes	Yes	Yes	Yes	-	_	Yes	_	
Program Suspended	Yes	Yes	Yes	Yes	-	-	_	Yes	
Erase Suspended	Yes	Yes	Yes	Yes	Yes	_	_	Yes	

Table 14. Dual Operations Allowed In Same Bank

	Commands allowed in same bank									
Status of bank	Read Array	Read Status Register	Read CFI Query	Read Electronic Signature	Program, Buffer Program	Block Erase	Program/ Erase Suspend	Program/ Erase Resume		
Idle	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes		
Programming	_(1)	Yes	Yes	Yes	_	_	Yes	_		
Erasing	_(1)	Yes	Yes	Yes	-	_	Yes	_		
Program Suspended	Yes ⁽²⁾	Yes	Yes	Yes	-	-	_	Yes		
Erase Suspended	Yes ⁽²⁾	Yes	Yes	Yes	Yes ⁽²⁾	_	_	Yes		

^{1.} The Read Array command is accepted but the data output is not guaranteed until the Program or Erase has completed.

Table 15. Dual Operation Limitations

		Commands allowed						
Current Status		Read CFI / OTP /	Read Parameter	Read Main Blocks				
		Electronic Signature	Blocks	Located in Parameter Bank	Not Located in Parameter Bank			
_	ing / Erasing ter Blocks	No	No	No	Yes			
Programming /Erasing Main	Located in Parameter Bank	Yes	No	No	Yes			
Blocks	Not Located in Parameter Bank	Yes	Yes	Yes	In Different Bank Only			
Program	ming OTP	No	No	No	No			

^{2.} Not allowed in the Word that is being erased or programmed.

9 Block locking

The M58LT256GT/B features an instant, individual block locking scheme that allows any block to be locked and unlocked with no latency. This locking scheme has three levels of protection.

- Lock/Unlock this first level allows software only control of block locking.
- V_{PP} ≤V_{PPLK} this level offers a complete hardware protection against program and erase on all blocks.

The protection status of each block can be set to Locked or Unlocked. *Table 16* defines all of the possible protection states (DQ0), and *Appendix C*, *Figure 24*, shows a flowchart for the locking operations.

9.1 Reading a Block's Lock status

The lock status of every block can be read in the Read Electronic Signature mode of the device. A Read Electronic Signature command must be issued to enter this mode. Subsequent reads at the address specified in *Table 7*, will output the protection status of that block.

The lock status is represented by DQ0. DQ0 indicates the Block Lock/Unlock status and is set by the Lock command and cleared by the Unlock command.

The following sections explain the operation of the locking system.

9.2 Locked state

The default status of all blocks on power-up or after a hardware reset is Locked. Locked blocks are fully protected from program or erase operations. Any program or erase operations attempted on a locked block will return an error in the Status Register. The Status of a Locked block can be changed to Unlocked using the appropriate software commands. An Unlocked block can be Locked by issuing the Lock command.

9.3 Unlocked state

Unlocked blocks, can be programmed or erased. All unlocked blocks return to the Locked state after a hardware reset or when the device is powered-down. The status of an unlocked block can be changed to Locked using the appropriate software commands. A locked block can be unlocked by issuing the Unlock command.

9.4 Locking operations during Erase Suspend

Changes to block lock status can be performed during an erase suspend by using the standard locking command sequences to unlock or lock a block. This is useful in the case when another block needs to be updated while an erase operation is in progress.

To change block locking during an erase operation, first write the Erase Suspend command, then check the Status Register until it indicates that the erase operation has been suspended. Next write the desired Lock command sequence to a block and the lock status will be changed. After completing any desired lock, read, or program operations, resume the erase operation with the Erase Resume command.

If a block is locked during an erase suspend of the same block, the locking status bits will be changed immediately, but when the erase is resumed, the erase operation will complete. Locking operations cannot be performed during a program suspend.

Table 16. Block Lock Status

Block Loc	rent k Status ⁽¹⁾ DQ0)	Next Block Lock Status ⁽¹⁾ (bit DQ0)			
Current State	Current State Program/Erase Allowed		After Block Unlock Command		
0 yes		1	0		
1 ⁽²⁾	1 ⁽²⁾ no		0		

^{1.} All blocks are locked at Power-up, so the default value of DQ0 is '1'.

^{2.} DQ0 is read by issuing a Read Electronic Signature command (see *Table 5* and *Table 7*).

10 Program and Erase times and endurance cycles

The Program and Erase times and the number of Program/ Erase cycles per block are shown in *Table 17* Exact erase times may change depending on the memory array condition. The best case is when all the bits in the block are at '0' (preprogrammed). The worst case is when all the bits in the block are at '1' (not preprogrammed). Usually, the system overhead is negligible with respect to the erase time. In the M58LT256GT/B the maximum number of Program/Erase cycles depends on the V_{PP} voltage supply used.

Table 17. Program/Erase Times and Endurance Cycles (1)(2)

	Param	eter	Condition	Min	Тур	Typical after 100kW/E Cycles	Max	Unit
		Parameter Block (16	KWord)		0.4	1	2.5	s
	Erase	Main Block	Preprogrammed		1	3	4	s
		(64 KWord)	Not Preprogrammed		1.2		4	S
		Single Cell	Word Program		30		60	μs
	(3)		Buffer Program		30		60	μs
Vpp		gram ⁽³⁾ Single Word	Word Program		90		180	μs
1 11	_		Buffer Program		90		180	μs
Vpp		Buffer (32 Words) (E	Buffer Program)		440		880	μs
		Main Block (64 KWo	ord) (Buffer Program)		880			ms
	Cuanand Latenay	Program			20		25	μs
	Suspend Latency	Erase			20		25	μs
	Program/Erase	Main Blocks		100,000				cycles
	Cycles (per Block)	Parameter Blocks		100,000				cycles

Table 17. Program/Erase Times and Endurance Cycles (continued)⁽¹⁾⁽²⁾

	Param	neter	Condition	Min	Тур	Typical after 100kW/E Cycles	Max	Unit
	Erase	Parameter Block (16	6 KWord)		0.4		2.5	S
	Elase	Main Block (64 KWo	ord)		1		4	S
		Single Cell	Word Program		30		60	μs
		Single Word	Word Program		85		170	μs
	Program ⁽³⁾		Buffer Enhanced Factory Program ⁽⁴⁾		10			μs
_		Buffer (32 Words)	Buffer Program		340		680	μs
= V _{PPH}			Buffer Enhanced Factory Program		320			μs
Vрр		M : DI I	Buffer Program		640			ms
		Main Block (64 KWords)	Buffer Enhanced Factory Program		640			ms
			Buffer Program		10			S
		Bank (16 Mbits)	Buffer Enhanced Factory Program		10			S
	Program/Erase Main Blocks						1000	cycles
	Cycles (per Block)	Parameter Blocks					2500	cycles

^{1.} $T_A = -25$ to 85°C; $V_{DD} = 1.7V$ to 2V; $V_{DDQ} = 2.7V$ to 3.6V.

^{2.} Values are liable to change with the external system-level overhead (command sequence and Status Register polling execution).

^{3.} Excludes the time needed to execute the command sequence.

^{4.} This is an average value on the entire device.

11 Maximum rating

Stressing the device above the rating listed in the Absolute Maximum Ratings table may cause permanent damage to the device. These are stress ratings only and operation of the device at these or any other conditions above those indicated in the Operating sections of this specification is not implied. Exposure to Absolute Maximum Rating conditions for extended periods may affect device reliability. Refer also to the STMicroelectronics SURE Program and other relevant quality documents.

Table 18. Absolute Maximum Ratings

Symbol	Parameter	Va	lue	Unit
Symbol	rarameter	Min	Max	Onit
T _A	Ambient Operating Temperature	-25	85	°C
T _{BIAS}	Temperature Under Bias	-25	85	°C
T _{STG}	Storage Temperature	-65	125	°C
V _{IO}	Input or Output Voltage	-0.5	4.2	V
V_{DD}	Supply Voltage	-0.2	2.5	V
V _{DDQ}	Input/Output Supply Voltage	-0.2	3.8	V
V _{PP}	Program Voltage	-0.2	10	V
Io	Output Short Circuit Current		100	mA
t _{VPPH}	Time for V _{PP} at V _{PPH}		100	hours


12 DC and AC parameters

This section summarizes the operating measurement conditions, and the DC and AC characteristics of the device. The parameters in the DC and AC characteristics Tables that follow, are derived from tests performed under the Measurement Conditions summarized in *Table 19: Operating and AC Measurement Conditions*. Designers should check that the operating conditions in their circuit match the operating conditions when relying on the quoted parameters.

Table 19. Operating and AC Measurement Conditions

	M58LT256GT	M58LT256GB		
Parameter	1	Units		
	Min	Max		
V _{DD} Supply Voltage	1.7	2.0	V	
V _{DDQ} Supply Voltage	2.7	3.6	V	
V _{PP} Supply Voltage (Factory environment)	8.5	9.5	V	
V _{PP} Supply Voltage (Application environment)	-0.4	V _{DDQ} +0.4	V	
Ambient Operating Temperature	-25	85	°C	
Load Capacitance (C _L)	3	80	pF	
Input Rise and Fall Times		5	ns	
Input Pulse Voltages	0 to	V		
Input and Output Timing Ref. Voltages	V _{DI}	_{OQ} /2	V	

Figure 7. AC Measurement I/O waveform



 V_{DDQ} V_{DQQ} V_{Q

Figure 8. AC measurement load circuit

Table 20. Capacitance⁽¹⁾

	Symbol	Parameter	Test Condition	Min	Max	Unit
Ī	C _{IN}	Input Capacitance	$V_{IN} = 0V$	6	8	pF
	C _{OUT}	Output Capacitance	$V_{OUT} = 0V$	8	12	pF

^{1.} Sampled only, not 100% tested.

Table 21. DC characteristics - currents

Symbol	Parameter	Test Condition	Тур	Max	Unit
I _{LI}	Input Leakage Current	0V ≤V _{IN} ≤V _{DDQ}		±1	μA
I _{LO}	Output Leakage Current	0V ≤V _{OUT} ≤V _{DDQ}		±1	μA
	Supply Current Asynchronous Read (f=5MHz)	$\overline{E} = V_{IL}, \overline{G} = V_{IH}$	13	15	mA
		4 Word	16	18	mA
I _{DD1}	Supply Current Synchronous Read (f=52MHz)	8 Word	18	20	mA
		16 Word	23	25	mA
		Continuous	25	27	mA
I _{DD2}	Supply Current (Reset)	$\overline{RP} = V_{SS} \pm 0.2V$	25	70	μA
I _{DD3}	Supply Current (Standby)	$\overline{E} = V_{DD} \pm 0.2V$	25	70	μA
I _{DD4}	Supply Current (Automatic Standby)	$\overline{E} = V_{IL}, \overline{G} = V_{IH}$	25	70	μА
	Supply Current (Program)	$V_{PP} = V_{PPH}$	8	15	mA
I _{DD5} ⁽¹⁾	Supply Current (Program)	$V_{PP} = V_{DD}$	10	20	mA
'DD5` ′	Supply Current (Frace)	$V_{PP} = V_{PPH}$	8	15	mA
	Supply Current (Erase)	$V_{PP} = V_{DD}$	10	20	mA

Table 21. DC characteristics - currents (continued)

Symbol	Parameter	Test Condition	Тур	Max	Unit
	Supply Current	Program/Erase in one Bank, Asynchronous Read in another Bank	23	35	mA
I _{DD6} ⁽¹⁾⁽²⁾	(Dual Operations)	Program/Erase in one Bank, Synchronous Read (Continuous f=52MHz) in another Bank	35	47	mA
I _{DD7} ⁽¹⁾	Supply Current Program/ Erase Suspended (Standby)	$\overline{E} = V_{DD} \pm 0.2V$	25	70	μA
	// Supply Current (Program)	V _{PP} = V _{PPH}	2	5	mA
I _{PP1} ⁽¹⁾	V _{PP} Supply Current (Program)	$V_{PP} = V_{DD}$	0.2	5	μA
'PP1` ′	V _{PP} Supply Current (Erase)	V _{PP} = V _{PPH}	2	5	mA
	VPP Supply Current (Elase)	$V_{PP} = V_{DD}$	0.2	5	μA
I _{PP2}	V _{PP} Supply Current (Read)	V _{PP} ≤V _{DD}	0.2	5	μA
I _{PP3} ⁽¹⁾	V _{PP} Supply Current (Standby)	V _{PP} ≤V _{DD}	0.2	5	μA

^{1.} Sampled only, not 100% tested.

Table 22. DC Characteristics - Voltages

Symbol	Parameter	Test Condition	Min	Тур	Max	Unit
V _{IL}	Input Low Voltage		0		0.4	V
V _{IH}	Input High Voltage		V _{DDQ} – 0.4		V _{DDQ} + 0.4	V
V _{OL}	Output Low Voltage	I _{OL} = 100μA			0.1	V
V _{OH}	Output High Voltage	$I_{OH} = -100 \mu A$	V _{DDQ} – 0.1			V
V _{PP1}	V _{PP} Program Voltage- Logic	Program, Erase	1.1	1.8	3.3	V
V _{PPH}	V _{PP} Program Voltage Factory	Program, Erase	8.5	9.0	9.5	V
V _{PPLK}	Program or Erase Lockout				0.4	V
V_{LKO}	V _{DD} Lock Voltage		1			V
V _{RPH}	RP pin Extended High Voltage				3.3	V

^{2.} $\ensuremath{V_{DD}}$ Dual Operation current is the sum of read and program or erase currents.

AI08906b + tehax —tEHQZ—▼ ⊢ tEHTZ ↑ tGHQX → - tGHQZ VALID VALID Notes: 1. Write Enable, $\overline{\rm W}_i$ is High, WAIT is active Low. 2. Latch Enable function is not required or supported. 2. Latch Enable, $\overline{\rm L}_i$ can be kept Low (also at board level) when the Latch Enable function is not required or supported. tELTV tLHAX tGLQV. tGLQX tAVAV tLLQV tELQV-▲— tGLTV tAVQVtelox . VALID tellH → tri T tAVLH-Hi-Z Hi-Z DQ0-DQ15 WAIT⁽¹⁾ [(2) Ιш lΩ

Figure 9. Asynchronous Random Access Read AC waveforms

577

AI08907b → Standby → VALID ADD VALID ADD. /ALID ADD. /ALID ADD, Valid Data /ALID ADD. /ALID ADD, VALID ADDRESS ▲ ★ TAVQV1 'ALID ADD. Outputs Enabled tLHAX tGLQVtGLTV -VALID ADDRESS tELTV tAVAV tELQV — Valid Address Latch **t**ELQX tLLQV. #ELLH— -tAVLH-Note 1. WAIT is active Low. DQ0-DQ15 WAIT (1) A3-A23 A0-A2 1... lΩ lш

Figure 10. Asynchronous Page Read AC waveforms

Table 23. Asynchronous Read AC Characteristics

	Symbol	Alt	Parameter		M58LT256GT, M58LT256GB	Unit
					110	
	t _{AVAV}	t _{RC}	ddress Valid to Next Address Valid Min		110	ns
	t _{AVQV}	t _{ACC}	Address Valid to Output Valid (Random)	dress Valid to Output Valid (Random) Max		ns
	t _{AVQV1}	t _{PAGE}	Address Valid to Output Valid (Page)	Max	25	ns
	t _{AXQX} ⁽¹⁾	t _{OH}	Address Transition to Output Transition	Min	0	ns
	t _{ELTV}		Chip Enable Low to Wait Valid	Max	20	ns
	t _{ELQV} (2)	t _{CE}	Chip Enable Low to Output Valid	Max	110	ns
gs	t _{ELQX} ⁽¹⁾	t _{LZ}	Chip Enable Low to Output Transition	Max	0	ns
Read Timings	t _{EHTZ}		Chip Enable High to Wait Hi-Z	nip Enable High to Wait Hi-Z Max		ns
ad T	t _{EHQX} ⁽¹⁾	t _{OH}	nip Enable High to Output Transition Min		0	ns
Re	t _{EHQZ} ⁽¹⁾	t _{HZ}	nip Enable High to Output Hi-Z Max		20	ns
	t _{GLQV} ⁽²⁾	t _{OE}	Output Enable Low to Output Valid	utput Enable Low to Output Valid Max		ns
	t _{GLQX} ⁽¹⁾	t _{OLZ}	Output Enable Low to Output Transition	utput Enable Low to Output Transition Min		ns
	t _{GLTV}		Output Enable Low to WAIT Valid	Max	20	ns
	t _{GHQX} ⁽¹⁾	t _{OH}	Output Enable High to Output Transition	Min	0	ns
	t _{GHQZ} ⁽¹⁾	t _{DF}	Output Enable High to Output Hi-Z	Max	20	ns
	t _{GHTZ}		Output Enable High to WAIT Hi-Z	Max	17	ns
	t _{AVLH}	t _{AVADVH}	Address Valid to Latch Enable High	Min	12	ns
nings	t _{ELLH}	t _{ELADVH}	Chip Enable Low to Latch Enable High	Min	11	ns
Tim	t _{LHAX}	t _{ADVHAX}	Latch Enable High to Address Transition	atch Enable High to Address Transition Min		ns
Latch Timings	t _{LLLH}	t _{ADVLADVH}	Latch Enable Pulse Width	Min	11	ns
	t _{LLQV}	t _{ADVLQV}	Latch Enable Low to Output Valid (Random)	Max	110	ns

^{1.} Sampled only, not 100% tested.

^{2.} \overline{G} may be delayed by up to t_{ELQV} - t_{GLQV} after the falling edge of \overline{E} without increasing t_{ELQV} .




Figure 11. Synchronous Burst Read AC waveforms




Figure 12. Single Synchronous Read AC waveforms

AI08909

AI08910 ← tEHTZ NOT VALID tGHÖZ **TEHOX** tEHQZ tehel. Note 1. The number of clock cycles to be inserted depends on the X latency set in the Configuration Register.

2. The WAIT signal is configured to be active during wait state. WAIT signal is active Low.

3. The CLOCK signal can be held high or low

4. Address latched and data output on the rising clock edge. Either the rising or the falling edge of the clock signal, K, can be configured as the active edge. Here, the active edge is the rising one. NOT VALID - tGLQV tGLTV Note 3 ★ tGHQZ **←** tGHTZ VALID tKHQV VALID tGLQV Note 1 tGLTV tGLQXtelty. VALID ADDRESS **tKHAX ↑** fLKH tAVKH tAVLHtelkH ★ Hi-Z Hi-Z DQ0-DQ15 WAIT⁽²⁾ A0-A23 ₹ 4 IΦ I = IΙш

Figure 13. Synchronous Burst Read Suspend AC waveforms

Figure 14. Clock input AC waveform




Table 24. Synchronous Read AC Characteristics⁽¹⁾⁽²⁾

	Symbol Alt		Parameter		M58LT256GT, M58LT256GB	Unit
					110	
	t _{AVKH}	t _{AVCLKH}	Address Valid to Clock High	Min	11	ns
	t _{ELKH}	t _{ELCLKH}	Chip Enable Low to Clock High	Min	11	ns
	t _{ELTV}		Chip Enable Low to Wait Valid	Max	20	ns
nings	t _{EHEL}		Chip Enable Pulse Width (subsequent synchronous reads)			ns
d Tir	t _{EHTZ}		Chip Enable High to Wait Hi-Z	Max	20	ns
Rea	t _{GLTV}		Output Enable Low to Wait Valid Max		20	ns
sno	t _{KHAX}	t _{CLKHAX}	Clock High to Address Transition Min		10	ns
Synchronous Read Timings	t _{KHQV}	t _{CLKHQV}	Clock High to Output Valid Clock High to WAIT Valid Max		20	ns
Ś	t _{KHQX}	t _{CLKHQX}	Clock High to Output Transition Clock High to WAIT Transition	Min	3	ns
	t _{LLKH}	t _{ADVLCLKH}	Latch Enable Low to Clock High	Min	11	ns
	t _{GHTZ}		Output Enable High to WAIT Hi-Z	Max	17	ns
suc	t _{KHKH}	t _{CLK}	Clock Period (f=52MHz)	Min	19	ns
ecificatio	t _{KHKL} t _{KLKH}		Clock High to Clock Low Clock Low to Clock High	I Min I		ns
Clock Specifications	t _f , t _r		Clock Fall or Rise Time Max		3	ns

^{1.} Sampled only, not 100% tested.

^{2.} For other timings please refer to Table 23: Asynchronous Read AC Characteristics.




Figure 15. Write AC Waveforms, Write Enable Controlled

Table 25. Write AC Characteristics, Write Enable Controlled⁽¹⁾

S	Symbol Alt Parameter				M58LT256GT, M58LT256GB	Unit
					110	
	t _{AVAV}	t_{WC}	Address Valid to Next Address Valid	Min	110	ns
	t _{AVLH}		Address Valid to Latch Enable High	Min	11	ns
	t _{DVWH}	t _{DS}	Data Valid to Write Enable High	Min	50	ns
Sc	t _{ELLH}		Chip Enable Low to Latch Enable High	Min	11	ns
Write Enable Controlled Timings	t _{ELWL}	t _{CS}	Chip Enable Low to Write Enable Low	Min	0	ns
j Di	t _{LHAX}		Latch Enable High to Address Transition	Min	10	ns
trolle	t _{LLLH}		Latch Enable Pulse Width	atch Enable Pulse Width Min		ns
Con	t _{WHDX}	t _{DH}	/rite Enable High to Input Transition Min		0	ns
able	t _{WHEH}	t _{CH}	Write Enable High to Chip Enable High	rite Enable High to Chip Enable High Min		ns
Ens	t _{WHEL} (2)		Write Enable High to Chip Enable Low	Min	25	ns
Vrite	t _{WHLL}		Write Enable High to Latch Enable Low	Min	0	ns
	t _{WHWL}	t _{WPH}	Write Enable High to Write Enable Low	Min	25	ns
	t _{WHQV}		Write Enable High to Output Valid (Status Register)	Min	135	ns
	t _{WLWH}	t_{WP}	Write Enable Low to Write Enable High	Min	50	ns
sbu	t _{QVVPL}		Output (Status Register) Valid to V _{PP} Low	Min	0	ns
Timi	t _{VPHWH}	t _{VPS}	V _{PP} High to Write Enable High	Min	200	ns
Protection Timings	t _{WHVPL}		Write Enable High to V _{PP} Low	Min	200	ns

^{1.} Sampled only, not 100% tested.

t_{WHEL} has the values shown when reading in the targeted bank. System designers should take this into account and may insert a software No-Op instruction to delay the first read in the same bank after issuing a command. If it is a Read Array operation in a different bank t_{WHEL} is 0ns.





Figure 16. Write AC Waveforms, Chip Enable Controlled

Table 26. Write AC Characteristics, Chip Enable Controlled⁽¹⁾

s	Symbol		Parameter		M58LT256GT, M58LT256GB	Unit
		110				
	t _{AVAV}	t _{WC}	Address Valid to Next Address Valid	Min	110	ns
	t _{AVLH}		Address Valid to Latch Enable High	Min	11	ns
	t _{DVEH}	t _{DS}	Data Valid to Chip Enable High	Min	50	ns
sbu	t _{EHDX}	t _{DH}	Chip Enable High to Input Transition	Min	0	ns
-imi	t _{EHEL}	t _{WPH}	Chip Enable High to Chip Enable Low	Min	25	ns
led T	t _{EHWH}	t _{CH}	Chip Enable High to Write Enable High	p Enable High to Write Enable High Min		ns
ntrol	t _{ELEH}	t _{WP}	ip Enable Low to Chip Enable High Min		50	ns
Chip Enable Controlled Timings	t _{ELLH}		Chip Enable Low to Latch Enable High	nip Enable Low to Latch Enable High Min		ns
able	t _{ELQV}		Chip Enable Low to Output Valid (Status Register)	hip Enable Low to Output Valid (Status Register) Min		ns
p Er	t _{LHAX}		Latch Enable High to Address Transition	atch Enable High to Address Transition Min		ns
S	t _{LLLH}		Latch Enable Pulse Width	Min	11	ns
	t _{WHEL} ⁽²⁾		Write Enable High to Chip Enable Low	Min	25	ns
	t _{WHQV}		Write Enable High to Input Valid	Min	135	ns
	t _{WLEL}	t _{CS}	Write Enable Low to Chip Enable Low	Min	0	ns
sbu	t _{EHVPL}		Chip Enable High to V _{PP} Low	nip Enable High to V _{PP} Low Min		ns
Timi	t _{QVVPL}		Output (Status Register) Valid to V _{PP} Low	Min	0	ns
Protection -	Protection Total t		V _{PP} High to Chip Enable High	Min	200	ns

^{1.} Sampled only, not 100% tested.

Figure 17. Reset and Power-up AC waveforms



t_{WHEL} has the values shown when reading in the targeted bank. System designers should take this into account and may insert a software No-Op instruction to delay the first read in the same bank after issuing a command. If it is a Read Array operation in a different bank t_{WHEL} is 0ns.

Table 27. Reset and Power-up AC Characteristics

Symbol	Parameter	Test Condition		110	Unit
tour	Reset Low to	During Program	Min	25	μs
t _{PLWL} t _{PLEL}	Write Enable Low,	During Erase	Min	25	μs
t _{PLGL} Chip Enable Low, t _{PLGL} Output Enable Low, t _{PLLL} Latch Enable Low	Other Conditions	Min	80	ns	
t _{PHWL} t _{PHEL} t _{PHGL} t _{PHLL}	Reset High to Write Enable Low Chip Enable Low Output Enable Low Latch Enable Low		Min	30	ns
t _{PLPH} ⁽¹⁾⁽²⁾	RP Pulse Width		Min	50	ns
t _{VDHPH} (3)	Supply Voltages High to Reset High		Min	100	μs

^{1.} The device Reset is possible but not guaranteed if t_{PLPH} < 50ns.

^{2.} Sampled only, not 100% tested.

^{3.} It is important to assert $\overline{\text{RP}}$ in order to allow proper CPU initialization during Power-Up or Reset.

13 Package mechanical




Figure 18. TBGA64 10x13mm - 8x8 ball array, 1mm pitch, bottom view package outline


1. Drawing is not to scale.

Table 28. TBGA64 10x13mm - 8x8 active ball array, 1mm pitch, Package Mechanical Data

Cumbal		millimeters			inches		
Symbol	Тур	Min	Max	Тур	Min	Max	
А			1.200			0.0472	
A1	0.300	0.200	0.350	0.0118	0.0079	0.0138	
A2	0.800			0.0315			
b		0.350	0.500		0.0138	0.0197	
D	10.000	9.900	10.100	0.3937	0.3898	0.3976	
D1	7.000	_	-	0.2756	-	-	
ddd			0.100			0.0039	
е	1.000	_	_	0.0394	_	_	
E	13.000	12.900	13.100	0.5118	0.5079	0.5157	
E1	7.000	_	_	0.2756	-	-	
FD	1.500	_	_	0.0591	_	_	
FE	3.000	_	-	0.1181	-	-	
SD	0.500	_	_	0.0197	_	_	
SE	0.500	_	_	0.0197	_	_	

Part numbering 14

Ordering Information Scheme Table 29.



E = ECOPACK Package, Standard Packing

F = ECOPACK Package, Tape & Reel Packing

Devices are shipped from the factory with the memory content bits erased to '1'.

For a list of available options (Speed, Package, etc.) or for further information on any aspect of this device, please contact the ST Sales Office nearest to you.

70/101

Appendix A Block address tables

The following set of equations can be used to calculate a complete set of block addresses using the information contained in *Table 30*, *Table 31*, *Table 32*, *Table 33*, *Table 34* and *Table 35*.

To calculate the block base address from the block number:

First it is necessary to calculate the Bank Number and the Block Number Offset. This can be achieved using the following formulas:

```
Bank_Number = (Block_Number -3) / 16
Block Number Offset = Block Number -3 -(Bank Number x 16)
```

If Bank_Number = 0, the Block Base Address can be directly read from *Table 30* or *Table 33* (Parameter Bank Block Addresses) in the Block Number Offset row. Otherwise:

Block_Base_Address = Bank_Base_Address + Block_Base_Address_Offset

To calculate the bank and the block number from the block base address:

If the address is in the range of the Parameter Bank, the Bank Number is 0 and the Block Number can be directly read from *Table 30* or *Table 33* (Parameter Bank Block Addresses), in the row that corresponds to the address given. Otherwise, the Block Number can be calculated using the formulas below:

For the top configuration (M58LT256GT):

```
Block_Number = ((NOT \text{ address}) / 2^{16}) + 3
```

For the bottom configuration (M58LT256GB):

```
Block_Number = (address / 2^{16}) + 3
```

For both configurations the Bank Number and the Block Number Offset can be calculated using the following formulas:

```
Bank_Number = (Block_Number -3) / 16
Block_Number_Offset = Block_Number -3 -(Bank_Number x 16)
```

Table 30. M58LR256GT - Parameter Bank block addresses

Block Number	Size (KWords)	Address Range
0	16	FFC000-FFFFFF
1	16	FF8000-FFBFFF
2	16	FF4000-FF7FFF
3	16	FF0000-FF3FFF
4	64	FE0000-FEFFFF
5	64	FD0000-FDFFFF
6	64	FC0000-FCFFFF
7	64	FB0000-FBFFFF
8	64	FA0000-FAFFFF
9	64	F90000-F9FFFF
10	64	F80000-F8FFFF
11	64	F70000-F7FFFF
12	64	F60000-F6FFFF
13	64	F50000-F5FFFF
14	64	F40000-F4FFFF
15	64	F30000-F3FFFF
16	64	F20000-F2FFFF
17	64	F10000-F1FFFF
18	64	F00000-F0FFFF

Table 31. M58LR256GT - Main Bank base addresses

Bank Number	Block Numbers	Bank Base Address
1	19-34	E00000
2	35-50	D00000
3	51-66	C00000
4	67-82	B00000
5	83-98	A00000
6	99-114	900000
7	115-130	800000
8	131-146	700000
9	147-162	600000
10	163-178	500000
11	179-194	400000
12	195-210	300000
13	211-226	200000

Table 31. M58LR256GT - Main Bank base addresses (continued)

14	227-242	100000
15	243-258	000000

Table 32. M58LR256GT - Block Addresses in Main Banks⁽¹⁾

Block Number Offset	Block Base Address Offset
0	0F0000
1	0E0000
2	0D0000
3	0C0000
4	0B0000
5	0A0000
6	090000
7	080000
8	070000
9	060000
10	050000
11	040000
12	030000
13	020000
14	010000
15	000000

There are two Bank Regions: Bank Region 1 contains all the banks that are made up of main blocks only; Bank Region 2 contains the banks that are made up of the parameter and main blocks (Parameter Bank).

Table 33. M58LR256GB - Parameter Bank block addresses

Block Number	Size (KWords)	Address Range
18	64	0F0000-0FFFFF
17	64	0E0000-0EFFFF
16	64	0D0000-0DFFFF
15	64	0C0000-0CFFFF
14	64	0B0000-0BFFFF
13	64	0A0000-0AFFFF
12	64	090000-09FFFF
11	64	080000-08FFFF
10	64	070000-07FFFF
9	64	060000-06FFFF
8	64	050000-05FFFF
7	64	040000-04FFFF

Table 33. M58LR256GB - Parameter Bank block addresses (continued)

Block Number	Size (KWords)	Address Range
6	64	030000-03FFFF
5	64	020000-02FFFF
4	64	010000-01FFFF
3	16	00C000-00FFFF
2	16	008000-00BFFF
1	16	004000-007FFF
0	16	000000-003FFF

Table 34. M58LR256GB - Main Bank base addresses

Bank Number	Block Numbers	Bank Base Address
15	243-258	F00000
14	227-242	E00000
13	211-226	D00000
12	195-210	C00000
11	179-194	B00000
10	163-178	A00000
9	147-162	900000
8	131-146	800000
7	115-130	700000
6	99-114	600000
5	83-98	500000
4	67-82	400000
3	51-66	300000
2	35-50	200000
1	19-34	100000

Table 35. M58LR256GB - block addresses in Main Banks (1)

Block Number Offset	Block Base Address Offset
15	0F0000
14	0E0000
13	0D0000
12	0C0000
11	0B0000
10	0A0000
9	090000
8	080000

Table 35. M58LR256GB - block addresses in Main Banks (continued)⁽¹⁾

7	070000
6	060000
5	050000
4	040000
3	030000
2	020000
1	010000
0	000000

There are two Bank Regions: Bank Region 2 contains all the banks that are made up of main blocks only; Bank Region 1 contains the banks that are made up of the parameter and main blocks (Parameter Bank).

Appendix B Common Flash Interface

The Common Flash Interface is a JEDEC approved, standardized data structure that can be read from the Flash memory device. It allows a system software to query the device to determine various electrical and timing parameters, density information and functions supported by the memory. The system can interface easily with the device, enabling the software to upgrade itself when necessary.

When the Read CFI Query Command is issued the device enters CFI Query mode and the data structure is read from the memory. *Figure 36*, *Figure 37*, *Figure 38*, *Figure 39*, *Figure 40*, *Figure 41*, *Figure 42*, *Figure 43*, *Figure 44* and *Table 45* show the addresses used to retrieve the data. The Query data is always presented on the lowest order data outputs (DQ0-DQ7), the other outputs (DQ8-DQ15) are set to 0.

The CFI data structure also contains a security area where a 64 bit unique security number is written (see *Figure 4: Protection Register Memory Map*). This area can be accessed only in Read mode by the final user. It is impossible to change the security number after it has been written by ST. Issue a Read Array command to return to Read mode.

Table 36. Query Structure Overview⁽¹⁾

Offset	Sub-section Name	Description
000h	Reserved	Reserved for algorithm-specific information
010h	CFI Query Identification String	Command set ID and algorithm data offset
01Bh	System Interface Information	Device timing & voltage information
027h	Device Geometry Definition	Flash device layout
Р	Primary Algorithm-specific Extended Query table	Additional information specific to the Primary Algorithm (optional)
А	Alternate Algorithm-specific Extended Query table	Additional information specific to the Alternate Algorithm (optional)
080h	Security Code Area	Lock Protection Register Unique device Number and User Programmable OTP

The Flash memory display the CFI data structure when CFI Query command is issued. In this table are listed the main sub-sections detailed in *Table 37*, *Table 38*, *Table 39* and *Table 40*. Query data is always presented on the lowest order data outputs.

Table 37. CFI Query Identification String

Offset	Sub-section Name	Description	Value
000h	0020h	Manufacturer Code	ST
001h	8870h 8871h	Device Code	Top Bottom
002h	reserved	Reserved	
003h	DRC	Die Revision Code	
004h- 00Fh	reserved	Reserved	
010h	0051h		"Q"
011h	0052h	Query Unique ASCII String "QRY"	"R"
012h	0059h		"Y"
013h	0001h	Primary Algorithm Command Set and Control Interface	
014h	0000h	ID code 16 bit ID code defining a specific algorithm	
015h	offset = P = 000Ah	Address for Primary Algorithm extended Query table	p =
016h	0001h	(see Table 40)	10Ah
017h	0000h	Alternate Vendor Command Set and Control Interface ID	NA
018h	0000h	Code second vendor - specified algorithm supported	INA
019h	value = A = 0000h	Address for Alternate Algorithm extended Query table	NA
01Ah	0000h	Address for Alternate Algorithm extended Query table	INA

Table 38. CFI Query System Interface Information

Offset	Data	Description	Value
01Bh	0017h	V _{DD} Logic Supply Minimum Program/Erase or Write voltage bit 7 to 4 BCD value in volts bit 3 to 0 BCD value in 100 millivolts	1.7V
01Ch	0020h	V _{DD} Logic Supply Maximum Program/Erase or Write voltage bit 7 to 4 BCD value in volts bit 3 to 0 BCD value in 100 millivolts	2V
01Dh	0085h	V _{PP} [Programming] Supply Minimum Program/Erase voltage bit 7 to 4 HEX value in volts bit 3 to 0 BCD value in 100 millivolts	8.5V
01Eh	0095h	V _{PP} [Programming] Supply Maximum Program/Erase voltage bit 7 to 4 HEX value in volts bit 3 to 0 BCD value in 100 millivolts	9.5V
01Fh	0008h	Typical time-out per single byte/word program = 2 ⁿ μs	256µs
020h	0009h	Typical time-out for Buffer Program = 2 ⁿ μs	512µs
021h	000Ah	Typical time-out per individual block erase = 2 ⁿ ms	1s
022h	0000h	Typical time-out for full chip erase = 2 ⁿ ms	NA

Table 38. CFI Query System Interface Information (continued)

Offset	Data	Description	Value
023h	0001h	Maximum time-out for word program = 2 ⁿ times typical	512µs
024h	0001h	Maximum time-out for Buffer Program = 2 ⁿ times typical	1024µ s
025h	0002h	Maximum time-out per individual block erase = 2 ⁿ times typical	4s
026h	0000h	Maximum time-out for chip erase = 2 ⁿ times typical	NA

Table 39. Device Geometry Definition

(Offset	Data	Description	Value
	027h	0019h	Device Size = 2 ⁿ in number of bytes	32 MBytes
	028h 029h	0001h 0000h	Flash Device Interface Code description	x16 Async.
	02Ah 02Bh	0006h 0000h	Maximum number of bytes in multi-byte program or page = 2 ⁿ	64 Bytes
	02Ch	0002h	Number of identical sized erase block regions within the device bit 7 to $0 = x =$ number of Erase Block Regions	2
	02Dh 02Eh	00FEh 0000h	Erase Block Region 1 Information Number of identical-size erase blocks = 00FEh+1	255
ЭТ	02Fh 030h	0000h 0002h	Erase Block Region 1 Information Block size in Region 1 = 0200h * 256 Byte	128 KByte
M58LT256GT	031h 032h	0003h 0000h	Erase Block Region 2 Information Number of identical-size erase blocks = 0003h+1	4
M5	033h 034h	0080h 0000h	Erase Block Region 2 Information Block size in Region 2 = 0080h * 256 Byte	32 KByte
	035h 038h	Reserved	Reserved for future erase block region information	NA
	02Dh 02Eh	0003h 0000h	Erase Block Region 1 Information Number of identical-size erase block = 0003h+1	4
ЗВ	02Fh 030h	0080h 0000h	Erase Block Region 1 Information Block size in Region 1 = 0080h * 256 bytes	32 KBytes
M58LT256GB	031h 032h	00FEh 0000h	Erase Block Region 2 Information Number of identical-size erase block = 00FEh+1	255
M58	033h 034h	0000h 0002h	Erase Block Region 2 Information Block size in Region 2 = 0200h * 256 bytes	128 KBytes
	035h 038h	Reserved	Reserved for future erase block region information	NA

Table 40. Primary Algorithm-Specific Extended Query Table

Offset	Data	Description	Value
(P)h = 10Ah	0050h		"P"
	0052h	Primary Algorithm extended Query table unique ASCII string "PRI"	"R"
	0049h		" "
(P+3)h =10Dh	0031h	Major version number, ASCII	"1"
(P+4)h = 10Eh	0033h	Minor version number, ASCII	"3"
(P+5)h = 10Fh	00E6h	Extended Query table contents for Primary Algorithm. Address	
	0003h	(P+5)h contains less significant byte.	
(P+7)h = 111h (P+8)h = 112h	0000h	bit 0 Chip Erase supported(1 = Yes, 0 = No) bit 1 Erase Suspend supported(1 = Yes, 0 = No) bit 2 Program Suspend supported(1 = Yes, 0 = No) bit 3 Legacy Lock/Unlock supported(1 = Yes, 0 = No) bit 4 Queued Erase supported(1 = Yes, 0 = No) bit 5 Instant individual block locking supported(1 = Yes, 0 = No) bit 6 Protection bits supported(1 = Yes, 0 = No) bit 7 Page mode read supported(1 = Yes, 0 = No) bit 8 Synchronous read supported(1 = Yes, 0 = No) bit 9 Simultaneous operation supported(1 = Yes, 0 = No) bit 10 to 31 Reserved; undefined bits are '0'. If bit 31 is '1' then another 31 bit field of optional features follows at the end of the bit-30 field.	No Yes Yes No No Yes Yes Yes Yes
(P+9)h = 113h	0001h	Supported Functions after Suspend Read Array, Read Status Register and CFI Query bit 0 Program supported after Erase Suspend (1 = Yes, 0 = No) bit 7 to 1 Reserved; undefined bits are '0'	Yes
(P+A)h = 114h (P+B)h = 115h	0003h 0000h	Block Protect Status Defines which bits in the Block Status Register section of the Query are implemented. bit 0 Block protect Status Register Lock/Unlock bit active (1 = Yes, 0 = No)	Vac
		bit 15 to 1 Reserved for future use; undefined bits are '0'	Yes No
(P+C)h = 116h	0018h	V _{DD} Logic Supply Optimum Program/Erase voltage (highest performance) bit 7 to 4 HEX value in volts bit 3 to 0 BCD value in 100 mV	1.8V
(P+D)h = 117h	0090h	V _{PP} Supply Optimum Program/Erase voltage bit 7 to 4 HEX value in volts bit 3 to 0 BCD value in 100 mV	9V

Table 41. Protection Register Information

Offset	Data	Description	Value
(P+E)h = 118h	0002h	Number of protection register fields in JEDEC ID space. 0000h indicates that 256 fields are available.	2
(P+F)h = 119h	0080h		80h
(P+10)h = 11Ah	0000h	Protection Field 1: Protection Description Bits 0-7 Lower byte of protection register address	00h
(P+ 11)h = 11Bh	0003h	Bits 8-15 Upper byte of protection register address Bits 16-23 2 ⁿ bytes in factory pre-programmed region	8 Bytes
(P+12)h = 11Ch	0003h	Bits 24-31 2 ⁿ bytes in user programmable region	8 Bytes
(P+13)h = 11Dh	0089h		89h
(P+14)h = 11Eh	0000h		00h
(P+15)h = 11Fh	0000h	Protection Register 2: Protection Description	00h
(P+16)h = 120h	0000h	Bits 0-31 protection register address Bits 32-39 n number of factory programmed regions (lower byte)	00h
(P+17)h = 121h	0000h	Bits 40-47 n number of factory programmed regions (upper byte)	0
(P+18)h = 122h	0000h	Bits 48-55 2 ⁿ bytes in factory programmable region	0
(P+19)h = 123h	0000h	Bits 56-63 n number of user programmable regions (lower byte) Bits 64-71 n number of user programmable regions (upper byte) Bits 72-79 2 ⁿ bytes in user programmable region	0
(P+1A)h = 124h	0010h		16
(P+1B)h = 125h	0000h		0
(P+1C)h = 126h	0004h		16

Table 42. Burst Read Information

Offset	Data	Description	Value
(P+1D)h = 127h	0004h	Page-mode read capability bits 0-7 'n' such that 2 ⁿ HEX value represents the number of read- page bytes. See offset 0028h for device word width to determine page-mode data output width.	16 Bytes
(P+1E)h = 128h	0004h	Number of synchronous mode read configuration fields that follow.	4
(P+1F)h = 129h	0001h	Synchronous mode read capability configuration 1 bit 3-7 Reserved bit 0-2 'n' such that 2 ⁿ⁺¹ HEX value represents the maximum number of continuous synchronous reads when the device is configured for its maximum word width. A value of 07h indicates that the device is capable of continuous linear bursts that will output data until the internal burst counter reaches the end of the device's burstable address space. This field's 3-bit value can be written directly to the read configuration register bit 0-2 if the device is configured for its maximum word width. See offset 0028h for word width to determine the burst data output width.	4
(P+20)h = 12Ah	0002h	Synchronous mode read capability configuration 2	8

Table 42. Burst Read Information

Offset	Data	Description	Value
(P-21)h = 12Bh	0003h	Synchronous mode read capability configuration 3	16
(P+22)h = 12Ch	0007h	Synchronous mode read capability configuration 4	Cont.

Table 43. Bank and Erase Block Region Information⁽¹⁾⁽²⁾

Flash memor	ash memory (top) Flash memo (bottom)		•	Description
Offset	Data	Offset	Data	
(P+23)h = 12Dh	02h	(P+23)h = 12Dh	02h	Number of Bank Regions within the device

^{1.} The variable P is a pointer which is defined at CFI offset 015h.

^{2.} Bank Regions. There are two Bank Regions, see *Table 30*, *Table 31*, *Table 32*, *Table 33*, *Table 34* and *Table 35*.

Table 44. Bank and Erase Block Region 1 Information (1)(2)

Flash memory	(top)	Flash memo (bottom)	ry	Description
Offset	Data	Offset	Data	
(P+24)h = 12Eh	0Fh	(P+24)h = 12Eh	01h	Number of identical banks within Bank Region 1
(P+25)h = 12Fh	00h	(P+25)h = 12Fh	00h	
(P+26)h = 130h	11h	(P+26)h = 130h	11h	Number of program or erase operations allowed in Bank Region 1: Bits 0-3: Number of simultaneous program operations Bits 4-7: Number of simultaneous erase operations
(P+27)h = 131h	00h	(P+27)h = 131h	00h	Number of program or erase operations allowed in other banks while a bank in same region is programming Bits 0-3: Number of simultaneous program operations Bits 4-7: Number of simultaneous erase operations
(P+28)h = 132h	00h	(P+28)h = 132h	00h	Number of program or erase operations allowed in other banks while a bank in this region is erasing Bits 0-3: Number of simultaneous program operations Bits 4-7: Number of simultaneous erase operations
(P+29)h = 133h	01h	(P+29)h = 133h	02h	Types of erase block regions in Bank Region 1 n = number of erase block regions with contiguous same-size erase blocks. Symmetrically blocked banks have one blocking region ⁽²⁾ .
(P+2A)h = 134h	0Fh	(P+2A)h = 134h	03h	Bank Region 1 Erase Block Type 1 Information
(P+2B)h = 135h	00h	(P+2B)h = 135h	00h	Bits 0-15: n+1 = number of identical-sized erase blocks in each bank
(P+2C)h = 136h	00h	(P+2C)h = 136h	80h	Bits 16-31: nx256 = number of bytes in erase block
(P+2D)h = 137h	02h	(P+2D)h = 137h	00h	region
(P+2E)h = 138h	64h	(P+2E)h = 138h	64h	Bank Region 1 (Erase Block Type 1)
(P+2F)h = 139h	00h	(P+2F)h = 139h	00h	Minimum block erase cycles x 1000
(P+30)h = 13Ah	02h	(P+30)h = 13Ah	02h	Bank Region 1 (Erase Block Type 1): Blts per cell, internal ECC Bits 0-3: bits per cell in erase region Bit 4: reserved for "internal ECC used" Blts 5-7: reserved
(P+31)h = 13Bh	03h	(P+31)h = 13Bh	03h	Bank Region 1 (Erase Block Type 1): Page mode and Synchronous mode capabilities Bit 0: Page-mode reads permitted Bit 1: Synchronous reads permitted Bit 2: Synchronous writes permitted Bits 3-7: reserved

Table 44. Bank and Erase Block Region 1 Information (continued)⁽¹⁾⁽²⁾

Flash memory	(top)	Flash memo (bottom)	ory	Description
Offset	Data	Offset	Data	
		(P+32)h = 13Ch	0Eh	Bank Region 1 Erase Block Type 2 Information
		(P+33)h = 13Dh	00h	Bits 0-15: n+1 = number of identical-sized
		(P+34)h = 13Eh	00h	erase blocks in each bank Bits 16-31: nx256 = number of bytes in erase block
		(P+35)h = 13Fh	02h	region
		(P+36)h = 140h	64h	Bank Region 1 (Erase Block Type 2)
		(P+37)h = 141h	00h	Minimum block erase cycles × 1000
		(P+38)h = 142h	02h	Bank Regions 1 (Erase Block Type 2): Blts per cell, internal ECC Bits 0-3: bits per cell in erase region Bit 4: reserved for "internal ECC used" Blts 5-7: reserved
		(P+39)h = 143h	03h	Bank Region 1 (Erase Block Type 2): Page mode and Synchronous mode capabilities Bit 0: Page-mode reads permitted Bit 1: Synchronous reads permitted Bit 2: Synchronous writes permitted Bits 3-7: reserved

^{1.} The variable P is a pointer which is defined at CFI offset 015h.

^{2.} Bank Regions. There are two Bank Regions, see *Table 30*, *Table 31*, *Table 32*, *Table 33*, *Table 34* and *Table 35*.

Table 45. Bank and Erase Block Region 2 Information (1)(2)

Flash memory	(top)	Flash memo (bottom)	ry	Description
Offset	Data	Offset	Data	
(P+32)h = 13Ch	01h	(P+3A)h = 144h	0Fh	Number of identical banks within bank region 2
(P+33)h = 13Dh	00h	(P+3B)h = 145h	00h	Number of identical banks within bank region 2
(P+34)h = 13Eh	11h	(P+3C)h = 146h	11h	Number of program or erase operations allowed in Bank Region 2: Bits 0-3: Number of simultaneous program operations Bits 4-7: Number of simultaneous erase operations
(P+35)h = 13Fh	00h	(P+3D)h = 147h	00h	Number of program or erase operations allowed in other banks while a bank in this region is programming Bits 0-3: Number of simultaneous program operations Bits 4-7: Number of simultaneous erase operations
(P+36)h = 140h	00h	(P+3E)h = 148h	00h	Number of program or erase operations allowed in other banks while a bank in this region is erasing Bits 0-3: Number of simultaneous program operations Bits 4-7: Number of simultaneous erase operations
(P+37)h = 141h	02h	(P+3F)h = 149h	01h	Types of erase block regions in Bank Region 2 n = number of erase block regions with contiguous same-size erase blocks. Symmetrically blocked banks have one blocking region. (2)
(P+38)h = 142h	0Eh	(P+40)h = 14Ah	0Fh	Bank Region 2 Erase Block Type 1 Information
(P+39)h = 143h	00h	(P+41)h = 14Bh	00h	Bits 0-15: n+1 = number of identical-sized erase
(P+3A)h = 144h	00h	(P+42)h = 14Ch	00h	Bits 16-31: nx256 = number of bytes in erase block
(P+3B)h = 145h	02h	(P+43)h = 14Dh	02h	region
(P+3C)h = 146h	64h	(P+44)h = 14Eh	64h	Bank Region 2 (Erase Block Type 1)
(P+3D)h = 147h	00h	(P+45)h = 14Fh	00h	Minimum block erase cycles × 1000
(P+3E)h = 148h	02h	(P+46)h = 150h	02h	Bank Region 2 (Erase Block Type 1): Blts per cell, internal ECC Bits 0-3: bits per cell in erase region Bit 4: reserved for "internal ECC used" Blts 5-7: reserved

Table 45. Bank and Erase Block Region 2 Information (continued)(1)(2)


Table 45. Bai		Flash memo		12 Information (continued)
Flash memory	(top)	(bottom)	ry	Description
Offset	Data	Offset	Data	·
(P+3F)h = 149h	03h	(P+47)h = 151h	03h	Bank Region 2 (Erase Block Type 1):Page mode and Synchronous mode capabilities (defined in <i>Table 42</i>) Bit 0: Page-mode reads permitted Bit 1: Synchronous reads permitted Bit 2: Synchronous writes permitted Bits 3-7: reserved
(P+40)h = 14Ah	03h			Bank Region 2 Erase Block Type 2 Information
(P+41)h = 14Bh	00h			Bits 0-15: n+1 = number of identical-sized erase blocks in each bank
(P+42)h = 14Ch	80h			Bits 16-31: n×256 = number of bytes in erase block
(P+43)h = 14Dh	00h			region
(P+44)h =14Eh	64h			Bank Region 2 (Erase Block Type 2)
(P+45)h = 14Fh	00h			Minimum block erase cycles × 1000
(P+46)h = 150h	02h			Bank Region 2 (Erase Block Type 2): Blts per cell, internal ECC Bits 0-3: bits per cell in erase region Bit 4: reserved for "internal ECC used" Blts 5-7: reserved
(P+47)h = 151h	03h			Bank Region 2 (Erase Block Type 2): Page mode and Synchronous mode capabilities (defined in <i>Table 42</i>) Bit 0: Page-mode reads permitted Bit 1: Synchronous reads permitted Bit 2: Synchronous writes permitted Bits 3-7: reserved
(P+48)h = 152h		(P+48)h = 152h		Feature Space definitions
(P+49)h = 153h		(P+43)h = 153h		Reserved

^{1.} The variable P is a pointer which is defined at CFI offset 015h.

^{2.} Bank Regions. There are two Bank Regions, see *Table 30*, *Table 31*, *Table 32*, *Table 33*, *Table 34* and *Table 35*.


Appendix C Flowcharts and pseudo codes

Figure 19. Program flowchart and pseudo code



- Status check of SR1 (Protected Block), SR3 (V_{PP} Invalid) and SR4 (Program Error) can be made after each program operation or after a sequence.
- 2. If an error is found, the Status Register must be cleared before further Program/Erase Controller operations.
- 3. Any address within the bank can equally be used.

Figure 20. Buffer Program flowchart and pseudo code



- 1. n + 1 is the number of data being programmed.
- Next Program data is an element belonging to buffer_Program[].data; Next Program address is an element belonging to buffer_Program[].address.
- 3. Routine for Error Check by reading SR3, SR4 and SR1.

57

Figure 21. Program Suspend & Resume flowchart and pseudo code





Figure 22. Block Erase flowchart and pseudo code



- 1. If an error is found, the Status Register must be cleared before further Program/Erase operations.
- 2. Any address within the bank can equally be used.

577

Figure 23. Erase Suspend & Resume flowchart and pseudo code





Figure 24. Locking operations flowchart and pseudo code



1. Any address within the bank can equally be used.

5





Figure 25. Protection Register Program flowchart and pseudo code

- Status check of SR1 (Protected Block), SR3 (V_{PP} Invalid) and SR4 (Program Error) can be made after each program operation or after a sequence.
- 2. If an error is found, the Status Register must be cleared before further Program/Erase Controller operations.
- 3. Any address within the bank can equally be used.

Figure 26. Buffer Enhanced Factory Program Flowchart and Pseudo Code



Appendix D Command Interface state tables

Table 46. Command Interface States - Modify Table, Next State⁽¹⁾

						Co	ommand Input				
Current	CI State	Read Array (FFh) ⁽²⁾	Program Setup (10/40h) (3)(4)	Buffer Program (E8h) (3)(4)	Block Erase, Setup (20h)	BEFP Setup (80h)	Erase Confirm, P/E Resume, Block Unlock Confirm, BEFP Confirm (D0h) ⁽³⁾⁽⁴⁾	Buffer Program, Program/ Erase Suspend (B0h)	Read Status Register (70h)	Clear status Register (50h) ⁽⁵⁾	Read Electronic Signature, Read CFI Query (90h, 98h)
Re	Ready Ready			Buffer Program Setup	Erase Setup	BEFP Setup		F	Ready		
Lock/C	R Setup		Read	ly (Lock Erro	or)		Ready (unlock block)		Ready (L	ock Error)	
ОТР	Setup						OTP Busy				
	Busy										
	Setup					F	Program Busy				
Program	Busy			Prog	ram Busy			Program Suspend		Program Bu	ısy
	Suspend		Prog	ram Susper	nd		Program Busy		Program	Suspend	
	Setup		Buffer Program Load 1 (give word count load (N-1));								
	Buffer Load 1		if N=0 go	to Buffer P	rogram Co	onfirm. El	se (N not =0) go to	Buffer Progra	nm Load 2 (data load)	
Buffer	Buffer Load 2		(note: Bu				en count =0; Else B if any block addres			t address)	
Program	Confirm		Re	eady (error)			Buffer Program Busy	Ready (error)			
	Busy			Buffer P	rogram Bu	sy		Buffer Program Suspend	Buf	fer Program	n Busy
	Suspend		Buffer P	rogram Sus	pend		Buffer Program Busy	E	Buffer Progr	am Susper	d
	Setup		Re	eady (error)			Erase Busy		Ready	(error)	
Erase	Busy			Era	se Busy			Erase Suspend		Erase Bus	y
Lidos	Suspend	Erase Suspend	Program in Erase Suspend	Buffer Program Setup Suspend	Erase S	Suspend	Erase Busy		Erase S	Suspend	
	Setup					Program E	Busy in Erase Susp	end			
Program in Erase Suspend	Busy		Pro	ogram Busy	in Erase S	Suspend		Program Suspend in Erase Suspend	Program	Busy in Era	se Suspend
	Suspend	Р	rogram Susp	pend in Eras	se Suspen	d	Program Busy in Erase Suspend	Progra	m Suspend	in Erase S	uspend

Table 46. Command Interface States - Modify Table, Next State⁽¹⁾ (continued)

					,	,	HOXI Olate	(00111111	,			
						Co	mmand Input					
Current CI State		Read Array (FFh) ⁽²⁾	Program Setup (10/40h) (3)(4)	Buffer Program (E8h) (3)(4)	Block Erase, Setup (20h) (3)(4)	BEFP Setup (80h)	Erase Confirm, P/E Resume, Block Unlock Confirm, BEFP Confirm (D0h)(3)(4)	Buffer Program, Program/ Erase Suspend (B0h)	Read Status Register (70h)	Clear status Register (50h) ⁽⁵⁾	Read Electronic Signature, Read CFI Query (90h, 98h)	
	Setup	Buffer Pro	gram Load 1	in Erase Su	uspend (giv		unt load (N-1)); if Na Iffer Program Load		er Program	confirm. Els	e (N not =0)	
	Buffer Load 1				Buffer Pro	gram Load	d 2 in Erase Susper	nd (data load))			
	Buffer Load 2	Buffer P	Buffer Program Confirm in Erase Suspend when count =0; Else Buffer Program Load 2 in Erase Suspend (note: Buffer Program will fail at this point if any block address is different from the first address)									
Buffer Program in Erase Suspend	Confirm		Re	eady (error)			Buffer Program Busy in Erase Suspend		Ready	(error)		
	Busy		Buffer	Program B	usy in Eras	se Suspen	d	Buffer Program Suspend in Erase Suspend	Buffer P	rogram Busy in Erase Suspend		
	Suspend	Buffe	er Program S	uspend in E	Erase Susp	end	Buffer Program Busy in Erase Suspend	Buffer Pro	gram Suspe	end in Eras	e Suspend	
	Lock/CR Setup Erase Suspend Erase Suspend (Lock Error) Erase Suspend Erase Suspend (Lock Error)						or)					
Buffer	Setup		Re	eady (error)			BEFP Busy		Ready	(error)		
EFP	Busy		-			E	BEFP Busy ⁽⁶⁾	-			_	

CI = Command Interface, CR = Configuration Register, BEFP = Buffer Enhanced Factory Program, P/E. C. = Program/Erase Controller.

- 2. At Power-Up, all banks are in Read Array mode. Issuing a Read Array command to a busy bank, results in undetermined data output.
- 3. The two cycle command should be issued to the same bank address.
- 4. If the P/E.C. is active, both cycles are ignored.
- 5. The Clear Status Register command clears the Status Register error bits except when the P/E.C. is busy or suspended.
- BEFP is allowed only when Status Register bit SR0 is set to '0'. BEFP is busy if Block Address is first BEFP Address. Any other commands are treated as data.

Table 47. Command Interface States - Modify Table, Next Output⁽¹⁾⁽²⁾

Table 47. Command						mand Input						
Current CI State	Read Array (FFh) ⁽³⁾	Program Setup (10/40h) (4)(5)	Buffer Program (E8h)	Block Erase, Setup (20h) (4)(5)	BEFP Setup (80h)	Erase Confirm, P/E Resume, Block Unlock Confirm, BEFP Confirm (D0h) ⁽⁴⁾⁽⁵⁾	Program /Erase Suspend (B0h)	Read Status Register (70h)	Clear status Register (50h)	Read Electronic signature, Read CFI Query (90h, 98h)		
Program Setup		•	Į.		u.		ľ		•			
Erase Setup												
OTP Setup												
Program in Erase Suspend												
BEFP Setup												
BEFP Busy]											
Buffer Program Setup]											
Buffer Program Load 1												
Buffer Program Load 2												
Buffer Program Confirm		Status Register										
Buffer Program Setup in Erase Suspend												
Buffer Program Load 1 in Erase Suspend												
Buffer Program Load 2 in Erase Suspend												
Buffer Program Confirm in Erase Suspend												
Lock/CR Setup												
Lock/CR Setup in Erase Suspend												
OTP Busy										Status Register		
Ready												
Program Busy												
Erase Busy												
Buffer Program Busy												
Program/Erase Suspend								Status	Output			
Buffer Program Suspend	Array		Status Re	egister		Output Ur	nchanged	Register	Unchanged	Electronic Signature/		
Program Busy in Erase Suspend										CFI		
Buffer Program Busy in Erase Suspend												
Program Suspend in Erase Suspend												
Buffer Program Suspend in Erase Suspend												

- The output state shows the type of data that appears at the outputs if the bank address is the same as the command address. A bank can be placed in Read Array, Read Status Register, Read Electronic Signature or Read CFI mode, depending on the command issued. Each bank remains in its last output state until a new command is issued to that bank. The next state does not depend on the bank output state.
- 2. CI = Command Interface, CR = Configuration Register, BEFP = Buffer Enhanced Factory Program, P/E. C. = Program/Erase Controller.
- 3. At Power-Up, all banks are in Read Array mode. Issuing a Read Array command to a busy bank, results in undetermined data output.
- 4. The two cycle command should be issued to the same bank address.
- 5. If the P/E.C. is active, both cycles are ignored.

Table 48. Command Interface States - Lock Table, Next State (1)

				C	Command Inpu	ıt				
Current (CI State	Lock/CR Setup (60h) ⁽²⁾	Setup OTP Setup Confirm Confirm Command							
Rea	dy	Lock/CR Setup	OTP Setup		Ready					
Lock/CR	Setup	Ready (L	ock error)	Rea	ady	Ready (L	ock error)	N/A		
ОТР	Setup			OTP	Rusy			N/A		
OIF	Busy			OIF	busy			Ready		
	Setup			Progran	m Busy			N/A		
Program	Busy	Program Busy								
	Suspend	Program Suspend								
	Setup		Buffer Pro	gram Load 1 (gi	ve word count l	oad (N-1));		N/A		
	Buffer Load 1	Buffer Program Load 2 ⁽⁵⁾ Exit ⁽⁵⁾								
Buffer Program	Buffer Load 2	Buffer Program Confirm when count =0; Else Buffer Program Load 2 (note: Buffer Program will fail at this point if any block address is different from the first address)								
	Confirm	Ready (error)								
	Busy			Buffer Pro	gram Busy			Ready		
	Suspend			Buffer Progra	am Suspend			N/A		
	Setup			Ready	(error)			N/A		
F	Busy			Erase	Busy			Ready		
Erase	Suspend	Lock/CR Setup in Erase Suspend			Erase Suspend	ı		N/A		

Table 48. Command Interface States - Lock Table, Next State (continued)⁽¹⁾ (continued)

		Command Input									
Current (CI State	Lock/CR Setup (60h) ⁽²⁾	OTP Setup (C0h) ⁽²⁾	Block Lock Confirm (01h)	Set CR Confirm (03h)	Block Address (WA0) (XXXXh) ⁽³⁾	Illegal Command (4)	WSM Operation Completed			
	Setup		F	Program Busy in	Erase Suspen	d		N/A			
Program in Erase Suspend	Busy		F	rogram Busy in	Erase Suspen	d		Erase Suspend			
	Suspend		Program Suspend in Erase Suspend								
	Setup	Buffe									
	Buffer Load 1										
Buffer Program in Erase Suspend	Buffer Load 2	Buffer Prograr Erase Susper	N/A								
Liado Gaspona	Confirm	Ready (error)									
	Busy	Buffer Program Busy in Erase Suspend									
	Suspend	Buffer Program Suspend in Erase Suspend									
Lock/CR in Erase S	•	Erase Suspend (Lock error) Erase Suspend (Lock error)					•	N/A			
	Setup	Ready (error)									
BEFP	Busy		BEFP	Busy ⁽⁷⁾		Exit	BEFP Busy ⁽⁷⁾	N/A			

CI = Command Interface, CR = Configuration Register, BEFP = Buffer Enhanced Factory Program, P/E. C. = Program/Erase Controller, WA0 = Address in a block different from first BEFP address.

- 3. BEFP Exit when Block Address is different from first Block Address and data are FFFFh.
- 4. Illegal commands are those not defined in the command set.
- 5. if N=0 go to Buffer Program Confirm. Else (N ≠ 0) go to Buffer Program Load 2 (data load).
- 6. if N=0 go to Buffer Program Confirm in Erase Suspend. Else (N ≠ 0) go to Buffer Program Load 2 in Erase Suspend.
- 7. BEFP is allowed only when Status Register bit SR0 is set to '0'. BEFP is busy if Block Address is first BEFP Address. Any other commands are treated as data.

^{2.} If the P/E.C. is active, both cycles are ignored.

Table 49. Command Interface States - Lock Table, Next Output⁽¹⁾⁽²⁾

Table 49. Command Inte				Command Inp							
Current CI State	Lock/CR Setup(60h)	OTP Setup (C0h) ⁽³⁾	Block Lock Confirm (01h)	Set CR Confirm (03h)	BEFP Exit (FFFFh) ⁽⁴⁾	Illegal Command ⁽⁵⁾	WSM Operation Completed				
Program Setup											
Erase Setup											
OTP Setup											
Program in Erase Suspend											
BEFP Setup											
BEFP Busy											
Buffer Program Setup											
Buffer Program Load 1											
Buffer Program Load 2		Status Register									
Buffer Program Confirm											
Buffer Program Setup in Erase Suspend											
Buffer Program Load 1 in Erase Suspend											
Buffer Program Load 2 in Erase Suspend											
Buffer Program Confirm in Erase Suspend							Output Unchanged				
Lock/CR Setup		Status Register	r	Array	Status	Register					
Lock/CR Setup in Erase Suspend			•	Allay	Status	· · · · · · · · · · · · · · · · · · ·					
OTP Busy											
Ready											
Program Busy											
Erase Busy											
Buffer Program Busy											
Program/Erase Suspend	Status					Output					
Buffer Program Suspend	Register Output Unchanged Array Unchanged										
Program Busy in Erase Suspend											
Buffer Program in Erase Suspend Busy											
Program Suspend in Erase Suspend											
Buffer Program Suspend in Erase Suspend											

- The output state shows the type of data that appears at the outputs if the bank address is the same as the command address. A bank can be placed in Read Array, Read Status Register, Read Electronic Signature or Read CFI mode, depending on the command issued. Each bank remains in its last output state until a new command is issued to that bank. The next state does not depend on the bank's output state.
- 2. CI = Command Interface, CR = Configuration Register, BEFP = Buffer Enhanced Factory Program, P/E. C. = Program/Erase Controller, WA0 = Address in a block different from first BEFP address.
- 3. If the P/E.C. is active, both cycles are ignored.
- 4. BEFP Exit when Block Address is different from first Block Address and data are FFFFh.
- 5. Illegal commands are those not defined in the command set.

15 Revision history

Table 50. Document Revision History

Date	Version	Revision Details
16-Dec-2005	1	First issue. (see Technical Note TNFL0019 for the full revision history)

Information furnished is believed to be accurate and reliable. However, STMicroelectronics assumes no responsibility for the consequences of use of such information nor for any infringement of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent or patent rights of STMicroelectronics. Specifications mentioned in this publication are subject to change without notice. This publication supersedes and replaces all information previously supplied. STMicroelectronics products are not authorized for use as critical components in life support devices or systems without express written approval of STMicroelectronics.

The ST logo is a registered trademark of STMicroelectronics. All other names are the property of their respective owners

STMicroelectronics group of companies

Australia - Belgium - Brazil - Canada - China - Czech Republic - Finland - France - Germany - Hong Kong - India - Israel - Italy - Japan - Malaysia - Malta - Morocco - Singapore - Spain - Sweden - Switzerland - United Kingdom - United States of America

www.st.com

47/

DocRev1 101/101