

RF-TCA8418-MVK MAVRK Module

User's Guide



Literature Number: SLAU383
December 2011

1	EVM Overview	5
1.1	EVM Description	5
1.2	Highlighted Products	5
1.3	Block Diagram	6
1.4	EVM Wiki	6
1.5	EVM Landing Page	6
2	Hardware Description	7
2.1	Power Requirements	7
2.2	Getting Started: Configuring the EVM	7
2.3	EVM Connectors, Fuses, and Switches	9
2.4	EVM Test Points	11
2.5	EVM LEDs	11
3	Software Description	12
3.1	MAVRK Software Minimum Requirements	12
3.2	How to get the MAVRK Software	12
3.3	Where do I find the MAVRK Qt Demo Application?	12
3.4	Where do I find the Demo and Test Code?	12
4	Board Files	13
4.1	Bill of Materials (BOM)	13
4.2	Layout (PDF)	13
4.3	Schematics (PDF)	14
4.4	Fabrication Drawings (PDF)	14
4.5	Request Gerber and Schematic files	14
5	MAVRK Links	15
5.1	I want more info on MAVRK	15
5.2	I have MAVRK Questions	15
5.3	I want more Technical Info on MAVRK Hardware	15
5.4	I want more Technical Info on MAVRK Software	15
5.5	I want to get a MAVRK board	15
6	Important Notices	16
6.1	ESD Precautions	16
6.2	Certifications	16
6.3	Evaluation Board/Kit/Module (EVM) Additional Terms	16
6.4	United States FCC and Canada IC Regulatory Compliance Information	17
6.5	Evaluation Board/Kit/Module (EVM) Warnings, Restrictions, and Disclaimers	17
6.5.1	Your Sole Responsibility and Risk	17
6.5.2	Certain Instructions	17
6.5.3	Agreement to Defend, Indemnify and Hold Harmless	18
6.5.4	Safety-Critical or Life-Critical Applications	18

RF-TCA8418-MVK MAVRK Module

This document goes into the details of the RF-TCA8418-MVK board. It includes information about how the module functions and how to use the board. Schematics and layout documentation are also included.

1 EVM Overview

The RF-TCA8418-MVK module provides I2C access to a keypad and joystick with select. The module is compatible with any Modular and Versatile Reference Kit (MAVRK) [motherboard](#) with an open [RF](#) slot. The RF slot is designed for communications and as an input interface between the MAVRK motherboard and a PC, external components, or users. This module connects to the motherboard's RF port. For a full list of RF pinouts with description please see the [RF Pinout for MAVRK](#) wiki page.

1.1 EVM Description




Figure 1. RF-TCA8418-MVK MAVRK Module

The RF-TCA8418-MVK Module provides row/column scanning of:

- Twelve (12) switch keypad with press and release detect.
- A four (4) position joystick (Up, Down, Right, Left) plus a *push to select* function.

TCA8418 features highlighted by this MAVRK module include:

- Last ten (10) keystroke storage.
- Keylock and Unlock functionality.

1.2 Highlighted Products

- [TCA8418 I2C Controlled Keypad Scan IC](#)
- [TS5A2066 Dual-Channel 10-Ohm SPST Analog Switch](#)

1.3 Block Diagram




Figure 2. A block diagram of the RF-TCA8418-MVK MAVRK Module

1.4 EVM Wiki

[RF-TCA8418-MVK MAVRK Module wiki page](#)

1.5 EVM Landing Page

[RF-TCA8418-MVK MAVRK Module tool folder](#)

2 Hardware Description

2.1 Power Requirements

3.3V DC is supplied to the RF-TCA8418-MVK through the [RF Connector](#) (RF2, pin 9). The RF-TCA8418-MVK module can operate over the voltage range of 1.65V to 3.65V DC with a typical current draw of less than 1mA.

2.2 Getting Started: Configuring the EVM

Configuring the RF-TCA8418-MVK EVM is as simple as installing it into one (1) of the RF slots on a motherboard, such as the [MAVRK Pro Motherboard](#).





Figure 3. RF-TCA8418-MVK Module on the MAVRK Pro Motherboard

Note: Most demos and test routines use MAVRK_RF1, but any of the RF slots can be used as long as the changes are noted in the #define of the software. For example, in the TCA8418 demo project, the RIGHT and LEFT are #defined to the MAVRK_RF3 and MAVRK_RF4 slots.




```

74 /*****
75 *
76 * Definitions
77 *****/
78 #define RIGHT    MAVRK_RF3
79 #define LEFT     MAVRK_RF4
80 /*****
81 *
82 * Prototypes
83 *****/
84 /*****
85 *
86 * Global Variables
87 *****/
88 // We will allocate 3 PC communication packets for this test. One will be used to send TCA8418 data, one will be used to ACK PC commands,
89 // and one will be used to receive commands from the PC. Note that we could have re-used a packet for the
90 // ACKs in order to save memory.
91 PC_Interface_Packet_type  PcrvPacket;

```

Figure 4. TCA8418 RF Slots Defined in the C Code

These definitions are used further in the code for initialization of the module and later for the checking for a key press for that module.



```

125 /*****
126 *
127 * Initialize TCA8418 Component
128 *****/
129 // Right is defined in the Definitions section of this file
130 mvk_Initialize_Keyboard (RIGHT);
131 // For Demo's requiring a second keyboard remove comments on the line below
132 mvk_Initialize_Keyboard (LEFT);
133 /*****
134 *
135 * Use for testing the PC Interface from MAVRK TCA8418 board to a host PC
136 *****/
137 // mvk_Send_TCA8418_Test_Packet(TCA8418_Packet_Data, TCA8418_DEVICE_SLOT, 1); // send one set of test packets
138 /*****
139 *
140 * #ifdef DEBUG
141 * // This call is necessary to enable any devices using the GPIOs on the AFE slots. It is used in DEBUG mode to light
142 * mvk_Enable_AFE_Latched_GPIOs (); // Enable the AFE Latched GPIO to start output of data
143 * #endif
144 *****/
145 /*****
146 *
147 * main.c - Background Tasks
148 *****/
149 mvk_UART_Debug_Printf_Flush ("\033[2J", 4);
150 mvk_UART_Debug_Printf_Flush ("\r\nTCA8418-MVK Demo\r\n", 20);
151 mvk_UART_Debug_Printf_Flush ("\r\nMAVRK packets and terminal messages will be provided for", 58);
152 mvk_UART_Debug_Printf_Flush ("\r\nEach press and release of keys.\r\n\r\n", 37);
153 while (1)
154 {
155     idle_count++; // Idle Count is incremented every time
156     if (mvk_Is_User_Button_Pushed ())
157     {
158         mvk_Toggle_MCU_LED (MCU_YELLOW);
159         mvk_Clear_User_Button_Status ();
160     }
161     // Is there a keypress and TCA8418 data ready to send to the PC?
162     if (TCA8418_DATA_AVAILABLE == mvk_Check_and_Process_Key_Press (RIGHT)) // Send current key events to the PC Interface
163     {
164         mvk_Toggle_MCU_LED (MCU_YELLOW);
165         idle_count = 0;
166     }
167 }

```

Figure 5. TCA8418 RF Slot Definitions Used as C Code Variable Names

The default slots of MAVRK_RF3 and MAVRK_RF4 from the demo can be easily changed to, for example, MAVRK_RF1 and MAVRK_RF2 by simply changing the RIGHT (#define RIGHT MAVRK_RF1) and LEFT (#define LEFT MAVRK_RF2).

2.3 EVM Connectors, Fuses, and Switches

The RF-TCA8418-MVK EVM has two connectors on the back side of the module that connect it to an RF slot on a motherboard like the [MAVRK Pro Motherboard](#). For a full list of RF pinouts with description please see the [RF Pinout for MAVRK](#) wiki page.



Figure 6. Back side of the RF-TCA8418-MVK MAVRK Module, showing the RF connectors

The RF-TCA8418-MVK EVM consists of twelve (12) momentary switch push buttons and one (1) 8 position navigation switch with a *push to select* function. The function of 11 of the momentary switches is defined by the 12th switch, the SHIFT switch.

The primary functions (SHIFT disabled) are shown below:




Figure 7. Functions of the keys while SHIFT is disabled

The SHIFT Lock functions (SHIFT enabled) are shown below:




Figure 8. Functions of the keys while SHIFT is enabled

2.4 EVM Test Points

Due to the simple nature of the RF-TCA8418-MVK, the EVM has no test points. The polling of the I2C lines can be done by utilizing an [RF Breakout module](#) in the RF slot adjacent to the slot containing the RF-TCA8418-MVK.

2.5 EVM LEDs

The RF-TCA8418-MVK Module has 3 LEDs:

- A green LED signifying a Shift-Lock function
- An orange LED signifying a Key-Lock function
- A user defined yellow LED




Figure 9. Map of LEDs on the RF-TCA8418-MVK MAVRK Module

3 Software Description

3.1 MAVRK Software Minimum Requirements

- [IAR Embedded Workbench](#) software or [TI Code Composer Studio](#) software installed on PC
- [MSP-FET430UIF - MSP430 USB Debugging Interface](#)
- USB Cable(A to Micro AB) to power the MAVRK Pro motherboard
- Windows XP SP3 or Windows 7

3.2 How to get the MAVRK Software

You will need the MAVRK Software repository installed on your PC. This repository will sync the MAVRK firmware to your PC.

Please see [Software Installation Guide](#).

3.3 Where do I find the MAVRK Qt Demo Application?

An application to visual packet information from the embedded system can be found in the **mavrk_qt_tool** software repository under the **Released Version - QT Demo Application** directory. Please see [Software Installation Guide](#) for instructions on cloning the QT Tool project.

If you desire to create your own Qt demonstration, please reference the following resources:

- [MAVRK Qt GUI SDK Installation Guide](#)
- [MAVRK Qt GUI Build Guide](#)

3.4 Where do I find the Demo and Test Code?

From the software library, synchronized from the Gerrit server you will find:

- Driver code related to the specific part can be found in a folder under the **mavrk_embedded\Modular_EVM_Libraries\Components** directory.
- Projects utilizing this part are located under the **mavrk_embedded\Modular_EVM_Projects** folder.
- Specific related projects for this part are:

Please refer to the links below for instructions on running a demo application with the TCA8418.

- [Running the TCA8418 Demo on CCS](#)
- [Running the TCA8418 Demo on IAR](#)

5 MAVRK Links

5.1 I want more info on MAVRK

[MAVRK Home Page](#)

5.2 I have MAVRK Questions

[MAVRK Forum](#) (Recommended):

5.3 I want more Technical Info on MAVRK Hardware

• Hardware Design Guide for MAVRK MCU Modules • Hardware Design Guide for MAVRK Modules • Hardware Design Guide for MAVRK PMU Charger Sub-Modules • Hardware Design Guide for MAVRK PMU DC/DC Sub-Modules	• Hardware Design Guide for MAVRK PMU Gas Gauge Sub-Modules • Hardware Design Guide for MAVRK PMU High-Power DC/DC Sub-Modules • Hardware Design Guide for MAVRK SCI Modules • Hardware Design Guide for MAVRK SCI Sub-Modules	• Hardware Design Guide for the uMAVRK Analog Interface • Hardware Design Guide for the uMAVRK Power Interface • Template - Hardware User's Guide
--	---	---

5.4 I want more Technical Info on MAVRK Software

• How to Convert a Project from IAR to CCS	• Software - CC11xx, CC25xx, CC430 Radio API Guide
--	--

5.5 I want to get a MAVRK board

[MAVRK Home Page](#)

6 Important Notices

6.1 ESD Precautions

The following guidelines should be followed in order to avoid ESD damage to the board components:

- Any person handling boards must be grounded either with a wrist strap or ESD protective footwear, used in conjunction with a conductive or static-dissipative floor or floor mat.
- The work surface where boards are placed for handling, processing, testing, etc., must be made of static-dissipative material and be grounded to ESD ground.
- All insulator materials either must be removed from the work area or they must be neutralized with an ionizer. Static-generating clothes should be covered with an ESD-protective smock.
- When boards are being stored, transferred between operations or workstations, or shipped, they must be maintained in a Faraday-shield container whose inside surface (touching the boards) is static dissipative.

6.2 Certifications

[FCC standard EMC test report for the RF-TCA8418-MVK MAVRK Module aboard a MAVRK Pro Motherboard](#)

[ICES standard EMC test report for the RF-TCA8418-MVK MAVRK Module aboard a MAVRK Pro Motherboard](#)

[Eco-Info & Lead-Free Home](#)

[RoHS Compliant Solutions](#)

[Statement on Registration, Evaluation, Authorization of Chemicals \(REACH\)](#)

6.3 Evaluation Board/Kit/Module (EVM) Additional Terms

Texas Instruments (TI) provides the enclosed Evaluation Board/Kit/Module (EVM) under the following conditions: The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user indemnifies TI from all claims arising from the handling or use of the goods.

Should this evaluation board/kit not meet the specifications indicated in the User's Guide, the board/ kit may be returned within 30 days from the date of delivery for a full refund. THE FOREGOING LIMITED WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. EXCEPT TO THE EXTENT OF THE INDEMNITY SET FORTH ABOVE, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

Please read the User's Guide and, specifically, the Warnings and Restrictions notice in the User's Guide prior to handling the product. This notice contains important safety information about temperatures and voltages. For additional information on TI's environmental and/or safety programs, please contact the TI application engineer or visit www.ti.com/esh.

No license is granted under any patent right or other intellectual property right of TI covering or relating to any machine, process, or combination in which such TI products or services might be or are used. TI currently deals with a variety of customers for products, and therefore our arrangement with the user is not exclusive. TI assumes no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein.

6.4 United States FCC and Canada IC Regulatory Compliance Information

This EVM complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This Class A or B digital apparatus complies with Canadian ICES-003. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Cet appareil numérique de la classe A ou B est conforme à la norme NMB-003 du Canada. Les changements ou les modifications pas expressément approuvés par la partie responsable de la conformité ont pu vider l'autorité de l'utilisateur pour actionner l'équipement.

6.5 Evaluation Board/Kit/Module (EVM) Warnings, Restrictions, and Disclaimers

6.5.1 Your Sole Responsibility and Risk

You acknowledge, represent and agree that:

1. You have unique knowledge concerning Federal, State and local regulatory requirements (including but not limited to Food and Drug Administration regulations, if applicable) which relate to your products and which relate to your use (and/or that of your employees, affiliates, contractors or designees) of the EVM for evaluation, testing and other purposes.

2. You have full and exclusive responsibility to assure the safety and compliance of your products with all such laws and other applicable regulatory requirements, and also to assure the safety of any activities to be conducted by you and/or your employees, affiliates, contractors or designees, using the EVM. Further, you are responsible to assure that any interfaces (electronic and/or mechanical) between the EVM and any human body are designed with suitable isolation and means to safely limit accessible leakage currents to minimize the risk of electrical shock hazard.

3. Since the EVM is not a completed product, it may not meet all applicable regulatory and safety compliance standards which may normally be associated with similar items. You assume full responsibility to determine and/or assure compliance with any such standards and related certifications as may be applicable. You will employ reasonable safeguards to ensure that your use of the EVM will not result in any property damage, injury or death, even if the EVM should fail to perform as described or expected.

6.5.2 Certain Instructions

It is important to operate this EVM within TI's recommended specifications and environmental considerations per the user guidelines. Exceeding the specified EVM ratings (including but not limited to input and output voltage, current, power, and environmental ranges) may cause property damage, personal injury or death. If there are questions concerning these ratings please contact a TI field representative prior to connecting interface electronics including input power and intended loads. Any loads applied outside of the specified output range may result in unintended and/or inaccurate operation and/or possible permanent damage to the EVM and/or interface electronics. Please consult the EVM User's Guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative. During normal operation, some circuit components may have case temperatures greater than 60° C as long as the input and output are maintained at a normal ambient operating temperature. These components include but are not limited to linear regulators, switching transistors, pass transistors, and current sense resistors which can be identified using the EVM schematic located in the EVM User's Guide. When placing measurement probes near these devices during normal operation, please be aware that these devices may be very warm to the touch. As with all electronic evaluation tools, only qualified personnel knowledgeable in electronic measurement and diagnostics normally found in development environments should use these EVMs.

6.5.3 Agreement to Defend, Indemnify and Hold Harmless

You agree to defend, indemnify and hold TI, its licensors and their representatives harmless from and against any and all claims, damages, losses, expenses, costs and liabilities (collectively, "Claims") arising out of or in connection with any use of the EVM that is not in accordance with the terms of the agreement. This obligation shall apply whether Claims arise under law of tort or contract or any other legal theory, and even if the EVM fails to perform as described or expected.

6.5.4 Safety-Critical or Life-Critical Applications

If you intend to evaluate the components for possible use in safety critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, such as devices which are classified as FDA Class III or similar classification, then you must specifically notify TI of such intent and enter into a separate Assurance and Indemnity Agreement.

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

TI products are not authorized for use in safety-critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use. Buyers represent that they have all necessary expertise in the safety and regulatory ramifications of their applications, and acknowledge and agree that they are solely responsible for all legal, regulatory and safety-related requirements concerning their products and any use of TI products in such safety-critical applications, notwithstanding any applications-related information or support that may be provided by TI. Further, Buyers must fully indemnify TI and its representatives against any damages arising out of the use of TI products in such safety-critical applications.

TI products are neither designed nor intended for use in military/aerospace applications or environments unless the TI products are specifically designated by TI as military-grade or "enhanced plastic." Only products designated by TI as military-grade meet military specifications. Buyers acknowledge and agree that any such use of TI products which TI has not designated as military-grade is solely at the Buyer's risk, and that they are solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI products are neither designed nor intended for use in automotive applications or environments unless the specific TI products are designated by TI as compliant with ISO/TS 16949 requirements. Buyers acknowledge and agree that, if they use any non-designated products in automotive applications, TI will not be responsible for any failure to meet such requirements.

Following are URLs where you can obtain information on other Texas Instruments products and application solutions:

Products

Audio	www.ti.com/audio
Amplifiers	amplifier.ti.com
Data Converters	dataconverter.ti.com
DLP® Products	www.dlp.com
DSP	dsp.ti.com
Clocks and Timers	www.ti.com/clocks
Interface	interface.ti.com
Logic	logic.ti.com
Power Mgmt	power.ti.com
Microcontrollers	microcontroller.ti.com
RFID	www.ti-rfid.com
OMAP Mobile Processors	www.ti.com/omap
Wireless Connectivity	www.ti.com/wirelessconnectivity

Applications

Communications and Telecom	www.ti.com/communications
Computers and Peripherals	www.ti.com/computers
Consumer Electronics	www.ti.com/consumer-apps
Energy and Lighting	www.ti.com/energy
Industrial	www.ti.com/industrial
Medical	www.ti.com/medical
Security	www.ti.com/security
Space, Avionics and Defense	www.ti.com/space-avionics-defense
Transportation and Automotive	www.ti.com/automotive
Video and Imaging	www.ti.com/video

TI E2E Community Home Page

e2e.ti.com

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2011, Texas Instruments Incorporated