


LPSS Series Snap-On Lens Shields

For use with EZ-SCREEN[®] LP Emitters and Receivers



- Provides impact protection for EZ-SCREEN LP emitters and receivers
- Clear PETG co-polyester lens shields snap into place; need no foam gasket for attachment
- Can be removed and reinstalled easily (modification required for use with side brackets)
- Reduces sensing range by approximately 10% per shield (20% per pair)

Models

Lens Shield Dimensions — Cross Section	Lens Shield Model	Fits Emitter/Receiver Models	Lens Shield Overall Length
	LPSS-270	SLP..-270	270 mm
	LPSS-410	SLP..-410	410 mm
	LPSS-550	SLP..-550	550 mm
	LPSS-690	SLP..-690	690 mm
	LPSS-830	SLP..-830	830 mm
	LPSS-970	SLP..-970	970 mm
	LPSS-1100	SLP..-1100	1100 mm
	LPSS-1250	SLP..-1250	1250 mm
	LPSS-1390	SLP..-1390	1390mm
	LPSS-1530	SLP..-1530	1530 mm
	LPSS-1670	SLP..-1670	1670 mm
	LPSS-1810	SLP..-1810	1810 mm

Installation

WARNING . . . Avoid Installation Near Reflective Surfaces

Avoid locating the defined area near a reflective surface; it could reflect sensing beam(s) around an object or person within the defined area, and prevent its detection by the EZ-SCREEN System. Perform the trip test, as described in the EZ-SCREEN Instruction Manual, to detect such reflection(s) and the resultant optical short circuit.

Failure to prevent reflection problems will result in incomplete guarding and could result in serious bodily injury or death.

The LPSS series lens shield can be installed either by sliding it over the emitter/receiver housing or by snapping it into place. *Sliding it on must be done prior to installing the sensors*; snapping it into place can be done after sensor installation. *If side brackets are used*, notches must be cut into the sides of the shield, before snapping it into place. Each shield is a bit longer than the sensor; the shield will overlap onto the end of the bracket plate.

1. Remove the shield's protective film. (***Take care; the shield's cut edges may be sharp.***)
2. If the end-cap bracket is already installed on the sensor housing, the shield can not be slid onto the housing; snap it on.
 - **To slide the shield onto the housing:** Carefully slide the shield onto the housing from either end, with the inside face of the shield against the sensor's front window, until the edge of the shield touches the other end bracket.
 - **To snap the shield onto the housing:** Holding the end of the shield to be located at the cabled end of the sensor, spread the sides of the shield apart. Butt the edge of the shield up to the edge of the end bracket and ease the sides of the shield around the housing, until it snaps in place. From that end, gradually press the rest of the shield into place.
3. Perform the trip test with the lens shield in place, before using the system.

Maintenance

To prevent loss of excess gain, clean the shields when they become dirty. Remove dirt and/or oil from the front face of the shield using a mild detergent or window cleaner and a soft cloth. Avoid industrial cleaning agents or cleaning agents containing alcohol, as they may damage the co-polyester shield material.

Replace the shield when it becomes pitted or scratched, or excess gain will be decreased.