
Rotary Actuator

ø50, ø63, ø80, ø100





Mounting interchangeable with the existing model

Weight is reduced by up to 14%.

Lightweight body by changing the body and the cover shape

Size	New CRA1[kg]	Existing model [kg]	Reduction rate [%]
50	1.3	1.5	13
63	2.2	2.5	12
80	3.9	4.3	10
100	7.3	8.5	14

Auto switch can be mounted from the front.

- Auto switch can be mounted from the front at any position on the mounting groove.
- Auto switch can be mounted after installation or when installation condition is changed.






Series CRA1



Series CRA1 ø**50**, ø**63**, ø**80**, ø**100 Rotating angle Easy adjustment** of cushion valve Cushion valve shape is changed so it can be adjusted using a hexagon wrench only. No protrusion from the body. Retaining ring is used to prevent drop-out. Retaining Port, cushion and ring auto switch are on Port the same surface. Easy to handle. Compact **Cushion seal** auto switches is replaceable. are mountable. Cushion seal has been made replaceable. Solid state auto switch (Not possible for existing model. Cushion seal only) D-M9□ Slider Tube gasket D-M9□W Piston seal Spring pin Cushion seal (New) Reed auto switch Interchangeable with D-A9□ existing model. Exterior dimension, shaft diameter. and mounting dimension are interchangeable with existing model. Many variations of shaft type Single shaft: Double shaft: CRA1BS CRA1BW New Series CRA1 Standard: 2 types Standard: 8 types Semi-standard: 6 types Shaft type can be selected to suit the specification. Part number is assigned for shaft types (single round shaft, double shaft (round shaft, with four chamfers), double round shaft). Single shaft with four Double shaft with key: Double shaft with four Single round shaft: Double shaft (round shaft, Double round shaft: chamfers: CRA1BX **CRA1BY** chamfers: CRA1BZ **CRA1BT** with four chamfers): CRA1BJ CRA1BK

Rotary Actuator






Rotary Actuator

Series CRA1



Rack & Pinion Type/Size: 50, 63, 80, 100



Applicable Auto Switches/Refer to Auto Switch Guide for further information on auto switches.

		Electrical	light	\A/ississ os	Lo	oad volta	ge	Auto swit	ch model	Lead	wire I	ength	n [m]	Dro wired		
Type	Special function	entry	Indicator light	Wiring (Output)	DC		AC	Perpendicular	In-line	0.5 (—)	1 (M)	3 (L)	5 (Z)	Pre-wired connector	Applical	ble load
,				3-wire (NPN)		5 V,12 V		M9NV	M9N	•	•	•	0	0	IC circuit	
switch				3-wire (PNP)		5 V,12 V		M9PV	M9P	•	•	•	0	0	io circuit	
				2-wire]	12 V		M9BV	M9B	•	•	•	0	0	_	
auto	Diagnosis indication			3-wire (NPN)		5 V,12 V		M9NWV	M9NW	•	•	•	0	0	IC circuit	Dalasi
al	(2-colour indication)	Grommet	Yes	3-wire (PNP)	24 V	J V,12 V	_	M9PWV	PWV M9PW		•	•	0	0	io circuit	Relay, PLC
state	(2-colour indication)			2-wire		12 V		M9BWV	M9BW	•	•	•	0	0	_	FLC
S	Water resistant			3-wire (NPN)		5 V,12 V		M9NAV**	M9NA**	0	0	•	0	0	IC circuit	
Solid	(2-colour indication)			3-wire (PNP)		5 V, 12 V		M9PAV**	M9PA**	0	0	•	0	0	ic circuit	
Ň	(2-colour indication)			2-wire		12 V		M9BAV**	M9BA**	0	0	•	0	0	_	
Reed auto switch		Grammat	Grommet	Yes	3-wire	5 V	_	A96V	A96	•	_	•	_	_	IC circuit	_
d aut		Grommet		2-wire	24 V	12 V	100 V	A93V	A93	•	_	•	_	_	_	Relay,
Ree			No	Z-WITE	24 V	12 V	100 V or less	A90V	A90	•		•		_	IC circuit	PLC

^{**} Although it is possible to mount water resistant type auto switches, note that the rotary actuator itself is not of water resistant construction.

* Lead wire length symbols: 0.5 m..... — (Example) M9NW

1 m····· M (Example) M9NWM

3 m····· L (Example) M9NWL 5 m····· Z (Example) M9NWZ

* Auto switches marked with "O" are produced upon receipt of order.


* Auto switches are shipped together, (but not assembled).

Made to Ro

Refer to Auto Switch Guide for detailed solid state auto switches with pre-wired connectors.

1





Specifications

Туре	Pneumatic									
Size	50 63 80 100									
Fluid		Air (No	n-lube)							
Max. operating pressure		1.0	MPa							
Min. operating pressure		0.1	MPa							
Ambient and fluid temperature		0 to 60°C (I	No freezing)							
Cushion		Not attached	l, Air cushion							
Backlash		With	in 1°							
Tolerance in rotating angle		+4								

Effective Torque

										[N·m]					
Size		Operating pressure [MPa]													
Size	0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1.0					
50	1.85	3.71	5.57	7.43	9.27	11.2	13.0	14.9	16.7	18.5					
63	3.44	6.88	10.4	13.8	17.2	20.6	24.0	27.5	31.0	34.4					
80	6.34	12.7	19.0	25.3	31.7	38.0	44.4	50.7	57.0	63.4					
100	14.9	29.7	44.6	59.4	74.3	89.1	104	119	133	149					

Made to Order (For details, refer to pages 11 to 23.)

Symbol	Description	Applicable shaft type
XA1 to XA24	Shaft pattern sequencing I	S, W, Y
XA33 to XA59	Shaft pattern sequencing II	X, Z, T, J, K
XC7	Reversed shaft	S, W, X, T, J
XC8 to XC11	Change of rotation range	S, W, Y
XC30	Changed to fluorine grease	S, W, X, Y Z, T, J, K
XC31 to XC36	Change of rotation range and shaft rotation direction	S, W, Y
XC59 to XC61	Change of port location (Mounting location of the cover is changed.)	S, W, X, Y Z, T, J, K

Allowable Kinetic Energy/Adjustable Range of Rotation Time Safe in Operation

Size	Allo	Allowable kinetic energy [J]									
Size	Without air cushion	With air	time safe in operation [s/90°]								
50	0.05	0.98		0.2 to 2							
63	0.12	1.50	Cushion angle	0.2 to 3							
80	0.16	2.00	35°	0.2 to 4							
100	0.54	2.90		0.2 to 5							

^{*} Allowable kinetic energy of the product with air cushion is the maximum absorbed energy when the cushion valve adjustment is optimised.

JIS Symbol



Weights

					[Kg]			
Size	Standar	d weight	Additional weight					
Size	90°	180°	With auto switch*	Foot bracket	Flange bracket			
50	1.3	1.5	0.2	0.3	0.5			
63	2.2	2.6	0.4	0.5	0.9			
80	3.9	4.4	0.6	0.9	1.5			
100	7.3	8.3	0.9	1.2	2.0			

^{*} With 2 auto switches

Foot Bracket/Part No.


Size	Foot bracket	Contents	Mounting screw size included in foot bracket
50	CRA1L50-Y-1Z		M8 x 1.25 x 35
63	CRA1L63-Y-1Z	Foot bracket: 2 pcs. Mounting screw: 4 pcs.	M10 x 1.5 x 40
80	CRA1L80-Y-1Z	Collar: 4 pcs.	M12 x 1.75 x 50
100	CRA1L100-Y-1Z		M12 x 1.75 x 50



Series CRA1


Rotation Range of Keyway/Auto Switch Mounting Position

Size: 50 to 100 CDRA1□□50 to 100




Working Principle


In the diagram below, the auto switch B is ON. When pressure is applied from A, the piston moves to B, causing the shaft to rotate clockwise. At this time, the magnet B goes out of the movement range of the auto switch B, causing the auto switch B to turn OFF. Furthermore, the piston moves to the right, causing the magnet A to enter the movement range of the auto switch A. As a result, the auto switch A turns ON.




Construction


Without air cushion








Without air cushion With auto switch



With air cushion



Component Parts

Con	nponent Parts		
No.	Description	Material	Note
1	Body	Aluminium alloy	Anodised
2	Right cover	Aluminium alloy	Metallic coating
3	Left cover	Aluminium alloy	Metallic coating
4	Piston	Aluminium alloy	
5	Shaft	Alloy steel	
6	Rack	Carbon steel	Nitrided
7	Slider	Resin	
8	Bearing retainer	Aluminium alloy	Chromated
9	Tube gasket	NBR	
10	Piston seal	NBR	
11	Bearing	High carbon chrome bearing steel	
12	Hexagon socket head cap screw with washer	Alloy steel	Zinc chromated
13	Spring pin	Steel	Zinc chromated
14	Parallel key	Carbon steel	
15	Connecting screw	Carbon steel	Zinc chromated
16	Cross-recessed pan head tapping screw	Steel	Zinc chromated
17	Wear ring	Resin	
18	Auto switch	_	
19	Magnet	_	
20	Switch spacer	Resin	
21	Cushion ring	Aluminium alloy	Anodised
22	Cushion valve	Steel	Zinc chromated
23	Cushion seal	Urethane	
24	O-ring	NBR	
25	Seal retainer	Steel	
26	Retaining ring	Steel	

Replacement Parts/Cushion Seal (Corresponding parts sh

neplacement Parts/Cusinon Sear (Corresponding parts shown below are set.)												
Size		Replacem	nent parl	ts								
Size	W	ithout air cushion	With air cushion									
CRA1□□50		P694020-20	F	P694020-21								
CRA1□□63		P694030-20	F	P694030-21								
CRA1□□80		P694040-20	F	P694040-21								
CRA1□□100		P694050-20	F	P694050-21								
	No.	Description	Qty.									
	7	Slider	2									
Corresponding	9	Tube gasket	2									
parts	10	Piston seal	2									
	13	Spring pin	4									
	23	Cushion seal*	2									

Note) When ordering spare parts, write "1" for one set of the parts per actuator.

A grease pack (10 g) is included. If an additional grease pack is needed, order with the following part number.

Grease pack part number: GR-S-010 (10 g)




^{*} For model with air cushion


Series CDRA1


Dimensions/Basic Type: C□RA1B□

Size: 50/63/80/100 Single shaft: C□RA1BS

Single shaft







- The dimensions above show pressurisation to B port.
 Drawing shows the auto switch mounted on the port side.
 * () are the dimensions for rotation of 180° and 190°.

Model	Port size	Α	В	С	D	DD	F	Н	J	K	W	ith a	uto s	witch		Without auto switch	U	w	ВА	вв	вс	¢ CA		Key dimensi	ote) ons
	3126				(g6)	(h9)					S	SB	SC	SD	SE	S								b	Lı
C□RA1BS50	1/8	62	48	46	15	25	2.5	36	M8 x 1.25 depth 8	5	156 (189)	1.5	5	14.5	33	144 (177)	98	17	17	8.5	6	9.5	7.5	5_0.030	25
C□RA1BS63	1/8	76	60	57	17	30	2.5	41	M10 x 1.5 depth 12	5	175 (213.5)	1.5	5	21.5	33	163 (201.5)	117	19.5	20	10	7	11	8	6-0.030	30
C□RA1BS80	1/4	92	72	70	20	35	3	50	M12 x 1.75 depth 13	5	199 (243)	1.5	5	29.5	33	186 (230)	142	22.5	23.5	12	8	13	9	6-0.030	40
C□RA1BS100	3/8	112	85	85	25	40	4	60	M12 x 1.75 depth 14	5	259 (325)	1.5	5	39.5	33	245 (311)	172	28	25	12.5	8	14	10	8-0.036	45

Note) A parallel key is included in the same package, (but not assembled).

★ For model with air cushion




Dimensions/Basic Type: C□**RA1B**□

Size: 50/63/80/100

Double shaft: C□RA1BW


Double shaft



Note) Other dimensions are the same as the single shaft type.

Model	D (g6)	G	М	N	UU	L
C□RA1BW50	15	11	20	15	118	14
C□RA1BW63	17	13	22	17	139	16
C□RA1BW80	20	15	25	20	167	19
C□RA1BW100	25	19	30	25	202	24


Double shaft with key: C□RA1BY



Note) Other dimensions are the same as the single shaft type.

Model	Н	K	UU	L
C□RA1BY50	36	5	134	25
C□RA1BY63	41	5	158	30
C□RA1BY80	50	5	192	40
C□RA1BY100	60	5	232	45


Single shaft with four chamfers: C□RA1BX



Note) Other dimensions are the same as the single shaft type.

Model	G	Н	N	U	L
C□RA1BX50	11	27	15	89	14
C□RA1BX63	13	29	17	105	16
C□RA1BX80	15	38	20	130	19
C□RA1BX100	19	44	25	156	24

Double shaft with four chamfers: C□RA1BZ



Note) Other dimensions are the same as the single shaft type.

, , , , , , , , , , , , , , , , , , ,								
Model	G	Н	M	N	U	UU	L	
C□RA1BZ50	11	27	20	15	89	109	14	
C□RA1BZ63	13	29	22	17	105	127	16	
C□RA1BZ80	15	38	25	20	130	155	19	
C□RA1BZ100	19	44	30	25	156	186	24	




Series CDRA1


Dimensions/Basic Type: C□**RA1B**□

Size: 50/63/80/100

Single round shaft: C□RA1BT



Double shaft (round shaft, with four chamfers): C□RA1BJ




Note) Other dimensions are the same as the single shaft type.

Model	D (g6)	Н
C□RA1BT50	15	36
C□RA1BT63	17	41
C□RA1BT80	20	50
C□RA1BT100	25	60

Note) Other dimensions are the same as the single shaft type.

Model	D (g6)	G	н	М	N	UU	L
C□RA1BJ50	15	11	36	20	15	118	14
C□RA1BJ63	17	13	41	22	17	139	16
C□RA1BJ80	20	15	50	25	20	167	19
C□RA1BJ100	25	19	60	30	25	202	24

Double round shaft: C□RA1BK





Note) Other dimensions are the same as the single shaft type.

Model	D (g6)	Н	UU
C□RA1BK50	15	36	134
C□RA1BK63	17	41	158
C□RA1BK80	20	50	192
C□RA1BK100	25	60	232

Dimensions/Foot Type: C□RA1L, Flange Type: C□RA1F


Size: 50/63/80/100 Foot type: C□RA1L□






Flange type

Single shaft: C□RA1FS





- Dimensions above show pressurisation to B port.
- Drawing shows the auto switch mounted on the port side.
- \ast () are the dimensions for rotating angle of 180° and 190°.

Model		LB	10 10		With auto switch		Without auto switch	
Model	LA	LB	LC	LD	LE	LD	LE	
C□RA1L□50	62	9	44	212 (245)	236 (269)	200 (233)	224 (257)	
C□RA1L□63	76	11	55	247 (285.5)	275 (313.5)	235 (273.5)	263 (301.5)	
C□RA1L□80	92	13	67	287 (331)	329 (373)	274 (318)	316 (360)	
C□RA1L□100	112	13	87	347 (413)	389 (455)	333 (399)	375 (441)	

Model	LF	LH	LT
C□RA1L□50	41	108	4.5
C□RA1L□63	48	127	5
C□RA1L□80	58	154	6
C□RA1L□100	73.5	189.5	6

Note) Other dimensions are the same as the basic type.

rette) Guiler dimensions are the same as the basic type.										
Model	F	н	мм	U	FD	FT	FX	FY	ZX	ZY
C□RA1F□50	4	39	M6 x 1.0 depth 12	114	9	13	90	50	110	81
C□RA1F□63	5	45	M6 x 1.0 depth 12	136	11.5	15	105	59	130	101
C□RA1F□80	5	55	M8 x 1.25 depth 16	165	13.5	18	130	76	160	119
C□RA1F□100	5	60	M10 x 1.5 depth 20	190	13.5	18	150	92	180	133


Series CDRA1

Dimensions/Flange Type: C□**RA1F**

Size: 50/63/80/100

Flange type

Double shaft: C□RA1FW




Note) Other dimensions are the same as the single shaft type.

Model	Н	N	U	UU
C□RA1FW50	39	15	114	134
C□RA1FW63	45	17	136	158
C□RA1FW80	55	20	165	190
C□RA1FW100	60	25	190	220

Flange type

Double shaft with key: C□RA1FY




Note) Other dimensions are the same as the single shaft type.

Model	Н	U	UU
C□RA1FY50	39	114	150
C□RA1FY63	45	136	177
C□RA1FY80	55	165	215
C□RA1FY100	60	190	250

Flange type

Single shaft with four chamfers: C□RA1FX




Note) Other dimensions are the same as the single shaft type.

Model	Н	N	U
C□RA1FX50	30	15	105
C□RA1FX63	33	17	124
C□RA1FX80	43	20	153
C□RA1FX100	44	25	174

Flange type

Double shaft with four chamfers: C□RA1FZ



Note) Other dimensions are the same as the single shaft type.


Model	Н	N	U	UU
C□RA1FZ50	30	15	105	125
C□RA1FZ63	33	17	124	146
C□RA1FZ80	43	20	153	178
C□RA1FZ100	44	25	174	204

Note) The dimensions of shaft key and four chamfers are the same as the basic type.



Series CRA1 Auto Switch Mounting

Auto Switch Proper Mounting Position (Detection at Rotation End)



Auto switch model	D-M9□/M9□V D-M9□W/M9□WV D-M9□A/M9□AV		D-A9□/A9□V	
Model	Proper mounting position A [mm]	Operating range θ [°]	Proper mounting position A [mm]	Operating range θ [°]
CDRA1□50-90	22.5	30°	18.5	44°
CDRA1□50-180	39	30*	35	44*
CDRA1□63-90	25	28°	21	49°
CDRA1□63-180	44.5	20	40.5	49
CDRA1□80-90	27.5	23°	23.5	41°
CDRA1□80-180	49.5	23	45.5	41
CDRA1□100-90	42.5	15°	38.5	29°
CDRA1□100-180	75.5	10	71.5	29"

^{*} Since this is a guideline including hysteresis, not meant to be guaranteed. (Assuming approximately ±30% dispersion) There may be the case to change substantially depending on an ambient environment.

Adjust the auto switch after confirming the operating conditions in the actual setting.


Switch Spacer Part No.

Size	Size 50 63		80	100
Switch spacer part no.	BMY3-016			

^{*} The above part number includes one switch spacer.

Auto Switch Mounting

To fix the auto switch, hold the switch spacer, and insert into the groove. Make sure that the switch spacer is in the right position or correct the position if necessary, then slide the auto switch in the groove so that it goes into the spacer. Confirm where the mounting position is, and tighten the auto switch mounting screw using a flat head screwdriver.



Note) When tightening an auto switch mounting screw, use a watchmakers' screwdriver with a handle of approximately 5 to 6 mm in diameter.

Also, tighten with a torque of about 0.1 to 0.15 N·m.

As a guide, turn about 90° past the point at which tightening can first be felt.



^{*} Two switch spacers are included with the product with built-in magnet.

Series CRA1 Simple Specials 1




Shaft shape pattern is dealt with simple made-to-order system. A specification sheet is available for ordering. Please access SMC website, or consult your nearest sales branch.

Symbol

Shaft Pattern Sequencing

-XA1 to -XA24

Applicable shaft type: S, W, Y



- * Combination of simple special and made-to-order is available for up to 4 types.
- * Above is the typical example of combination.

Symbol

Shaft Pattern Sequencing I

-XA1 to -XA24

Applicable shaft type: S, W, Y

Combination Chart of Simple Specials for Shaft-End Shape

Chart (1) Combination between XA□ and XA□ (S, W, Y shaft)

0:	Symbol Description		Axial direction		Applicable shaft type		Combination			
Symbol			Bottom	S	W	Υ	XA1	XA2	XA13	XA24
XA1	Shaft-end female thread	•	_	•	•	•	-	•	_	•
XA2	Shaft-end female thread	_	•	•	•	•	•	_	_	•
XA13	Shaft through-hole	•	•	•	•	•	_	_	_	•
XA14	Shaft through-hole + Shaft-end female thread	•	_	•	•	•	_	_	_	•
XA15	Shaft through-hole + Shaft-end female thread	_	•	•	•	•	-	_	_	•
XA16	Shaft through-hole + Double shaft-end female thread	•	•	•	•	•	_	_	_	•
XA17	Shortened shaft (Long shaft with key)	•	_	•	•	•	_	•	•	_
XA18	Shortened shaft (Short shaft with key and with four chamfers)	_	•	_	•	•	W, Y*	_	W, Y*	_
XA19	Shortened shaft (Double shaft)	•	•	_	•	•	-	_	W, Y*	_
XA20	Reversed shaft, Shortened shaft	•	•		•	•	_	_	S, W*	_
XA24	Double key	•		•	•	•			_	_

 $[\]ast$ Shaft type available for combination.

Combination Chart of Made to Order

Chart (2) Combination between XA□ and XC□

Ol	December 41 and	Applicable shaft type			Combination		
Symbol	Symbol Description		W	Υ	XA1, 2, 13 to 19	XA20, 24	
XC7	Reversed shaft	•	•	_	_	_	
XC8 to XC11	Change of rotation range	•	•	•	•	_	
XC30	Changed to fluorine grease	•	•	•	•	•	
XC31 to XC36	Change of rotation range and shaft rotation direction	•	•	•	•	_	
XC59 to XC61	Change of port location	•	•	•	•	•	



Series CRA1 Simple Specials 2



Shaft shape pattern is dealt with simple made-to-order system. A specification sheet is available for ordering. Please access SMC website, or consult your nearest sales branch.

Symbol

Shaft Pattern Sequencing I

-XA1 to -XA17

Applicable shaft type: S, W, Y

Additional Reminders

- 1. Enter the dimensions within a range that allows for additional machining.
- 2. SMC will make appropriate arrangements if no dimensional, tolerance, or finish instructions are given in the diagram.
- 3. The length of the unthreaded portion is 2 to 3 pitches.
- 4. Unless specified otherwise, the thread pitch is based on coarse metric threads.


P = Thread pitch

M4 x 0.7, M5 x 0.8

- M6 x 1, M8 x 1.25, M10 x 1.5 portion of the diagram. 5. Enter the desired figures in the
- 6. Chamfer face of the parts machining additionally is C0.5.

Symbol: A1 Female threads are machined into the long shaft. Note) Except flange type The maximum dimension L1 is, as a rule, twice the thread size.

(Example) For M4: L1 = 8 • Applicable shaft type: S, W, Y




	[mm]
Size	Q1
50	M4, M5, M6
63	M4, M5, M6
80	M4, M5, M6, M8
100	M5, M6, M8, M10

Symbol: A2

Female threads are machined into the short shaft. Note) Except flange type

The maximum dimension L2 is, as a rule, twice the thread size. (Example) For M4: L2 = 8

· Applicable shaft type: S, W, Y




	[mm]
Size	Q2
50	M4, M5, M6
63	M4, M5, M6
80	M4, M5, M6, M8
100	M5, M6, M8, M10

Symbol: A13

Shaft through-hole Note) Except flange type

The minimum unit of the dimensions within a range that allows for machining d1 is 0.1.

· Applicable shaft type: S, W, Y




	[mm]
Size	d1
50	ø4 toø 7
63	ø4 toø 8
80	ø6.8 to ø11
100	ø6.8 to ø13

Symbol: A14 Note) Except flange type

A special end is machined onto the long shaft, and a through-hole is drilled into it. Female threads are machined into the throughhole, whose diameter is equivalent to the pilot hole diameter.

The maximum dimension L1 is, as a rule, twice the thread size. (Example) For M5: L1 = 10


Applicable shaft type: S, W, Y



				[111111]
Size	50	63	80	100
M5 x 0.8	ø4	ø4	_	
M6 x 1	ø5	ø5	_	_
M8 x 1.25	_	ø6.8	ø 6.8	ø 6.8
M10 x 1.5	_	_	ø 8.5	ø 8.5
M12 x 1.75	_	_	ø10.3	ø10.3
Rc1/8	_		ø 8	ø 8
Rc1/4	_	_	_	ø11

Symbol: A15 Note) Except flange type


A special end is machined onto the short shaft, and a through-hole is drilled into it. Female threads are machined into the through-hole, whose diameter is equivalent to the pilot hole diameter. The maximum dimension L2 is, as a rule, twice the thread size.



				T [IIIIII]
Thread Size	50	63	80	100
M5 x 0.8	ø4	ø4	_	_
M6 x 1	ø5	ø5	_	_
M8 x 1.25	_	ø6.8	ø 6.8	ø 6.8
M10 x 1.5	_	_	ø 8.5	ø 8.5
M12 x 1.75	_	_	ø10.3	ø10.3
Rc1/8	_	_	ø 8	ø 8
Rc1/4	_	_	_	ø11

Note) Except flange type Symbol: A16


A special end is machined onto both the long and short shafts, and a through-hole is drilled into both shafts. Female threads are machined into the through-holes, whose diameter is equivalent to the diameter of the pilot holes. The maximum dimension




				† [mmj
Thread Size	50	63	80	100
M5 x 0.8	ø4	ø4	_	_
M6 x 1	ø5	ø5	_	_
M8 x 1.25	_	ø6.8	ø 6.8	ø 6.8
M10 x 1.5	-	_	ø 8.5	ø 8.5
M12 x 1.75	_	_	ø10.3	ø10.3
Rc1/8	_	_	ø 8	ø 8
Rc1/4	_	_	_	ø11

Symbol: A17

• The long shaft is shortened.






	[111111]
Size	Х
50	18.5 to 36
63	21 to 41
80	25 to 50
100	32.5 to 60

Symbol

Shaft Pattern Sequencing I

-XA18 to -XA24

Applicable shaft type: S, W, Y




Symbol: A24

Keys and keyways are machined additionally at 180° from the standard position.







Series CRA1 Simple Specials 3




Shaft shape pattern is dealt with simple made-to-order system. A specification sheet is available for ordering. Please access SMC website, or consult your nearest sales branch.

Symbol

Shaft Pattern Sequencing II

-XA33 to -XA59

Applicable shaft type: X, Z, T, J, K



 Combination of simple special and made-to-order, is available for up to 4 types.

Chart (3), (4), (5)

Chart (3), (4), (5)

Combination is available only when all the conditions are fulfilled in above combination chart.

 \ast Above is the typical example of combination.

A33 A34 C30 C59

A45 A46 C30 C61

Symbol

Shaft Pattern Sequencing II

-XA33 to -XA59

Applicable shaft type: X, Z, T, J, K

Combination Chart of Simple Specials for Shaft-End Shape

Chart (3) Combination between XA \square and XA \square

0 1 1		Axial direction Applicable shaft type				/ре	Combination											
Symbol	Description	Тор	Bottom	X	Z	Т	J	K					,	Shaft t	ype ava	ilable fo	or comb	nation.
XA33	Shaft-end female thread	•	-	_	_	•	•	•	XA33									
XA34	Shaft-end female thread	_	•	_	_	•	•	•	T, J, K*	XA34		_						
XA35	Shaft-end female thread	•	_	•	•	_	_	_	_	_	XA35							
XA36	Shaft-end female thread	_	•	•	•	_	—	_	_	_	X,Z*	XA36						
XA37	Stepped round shaft	•	_	_	_	•	•	•	_	T, J, K*	_	_	XA37					
XA38	Stepped round shaft	_	•	_	_	_	_	•	K*	_	_	_	K*					
XA40	Shaft through-hole	•	•	_	_	•	_	•	_	_	_	_	_					
XA41	Shaft through-hole	•	•	•	•	_	•	_	_	_	_	_	_					
XA43	Shaft through-hole + Double shaft-end female thread	•	•	_	_	•	—	•	_	_	-	_	_					
XA44	Shaft through-hole + Double shaft-end female thread	•	•	•	•	_	•	_	_	_	_	_	_	XA38				
XA45	Middle-cut chamfer	•	_	_	_	•	•	•	_	T, J, K*	_	_	_	K*	XA40	XA41	XA45	
XA46	Middle-cut chamfer	_	•	_	_	_	_	•	K*	_	_	_	K*	_	_	_	K*	XA46
XA51	Change of long shaft length (Without keyway)	•	-	_	_	•	•	•	_	T, J, K*	—	_	_	K*	T, K*	J*	_	K*
XA52	Change of short shaft length (Without keyway)	_	•	_	_	_	_	•	K*	_	—	_	_	_	K*	_	K*	-
XA53	Change of double shaft length (Both without keyway)	•	•	_	—	_	_	•	_	_	_	_	_	_	K*	_	_	_
XA54	Change of long shaft length (With four chamfers)	•	_	•	•	_	_	_	_	_	_	X, Z*	_	_	_	X, Z*	_	_
XA55	Change of short shaft length (With four chamfers)	_	•	_	•	_	•	_	J*	_	Z*	_	J*	_	_	J, Z*	J*	_
XA56	Change of double shaft length (Both with four chamfers)	•	•	_	•	_		_				_	_	_	_	Z*		
XA57	Change of double shaft length (Without keyway, With hour chamfers)	•	•	_	_	_	•	_				_	_	_	_	J*		
XA58	Reversed shaft, Change of shaft length (With four chamfers, Without keyway)	•	•	_	_	•	•	_	_	_	_	_	_	_	T*	J*	_	_
XA59	Reversed shaft, Change of shaft length (With four chamfers)	_	•	•	_	_	_	_	_	_	_	_	_	_	_	X*	_	_

Combination Chart of Made to Order

Chart (4) Combination between $XA\square$ and $XC\square$

O. week al	Description		Applica	able sha	aft type		Combination	
Symbol			Z	Т	J	K	XA33 to 38, 40 to 46, 51 to 59	
XC7	Reversed shaft	•	_	•	•	_	_	
XC8 to XC11	Change of rotation range	_	_	_	_	_	_	
XC30	Changed to fluorine grease	•	•	•	•	•	•	
XC31 to XC36	Change of rotation range and shaft rotation direction	_	_	_	_	_	_	
XC59 to XC61	Change of port location	•	•	•	•	•	•	



Series CRA1 Simple Specials 4



Shaft shape pattern is dealt with simple made-to-order system. A specification sheet is available for ordering. Please access SMC website, or consult your nearest sales branch.

Symbol

Shaft Pattern Sequencing II

-XA33 to -XA41

Applicable shaft type: X, Z, T, J, K

Additional Reminders

- 1. Enter the dimensions within a range that allows for additional machining.
- 2. SMC will make appropriate arrangements if no dimensional, tolerance, or finish instructions are given in the diagram.
- 3. The length of the unthreaded portion is 2 to 3 pitches.
- 4. Unless specified otherwise, the thread pitch is based on coarse metric threads.

P = Thread pitch

M4 x 0.7, M5 x 0.8

Symbol: A35

(Example) For M4: L1 = 8

· Applicable shaft type: X, Z

M6 x 1, M8 x 1.25, M10 x 1.5

- 5. Enter the desired figures in the portion of the diagram.
- 6. Chamfer face of the parts machining additionally is C0.5.

Note) Except flange type

The maximum dimension L1 is, as a rule, twice the thread size.


Female threads are machined into the long shaft.

Symbol: A33

Female threads are machined into the long shaft. Note) Except flange type

The maximum dimension L1 is, as a rule, twice the thread size. (Example) For M4: L1 = 8


· Applicable shaft type: J, K, T



	[mm]
Size	Q1
50	M4, M5, M6, M8
63	M4, M5, M6, M8, M10
80	M4, M5, M6, M8, M10, M12
100	M5, M6, M8, M10, M12

Female threads are machined into the short shaft.

Applicable shaft type: X, Z




	[111111]
Size	Q1
50	M4, M5, M6, M8
63	M4, M5, M6, M8, M10
80	M4, M5, M6, M8, M10, M12
100	M5, M6, M8, M10, M12

Symbol: A38 Note) Except flange type

The short shaft can be further shortened by machining it into a stepped round shaft.

- The minimum unit of the dimensions within a range that allows for machining is 0.1.
- (If shortening the shaft is not required, indicate "*" for dimension Y.) (If not specifying dimension C2, indicate "*" instead.)
- Applicable shaft type: K
- · Equal dimensions are indicated by the same marker.




	Size	Υ	L2 max	D2
	50	1 to 36	Υ	ø5 to ø14.9
	63	1 to 41	Υ	ø5 to ø16.9
ľ	80	1 to 50	Υ	ø8 to ø19.9
	100	1 to 60	Υ	ø8 to ø24.9

Symbol: A36

Note) Except flange type

The maximum dimension L2 is, as a rule, twice the thread size. (Example) For M4: L2 = 8




	[mm]
Size	Q2
50	M4, M5, M6, M8
63	M4, M5, M6, M8, M10
80	M4, M5, M6, M8, M10, M12
100	M5, M6, M8, M10, M12

Symbol: A40

Shaft through-hole Note) Except flange type

- The minimum unit of the dimensions within a range that allows for machining d1 is 0.1.
- Applicable shaft type: K, T




	[mm]
Size	d1
50	ø4 to ø7.5
63	ø4 toø8
80	ø6.8 to ø11
100	ø6.8 to ø13

Symbol: A34 Female threads are machined into the short shaft. Note) Except flange type

The maximum dimension L2 is, as a rule, twice the thread size. (Example) For M4: L2 = 8

· Applicable shaft type: J, K, T




	[mm]
Size	Q2
50	M4, M5, M6, M8
63	M4, M5, M6, M8, M10
80	M4, M5, M6, M8, M10, M12
100	M5, M6, M8, M10, M12

Symbol: A37 Note) Except flange type

The long shaft can be further shortened by machining it into a stepped round shaft.

 The minimum unit of the dimensions within a range that allows for machining is 0.1.

(If shortening the shaft is not required, indicate "*" for dimension X.) (If not specifying dimension C1, indicate "*" instead.)




Size	X	L1 max	D1
50	3.5 to 36	X-2.5	ø5 to ø14.9
63	3.5 to 41	X-2.5	ø5 to ø16.9
80	4 to 50	X-3	ø8 to ø19.9
100	5 to 60	X-4	ø8 to ø24.9

Symbol: A41

Shaft through-hole Note) Except flange type

- The minimum unit of the dimensions within a range that allows for machining d1 is 0.1.
- Applicable shaft type: J, X, Z



J axis	X axis


[111111]
d1
ø4 to ø7.5
ø4 to ø8
ø6.8 to ø11
ø6.8 to ø13

Symbol

Shaft Pattern Sequencing II

-XA43 to -XA55

Applicable shaft type: X, Z, T, J, K




				[mm]
Size Thread	50	63	80	100
M5 x 0.8	ø4	ø4	_	_
M6 x 1	ø5	ø5	_	_
M8 x 1.25	_	ø6.8	ø 6.8	ø 6.8
M10 x 1.5	_	_	ø 8.5	ø 8.5
M12 x 1.75	_	_	ø10.3	ø10.3
Rc1/8		_	ø 8	ø 8
Bc1/4				ø11

T axis

Symbol: A44 Note) Except flange type

Shaft through-hole and female thread machining

- Applicable shaft type: J, X, Z
- Equal dimensions are indicated by the same marker




Size	50	63	80	100
M5 x 0.8	ø4	ø4	_	_
M6 x 1	ø5	ø5	_	_
M8 x 1.25	_	ø6.8	ø 6.8	ø 6.8
M10 x 1.5	_	_	ø 8.5	ø 8.5
M12 x 1.75			ø10.3	ø10.3
Rc1/8	_	_	ø 8	ø 8
Rc1/4		_		ø11

Symbol: A45 Note) Except flange type

The long shaft can be further shortened by machining a middle-cut chamfer into it.

- The minimum unit of the dimensions within a range that allows for machining is 0.1.
- (The position of the middle-cut chamfer is on the standard chamfer at the keyway portion.)
- (If shortening the shaft is not required, indicate "*" for dimension X.)





		1		[iiiiii]
Size	Х	W1	L1 max	L3 max
50	12.5 to 36	1 to 5.5	X-2.5	L1-2
63	13.5 to 41	1 to 6.5	X-2.5	L1-2
80	16.5 to 50	1 to 8	X-3	L1-3
100	21 to 60	1.5 to 10.5	X-4	L1-4


Symbol: A46 Note) Except flange type

The short shaft can be further shortened by machining a middle-cut chamfer into it.

- The minimum unit of the dimensions within a range that allows for machining is 0.1.
- (The position of the middle-cut chamfer is on the standard chamfer at the keyway portion.)
- (If shortening the shaft is not required, indicate "*" for dimension Y.)

Applicable shaft type: K

K axis




				F
Size	Υ	L2 max	L4 max	
50	10 to 36	1 to 5.5	Υ	L2-2
63	11 to 41	1 to 6.5	Υ	L2-2
80	13.5 to 50	1 to 8	Υ	L2-3
100	17 to 60	1.5 to 10.5	Υ	L2-4

Symbol: A51

The long shaft is shortened.

• Applicable shaft type: J, K, T




	[mm]
Size	X
50	3.5 to 36
63	3.5 to 41
80	4 to 50
100	5 to 60

Symbol: A52

The short shaft is shortened.

Applicable shaft type: K



	[mm]
Size	Υ
50	1 to 36
63	1 to 41
80	1 to 50
100	1 to 60


Symbol: A53

Size 50

63

80

100



1 to 36

1 to 41

1 to 50

1 to 60

3.5 to 36

3.5 to 41


4 to 50

to 60

Symbol: A54

The long shaft is shortened.

• Applicable shaft type: X, Z




	[mm]
Size	Х
50	3.5 to 27
63	3.5 to 29
80	4 to 38
100	5 to 44

Symbol: A55

The short shaft is shortened.

Applicable shaft type: J, Z



Size	Υ
50	1 to 20
63	1 to 22
80	1 to 25
100	1 to 30

Series CRA1

Simple Specials 5




Shaft shape pattern is dealt with simple made-to-order system. A specification sheet is available for ordering. Please access SMC website, or consult your nearest sales branch.

Symbol

Shaft Pattern Sequencing II

-XA56 to -XA59


Applicable shaft type: X, Z, T, J, K



Symbol: A59

The shafts are reversed, and both the long shaft and short shaft are shortened.

Applicable shaft type: X




Series CRA1

Made to Order 1









Combination Chart of Made to Order

Chart (5) Combination between XA□ and XC□


onart (b) combination between AAL and AGL														
Ol	December		Α	pplic	able	sha	aft ty	ре		Combination				
Symbol	Description	S	W	X	Υ	Z	Т	J	K					
XC7	Reversed shaft	•	•	•	_	_	•	•	_	XC7		* Shaft	type available fo	or combination.
XC8 to XC11	Change of rotation range	•	•	_	•	_	_	_	_	_	XC8 to XC11			
XC30	Changed to fluorine grease	•	•	•	•	•	•	•	•	S,W,X,T,J*	S,W,Y*	XC30		
XC31 to XC36	Changes of rotation range and shaft location direction	•	•	-	•	_	-	_	_	_	_	S,W,Y*	XC31 to XC36	
XC59 to XC61	Change of port location	•	•	•	•	•	•	•	•	S,W,X,T,J*	•	•	S,W,Y*	XC59 to XC61



Series CRA1 **Made to Order 2**

Please contact SMC for further details about dimensions, specifications and delivery.






Symbol -XC7



Reversed shaft (-XC7)

Specifications

Applicable size	50, 63, 80, 100
Applicable shaft type	S, W, X, T, J



2 Change of Rotation Range

Symbol -XC8 to -XC11

Change of


rotation range (-XC8 to -XC11)

CRA₁ Refer to "How to Order" on page 1. **- XC8**

Specifications

Applicable size	50, 63, 80, 100
Applicable shaft type	S, W, Y

The patterns with the rotation range of 90° and 180° are applicable to the respective patterns with the rotation range of 100° and 190° of the semi-standard specifications.




Note) If it is pressurised from the port indicated with the arrow, the shaft rotates in the clockwise direction.

Note) If it is pressurised from the port indicated with the arrow, the shaft rotates in the clockwise direction.

Symbol: C10


The rotation range is changed.



Note) If it is pressurised from the port indicated with the arrow, the shaft rotates in the clockwise direction.

Symbol: C11

The rotation range is changed.



Note) If it is pressurised from the port indicated with the arrow, the shaft rotates in the clockwise direction.

3 Changed to Fluorine Grease

Symbol -XC30

CRA1 Refer to "How to Order" on page 1. **XC30**

Lubricant oil in the seal part of packing and inner wall of the cylinder is changed to fluoro type.

(Not the low speed specifications)

Changed to fluorine grease

Specifications

Applicable size	50, 63, 80, 100
Applicable shaft type	S, W, X, Y, Z, T, J, K


^{*} Refer to page 2 for other specifications.



Symbol

4 Change of Rotation Range and Shaft Rotation Direction


-XC31 to -XC36



The patterns with the rotation range of 90° and 180° are applicable to the respective patterns with the rotation range of 100° and 190° of the semi-standard specifications.

Symbol: C31


The rotation range is changed and the rotation direction is reversed.



Note) If it is pressurised from the port indicated with the arrow, the shaft rotates in the clockwise direction.

Symbol: C32


The rotation range is changed and the rotation direction is reversed.



Note) If it is pressurised from the port indicated with the arrow, the shaft rotates in the clockwise direction.

Symbol: C33


The rotation range is changed and the rotation direction is reversed.



Note) If it is pressurised from the port indicated with the arrow, the shaft rotates in the clockwise direction.

Symbol: C34


The rotation range is changed and the rotation direction is reversed.



Note) If it is pressurised from the port indicated with the arrow, the shaft rotates in the clockwise direction

Symbol: C35


The rotation range is changed and the rotation direction is reversed.



Note) If it is pressurised from the port indicated with the arrow, the shaft rotates in the clockwise direction

Symbol: C36

The rotation range is changed and the rotation direction is reversed.



Note) If it is pressurised from the port indicated with the arrow, the shaft rotates in the clockwise direction.



Series CRA1


Made to Order 3




Please contact SMC for further details about dimensions, specifications and delivery.

5 Change of Port Location (Mounting location of the cover is changed.)

Symbol -XC59 to -XC61



The patterns with the rotation range of 90° and 180° are applicable to the respective patterns with the rotation range of 100° and 190° of the semi-standard specifications.



⚠ Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)*1), and other safety regulations.

Caution indicates a hazard with a low level of risk Caution: which, if not avoided, could result in minor or moderate injury.

Warning indicates a hazard with a medium level of ⚠ Warning: risk which, if not avoided, could result in death or serious injury.

Danger indicates a hazard with a high level of risk Danger: which, if not avoided, will result in death or serious injury.

*1) ISO 4414: Pneumatic fluid power - General rules relating to systems. ISO 4413: Hydraulic fluid power – General rules relating to systems. IEC 60204-1: Safety of machinery – Electrical equipment of machines. (Part 1: General requirements)

ISO 10218-1: Manipulating industrial robots - Safety. etc.

⚠ Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications. Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalogue information, with a view to giving due consideration to any possibility of equipment failure when configuring the

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and

- 3. Do not service or attempt to remove product and machinery/equipment until safety is confirmed.
 - 1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects
 - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
 - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
- 4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following
 - 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
 - 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalogue
 - 3. An application which could have negative effects on people, property, or animals requiring special safety analysis.
 - 4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

1. The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing industries.

If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary.

If anything is unclear, contact your nearest sales branch.

Limited warranty and Disclaimer/ Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

Limited warranty and Disclaimer

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, wichever is first.*2)
 - Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalogue for the particular products.
 - *2) Vacuum pads are excluded from this 1 year warranty.

A vacuum pad is a consumable part, so it is warranted for a year after it is delivered.

Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty

Compliance Requirements

- 1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

/!\ Safety Instructions

Be sure to read "Handling Precautions for SMC Products" (M-E03-3) before using.

SMC Corporation (Europe)

** +43 (0)2262622800 www.smc.at Austria office@smc.at Belaium ***** +32 (0)33551464 www.smconeumatics.be info@smconeumatics.be **2** +359 (0)2807670 Bulgaria www.smc.ba office@smc.ba Croatia **2** +385 (0)13707288 www.smc.hr office@smc.hr www.smc.cz Czech Republic *****+420 541424611 office@smc.cz Denmark ★+45 70252900 www.smcdk.com smc@smcdk.com smc@smconeumatics.ee Estonia **2** +372 6510370 www.smcpneumatics.ee Finland ***** +358 207513513 www.smc.fi smcfi@smc.fi **2** +33 (0)164761000 France www.smc-france.fr promotion@smc-france.fr ***** +49 (0)61034020 info@smc.de Germany www.smc.de **2** +30 210 2717265 www.smchellas.gr sales@smchellas.gr Greece Hungary **2** +36 23511390 www.smc.hu office@smc.hu Ireland **2** +353 (0)14039000 www.smcpneumatics.ie sales@smcpneumatics.ie mailbox@smcitalia.it **2** +39 0292711 www.smcitalia.it Italy Latvia **2**+371 67817700 www.smclv.lv info@smclv.lv

Lithuania *****+370 5 2308118 Netherlands Norway Poland Portugal Romania Russia Slovakia Slovenia Spain Sweden

 +31 (0)205318888 *****+47 67129020 +48 (0)222119616 *****+351 226166570 +40 213205111 +7 8127185445 +386 (0)73885412 *****+34 902184100 +46 (0)86031200 Switzerland +41 (0)523963131 +90 212 489 0 440 +44 (0)845 121 5122

www.smclt.lt www.smcpneumatics.nl www.smc-norge.no www.smc.pl www.smc.eu www.smcromania.ro www.smc-pneumatik.ru ** +421 (0)413213212 www.smc.sk

www.smc.si www.smc.eu www.smc.nu www.smc.ch www.smcpnomatik.com.tr www.smcpneumatics.co.uk sales@smcpneumatics.co.uk

info@smclt.lt info@smcpneumatics.nl post@smc-norge.no office@smc.pl postpt@smc.smces.es smcromania@smcromania.ro info@smc-pneumatik.ru office@smc.sk office@smc.si post@smc.smces.es post@smc.nu info@smc.ch

info@smconomatik.com.tr

SMC CORPORATION Akihabara UDX 15F, 4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021, JAPAN Phone: 03-5207-8249 FAX: 03-5298-5362

Turkey

UK