


Description	Material	Finish
Body	Brass	Nickel
Socket	BE CU	Gold
Insulation	PTFE	N/A
Spacer	PTFE	N/A
Gasket	SI Rubber	Rubber
Support	BE CU	Gold
Heat Shrink	Polyolefin	Black



REVISIONS			
REV	DESCRIPTION	DATE	APPV
В	Updated footprint and dimensions; Added new title block	2-JUL-12	SAH
С	C Updated stripping dimensions; Added dimensions to spacer and support 12-Jun-13 SAF		SAH


RECOMMENDED CABLE STRIPPING DIMENSIONS





CONREVSMA007-R178 ASSEMBLY INSTRUCTIONS

- 1. Strip cable to recommended dimensions.
- 2. Slip heat shink and crimp ring onto cable.
- 3. Solder support onto the braid.
- 4. Place the spacer onto the center conductor.
- 5. Solder or crimp the socket onto the center conductor.
- Insert the socket, center conductor, spacer and support into the body until the top of the socket is even with the white insulation in the body.
- 7. Crimp the tail of the body onto the support with a 0.093" hex crimp tool (or one labeled for use with RG-178 cable).
- 8. Use heat shrink to cover crimp.



DESIGNATED AGENTS.				
MATERIAL:	TOLERANCES:	PROJECTION:		
	.020 [0.50]200 [5.00]=±.008 [0.20] .200 [5.00]-1.200 [30.00]=±.016 [0.40] 1.20 [30.0]-4.75 [120.0]=±.024 [0.60] 4.75 [120.0]-12.40 [315.0]=±.040 [1.0]			
FINISH:		2- -12		

ENGR: S.HOGAN

Linx

NOTES: (UNLESS OTHERWISE SPECIFIED)

1. ALL DIMENSIONS ARE IN INCHES [mm].

2. DIMENSIONS APPLY AFTER FINISHING.

159 ORT LANE MERLIN, OR 97532

TITLE:

DT: 2-JUL-12

RP-SMA MALE CABLE END CRIMP FOR RG-178 CABLE

3. MANUFACTURE TO BE COMPLIANT WITH EU ROHS DIRECTIVE.

4. SAFETY BREAK ALL SHARP CORNERS AND EDGES .02 MAXIMUM.

SIZE DWG. NO.
CONREVSMA007-R178

SCALE: 2:1

DO NOT SCALE DRAWING

SHEET 1 OF 1

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Linx Technologies: CONREVSMA007-R178