





ELECTRICAL CHARACTERISTICS



NOTES

1. TO ACTUATE THE DEVICE, THE SOUTH POLE OF THE MAGNET OR MAGNETIC FLUX GENERATOR MUST BE PRESENTED TO THE CENTER OF THE FRONT SURFACE OF THE DEVICE. (THIS ASSUMES THE CONVENTION THAT THE DIRECTION OF THE EXTERNAL FLUX OF A MAGNET IS FROM THE NORTH TO THE SOUTH POLE OF THE MAGNET.)

2. THE MAGNETIC FIELD STRENGTH (GAUSS) REQUIRED TO CAUSE THE SWITCH TO CHANGE STATE (OPERATE AND RELEASE) WILL BE AS SPECIFIED IN THE OPERATING CHARACTERISTICS. TO TEST THE SWITCH AGAINST THE SPECIFIED OPERATING CHARACTERISTICS, THE SWITCH MUST BE PLACED IN A UNIFORM MAGNETIC FIELD

3. CATALOG LISTING AND LOT NO. WILL BE STAMPED ON THE PACKAGE

4. AT SUPPLY VOLTAGE OF 6 TO 16 VDC AND OVER THE TEMPERATURE RANGE SPECIFIED

5. AT $24 \pm 2^\circ\text{C}$

6. V_s IS THE UNREGULATED SUPPLY VOLTAGE

THIS DRAWING COVERS A PROPRIETARY ITEM AND IS THE PROPERTY OF MICRO SWITCH, A DIVISION OF HONEYWELL. THIS DRAWING IS NOT TO BE COPIED OR USED WITHOUT THE APPROVAL OF MICRO SWITCH.			TOLERANCES ARE		
MICRO SWITCH a Honeywell Division FED. MFG. CODE 91929	SOLID STATE SWITCH MAGNETICALLY OPERATED	CATALOG LISTING	ONE PLACE	(.0)	±.030
		613SS SERIES	TWO PLACES	(.00)	±.015
		CHART I	THREE PLACES	(.000)	±.005
			ANGLES		±
			WEIGHT		