Soft Polyurethane Tubing

Series TUS



Suitable for piping in confined spaces **Extremely flexible** Soft polyurethane tubing

TUS related accessories Inner sleeve Series TJ

Reinforces soft polyuretharane tubing. Insert an inner sleeve into soft polyurethane tubing when used with a One-touch fitting.



Model

Model	Applicable tubing model	Length
TJ-0425	TUS0425	18
TJ-0604	TUS0604	19
TJ-0805	TUS0805	20.5
TJ-1065	TUS1065	23
TJ-1208	TUS1208	24


Specifications

Material	C2700T (Electroless nickel plated)
Wall thickness	0.2 mm

∕ Precautions

Be sure to read before handling. Refer to front matter 56 for Safety Instructions and pages 13 to 16 for Fittings and Tubing Precautions.

- 1. Use a nylon or polyurethane tubing for general industrial water, otherwise the tube may result in being fallen out or bursted when the max. operating pressure is lower and the surge pressure is occurred.
- 2. The value of the max. operating pressure is at a temperature of 20°C. Refer to the burst pressure characteristics curve for other temperatures. Furthermore, abnormal temperature rises caused by adiabatic compression may result in the burst of the tube.
- 3. The value of the minimum bending radius is measured at the temperature of 20°C as shown in the figure on the right.
- 4. Use inner sleeve, taking the removing force into consideration when used with One-touch fittings.




RoHS

Fluid		Air								
Max. operating pre	essure at 20°C	0.6 MPa								
Burst pressure		Refer to the burst pressure characteristics curve.								
Applicable fitting	gs	One-touch fitting, Insert tube fitting, Hose nipple (3)								
Min. bending rad	8	15		15	5	22		29	9	
Operating temper	-20 to +60°C (No freezing)									
Material		Polyurethane								
Tube drawing	Without inner sleeve	15	60)	60)	8	5	11	0
strength (N) (Using One-touch fitting)	With inner sleeve	80	230	C	25	0	30	00	48	0


Note 1) Not clear, but translucent due to material

Note 2) Min. bending radius is measured as shown in the figure below.



Note 3) Always use inner sleeve (Series TJ) in safety circuit or critical area.

Burst Pressure Characteristics



How to Order

