
# **Energy Management Energy Meter Type EM21 72D**





- Certified according to MID Directive, Annex "B" "Type examination" relevant to active electrical energy meters (see Annex MI-003), see option "P" below
- Certified according to MID Directive, Annex "B" + Annex "F" for legal metrology relevant to active electrical energy meters (see Annex MI-003), see option "PF" below.

- Class B (kWh) according to EN50470-3
- Class 1 (kWh) according to EN62053-21
- Class 2 (kvarh) according to EN62053-23
- Accuracy ±0.5 RDG (current/voltage)
- Energy meter
- Instantaneous variables readout: 3 DGT
- Energies readout: 6+1 DGT
- System variables: W, var, PF, Hz, Phase-sequence.
- Single phase variables: V<sub>LL</sub>, V<sub>LN</sub>, A, PF
- Energy measurements: total kWh and kvarh
- TRMS measurements of distorted sine waves (voltages/currents)
- Self power supply
- Dimensions: 4-DIN modules and 72x72mm
- Protection degree (front): IP50
- Application adaptable display and programming procedure (Easyprog function)
- Easy connections management
- Detachable display
- Multi-use housing: for both DIN-rail and panel mounting applications

### **Product Description**

Three-phase energy meter with removable front LCD display unit. The same unit can be used either as a DIN-rail mounting or a panel mounting energy meter. This general purpose threephase energy meter is suitable for both active and reactive energy metering for cost allocation but also for main electrical paramemeasurement and retransmission (transducer function). Housing for DINrail mounting with IP50

(front) protection degree. Current measurements carried out by means of external current transformers and voltage measurements carried out either by means of direct connection or by means of potential transformers. EM21-72D is provided, as standard, with a pulsating output for active energy retransmission. In addition a 2-wire RS485 communication port available as an option.

### How to order EM21 72D AV5 3 X O X X

Model —		T $T$ $T$	
Range code ———			
System —			
Power supply ——	 	]	
Output 1			
Output 2			
Option —			

## **Type Selection**

Range codes	System	Power supply	Options		
AV5 (*): 400V <sub>LL</sub> AC, 5(6)A or 1(6)A (***) (CT connection) AV6 (**):120V <sub>LN</sub> /230V <sub>LL</sub> AC 5(6)A or 1(6)A (***) (VT/PT and CT connections)	3 (*): balanced and unbalanced load: 3-phase, 4-wire; 3-phase, 3-wire; 2-phase, 3-wire; 1-phase, 2-wire	X (*): Self power supply from 18V to 260VAC VLN, 45 to 65 Hz (connection VL1-N)	X (*): P:	None Certified according to MID Directive, Annex "B" "Type examination" relevant to active electrical energy meters (see Annex MI-003) (*)	
Output 2	Output 1	(*) as standard. (**) on request. (***) the range 1(6)A	PF:	Certified according to MID Directive, Annex "B" + Annex "F" for legal metrolo- gy relevant to active	
X (*): None S (**): RS485 port	O (*): Single static output (opto-mosfet)	is available but not in compliance with the EN50470-3 standard.		electrical energy meters (see Annex MI-003) (**)	



# Input specifications

Rated inputs Current type	System type: 3 Not isolated (shunt inputs). Note: the external current transformers can be con- nected to earth individually.	
Current range (by CT)	AV5 and AV6: 5(6)A. The "1(6)A" range is available but not in compliance with the EN50470-3 standard.	
Voltage (direct or by VT/PT)	AV5: 400VLL; AV6: 120/230VLL	
<b>Accuracy</b> (Display + RS485) (@25°C ±5°C, R.H. ≤60%, 48 to 62 Hz)	In: see below, Un: see below	Ī
AV5 model	In: 5A, Imax: 6A; Un: 160 to	
AV6 model	260VLN (277 to 450VLL). In: 5A, Imax: 6A; Un: 40 to 144VLN (70 to 250VLL).	
Current AV5, AV6 models	From 0.002In to 0.2In: ±(0.5% RDG +3DGT). From 0.2In to Imax: ±(0.5% RDG +1DGT).	
Phase-neutral voltage	In the range Un: ±(0,5% RDG +1DGT).	
Phase-phase voltage	In the range Un: ±(1% RDG +1DGT).	Ν
Frequency	Range: 45 to 65Hz; resolution: ±1Hz	
Active power Power Factor	±(1%RDG +2DGT). ±[0.001+1%(1.000 - "PF RDG")].	
Reactive power Active energy	±(2%RDG +2DGT). class B according to EN50470-1-3; class 1 according to EN62053-21.	7
Reactive energy	class 2 according to EN62053-23. In: 5A, Imax: 6A; 0.1 In: 0.5A. Start up current: 10mA.	(
Energy additional errors		_
Influence quantities	According to EN62053-21, EN50470-1-3, EN62053-23	١
Temperature drift	≤200ppm/°C.	_
Sampling rate	1600 samples/s @ 50Hz, 1900 samples/s @ 60Hz	_
Display refresh time	1 second	١
Display	2 lines 1st line: 7-DGT, 2nd line: 3-DGT or 1st line: 3-DGT + 3-DGT, 2nd line: 3-DGT.	F
Type Instantaneous variables read-out	LCD, h 7mm. 3-DGT.	

Energies	Imported Total: 6+1DGT or 7DGT
Overload status	EEE indication when the value being measured is exceeding the "Continuous inputs overload" (maximum
Max. and Min. indication	measurement capacity) Max. instantaneous variables: 999; energies: 999 999.9 or 9 999 999. Min. instantaneous variables: 0; energies 0.0.
LEDs	Red LED (Energy con-
Max frequency	sumption) 0.001 kWh by pulse if CT ratio x VT ratio is <7; 0.01 kWh by pulse if CT ratio x VT ratio is ≥ 7.0 < 70.0; 0.1 kWh by pulse if CT ratio x VT ratio is ≥ 70.0 < 700.0; 1 kWh by pulse if CT ratio x VT ratio is ≥ 70.0; 1 kWh by pulse if CT ratio x VT ratio is ≥ 700.0; 16Hz, according to EN50470-3 Green LED (on the terminal blocks side) for power on (steady) and communica- tion status: RX-TX (in case of RS485 option only)
	blinking.
Measurements	See "List of the variables
Method	that can be connected to:" TRMS measurements of distorted wave forms.
Coupling type	By means of external CT's.
Crest factor	In 5A: ≤3 (15A max. peak).
Current Overloads Continuous	6A, @ 50Hz.
For 500ms	120A, @ 50Hz.
Voltage Overloads	4.011
Continuous For 500ms	1.2 Un 2 Un
Current input impedance	2 011
5(6)A	< 0.3VA
Voltage input impedance Self-power supply	Power consumption: <2VA.
Frequency	45 to 65 Hz.
Key-pad	Two push buttons for variable selection and programming of the instrument working parameters.



# **Output specifications**

<b>Pulse output</b> Number of outputs Type	1 Programmable from 0.01 to 9.99 kWh per pulses. Output connectable to the	Addresses  Protocol Data (bidirectional)	on the instrument. 247, selectable by means of the front keypad MODBUS/JBUS (RTU)
Pulse duration	energy meters (kWh) ≥100ms < 120ms (ON), ≥120ms (OFF), according to EN62052-31.	Dynamic (reading only)	System and phase variables: see table "List of variables"
Output	Static: opto-mosfet.	Static (reading and writing)	All the configuration parameters.
Load	V <sub>ON</sub> 2.5 VAC/DC max. 70 mA, V <sub>OFF</sub> 260 VAC/DC max.	Data format	1 start bit, 8 data bit, no parity,1 stop bit.
Insulation	By means of optocouplers, 4000 VRMS output to measuring inputs.	Baud-rate Driver input capability	9600 bits/s. 1/5 unit load. Maximum 160 transceiver on the
RS485			same bus.
Туре	Multidrop, bidirectional (static and dynamic variables)	Insulation	By means of optocouplers, 4000 VRMS output to measuring input.
Connections	2-wire. Max. distance 1000m, termination directly		

## **Software functions**

Password	Numeric code of max. 3 digits;	Transformer ratio VT (PT)	1.0 to 99.9 / 100 to 999 /
	2 protection levels of the	,	1.00k to 6.00k
	programming data:	CT	1.0 to 99.9 / 100 to 999 /
1st level	Password "0", no protection;		1.00k to 9.99k / 10.0k to 60.0k.
2nd level	Password from 1 to 999, all data are protected		The maximum power being measured cannot exceed
Programming lock	By means of potentiometer (back-side of the display module) it is possible to lock the access to all the configuration parameters.		210 MW calculated as maximum input voltage and current, (see the "Accuracy" paragraph). The maximum VT by CT
System selection	-		ratio is 48.600. For MID complaint applications the
System 3-Ph.n unbalanced loa	3-phase (3-wire)		maximum power being measured is 25 MW.
System 3-Ph.1 balanced load     • 3-phase (3-wire) one current and 3-phase to phase voltage measurements.     Note: the phase to phase voltage is calculated multiplying by 1.73 the virtual phase to neutral voltage.		Displaying	Up to 3 variables per page. See « Display pages », 3 different set of variables available (see « Display pages ») according to the metering function being selected.
	• 3-phase (4-wire) one current and 3-phase to neutral voltage measurements.  Note: the phase to phase	Reset	By means of the front key- pad: total energies (kWh, kvarh).
	voltage is calculated multiplying by 1.73 the virtual phase to neutral voltage.  • 3-phase (2-wire) one current and 1-phase (L1) to neutral voltage measurement.	Easy connection function	Wrong phase detection and displaying. For all the display selections, both energy measurements are dependent from the current direction, both power mea- surements are independent
System 2-Ph System 1-Ph	2-phase (3-wire) 1-phase (2-wire)		from the current direction. The power measurements are always positive.



# **General specifications**

Operating temperature	-25°C to +55°C (-13°F to 131°F) (R.H. from 0 to 90% non-condensing @ 40°C) according to EN62053-21 and EN62053-23.	Surge  Radio frequency suppression  Standard compliance	On current and voltage measuring inputs circuit: 6kV; According to CISPR 22
Storage temperature  Installation category	-30°C to +70°C (-22°F to 158°F) (R.H. < 90% non-condensing @ 40°C) according to EN62053-21 and EN62053-23.  Cat. III (IEC60664,	Safety  Metrology  Pulse output	IEC60664, IEC61010-1 EN60664, EN61010-1 EN62052-11 EN62053-21, EN62053-23, EN50470-3 DIN43864, IEC62053-31
	EN60664).	Approvals	CE, cULus listed
Insulation (for 1 minute)	4000 VRMS between measuring inputs and digital output.	Connections Cable cross-section area	Screw-type 2.4 x 3.5 mm Min./Max. screws tighten- ing torque: 0.4 Nm / 0.8 Nm
Dielectric strength	4000 VRMS for 1 minute.	Housing	g to que or rum, ere rum
Noise rejection CMRR	100 dB, 48 to 62 Hz.	Dimensions (WxHxD)	72 x 72 x 65 mm
EMC Electrostatic discharges Immunity to irradiated Electromagnetic fields Burst	According to EN62052-11 15kV air discharge; Test with current: 10V/m from 80 to 2000MHz; Test without any current: 30V/m from 80 to 2000MHz;	Material  Mounting  Protection degree Front Screw terminals  Weight	Noryl PA66, self-extinguishing: UL 94 V-0 Panel and DIN-rail  IP50 IP20  Approx. 400 g (packing
Immunity to conducted disturbances	On current and voltage measuring inputs circuit: 4kV 10V/m from 150KHz to 80MHz	worgin	included)

# **Power supply specifications**

Self power supply	18 to 260VAC (48-62Hz). Across input "VL1" and "N"	Power consumption	≤2VA/1W

# Insulation between inputs and outputs


	Measuring Inputs	Opto-Mosfet output	Communication port	Self power supply
Measuring Inputs	-	4kV	4kV	0kV
Opto-Mosfet output	4kV	-	-	4kV
Communication port	4kV	-	-	4kV
Self power supply	0kV	4kV	4kV	-

**NOTE:** all the models have, mandatorily, to be connected to external current transformers.




## Accuracy (According to EN50470-3 and EN62053-23)

kWh, accuracy (RDG) depending on the current



kvarh, accuracy (RDG) depending on the current



## MID "Annex MI-003" compliance

Accuracy

 $0.9 \text{ Un} \le U \le 1.1 \text{ Un};$  $0.98 \text{ fn} \le f \le 1.02 \text{ fn};$ fn: 50Hz; cosφ: 0.5 inductive to 0.8 capacitive. Class B I st: 0.01A; I min: 0.05A; I tr: 0.25A;

	I n: 5A I max: 6A.
Operating temperature	-25°C to +55°C (-13°F to 131°F) (R.H. from 0 to 90% non-condensing @ 40°C)
EMC compliance	E2

### **Used calculation formulas**

### Phase variables

Instantaneous effective voltage

$$V_{1N} = \sqrt{\frac{1}{n}} \cdot \sum_{i}^{n} (V_{1N})_{i}^{2}$$
 Instantaneous active power

$$W_1 = \frac{1}{n} \cdot \sum_{i=1}^{n} \left( V_{1N} \right)_i \cdot \left( A_1 \right)_i$$

Instantaneous power factor

$$\cos \varphi_1 = \frac{W_1}{VA_1}$$

Instantaneous effective current

$$A_{1} = \sqrt{\frac{1}{n} \cdot \sum_{1}^{n} (A_{1})_{i}^{2}}$$

Instantaneous apparent power

$$VA_1 = V_{1N} \cdot A_1$$

Instantaneous reactive power  $var_1 = \sqrt{(VA_1)^2 - (W_1)^2}$ 

### System variables

Equivalent three-phase voltage 
$$V_{\Sigma} = \frac{V_1 + V_2 + V_3}{3} \cdot \sqrt{3}$$

Voltage asymmetry

Three-phase power factor

$$\cos \varphi_{\Sigma} = \frac{W_{\Sigma}}{VA_{-}}$$

(TPF)

### **Energy metering**

$$k \operatorname{var} hi = \int_{t_1}^{t_2} Qi(t) dt \cong \Delta t \sum_{n=1}^{n_2} Qnj$$

$$kWhi = \int_{t1}^{t2} Pi(t)dt \cong \Delta t \sum_{n=1}^{n2} Pnj$$

i= considered phase (L1, L2 or L3) P= active power; Q= reactive power;  $t_1$ ,  $t_2$  =starting and ending time points of consumption recording; n= time unit;∆t= time interval between two successive power consumptions;  $n_1$ ,  $n_2$  = starting and ending discrete time points of consumption recording

$$W_{\Sigma} = W_1 + W_2 + W_3$$

Three-phase apparent power

$$VA_{\Sigma} = \sqrt{W_{\Sigma}^2 + var_{\Sigma}^2}$$



### List of the variables that can be connected to:

- RS485 communication port
- Pulse outputs (only "energies")

No	Variable	1-ph. sys.	2-ph. sys.	3-ph. 4-wire balanced system	3-ph. 3-wir balanced system	3-ph. 4-wire unbalanced system	3-ph. 3-wir unbalanced system	Notes
1	kWh	Х	Х	х	Х	х	Х	Total
2	kvarh	Х	Х	х	Х	х	Х	Total
3	V L-N sys (1)	0	Х	х	Х	х	Х	sys=system (∑)
4	V L1	Х	Х	х	Х	х	Х	
5	V L2	0	Х	Х	Х	х	Х	
6	V L3	0	0	х	Х	х	Х	
7	V L-L sys (1)	0	Х	X	Х	X	Х	sys=system (∑)
8	V L1-2	0	Х	X	Х	X	Х	
9	V L2-3	0	0	Х	Х	х	Х	
10	V L3-1	0	0	X	Х	X	Х	
11	A L1	Х	Х	X	X	X	Х	
12	A L2	0	Х	X	X	X	Х	
13	A L3	0	0	X	Х	X	X	
14	VA sys (1)	Х	Х	X	Х	X	Х	sys=system (∑)
15	VA L1 (1)	Х	х	X	Х	х	Х	
16	VA L2 (1)	0	Х	X	X	X	Х	
17	VA L3 (1)	0	0	X	Х	X	X	
18	var sys	Х	Х	X	X	X	X	sys=system (∑)
19	var L1 (1)	Х	Х	X	X	X	Х	
20	var L2 (1)	0	Х	X	X	X	X	
21	var L3 (1)	0	0	X	X	X	Х	
22	W sys	Х	Х	X	Х	X	Х	sys=system (∑)
23	W L1 (1)	Х	Х	X	X	X	Х	
24	W L2 (1)	0	Х	X	X	X	X	
25	W L3 (1)	0	0	X	X	X	Х	
26	PF sys	Х	Х	Х	Х	Х	Х	sys=system (∑)
27	PF L1	Х	Х	Х	Х	Х	Х	
28	PF L2	0	Х	X	Х	х	Х	
29	PF L3	0	0	Х	Х	Х	Х	
30	Hz	Х	Х	х	Х	х	Х	
31	Phase sequence	0	0	Х	Х	Х	Х	

- (x) = available
- (o) = not available (zero indication on the display)
- (1) = Variable available only through the serial communication port RS485

# **Display pages**

No	1st variable	2nd variable 3rd variable		Note		Applications		
NO	(1st half-line)	(2 <sup>nd</sup> half-line)	(2nd line)	Note	Α	В	С	
	Phase sequence			The phase sequence triangle appears in any page only if there is a phase reverse	х	х	х	
1	Total	kWh	W sys		Х	Х	х	
2	Total	kvarh	kvar sys			Х	х	
3		PF sys	Hz	Indication of C, -C, L, -L depending on the quadrant	х	х	х	
4	PF L1	PF L2	PF L3	Indication of C, -C, L, -L depending on the quadrant			х	
5	A L1	A L2	A L3				х	
6	V L1-2	V L2-3	V L3-1				х	
7	V L1	V L2	V L3				х	




## Additional available information on the display

Туре	1st line	2nd line	note
Meter information 1	Y. 2007	r.A0	Year of production and firmware release
Meter information 2	value	LEd (kWh)	KWh per pulse of the LED
Meter information 3	SYS [3P.n]	value	System type and connection type
Meter information 4	Ct rAt.	value	Current transformer ratio
Meter information 5	Ut rAt.	value	Voltage transformer ratio
Meter information 6	PuLSE (kWh)	value	Pulse output: kWh per pulse
Meter information 7	Add	value	Serial communication address


# List of selectable applications

	Description	Notes	
Α	Active energy meter	Active energy measurement with some minor parameters	
В	Active and reactive energy meter	Active and reactive energy measurement with some minor parameters	
С	Full set of variables	Full set of available variables can be displayed	

## One instrument with double mounting capability




By means of the patented detachable display it is possible to configure the same instrument either as a panel mounting meter or...




... as DIN-rail mounting meter.


# CARLO GAVAZZI

## Wiring diagrams





### (6A) Self power supply, system type selection: 3P.n







### (6A) System type selection: 3P.n









### (6A) Self power supply, system type selection: 3P.1









(\*) NOTE: For a correct power supply of the instrument, the neutral must always be connected.




## Wiring diagrams

### (6A) System type selection: 2P







# (6A) System type selection: 1P




## Static output wiring diagram

### (6A) System type selection: 1P






## RS485 port wiring diagram



**RS485 NOTE:** additional devices provided with RS485 are connected as per the picture above. The termination of the serial output is carried out only on the last instrument of the network, by means of a jumper between (B+) and (T).



## Front panel description



### 1. Keypad

To program the configuration parameters and scroll the variables on the display.

### 2. Pulse output LED

Red LED blinking proportional to the energy being measured.

### 3. Display

LCD-type with alphanumeric indications to display all the measured variables.


### 4. Connections

Screw terminal blocks for instrument wiring.

### 5. Green LED

Lit when power supply is available

## **Dimensions (DIN configuration)**



# Dimensions and panel cut out (72x72 panel mounting configuration)

